


# SERVICE MANUAL

MAILED 10/25/54

# HR-J425E/EG



## SHOWVIEW



## SPECIFICATIONS *(The specifications shown pertain specifically to the model HR-J425EG)*

## GENERAL

Power requirement	: AC 220 - 240 V~, 50/60 Hz
Power consumption	: 20 W
Temperature	
Operating	: 5°C to 40°C
Storage	: -20°C to 60°C
Dimensions (WxHxD)	: 400 x 94 x 344 mm
Weight	: 4.3 kg
Format	: VHS PAL standard
Maximum recording time	
(SP)	: 240 min. with E-240 video cassette
(LP)	: 480 min. with E-240 video cassette

## VIDEO/AUDIO

<b>Signal system</b>	: PAL-type colour signal and CCIR monochrome signal, 625 lines/50 fields
<b>Recording/Playback system</b>	: DA-4 (Double Azimuth) head helical scan system
<b>Signal-to-noise ratio</b>	: 45 dB
<b>Horizontal resolution</b>	: 250 lines
<b>Frequency range</b>	: 70 Hz to 10,000 Hz
<b>Input/Output</b>	: 21-pin scart connector x 2 (IN/OUT x 1, IN/DECODER x 1) RCA connectors (VIDEO IN x 1, AUDIO IN x 1)

## TUNER/TIMER

TV channel storage capacity	: 80 positions (+AUX position "AU")
Channel coverage	: VHF 47 - 89/104 - 300/ 302 - 470 MHz UHF 470 - 862 MHz
Aerial output	: UHF channel 36 (Adjustable 32 - 40)
Memory backup time	: Approx. 3 min.

## ACCESSORIES

**Provided accessories :** Aerial cable,  
Infrared remote control unit,  
"R03" battery x 2

**Design and specifications subject to change without notice.  
Specifications shown are for SP mode unless otherwise  
specified.**

# TABLE OF CONTENTS

Section	Title	Page	Section	Title	Page
	<b>Important Safety Precautions</b>				
	<b>INSTRUCTIONS</b>				
<b>1. DISASSEMBLY</b>			<b>2.7 TAPE INTERCHANGEABILITY ADJUSTMENT</b>		2-14
1.1	DISASSEMBLY FLOW CHART	1-1	2.7.1	Tape pattern	2-14
1.2	HOW TO READ THE DISASSEMBLY AND ASSEMBLY	1-1	2.7.2	A/C head height & azimuth	2-15
1.3	DISASSEMBLY/ASSEMBLY METHOD	1-1	2.7.3	A/C head phase (X-value)	2-16
1.4	CASSETTE HOUSING INSTALLATION	1-4	2.7.4	LP mode auto tracking	2-16
1.5	SERVICE POSITION	1-4	2.7.5	Tension pole position	2-17
1.5.1	How to take out the Mechanism and Main board assemblies	1-4	2.7.6	Take-up torque	2-17
1.5.2	Cautions on cassette loading when mechanism is in service position	1-5			
1.5.3	Cassette loading and ejecting procedures when mechanism is in service position	1-5	<b>3. ELECTRICAL ADJUSTMENT</b>		
1.5.4	Opening on the chassis	1-6	3.1	PRECAUTION	3-1
1.6	MECHANISM SERVICE MODE	1-7	3.1.1	Required test equipment	3-1
1.6.1	How to set the "MECHANISM SERVICE MODE"	1-7	3.1.2	Required adjustment tools	3-1
1.7	EMERGENCY DISPLAY FUNCTION	1-8	3.1.3	Colour bar signal, colour bar pattern	3-1
1.7.1	How to display record of an emergency faults	1-8	3.2	SERVO CIRCUIT	3-2
1.7.2	Detail of emergency faults	1-8	3.3	VIDEO CIRCUIT	3-3
1.7.3	How to clear emergency record	1-8	3.3.1	EE Y LEVEL	3-3
			3.3.2	WHITE / DARK CLIP	3-3
<b>2. MECHANISM ADJUSTMENT</b>			3.3.3	CARRIER	3-4
2.1	PREPARATION	2-1	3.3.4	DEVIATION	3-4
2.1.1	Precautions	2-1	3.3.5	REC COLOR LEVER	3-4
2.1.2	Check without cassette housing assy	2-1	3.3.6	PB Y LEVEL	3-4
2.1.3	Manual removal of loaded tape	2-1	3.4	SYSCON CIRCUIT	3-5
2.1.4	Test Equipment	2-2	3.4.1	Timer clock	3-5
2.2	MAIN MECHANISM PARTS	2-2	3.5	TUNER CIRCUIT	3-5
2.2.1	Cleaning	2-3	3.5.1	RF AGC	3-5
2.2.2	Lubrication	2-3			
2.3	INSPECTION AND MAINTENANCE	2-4	<b>4. CHARTS AND DIAGRAMS</b>		
2.3.1	Suggested servicing schedule for main components	2-4			
2.4	DISASSEMBLY/ASSEMBLY PROCEDURE OF MECHANISM	2-4			
2.4.1	Precaution before disassembling mechanism	2-4			
2.4.2	How to set the exclusive mechanism operation mode (MECHANISM ASSEMBLING MODE)	2-4			
2.5	MAIN PARTS REPLACEMENT OF MECHANISM	2-4			
2.5.1	Pinchi Roller Arm Assy	2-4			
2.5.2	A/C Head	2-5			
2.5.3	Pinch plate	2-5			
2.5.4	Mode Motor	2-6			
2.5.5	Lever Assy, Sub Deck Assy, Capstan Motor	2-6			
2.5.6	Control Bracket-1, Earth Plate	2-7			
2.5.7	Reel Bracket, Slit Disk (take-up)	2-7			
2.5.8	Control Bracket-2, Control Plate	2-7			
2.5.9	Sub Brake (take-up), Control Cam	2-8			
2.5.10	Slide Plate	2-8			
2.5.11	Change Lever, Rotary Encoder	2-8			
2.5.12	Sub Brake (supply), Tension Band Assy, Tension Arm Assy, Take-up Lever Assy, Slit Disk (supply)	2-9			
2.5.13	Take-up Head, Tension Arm Lever	2-9			
2.5.14	Guide Rail	2-10			
2.5.15	Stator Assy	2-10			
2.5.16	Rotor Assy	2-10			
2.5.17	Upper Drum Assy	2-11			
2.6	CHECKUP AND ADJUSTMENT OF MECHANISM PHASE	2-12			
2.6.1	Precaution	2-12			
2.6.2	Loading Arm Assy (supply, take-up)	2-12			
2.6.3	Rotary Encoder, Change Lever, Control Cam	2-13			
2.6.4	Slide plate	2-13			
2.6.5	Control Plate	2-13			

The following table lists the differing points between Models (HR-J425E and HR-J425EG) in this series.

	HR-J425E	HR-J425EG
VPS	x (OPTION)	○

○ : USED

x : NOT USED

# Important Safety Precautions

Prior to shipment from the factory, JVC products are strictly inspected to conform with the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

## ● Precautions during Servicing

1. Locations requiring special caution are denoted by labels and inscriptions on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.

2. Parts identified by the  $\triangle$  symbol and shaded ( ) parts are critical for safety.

Replace only with specified part numbers.

Note: Parts in this category also include those specified to comply with X-ray emission standards for products using cathode ray tubes and those specified for compliance with various regulations regarding spurious radiation emission.

3. Fuse replacement caution notice.

Caution for continued protection against fire hazard.  
Replace only with same type and rated fuse(s) as specified.

4. Use specified internal wiring. Note especially:

- 1) Wires covered with PVC tubing
- 2) Double insulated wires
- 3) High voltage leads

5. Use specified insulating materials for hazardous live parts. Note especially:

- |                    |                                      |            |
|--------------------|--------------------------------------|------------|
| 1) Insulation Tape | 3) Spacers                           | 5) Barrier |
| 2) PVC tubing      | 4) Insulation sheets for transistors |            |

6. When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.) wrap ends of wires securely about the terminals before soldering.




Fig. 1

7. Observe that wires do not contact heat producing parts (heat-sinks, oxide metal film resistors, fusible resistors, etc.)

8. Check that replaced wires do not contact sharp edged or pointed parts.

9. When a power cord has been replaced, check that 10–15 kg of force in any direction will not loosen it.




Fig. 2

10. Also check areas surrounding repaired locations.

11. Products using cathode ray tubes (CRTs)

In regard to such products, the cathode ray tubes themselves, the high voltage circuits, and related circuits are specified for compliance with recognized codes pertaining to X-ray emission. Consequently, when servicing these products, replace the cathode ray tubes and other parts with only the specified parts. Under no circumstances attempt to modify these circuits. Unauthorized modification can increase the high voltage value and cause X-ray emission from the cathode ray tube.

12. Crimp type wire connector

In such cases as when replacing the power transformer in sets where the connections between the power cord and power transformer primary lead wires are performed using crimp type connectors, if replacing the connectors is unavoidable, in order to prevent safety hazards, perform carefully and precisely according to the following steps.

1) Connector part number : E03830-001

2) Required tool : Connector crimping tool of the proper type which will not damage insulated parts.

3) Replacement procedure

(1) Remove the old connector by cutting the wires at a point close to the connector.

Important : Do not reuse a connector (discard it).




Fig. 3

(2) Strip about 15 mm of the insulation from the ends of the wires. If the wires are stranded, twist the strands to avoid frayed conductors.




Fig. 4

(3) Align the lengths of the wires to be connected. Insert the wires fully into the connector.




Fig. 5

(4) As shown in Fig. 6, use the crimping tool to crimp the metal sleeve at the center position. Be sure to crimp fully to the complete closure of the tool.




Fig. 6

(5) Check the four points noted in Fig. 7.




Fig. 7

## ● Safety Check after Servicing

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts and wires have been returned to original positions. Afterwards, perform the following tests and confirm the specified values in order to verify compliance with safety standards.

### 1. Insulation resistance test


Confirm the specified insulation resistance or greater between power cord plug prongs and externally exposed parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table 1 below.

### 2. Dielectric strength test

Confirm specified dielectric strength or greater between power cord plug prongs and exposed accessible parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table 1 below.

### 3. Clearance distance

When replacing primary circuit components, confirm specified clearance distance (d), (d') between soldered terminals, and between terminals and surrounding metallic parts. See table 1 below.



### 4. Leakage current test

Confirm specified or lower leakage current between earth ground/power cord plug prongs and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).

**Measuring Method: (Power ON)**

Insert load Z between earth ground/power cord plug prongs and externally exposed accessible parts. Use an AC voltmeter to measure across both terminals of load Z. See figure 9 and following table 2.




Fig. 9

### 5. Grounding (Class I model only)

Confirm specified or lower grounding impedance between earth pin in AC inlet and externally exposed accessible parts (Video in, Video out, Audio in, Audio out or Fixing screw etc.).

**Measuring Method:**

Connect milli ohm meter between earth pin in AC inlet and exposed accessible parts. See figure 10 and grounding specifications.




Fig. 10

#### Grounding Specifications

Region	Grounding Impedance (Z)
USA & Canada	$Z \leq 0.1 \text{ ohm}$
Europe & Australia	$Z \leq 0.5 \text{ ohm}$

AC Line Voltage	Region	Insulation Resistance (R)	Dielectric Strength	Clearance Distance (d), (d')
100 V	Japan	$R \geq 1 \text{ M}\Omega / 500 \text{ V DC}$	AC 1 kV 1 minute	$d, d' \geq 3 \text{ mm}$
100 to 240 V			AC 1.5 kV 1 minute	$d, d' \geq 4 \text{ mm}$
110 to 130 V	USA & Canada	—	AC 1 kV 1 minute	$d, d' \geq 3.2 \text{ mm}$
110 to 130 V 200 to 240 V	Europe & Australia	$R \geq 10 \text{ M}\Omega / 500 \text{ V DC}$	AC 3 kV 1 minute (Class II) AC 1.5 kV 1 minute (Class I)	$d \geq 4 \text{ mm}$ $d' \geq 8 \text{ mm (Power cord)}$ $d' \geq 6 \text{ mm (Primary wire)}$

Table 1 Specifications for each region

AC Line Voltage	Region	Load Z	Leakage Current (i)	a, b, c
100 V	Japan		$i \leq 1 \text{ mA rms}$	Exposed accessible parts
110 to 130 V	USA & Canada		$i \leq 0.5 \text{ mA rms}$	Exposed accessible parts
110 to 130 V 220 to 240 V	Europe & Australia		$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Antenna earth terminals
			$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Other terminals

Table 2 Leakage current specifications for each region

**Note:** These tables are unofficial and for reference only. Be sure to confirm the precise values for your particular country and locality.



# INSTRUCTIONS

## Safety Precautions

The rating plate and the safety caution are on the rear of the unit.

**WARNING: DANGEROUS VOLTAGE INSIDE**  
**WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.**

The OPERATE button does not completely shut off mains power from the unit, but switches operating current on and off.

### CAUTION

- When you are not using the recorder for a long period of time, it is recommended that you disconnect the power cord from the AC outlet.
- Dangerous voltage inside. Refer internal servicing to qualified service personnel. To prevent electric shock or fire hazard, remove the power cord from the AC outlet prior to connecting or disconnecting any signal lead or aerial.

### WARNING

There are two different types of SECAM colour systems. SECAM-L, used in FRANCE (also called SECAM-West), and SECAM-B, used in Eastern European countries (also called SECAM-East).

- This recorder can also receive SECAM-B colour television signals for recording and playback.
- Recordings made of SECAM-B television signals produce monochrome pictures if played back on a video recorder of SECAM-L standard, or do not produce normal colour pictures if played back on a PAL video recorder with SECAM-B system incorporated (even if the TV set is SECAM-compatible).
- SECAM-L prerecorded cassettes or recordings made with a SECAM-L video recorder produce monochrome pictures when played back with this recorder.
- This recorder cannot be used for the SECAM-L standard. Use a SECAM-L recorder to record SECAM-L signals.

### IMPORTANT:

- It may be unlawful to record or play back copyrighted material without the consent of the copyright owner.
- Please read the "Precautions" section of this instruction manual before installing or operating the recorder.

Video tapes recorded with this video recorder in the LP(Long Play) mode cannot be played back on a single-speed video recorder.

**VHS HQ SHOWVIEW**


- Only cassettes marked "VHS" can be used with this video recorder.
- HQ VHS is compatible with existing VHS equipment.
- ShowView is a trademark applied for by Gemstar Development Corp. ShowView system is manufactured under licence from Gemstar Development Corporation.

## Contents

Controls And Indicators .....	3	Timer-Recording .....	17
Connections .....	5	Other Functions .....	19
Information On Scrambled Broadcasts .....	6	Audio Dubbing .....	20
Setting The Clock .....	7	Editing .....	21
Setting The Tuner .....	8	Using The Remote Control For	
Playback .....	9	TV Operation .....	22
Recording .....	12	Precautions .....	23
Preparation For ShowView Timer		Specifications .....	23
Programming .....	14	In Case Of Difficulty .....	24


## Controls And Indicators

### Front Panel



## Controls And Indicators (cont'd)

### Wireless Remote Control



#### Installing Batteries

- Open the battery compartment cover.
- Insert 2 "R03"-size batteries (provided) in the correct directions.
- Replace the cover.

#### How To Use

The remote control can operate most of your video recorder's functions, as well as basic functions of TV sets of JVC and other brands. *See* p. 22.

- Point the remote control toward the sensor window.
- The maximum operating distance of the remote control is about 8 m.

## Connections

It's essential that your video recorder be properly connected. Follow these steps carefully. THESE STEPS MUST BE COMPLETED BEFORE ANY VIDEO OPERATION CAN BE PERFORMED.

### A RECORDER-TO-TV CONNECTION

#### RF CONNECTION


For TV sets without AV input terminals:

- Connect the TV aerial cable to the recorder.
- Connect the recorder to the TV's aerial terminal.

#### AV CONNECTION

For TV sets with AV input terminals:

- Connect the aerial, recorder and TV as per "RF CONNECTION".
- Connect the recorder to the TV's 21-pin SCART connector.




### B TUNE THE TV TO YOUR VIDEO RECORDER

The video recorder sends picture and sound signals via the RF connecting cable to your TV on UHF channel 36.

#### TEST SIGNAL

- Turn on the recorder.
- Set the RF TEST switch to ON.
- Press TV/VIDEO to engage the VIDEO mode.
- Set your TV to the video channel. Tune the TV to bring the two vertical white bars on the screen most clearly. (UHF/CH 36)
- Your TV should be set to the channel designated for use with a video recorder or to a spare channel if there is not a specified video channel on your TV.
- Reset the RF TEST switch to OFF.




#### NOTES:

- If CH36 is occupied by a local station, adjust the RF output channel adjustment screw to use another channel between CH32 and CH40 instead.
- If some interference noise is continually seen on the screen, consult your JVC dealer.

#### IMPORTANT:

To operate the recorder with your TV using the RF connection, it is always necessary to set your TV's channel to the VIDEO channel. With an AV connection, set the TV to the VIDEO (or AV) mode.

## Information On Scrambled Broadcasts



### SET UP

The AV2 IN/DECODER connector can be used as an input terminal for an external decoder (descrambler). Simply connect a decoder and you can enjoy the variety of programming that is available through scrambled channels.

1. Connect your recorder and TV via their AV connectors (see p. 5, AV CONNECTION).
2. Set the AV2 SELECT switch on the recorder's rear panel to "DECODER".
3. Connect your recorder's AV2 IN/DECODER connector to the decoder's Euroconnector using a 21-pin SCART cable.
4. Set the tuner to receive scrambled channels (see p. 8, Setting The Tuner).

### NOTES:

When connecting a satellite tuner...

- Connect the satellite tuner to the decoder (1), or if you don't have a decoder connect the satellite tuner directly to the video recorder (2).
- Set the AV2 SELECT switch on the rear panel to "AV2".
- To view a programme via the satellite tuner, select AU 2 mode by pressing TV PROG. until "AU 2" appears on the display panel.

### WATCHING SCRAMBLED CHANNELS

#### Preparation

- Turn on the TV.
- Select VIDEO channel (or AV mode).

1. Press TV/VIDEO to select the VIDEO mode.
2. Choose a scrambled channel using the Numeric keys or TV PROG just as you would with regular stations.

#### Watching One Programme While Recording Another


To watch a regular TV programme while recording a scrambled programme:

- Press the TV PROGRAM button on the TV's remote control and select the channel you want to watch.
- To watch the scrambled programme that is being recorded, press TV/VIDEO and select the VIDEO mode.


To watch a scrambled TV programme while recording a regular programme:

- Press the TV PROGRAM button on the TV's remote control and select the scrambled channel. After displaying a scrambled picture for a few seconds, the programme will become descrambled and a viewable picture will appear on the TV screen.


## Setting The Clock



1. Load batteries (see p. 4).




2. Press CLOCK.




3. Press the appropriate numeric keys to input the time.

- Example: For 21.05, press 2 1 0 5.



4. Press the appropriate numeric keys to input the day, month and year.


- Example: For 6th August, 1995, press 0 6 0 8 1 9 9 5.



Transfer-ready mark

5. Press TRANS with the remote control directed to the recorder's remote sensor window.

- The remote control's clock will start. At the same time, the set data will be transferred to the recorder.



Recorder's Display Panel

### TO MAKE CORRECTIONS

Press SELECT button so that the item you want to change blinks. Re-input that item. Continue to step 5.

### AFTER A POWER CUT


Since your video recorder has a 3-minute backup memory, it will not be affected by short power cuts. If mains power is unavailable for over 3 minutes, however, the recorder's display will reset to 0:00. In such a case, simply transfer the remote control's time to the recorder.

1. Press CLOCK three times.
2. Press TRANS with the remote control directed to the recorder's remote sensor window.

### NOTES:

- If the day and month data is invalid (such as 31st April), the month digits are cleared automatically and the day digits will blink. Input again.
- If the year digits are automatically cleared in step 4, it is possible that you have input 29th February for a non-leap year. Input again.
- When the batteries are exhausted, the time display will change to "0:00" and start blinking. Replace all the batteries and set the clock again.


## Setting The Tuner




- Turn on the TV: Select VIDEO channel (or AV mode).
- When the decoder is connected, switch on the decoder.

The procedure introduced here lets you assign receivable channels in your area to channel positions on your video recorder's tuner. Once stored, these can be accessed with the TV PROG. buttons.

1. Press OPERATE to turn on the recorder.
2. Press TV/VIDEO to engage the VIDEO mode.
3. Press CH SET/SEARCH until the display panel shows the following.




4. Press CH SET/SEARCH again briefly to start automatic scanning for receivable channels.




- Automatic scanning stops when a station is detected, and the channel position will blink.
- Holding down CH SET/SEARCH will start reverse search.
- If you don't want to store the station detected, simply press CH SET/SEARCH to continue automatic scanning.

5. Press TV/VIDEO on the remote control when a scrambled broadcast is detected.



- The programme will be descrambled. For normal (non-scrambled) broadcasts, do not press TV/VIDEO.

6. Press numeric keys or TV PROG. to select the channel position where you wish to store that TV station.



7. Press STORE to store the station.

- The colon will disappear when the station is stored.

8. Repeat steps 4 through 7 for other receivable channels.

- If the picture of the detected station is not satisfactory, try fine-tuning. See below.


9. Press Stop on the recorder to disengage the Channel Set mode.

### TO GET A CLEARER PICTURE — Fine-Tuning —


After step 8, you can perform Auto Fine-Tuning for all the stored stations at once.

1. Press Pause for more than 2 seconds.

- Auto Fine-Tuning will start.




- After completion of Auto Fine-Tuning for all the stored stations, the display panel will return to step 7.



2. Continue to step 9.

If you want to fine-tune a specified station, try fine-tuning manually.


1. Press TV PROG. (+ or -) to select the station you wish to fine-tune.
2. Press Pause briefly.
3. Press TV PROG. (+ or -) so that the picture becomes clearer.
4. Press Pause briefly again.
5. Continue to step 9.




### TO DELETE STORED CHANNELS

Please follow the procedure described below when you wish to delete a poorly received channel.

1. Press TV PROG. to select the channel position you want to skip.
2. Press CH SET/SEARCH for more than 2 seconds.



3. Press CANCEL.



- The colon will appear when the station is deleted. Channel position 5 can no longer be chosen by TV PROG. buttons.


4. Press Stop on the recorder to disengage the Channel Set mode.

### TO STORE NEW CHANNELS

Please follow the procedure described below when you wish to add a new channel.

1. Press CH SET/SEARCH for more than 2 seconds.
2. Press TIMER.
3. Press TIMER to change the band between Ch and CC, if necessary.
4. Press numeric keys to input the number of the real channel you want to store.
5. Press numeric keys to input the number of a vacant channel position.
6. Press STORE to store the channel.
7. Press Stop on the recorder to disengage the Channel Set mode.

## Playback



### Basic Operations

#### Preparation

- Turn on the TV.
- Select VIDEO channel (or AV mode).

1. Load a cassette.

- The recorder power will come on automatically.
- The counter will be reset to "0:00:00" automatically.
- If the safety tab on the cassette is removed, playback will start automatically.

2. Press Play to start playback.

3. Press Stop to stop playback.

- To rewind the tape, press Rewind or turn the SHUTTLE to the left and release it.
- To fast-forward the tape, press Fast Forward or turn the SHUTTLE to the right and release it.
- To stop rewind or fast-forward, press Stop.

4. Press Stop/Eject on the recorder to eject the tape.

#### Variable-Speed/High-Speed (Turbo) Search, Still Playback/Frame Advance/Forward Slow Motion


##### During Playback:

- Press PUSH JOG ◀◀ or ▶▶ for variable-speed search.
- The more times the button is pressed, the faster the playback picture will move.
- To decrease speed, press the button for the opposite direction.
- Press Fast Forward for high-speed forward search, or Rewind for high-speed reverse search.
- For short searches, keep Fast Forward or Rewind pressed for more than 2 seconds. When released, normal playback will continue.
- Press Pause/Slow to view a still picture.
- Press again to advance the picture frame by frame.
- Press Pause/Slow for 2 seconds for slow motion.

##### During Still:

- For frame-by-frame playback in the forward or reverse direction, press PUSH JOG ◀◀ or ▶▶ in the corresponding direction.

## Playback (cont'd)



### Other Functions

#### JOG/SHUTTLE Control

You can view pictures in slow to fast motion, or frame-by-frame.


**During Playback or Still:**

1. Turn the outer ring (SHUTTLE) in either direction. The farther the ring is rotated, the faster the search speed. Releasing the ring stops the picture in the Still mode.
  - For fast-forward with a visible picture, turn the SHUTTLE all the way to the right and release it within 1 second.
  - For rewind with a visible picture, turn the SHUTTLE all the way to the left and release it within 1 second.

**During Playback or Still:**

1. Turn the inner dial (JOG) clockwise or counterclockwise for jog control. The tape moves frame-by-frame at the speed with which the dial is turned, in the direction the dial is rotated.

To resume normal playback, press Play button.



#### SQ² (Super Quality) Button

Your video recorder is equipped with a special picture circuit that provides a clearer picture.

Whenever you plug in your recorder and press the OPERATE button, the SQ² function turns on also. If you wish to cancel SQ², press SQ² so that its light goes off. Pressing SQ² turns the function on/off.

##### NOTES:

- Normally, it is recommended that you keep SQ² turned on.
- This button has effect only on playback picture (excluding, however, special playback picture and also during NTSC playback), no effect on recording picture.

#### Manual Tracking

Your video recorder is equipped with automatic tracking control. If you wish to adjust tracking manually, you can override this function.

**During Playback:**


1. Press the recorder's TV PROG. + and - buttons simultaneously.
  - The AT indicator will go out.
2. Press TV PROG. + or - to adjust tracking.
  - Press TV PROG. + and - simultaneously to return to automatic tracking.
  - To adjust tracking manually with the remote control, first press the /// button and then press TV PROG. - or +. Press the /// button again to return to automatic tracking.

**During Slow:**

1. Simply press TV PROG. + or - to adjust tracking.

##### NOTES:

- The recorder automatically stops when still continues for more than 5 minutes.
- If the still picture is unstable, use the TV PROG. buttons to correct the picture.
- During search playback, some noise bars will appear.
- There is no audio during search, slow, still, or frame-by-frame playback.
- When a new tape is inserted, the recorder enters the automatic tracking mode automatically.
- When playing back LP recordings in the search, still or frame-by-frame playback mode, the picture will be distorted and there will be a loss of colour.



#### Index Sea


Your recorder automatically marks index codes at the beginning of each recording. This function gives you quick access to any one of 9 index codes in either direction.

**During Stop:**

1. Press PUSH JOG ◀ or ▶, "INDEX -1" or "INDEX 1" will be displayed on the display panel and search will begin in the corresponding direction.
2. If you wish to access index codes 2 through 9, press PUSH JOG repeatedly until the correct index number is displayed.

Ex.: To locate the beginning of B from the current position, press PUSH JOG ◀ twice.

To locate the beginning of D from the current position, press PUSH JOG ▶ once.



- When the specified index code is found, playback will start automatically.

#### ReView Function

Simply by pressing a single button, the recorder power comes on, rewinds, and begins playback of the last recording. This makes it easier to "review" the programme you have timer-recorded.

**When the recorder power is off:**

Press REVIEW.

- After the recorder power comes on, the tape will be rewound to the beginning of the last recording (where the index code is placed) and playback will start automatically.
- To play back a recording located 2 index codes away, press REVIEW twice. You can access any one of up to 9 index codes.
- ReView is not possible while the recorder is in the Timer mode.
- The recorder's REVIEW button lights when timer-recording is finished, and blinks while the tape is being rewind.

#### NTSC Playback

Your video recorder is equipped with NTSC circuitry that can play back NTSC tapes.

1. Insert a cassette recorded in NTSC.
2. Press Play.

**When playing back NTSC tapes:**


- "NTSC - PAL" will appear on the display panel.
- Some TVs shrink the picture vertically and place black bars at the top and bottom of the screen. This is not a malfunction on the part of either the video recorder or the TV.
- The picture may roll up or down. This can be corrected using the V-HOLD control found on some TVs. (This cannot be corrected if the TV does not have a V-HOLD control.)
- The counter reading will be incorrect.
- During search, still, or frame-by-frame playback, the picture will be distorted, and there may be a loss of colour.

#### Repeat Playback

**During Playback:**

1. Press Play for more than 5 seconds, and release.
  - The Play indicator (▶) on the display panel will blink slowly.
  - The tape will be played all the way to the end 20 times automatically, and then stop.
2. To stop playback at any time, press Stop.

## Playback (cont'd)



### Other Functions (cont'd)

#### Counter Memory

##### During Playback:

1. Press DISPLAY until a counter reading appears on the display panel.
  - The counter will read "0:00:00".
2. Press C.RESET at a point you wish to locate later.
  - The M indicator will light on the display panel.
3. Press C.MEMORY.
  - The tape will rewind and stop at about "0:00:00" automatically.
4. When you wish to return to that point, press Stop and then Rewind.
  - The tape will rewind and stop at about "0:00:00" automatically.
5. To cancel the Counter Memory mode, press C.MEMORY again.

#### Next Function Memory

Your recorder can memorise what to do after rewind.  
During Stop:

For automatic start of playback after the tape is rewind:

1. Press Rewind.
2. Press Play within 2 seconds.


For automatic power off after the tape is rewind:

1. Press Rewind.
2. Press OPERATE within 2 seconds.

For automatic timer standby after the tape is rewind:

1. Press Rewind.
2. Press TIMER within 2 seconds.

## Recording



### Basic Operations


#### Preparation

- Turn on the TV.
- Select VIDEO channel (or AV mode).

1. Load a cassette.
  - The recorder power will come on automatically.
2. Press TV/VIDEO to engage the VIDEO mode.
3. Press TV PROG. or the numeric keys to select the channel you wish to record.
  - You can also use the recorder's JOG dial to select the channel.
4. Press SP/LP to select the tape speed.
5. Press Record and Play simultaneously.
6. Press Pause/Slow to pause recording.
7. Press Play to resume recording.
8. Press Stop to stop recording.

#### NOTES:

- To start recording with the recorder's Record button, press it once on its own.
- After pause, when recording is resumed, a few frames recorded before the pause may be overlapped by the new recording. This is meant to reduce picture distortion and is not a malfunction.
- The recorder automatically stops when record-pause continues for more than 5 minutes.
- If the Record button does not work, check to see if the cassette's safety tab has been removed.
- The channel cannot be changed while recording is in progress. To change the channel, engage the record-pause mode, then change the channel.
- The recorder automatically rewinds when the end of the tape is reached during recording.
- When a VPS programme is being broadcast on the selected channel, "E" mark appears on the display panel (p. 19 for information on VPS).



### Other Functions

#### To Watch Another Programme While Recording

##### During Record:

1. If your recorder is connected to the TV via AV connection, press TV/VIDEO.
  - The recorder's VIDEO indicator and the TV broadcast being recorded will disappear.
2. Use the channel controls on the TV to select the other channel you wish to view.
  - The programme selected with the TV channel controls will appear on the TV screen while the one selected with the video recorder's channel controls will be recorded on the tape.
  - If a decoder is connected to the recorder (p. 6), you can select a scrambled channel as well with the TV channel controls.

#### Instant Timer Recording (Off Timer)

You can start a recording and then set the recorder to shut off automatically after a set duration.

##### During Record:

1. Press recorder's Record. "ITR" and "0:30" indications appear, advising that power will switch off after 30 minutes.
2. Press Record again to delay the off-time by 30-minute increments (up to 4 hours).
  - For more precise setting, use the remote control's SELECT and TV PROG. buttons to set the exact time required (possible up to 8 hours and 59 minutes).

#### Elapsed Recording Time Indication

When you need to know the exact time of a recording.

1. Press DISPLAY until a counter reading appears on the display panel.
2. Press C.RESET before starting recording or playback.
  - The counter will be reset to "0:00:00" and show the exact elapsed time as the tape runs.

#### Display Button

When you wish to check the time, date, or counter reading.


1. Press DISPLAY to display the current clock time.
2. Press DISPLAY again to display the current date.
3. Press DISPLAY again to display the counter reading.

#### Information on Colour System

- You can also record SECAM signals, or play back a MESECAM tape on this recorder.
- When SECAM signals are being received, "MESECAM" will be displayed on the display panel.
- When a MESECAM tape is played back, "MESECAM" will be displayed on the display panel.
- MESECAM is the designation for tapes with SECAM signals that have been recorded on MESECAM-capable PAL recorder.

### Special Note On Video Cassettes

To prevent accidental recording on a recorded cassette, remove its safety tab. To record on it later, cover the hole with adhesive tape.



## Preparation for ShowView Timer Programming

### What Is ShowView?

For timer-recording to take place, information such as the channel, date, start time and stop time of the programme you wish to record, must be programmed into the recorder's timer memory. The ShowView system condenses all this information into a simple ShowView code number. Since the ShowView number contains information on the channel number, if you live in an area that uses channel numbers that are different from those listed in your TV directory, these "differences" must be input into the remote control. This process is called "Channel Mapping" (CH MAP).

### CHECK THE GUIDE PROG. NUMBERS

#### Preparation

- Make sure you have set the clock. (r p. 7)
- Make sure you have set the tuner. (t p. 8)
- Get a TV schedule listing (magazine, newspaper, etc.) which carries ShowView code numbers.


- [A] Find out the channel position numbers your recorder tunes to when you use the TV PROG. -/+ buttons (the positions you stored on page 8) and write them into the list.

Example: 1, 2, 3, 4, 6, 8, 10, 12

- [B] Look through the TV listing and find out the broadcast station name of each of the channels.
- [C] Use the ShowView numbers to find out the GUIDE PROG. numbers for each of the stations.




#### How to check:

1. Press PROG.




2. Press the appropriate numeric keys to enter the ShowView number for a programme as it appears in your TV listing.

- Make sure the ShowView number is for a programme which has not been broadcast yet.



3. Press TRANS.



- The number is the GUIDE PROG. number for that station. Write it into the list.

#### ATTENTION

- When you press the TRANS button in step 3, "Err(or)" may appear on the LCD. This may mean that you have entered a ShowView number for a programme which has already been broadcast.
- For GUIDE PROG. numbers, refer to the GUIDE PROG. number list enclosed with this instruction manual too or consult your JVC dealer.


4. Press PROG.

- Repeat steps 1-4 and check the GUIDE PROG. number for each of the channels your recorder receives.

[A] Channel on your recorder (TV PROG. number)	[B] Station name	[C] GUIDE PROG. number
(ex.) 1	ARD	1
2	ZDF	2
3	WDR	17


5. Press PROG. until the display shows the clock time.

- [D] If the channel number that your recorder receives [A] and the GUIDE PROG. number [C] for that station do not match, it is necessary to change the remote control's Channel Map. (continued on next page)




### INPUT GUIDE PROG. NUMBERS INTO REMOTE

1. Press CH MAP until the Channel Map display (below) appears in the remote control's LCD.




2. Press the appropriate numeric keys to enter the GUIDE PROG. number ([C] column in your list).

Ex.: For "1", press  
0, 0, 1.  
For "10", press  
0, 1, 0.



3. Press the appropriate numeric keys to enter the channel number your recorder receives that station on. (TV PROG. number, [A] column in your list.)

Ex.: For "3", press  
0, 3.



4. Press SELECT.


- To input other channels into the Channel Map, repeat steps 2-4 above.

5. Press CH MAP and display the clock time.


Ex.: From column [C] in the list: The GUIDE PROG. number for WDR is "17".  
From column [A] in the list: The TV PROG. number for WDR is "3".

### TO CHECK/CANCEL GUIDE PROG. NUMBERS IN THE REMOTE

1. Press CH MAP until the Channel Map display (below) appears in the remote control's LCD.



2. Press SELECT until the GUIDE PROG. number you wish to check or cancel is displayed.




#### To Cancel:


3. Press CANCEL.
4. Press CH MAP and display the clock time.

#### NOTES:

- When you move to another area, be sure to make changes in the Channel Map as necessary.
- When the remote control's batteries are replaced, the time or Guide Channel numbers you have set may be erased. If this happens, reset them again.



## Preparation for ShowView Timer Programming (cont'd)




### TO RECORD SATELLITE PROGRAMMES

Timer programming is also possible for programmes received via satellite tuner.


#### Preparation

1. Connect the satellite tuner as illustrated to the AV2 IN/DECODER connector.
  - Make sure the AV2 SELECT switch is set to "AV2".
2. Press CH MAP until the Channel Map display (below) appears in the remote control's LCD.



3. Press the appropriate numeric keys to enter the GUIDE PROG. and TV PROG. numbers as follows:

- For GUIDE PROG., enter the GUIDE PROG. numbers of the satellite stations that are receivable through your satellite tuner.
- For TV PROG., always enter "00". When "00" is entered, "AU" will appear in the LCD.



4. Press SELECT.
  - To input other satellite stations into the Channel Map, repeat steps 3 - 4 above.
5. Press CH MAP and display the clock time.

#### Operation


1. Turn on the satellite tuner and select the channel you wish to record.
2. Enter the ShowView number in the same way as shown in steps 1 - 7 of ShowView Timer Programming on p. 17.

#### NOTE:

- After selecting the programme you wish to record from your satellite tuner, set the system's timer. If your satellite tuner does not have a timer, leave it switched on.

## Timer-Recording

### — ShowView Timer Programming —



The built-in ShowView programming system greatly simplifies timer programming because you won't have to enter all the data that is usually necessary (such as date, start and stop time, and channel).

**TIMER PROGRAMMING IS NOT POSSIBLE UNLESS THE CLOCK HAS BEEN SET.**

#### Preparation


- Make sure you have set the GUIDE PROG. numbers (r.p. 14 - 16).
- Insert a cassette with the safety tab in place. The recorder power will come on automatically.

1. Press PROG.




2. Press the appropriate numeric keys to enter the ShowView number for the TV programme you wish to record.

- For ShowView numbers, refer to your newspaper or TV directory.



3. Press SELECT.

- The LCD will show the data for the ShowView number you just entered.
- If the entered ShowView number is not proper, "Err" appears on the LCD. Check the ShowView number again and re-enter it.
- If you wish to take advantage of VPS recording (r.p. 19), "(3)" should be displayed on the LCD; if not, press (3) (the numeric key "7") to make it appear.



- WEEKLY program: After step 3, press numeric key "9".
- DAILY (Mon. - Fri.) program: After step 3, press numeric key "8".

4. Press SP/LP to select the tape speed.

5. Press TRANS with the remote control directed toward the recorder's Remote Sensor window.

6. Press PROG.

- The LCD returns to the clock display and the entered data will be automatically cleared.

- If you need to set another program, repeat steps 1 - 6.

7. Press TIMER.

- The recorder will enter the Timer mode and power will go off.

#### TO DELAY THE STOP TIME

After you press SELECT in step 3, press the ADD TIME button. Each time the ADD TIME button is pressed, the Stop time is delayed by 5 minutes (5 minutes of recording time is added). You can easily compensate for anticipated programme schedule delays this way.

### TO MAKE CORRECTIONS


- In step 2, press CANCEL to backspace and re-enter the correct ShowView number.
- After checking the data in step 3, press PROG. twice and re-enter the correct ShowView number.
- After checking the data in step 3, if you want to delay the stop time, etc. press SELECT to make the item you want to change blink, and input new data.
- Pressing PROG. clears the programmed data.

To check, cancel and replace programs, r.p. 18.

To use the recorder after setting to the Timer mode, r.p. 18.



## Timer-Recording (cont'd) — LCD Timer Programming —




The LCD timer programming lets you input all necessary settings manually. It's helpful if the ShowView number for the TV programme you want isn't readily available.

### Preparation

- Insert a cassette with the safety tab in place. The recorder power will come on automatically.


- Press PROG. twice.
- Press numeric keys to input the date.

Ex.: For 26th May, press 2 6 0 5.



- Press numeric keys to input the start time, stop time and channel.

Ex.: For 8:00, press 0 8 0 0.



Transfer-ready mark

**WEEKLY program:** After you input the channel and the transfer-ready mark has appeared on the LCD, press numeric key "9".

**DAILY (Mon. - Fri.) program:**

After you input the channel and the transfer-ready mark has appeared on the LCD, press numeric key "8".

- If you wish to take advantage of VPS recording (p. 19), (3) should be displayed on the LCD; if not, press (3) (the numeric key "7") to make it appear.

- Press SP/LP to select the tape speed.
- Press TRANS with the remote control directed to the recorder's Remote Sensor window.
- Press PROG.
  - The LCD returns to the clock display and the entered data will be automatically cleared.
- Press TIMER.
  - The recorder will enter the Timer mode and power will go off.

### TO MAKE CORRECTIONS

- During steps 2 and 3, press CANCEL to backspace and input new data.
- After setting the channel in step 3, press SELECT to make the item you want to change blink, and input new data.
- Pressing PROG. clears the programmed data.

### TO CHECK, CANCEL AND REPLACE PROGRAMS

To check preset programs:

- Press ADJUST until the program settings are displayed on the display panel.
  - Program 1 is displayed with the number blinking.
- Press SELECT to review the program contents in succession.
- To check another program, press ADJUST again.
- To cancel the program:
  - Press CANCEL.
  - You can press CANCEL at any stage while the program is open.

To replace a program:

- Use the SELECT and TV PROG. buttons to input new data.

### TO USE THE RECORDER AFTER SETTING TO THE TIMER MODE

For safety, your recorder disables all other functions while in the Timer mode.

- Press TIMER to disengage the Timer mode.
- To re-engage the Timer mode, press TIMER.

### NOTE:

- If you have a satellite tuner connected to the recorder's AV2 IN/DECODER socket and wish to timer-record satellite programmes, make sure to input "0" for the channel number in step 3 to make "AU" appear on the LCD. After you transfer the data to the recorder, "AU 2" will be displayed instead of a channel number on the recorder's display panel.

### Error Indications

The following error indications may appear on the recorder when you press the TIMER button to engage the Timer Standby mode. Here's why, and what you should do.

- "TIMER" and "00" on the display panel continue blinking.
 

**WHY:** There is no cassette in the recorder.

**WHAT TO DO:** Insert a cassette.
- The cassette is automatically ejected. "TIMER" and "00" continue blinking.
 

**WHY:** The inserted cassette has its safety tab removed.

**WHAT TO DO:** Insert a cassette with its safety tab intact. Or cover the safety tab hole of the cassette with adhesive tape and re-insert it. (p. 13).
- "TIMER" blinks for 10 seconds and the Timer Standby mode is cancelled.
 

**WHY:** There are no preset programs in memory, or they have all been incorrectly preset.

**WHAT TO DO:** Check the programmed data and re-program it as necessary. Press TIMER again.

### Other Indications

- "TIMER" steady lit (with clock display).
 

**WHY:** The recorder is in the Timer Standby mode. This is the normal display you should see when you press the TIMER button.
- "00" and "TIMER" steady lit.
 

**WHY:** Normal display while timer-recording is in progress.
- The cassette was ejected, with power off and "TIMER" and "00" are blinking.
 

**WHY:** This means that the end of the tape was reached while timer-recording was in progress. Therefore, the preset program may not be recorded in its entirety.
- "00" blinking.
 

**WHY:** This means the clock must be set. It's displayed when time-keeping is terminated due to a power failure or because the recorder's power plug was pulled from the AC outlet.

**WHAT TO DO:** Set the clock. (p. 7).
- If power was interrupted, it's also likely that all preset timer programming data has been erased. Please check and re-program as necessary.
- "..." is displayed for about 5 seconds when the TRANS button is pressed.
 

**WHY:** Data was not successfully transferred. The program may have been incorrectly preset, or the recorder's clock has not been set, or all the recorder's timer programs (1 - 8) are preset.

**WHAT TO DO:** Check the LCD program, and re-program as necessary. Transfer the correct data. Or cancel unnecessary programs, and transfer again.

## Other Functions

### VPS Recording

Now available from some TV stations, VPS (Video Program System) is a service designed to assure safe, accurate timer-recording. With this system, special code signals are transmitted together with the audio/video signals. These code signals control your video recorder and have precedence over advertised times you preset in the timer. This means that your recorder will start and stop recording when the preset TV programmes actually start and end — even if the broadcast time of a preset TV programme is changed.

#### TO USE VPS SERVICE

- During ShowView or LCD timer programming, make sure that (3) is displayed on the LCD before transferring the programme data to the recorder.
- If (3) is not displayed on the LCD, press the (3) button (the numeric key "7") to make it appear. Pressing the (3) button alternates the setting.

### NOTES:

- When you enter programmes, set the start time (VPS time) exactly as advertised in the TV listing. A different time than advertised will result in no recording.
- VPS recording is not possible via external input.

### Locking The Recorder's Controls

To avoid unwanted operation and prevent accidental recording...

- Press the remote control's OPERATE button to turn the recorder's power off. Keep this button pressed for about 2 more seconds after the power LED indicator has gone off.
  - The Child Lock Indicator (-) will appear on the display panel.
- Child Lock is cancelled when you switch the recorder's power on with the remote's OPERATE button.
  - Pressing the TIMER button during timer-recording also cancels the Child Lock mode.

### NOTES:

- While Child Lock is engaged, make sure you keep your remote control in a safe place inaccessible to children.
- Timer-recording is possible in the Child Lock mode. After timer-recording is done, Child Lock remains in effect.

## Other Functions (cont'd)

### Remote A/B Code Switching


The remote control is capable of controlling two JVC video recorders independently; one set to respond to your remote control's A code control signals and another set to respond to B code control signals. The remote control is preset to send A code signals because your video recorder is initially set to respond to A code signals. You can easily modify your video recorder to respond to B code signals.

1. Unplug the recorder's power cord from the AC outlet.
2. Press the A/B button for more than 2 seconds to switch to B code.
3. Plug the power cord back into the AC outlet. Do not use other remote controls at this stage.
4. Turn the recorder power on by using the remote control's OPERATE button. The recorder will now only respond to B code signals.

#### NOTE:


Some TV sets may malfunction in response to the B mode. If this happens switch back to the A mode.

### To Watch A Compact VHS Tape



Compact VHS camcorder recordings can be played on your video recorder. Place the recorded cassette into a C-P6 Cassette Adapter and it can be used like any full-sized VHS cassette.

## Audio Dubbing



Audio dubbing replaces the normal audio sound of a previously recorded tape with a new soundtrack.

#### Preparation


Connect an audio component to the recorder's front panel AUDIO input connector.

1. Select the recorder's external input mode by pressing numeric key "0". "F-AU" will appear instead of a preset number.
2. Start playback and engage the Still mode at the point from which you wish to start audio dubbing.
3. Press A. DUB.
4. Start playback of the audio source, and then press Play.
  - Audio dubbing will start.
5. Press Pause/Slow to stop audio dubbing temporarily.
6. Press Stop to stop audio dubbing.

#### NOTES:

- Audio dubbing will stop automatically at the counter reading of "0:00:00", and the recorder will enter the Play mode. Check the counter before starting audio dubbing.
- Audio dubbing is also possible with input via the rear panel AV1 or AV2. With AV2, set the AV2 SELECT switch on the rear panel to AV2.
- Connections made to the front panel V(Video) and A(Audio) input automatically override the rear panel AV1 or AV2 input connection.

## Editing



### Editing To/From Another Recorder


#### Preparation

Connect the player's AV1 IN/OUT connector to the recorder's AV1 IN/OUT or AV2 IN/DECODER connector.

1. Select the recorder's external input mode.
  - With this video recorder,
    - If connected to the AV1 IN/OUT connector, press TV PROG. until "AU 1" appears on the display panel.
    - If connected to the AV2 IN/DECODER connector, make sure the AV2 SELECT switch is set to "AV2", and press TV PROG. until "AU 2" appears.
2. Put the player in the Play mode.
3. Put the recorder in the Record mode.

#### NOTE:

- While editing, it is recommended that you turn off SQ<sup>2</sup>.



### Editing From A Camcorder

#### Preparation


Connect the camcorder's AUDIO and VIDEO OUT connectors to the recorder's front panel AUDIO and VIDEO connectors.

1. Select the recorder's external input mode by pressing numeric key "0". "F-AU" will appear instead of a channel number.
2. Put the camcorder in the Play mode.
3. Put the recorder in the Record mode.

#### NOTES:

- If the camcorder is equipped with the Master Edit Control system, you can control the recorder using the camcorder's controls. See the camcorder's instruction manual for operating procedures.
- Connections made to the front panel VIDEO and AUDIO input automatically override the rear panel AV1 or AV2 input connection.

## Using The Remote Control For TV Operation



### TV Code Setting

Your remote control can operate the basic functions of your TV set. In addition to JVC televisions, other manufacturers' televisions listed on the right can also be controlled by setting the remote control to "TV". If your television is a JVC (Code 01), you don't have to set the TV code in step 2.

- Set the TV/VIDEO switch to "TV".
- While holding down the OPERATE button, press the numeric keys corresponding to the code number for your TV's brand and then press Stop.
  - Press OPERATE to turn the TV power on.
  - Press TV/VIDEO to switch the TV between TV and VIDEO (or AV) mode.
  - Press TV PROG. to select the TV's channel.
  - Press VOL. to adjust the TV's sound volume.
  - Press Mute to mute the TV's sound.
- To operate your recorder, set the TV/VIDEO switch back to "VIDEO".

### NOTES:

- The TV PROG. button does not function with televisions using Code 02.
- The TV/VIDEO button does not function with televisions using Code 03.
- With some televisions, the OPERATE button functions only to turn the TV power off, and the TV/VIDEO button functions only to switch the TV to the VIDEO (AV) mode.
- Whenever you replace batteries in the remote control, it is necessary to re-set the TV code if your television is not a JVC TV.

### IMPORTANT

Although the provided remote control unit is compatible with JVC television, as well as many other TV models, it may not work with your TV, or in some instances, may have limited function capability.

CODE	TV BRAND NAME
01	JVC
02	BRANDT, NORDMENDE, SABA, TELEAVIA, TELEFUNKEN, THOMSON
03	FERGUSON
04	PHILIPS
05	BLAUPUNKT, GRUNDIG
06	SONY
07	PANASONIC
08	GRAETZ, ITT, LUXOR, SALORA, SELECO
09	MIVAR

### To Control Your Television With Additional Buttons

The numeric keys can also be used to select the TV's channel by setting the remote control to the TV mode.

- Set the TV/VIDEO switch to "TV".
- Use the numeric keys and the Digit entry button or the PUSH JOG button or DISPLAY button to select the TV's channel.
  - With televisions under Code 01, 03, 04, 06 or 07 the Digit entry button corresponds to the 1-digit/2-digit entry switching button (often labelled +/-) of your TV's remote control.
  - With televisions under Code 01, 08 or 09, the PUSH JOG - button corresponds to the 10 + button, and the PUSH JOG + button, to the 20 + button of your TV's remote control.
  - With televisions using Code 09 the DISPLAY button corresponds to the 30 + button.

### NOTE:

The way these buttons are used is determined by your TV. Use these buttons as instructed for your TV's remote control.

## Precautions

Please follow these safety precautions. Not doing so may result in damage to the recorder, remote control, or video cassette.

- Avoid extreme heat and direct sunlight.
- Avoid extreme cold.
- Avoid extreme humidity.
- Avoid dust.
- Avoid places subject to vibrations.
- Avoid strong magnetic fields.
- Do not block the recorder's ventilation openings.
- Do not place anything heavy on the recorder or remote control.
- Do not place anything which might spill on top of the recorder or remote control.
- Do not place the recorder on cushions, pillows, or thick carpeting.
- Use the recorder in a stable, horizontal position only.

### Beware of moisture condensation

Moisture in the air will condense on the recorder when you move it from a cold place to a warm place, or under extremely humid conditions — just as water droplets form on the surface of a glass filled with cold liquid. Moisture condensation on the head drum will cause damage to the tape. In conditions where condensation may occur, keep the recorder's power turned on for a few hours to let the moisture dry.

### When transporting

- Be sure to remove cassette from recorder before packing.
- Avoid violent shocks to the recorder during packing and transport.

Place cassettes in cassette cases and store vertically.

## Specifications

### GENERAL

Power requirement : AC 220 – 240 V~, 50/60 Hz  
Power consumption : 20 W  
Temperature

Operating : 5°C to 40°C  
Storage : -20°C to 60°C

Dimensions (WxHxD) : 400 x 94 x 344 mm

Weight : 4.3 kg

Format : VHS PAL standard

Maximum recording time (SP) : 240 min. with E-240 video cassette  
(LP) : 480 min. with E-240 video cassette

### VIDEO/AUDIO

Signal system : PAL-type colour signal and CCIR monochrome signal, 625 lines/50 fields

Recording/Playback system : DA-4 (Double Azimuth) head helical scan system

Signal-to-noise ratio : 45 dB

Horizontal resolution : 250 lines

Frequency range : 70 Hz to 10,000 Hz

Input/Output : 21-pin scart connector x 2  
(IN/OUT x 1, IN/DECODER x 1)  
RCA connectors  
(VIDEO IN x 1, AUDIO IN x 1)

### TUNER/TIMER

TV channel storage capacity : 80 positions (+AUX position "AU")

Channel coverage : VHF 47 – 89/104 – 300/

302 – 470 MHz  
UHF 470 – 862 MHz

Aerial output : UHF channel 36  
(Adjustable 32 – 40)

Memory backup time : Approx. 3 min.

### ACCESSORIES


Provided accessories : Aerial cable,  
Infrared remote control unit,  
"R03" battery x 2

Design and specifications subject to change without notice.  
Specifications shown are for SP mode unless otherwise specified.

## SECTION 1 DISASSEMBLY

### 1.1 DISASSEMBLY FLOW CHART

This flowchart lists shows the disassembly steps for the cabinet parts and P.C. boards in order to gain access to item(s) to be serviced. When reassembling, perform the step(s) in reverse order. Bend, route and dress the flat cables as they were originally.



### 1.2 HOW TO READ THE DISASSEMBLY AND ASSEMBLY

STEP /LOC NO.	PART NAME	FIG. NO.	POINT	NOTE
①	TOP COVER	D1	4(S1)	
②	BOTTOM COVER	D2	(S2), 7(L1)	
③	FRONT PANEL ASSY	D3	7(L2), *JOG/SHUTTLE	<NOTE 1>
④	SW/JACK & DISPLAY BOARD ASSIES	D4	12(L3), *CN1,	<NOTE 2>
⑤	CASSETTE HOUSING ASSY	D5	4(S3) EARTH PLATE	<NOTE 3>
⑥	PRE/REC BOARD ASSY	D6	2(S4), *CN1 *CN201, *CN202 SHIELD CASE	

↑ (1)      ↑ (2)      ↑ (3)      ↑ (4)      ↑ (5)

#### (1) Order of steps in Procedure

When reassembling, perform the step(s) in the reverse order. These numbers are also used as the identification (location) NO. of parts Figures.

#### (2) Part name to be removed or installed.

#### (3) Fig.No. showing procedure or part location

#### (4) Identification of part to be removed, unhooked, unlocked, released, unplugged, unclamped or unsoldered. P = Spring, W = Washer, S = Screw, L = Locking tab, \* = Unhook, unlock, release, unplug or unsolder.

#### (5) Adjustment information for installation

### 1.3 DISASSEMBLY/ASSEMBLY METHOD

STEP /LOC NO.	PART NAME	FIG. NO.	POINT	NOTE
①	TOP COVER	D1	4(S1)	
②	BOTTOM COVER	D2	(S2), 7(L1)	
③	FRONT PANEL ASSY	D3	7(L2), *JOG/SHUTTLE	<NOTE1>
④	SW/JACK & DISPLAY BOARD ASSIES	D4	12(L3), *CN1	<NOTE2>
⑤	CASSETTE HOUSING ASSY	D5	4(S3) EARTH PLATE	<NOTE3>
⑥	PRE/REC BOARD ASSY	D6	2(S4), *CN1 *CN201, *CN202 SHIELD CASE	
⑦	DRUM ASSY	D7	3(S5), WR1, 4(L4) INERTIA PLATE	<NOTE4>
⑧	MAIN DECK ASSY	D8	2(S6), WR2 WR3, 2(L5), *CN603	<NOTE5>
⑨	MAIN BOARD ASSY	D9	2(S7)	

#### <NOTE1>

When reattaching the front panel assy, make sure that the door opener (a) of the cassette housing assy is lowered in position prior to the reinstallation.

#### <NOTE2>

When plugging the connector in, check that the flat wire is inserted properly and fully.

#### <NOTE3>

When reattaching the cassette housing assy, pay careful attention to the switch lever not to make it touch the REC switch knob of the REC SAFETY board assy from the up-side.

(If the REC switch knob of the REC SAFETY board assy is damaged, cassette loading is impossible.)

#### <NOTE4>

When plugging the connector in, check that the flat wire is inserted properly and fully.

#### <NOTE5>

- When removing the Main deck assy only, unhook the two spacers connecting it with the Main board assy with pliers from the back side of the Main board assy first, and then remove the Main deck assy.

- When reattaching the Main deck assy to the Main board assy, make sure to set the spacers into the retaining slots respectively.




Fig. D1




Fig. D3




Fig. D2




Fig. D4




Fig. D5




Fig. D7




Fig. D6




Fig. D8




Fig. D9

#### 1.4 CASSETTE HOUSING INSTALLATION

**NOTE:** Observe the mechanical phase and position (see figure) when installing the cassette housing assembly. If these are incorrect, the system will not operate properly even when tape is inserted.

1. Check that the hole of the control cam are aligned to the deck hole. If necessary, turn the mode motor belt by hand to adjust the position.




Fig. 1-4-1

#### 1.5 SERVICE POSITION

##### 1.5.1 How to take out the Mechanism and Main board assemblies.

- (1) Remove the Top cover, Front panel assy and CN1 of the DISPLAY board assy.
- (2) Take out 4 screws (A), 2 screws (B) and 1 screw (C) as shown in Fig.1-5-1.




Fig. 1-5-1

- (3) Remove the Mechanism assy (including Cassette housing) and Main board assy out of the chassis as shown in Fig. 1-5-2.




Fig. 1-5-2

- (5) Turn over the Mechanism assy and Main board assy then connect CN1 of the DISPLAY board assy.
- (6) Carry out checks & repairs as necessary as shown in Fig.1-5-3.

**Note:** When input the AUDIO/VIDEO signal from connector, connect CN4 of the SW/JACK board assy.




Fig. 1-5-3

### 1.5.2 Cautions on cassette loading when mechanism is in service position

The REC SAFETY board assembly of this set serves both for detecting the safety tab (erasure prevention tab) of a cassette and detecting a cassette loaded. Therefore, cassette loading in the condition that the mechanism is disassembled from the set needs manual operation of the switches of the REC SAFETY board assembly and the CASSETTE SWITCH board assembly.

### 1.5.3 Cassette loading and ejecting procedures when mechanism is in service position

- (1) Insert a cassette tape halfway into the cassette housing assembly.
- (2) Press the switch of the REC SAFETY board assembly to turn on.
- (3) When the cassette loading begins and the cassette goes down to the bottom, immediately press the switch of the REC SAFETY board assembly to turn off and hold the status that the switch of the CASSETTE SWITCH board assembly is turned on. (Fix the switch with adhesive tape or put a screwdriver, etc. on it to leave the switch in the ON status.)

- (4) In this status, desired operations (recording, playback, fast forward, rewind, etc.) can be performed.

**Note:** When the mechanism is in the service position, the safety tab of cassette tape is not detected and recording on cassette tapes without safety tab is possible. Therefore, carefully choose a cassette tape for operation in this mode so as to avoid using cassette tapes of important recording.

- (5) For ejecting the cassette in this status, do it in the reverse order of cassette loading mentioned above.

**Note:** If the manual operation REC SAFETY switch timing is incorrect, the cassette may be completely or partially ejected, and the cassette is often ejected incompletely. In such a case, it is possible to take out the cassette by hand.

If it is desired to load a cassette again after the cassette is ejected in the above procedure, make sure to set the tray of the cassette housing assembly in the frontmost position prior to loading the cassette once again.



#### 1.5.4 Opening on the chassis.

The chassis assy has openings for easy access to the check-points and connector pins as shown in Fig.1-5-4.




Fig. 1-5-4

## 1.6 MECHANISM SERVICE MODE

This model has a unique function to enter the mechanism into every operation mode without loading of any cassette tape. This function is called the "MECHANISM SERVICE MODE".

- (3) Connect TP2 (GND) and TP1 (TEST) on the DISPLAY board assy with a jump wire.
- (4) Connect VCR to AC.
- (5) Press the POWER button.
- (6) Select the desired operation modes with the operation buttons or remote controller.

### 1.6.1 How to set the "MECHANISM SERVICE MODE"

- (1) Disconnect VCR from AC.
- (2) Remove the Top cover, Front panel assy and cassette housing assy. (See Page 1-2, 1-3)




Fig. 1-6-1

## 1.7 EMERGENCY DISPLAY FUNCTION

This product has the function to store the last two previous emergency faults which can be displayed in the FDP when servicing.


### 1.7.3 How to clear emergency record

Press the COUNTER RESET button on the remote controller in the emergency record display mode, and the record of the emergency fault(s) is cleared.

#### 1.7.1 How to display record of an emergency faults

- (1) Press 'N' button of the presetting unit more than 2 seconds, and the two previous emergency faults are shown in the FDP.
- (2) Press 'N' button of the presetting unit again when return the normal mode.

[Example] E : 01 : 03



Emergency faults before last  
Emergency faults of the last time

[Example] E : — : — — ← No record of emergency

#### 1.7.2 Detail of emergency faults

FDP	Symptom	Detect mode	Resulting mode
E : 01	Loading motor rotates for more than 8 Sec without shift to next mode.	Loading	POWER OFF
E : 02	Loading motor rotates for more than 8 Sec without shift to next mode.	Unloading	POWER OFF
E : 03	TU REEL FG input is absent(for more than 4 Sec)	REC/PLAY/FF/REW SEARCH FF/SEARCH REW	STOP → POWER OFF
E : 04	DRUM FF input is absent(for more than 3 Sec)	REC/PLAY/FF/REW SEARCH FF/SEARCH REW	STOP
E : 06	CAPSTAN FG input is absent(for more than 1 Sec)	REC/PLAY/FF/REW SEARCH FF/SEARCH REW	STOP → POWER OFF
E : 07	No SWD5V/12V	POWER ON	POWER OFF

Table 1-7-1 EMERGENCY FAULTS

## SECTION 2 MECHANISM ADJUSTMENT

### 2.1 PREPARATION

#### 2.1.1 Precautions

- (1) Disconnect VCR from AC power before soldering.
- (2) Avoid imparting stress to wires when disengaging connectors.
- (3) Determine and correct the cause of difficulty before proceeding to adjustments. Do not disturb settings unnecessarily.
- (4) Use care not to damage tabs, claws, etc during repairs.
- (5) Install the cassette housing assy only when the mechanism is in the MECHANISM ASSEMBLING MODE position.
- (6) When installing the Front panel assy, be sure to engage the housing door with the door opener of the cassette housing assy.  
If this is omitted, the cassette door will not open at Eject and the cassette can not be removed. (See SECTION 1 DISASSEMBLY.)

#### 2.1.2 Check without cassette housing assy.

Mechanism operations can be observed easily by removing the cassette housing assy. Use the MECHANISM SERVICE MODE (See SECTION 1 DIASSEMBLY)

#### 2.1.3 Manual removal of loaded tape

When the deck enters the emergency mode with cassette tape loaded and it can not be ejected by pressing the EJECT button, take out of the cassette tape according to the following procedure.

- (1) Disconnect the power cord from AC outlet then take out the Top cover and Front panel assy.
- (2) Turn the mode motor on the Main deck assy by hand in the unloading direction to where the pole base assy (supply and take-up) is positioned below the cassette tape. At that time, pay careful attention to the tape not to get soiled with grease.
- (3) Take out 4 screws of the cassette housing assy. (See SECTION 1 DISASSEMBLY)
- (4) Remove the cassette housing with slackened tape and guard panel of cassette.
- (5) Wind up the tape by turning the reel hub (either supply or take-up side for convenience) from the bottom of the cassette, and remove the cassette tape.




Fig. 2-1-1

## 2.1.4 Test Equipment








Alignment tape (SP) MHPE	Alignment tape (LP) MHPE-L	Back tension cassette gauge PUJ48076-2	A/C head positioning tool PTU94010
			
Roller driver PTU94002	Presetting unit PTU94008	Grease KYODO-SH-P	
			

Table 2-1 Test equipment

## 2.2 MAIN MECHANISM PARTS




Fig. 2-2-1 Top view of main deck




Fig. 2-2-2 Bottom view of main deck

### 2.2.1 Cleaning

Periodic cleaning of the tape transport system is desirable, but ordinarily not feasible in practice. Therefore, perform cleaning when a set is brought in for repairs or maintenance. Contamination of the video heads, tape guides and brush can detract from playback picture quality and in extreme cases, even damage the tape. For cleaning, use a finemesh cotton cloth (about the texture of a white dress-shirt) moistened in alcohol. It is recommended to also clean the tape tension posts and capstan.

- To clean the video heads, press the moistened cloth gently against the upper drum with fingertip and turn the drum by hand.
- Do not use a vertical stroke, as this may damage the heads.

### 2.2.2 Lubrication

Oil and grease do not normally require periodic replenishing. Apply only when replacing lubricated parts (also clean and replace lubrication of mating parts if soiled). For parts and points to apply oil and grease, refer to the exploded views of the mechanism assy. Before oiling, clean with alcohol. Apply one or two drops of oil. Avoid excess oil.

1. Table 2-2-1 indicates the oil and grease used in this set. Use these or recommended locally available equivalents.

Category	Part No.
Oil	COSMO-HV56
Grease	KYODO-SH-P

Table 2-2-1

2. Grease is not required for a replacement cassette housing assy, as this has been applied at the factory.

**NOTE :** *Stir grease that has been stored for an extended period.*

## 2.3 INSPECTION AND MAINTENANCE

This product employs rotary and moving parts which wear out in the course of usage. Periodic inspection, cleaning, lubrication and maintenance are therefore important for ensuring maximum performance. Worn parts must also be replaced as and when required.

### 2.3.1 Suggested servicing schedule for main components

The following table indicates the suggested period for such service measures as cleaning, lubrication and replacement. In practice, the indicated periods will vary widely according to environmental and usage conditions. However, the indicated components should be inspected when a set is brought for service and the maintenance work performed if necessary. Also note that rubber parts may deform in time, even if the set is not used.

System	Parts Name	Operation Hours	
		~1000H	~2000H
Tape transport	Upper drum assy	★ ○	○
	A/C head	★ ○	★ ○
	Lower drum motor assy	★	★ ○
	Pinch roller arm assy	★	★
	Full erase head	★	★
	Tension arm assy	★	★
	Guide arm assy	★	★
Drive	Capstan motor		○
	Belt (Capstan)	○	○
	Belt (Mode motor)		○
	Mode motor		○
	Slit disk (supply, take-up)		○
	Clutch unit (supply, take-up)		○
	Worm gear assy		○
	Control plate		○
	Slide plate		○
Other	Brush assy	★ ○	★ ○
	Tension band assy	○	○
	Rotary encoder		○

★ : Cleaning

○ : Inspection or Replacement if necessary

Table 2-3-1

## 2.4 DISASSEMBLY/ASSEMBLY PROCEDURE OF MECHANISM

### 2.4.1 Precaution before disassembling mechanism

This mechanism has an exclusive operation mode provided for disassembling and installation of the mechanism (MECHANISM ASSEMBLING MODE), and it is suggested to set the mechanism to this mode before disassembly and installation. The exclusive mechanism operation mode is not generally used and becomes available by manual setting only. Then this procedure starts with the condition that the cabinet parts, cassette housing assy and PRE/REC board assy have been removed.

### 2.4.2 How to set the exclusive mechanism operation mode (MECHANISM ASSEMBLING MODE)

- (1) Turn the mode motor belt by hand.
- (2) Confirm that the hole of the control cam are aligned to the deck hole as shown in Fig.2-4-1.




Fig. 2-4-1

## 2.5 MAIN PARTS REPLACEMENT OF MECHANISM

### 2.5.1 Pinch Roller Arm ASSY

- (1) Remove the slit washer.
- (2) Tilt up the pinch roller assy in direction of arrow.




Fig.2-5-1

## 2.5.2 A/C Head

### 1. Removal

- (1) Take out 2 screws (A).
- (2) Remove the A/C head with head base.




Fig.2-5-2

- (3) When replacing the A/C head only, remove 3 screws (B), use care not to misplace the 3 springs.




Fig.2-5-3

### 2. Installation

- (1) Temporarily set A/C head height as indicated in Fig. 2-5-4.




Fig.2-5-4

### NOTES:

- It is very important to correctly adjust the control pulse and audio signal in addition to the mechanical tape path.
- Perform interchangeability adjustments after electrical adjustments.

## 2.5.3 Pinch Plate

### 1. Removal

- (1) Disengage 2 claws, then remove the pinch plate.




Fig.2-5-5

### 2. Installation

- (1) When installing pinch plate, align rack of pinch plate and triangle mark of control cam as indicated in Fig.2-5-6.




Fig. 2-5-6



#### 2.5.4 Mode Motor

- (1) Engage the belt between mode motor and worm gear.
- (2) Take out 2 screws (A) then remove the mode motor.




Fig.2-5-7




Fig.2-5-9

#### 2.5.5 Lever Assy,Sub Deck Assy,Capstan Motor

- (1) Take out 1 slit washer, then remove the lever assy.
- (2) Engage the belt( capstan motor) from bottom of mechanism assy first as indicated in Fig.2-5-10.
- (3) Take out 3 screws (A) and remove the sub deck assy as indicated in Fig.2-5-8.
- (4) Take out 3 screws (B) and remove the capstan motor from the sub deck assy as indicated in Fig.2-5-9.




Fig.2-5-8




Fig.2-5-10

### 2.5.6 Control Bracket-1, Earth Pillate

- (1) Take out 1 screw (A) and 1 screw (B).
- (2) Remove the control bracket-1 and earth pillate.




Fig.2-5-11




Fig.2-5-13

### 2.5.7 Reel Bracket, Slit disk (take-up)

- (1) Take out 2 slit washers.
- (2) Remove the reel bracket and slit disk (take-up).




Fig.2-5-12

### 2.5.8 Control Bracket-2, Control Plate

- (1) Take out 1 screw (A) and remove the control bracket-2.
- (2) Take out 1 slit washer.
- (3) Disengage 2 claws and remove the control plate.




Fig.2-5-14

### 2.5.9 Sub Brake(take-up),Control Cam

- (1) Disengage 1 spring (a) and 1 claw then remove the sub brake (take-up).
- (2) Disengage 1 claw and remove the control cam.




Fig.2-5-15

### 2.5.10 Slide Plate

- (1) Disengage 7 claws from bottom of the mechanism assy and remove the slide plate.




Fig. 2-5-16




Fig. 2-5-17

### 2.5.11 Change Lever,Rotary Encoder

- (1) Remove the change lever.
- (2) Disengage 2 claws and remove the rotary encoder.




Fig. 2-5-18

### 2.5.12 Sub Brake (supply),Tension Band Assy,Tension Arm Assy,Take-up Lever Assy,Slit Disk(supply)

- (1) Disengage 1 spring (a).
- (2) Disengage 1 claw and remove the sub brake (supply).
- (3) Take out 1 screw (A),spring (c) and slit washer.
- (4) Remove the tension arm assy with tension band assy.
- (5) Disengage 1 spring (b) and remove the take-up lever assy.
- (6) Remove the slit disk(supply).




Fig. 2-5-19

### 2.5.13 Take-up Head,Tension Arm Lever

- (1) Remove the take-up head and tension arm lever.




Fig.2-5-20

### 2.5.14 Guide Rail

- (1) Take out 5 screws (A) and 1 screw (B).
- (2) Disengage 3 claws and remove the guide rail.




Fig. 2-5-21

### 2.5.15 Stator Assy

- (1) Take out 2 screws (A).
- (2) Raise the stator assy in the direction indicated by the arrow to remove it (also remove the inertia roller).
- (3) Remove the flat cable.
- (4) To reinstall, first secure the flat cable, then insert 2 screws (A).
- (5) After reinstalling, be sure to perform PB switching point adjustment (See SECTION 3 ELECTRICAL ADJUSTMENT).




Fig. 2-5-22

**NOTE :** When refitting the connector, check that the flat wire is inserted correctly.

### 2.5.16 Rotor Assy

- (1) Remove the stator assy.
- (2) Take out 2 screws (B) and remove the rotor assy.




Fig.2-5-23

- (3) Align the upper drum assy and rotor assy phase as indicated in Fig.2-5-22.
- (4) Overlap holes (a) of the upper drum assy with holes (b) of the rotor assy (align holes in 3 locations) and secure with 2 screws (B) as indicated in Fig.2-5-21.




Fig. 2-5-24

### 2.5.17 Upper Drum Assy

#### 1. Removal

- (1) Remove the stator assy and rotor assy.
- (2) Use a 1.5 mm hexagonal wrench to loosen the collar assy screw and remove the collar assy.
- (3) Remove the upper drum assy and use tweezers to remove the Washer.




Fig. 2-5-25

**NOTE :** If the Brush is replaced, do not apply the grease to the contacts.

#### 2. Installation

- (1) Use an air brush to clean the lower drum assy and the coil section of the new upper drum assy.
- (2) Set a new washer on the drum shaft as indicated in Fig.2-5-25.

**NOTE :** Be sure to use the new washer when replace the upper drum assy.




Fig.2-5-26

- (3) Note the top and bottom of the collar assy and determine the position as indicated in Fig.2-5-25.




Fig.2-5-27

- (4) While pressing the collar assy evenly from above with your fingertips, secure the hexagonal screw.




Fig. 2-5-28

- (5) After installing, gently turn the upper drum by hand and confirm normal rotation.
- (6) Install the rotor assy and stator assy.
- (7) Clean the upper and lower drum assies and perform the following adjustments;
- PB switching point adjustment
  - Slow tracking preset adjustment
  - Interchangeability adjustment ( be sure to check LP mode)

## 2.6 CHECKUP AND ADJUSTMENT OF MECHANISM PHASE

### 2.6.1 Precaution

The rotary encoder and syscon circuit are closely interrelated. Therefore, the rotary encoder and control cam connection determines the operations of mechanical parts such as plates, gears, brakes, etc. Correct positioning of these parts is essential for smooth tape loading and mechanical operations.

### 2.6.2 Loading Arm Assy (supply, take-up)

- (1) Install the supply loading arm assy and the take-up loading arm assy so that their positioning markings on the respective gear face each other and the holes of their arms correspond to the holes on the main deck assy respectively.
- (2) After setting the guide rails, engage the pole base assies with the tip of the loading arms respectively. Then, enter the mechanism into the unloading mode to return the pole base assies to the front position.
- (3) Reassemble the peripheral parts of the guide rail as originally.




Fig. 2-6-1

### 2.6.3 Rotary Encoder, Change Lever, Control Cam

- (1) When reinstalling the rotary encoder, adjust its position so as to fit the triangle marks each other and push it deep untill it is locked by the pawls.
- (2) When reinstalling the change lever, set it so as to make its positioning hole correspond to the hole of the main deck assy.
- (3) When re-engaging the control cam, lower the capstan brake assy while setting it so as to make its positioning hole correspond to the hole of the main deck assy.




Fig. 2-6-2




Fig. 2-6-3

### 2.6.4 Slide Plate

- (1) Lower both the main brake assies (supply and take-up) untill they touch the edge of the main deck assy while reinstalling the slide plate so as to make the respective positioning holes of the main brake assies correspond to the holes on the main deck assy.




Fig.2-6-4

### 2.6.5 Control Plate

- (1) Reinstall the control plate so as to set the two positioning holes of it on the holes on the main deck assy respectively and to set the positioning hole of the take-up lever on the hole of the main deck at the same time. When adjusting the hole position of the take-up lever, use a pair of tweezers to hold and move it since it is pulled by a tension spring.
- (2) After reinstalling the control plate, fix it with the slit washer, control bracket-1 and -2.




Fig. 2-6-5



## 2.7 TAPE INTERCHANGEABILITY ADJUSTMENT

- NOTE :**
- This adjustment is extremely important. However, it is normally not required during routine service. Perform only after replacing major components(A/C head,upper/lower drum assy,pole base assy,etc).
  - Before using costly alignment tape,use a spare tape and confirm correct operation of the tape transport.

### 2.7.1 Tape pattern

- (1) Connect the oscilloscope to TP6(PB FM) on the PRE/REC board.Use TP11(D.FF) on the PRE/REC board as a trigger.
- (2) Playback the SP stairstep portion of the alignment tape [MHPE].Confirm that the FM waveform appears as indicated in Fig.2-7-1.
- (3) Set the manual tracking position by pressing the **///** button on the remote controller or TV PROG **-** and **+** buttons simultaneously.
- (4) Operate the tracking adjustment (press the TV PROG buttons during playback) and set for maximum playback FM waveform.
- (5) By operating the TV PROG button,vary the FM waveform from maximum to minimum and vice versa to confirm that the waveform varies nearly in a flat shape as shown in Fig.2-7-1.
- (6) When the FM waveform does not remain flat during this process,first slightly loosen the set screw located at the bottom of the guide roller.Using the supply and take-up guide rollers (refer to Fig.2-7-2) to obtain the correct waveform as indicated in Fig.2-7-3.
- (7) By pressing the TV PROG buttons several times,vary the FM waveform output from maximum to minimum (and vice versa) gradually,and confirm that the variation proceeds in flat shape, as shown in Fig.2-7-3.
- (8) Next playback the LP stairstep portion of the alignment tape [MHPE-L] and adjust the tracking control from maximum to minimum the FM waveform,confirm that FM waveform variation is always flat.
- (9) Record the signal and play it back in both of the SP and LP mode,confirm that the FM waveform is flat in both mode.
- (10) After adjustments,tighten the set screw of the guide rollers.
- (11) Confirm that the tape wrinkling does not occur at the roller upper or lower limits as indicated in Fig.2-7-4.




Fig. 2-7-1




Fig. 2-7-2




Fig. 2-7-3




Fig. 2-7-4

## 2.7.2 A/C head height & azimuth

**NOTE :**

- Temporarily set A/C head height as indicated in Fig. 2-5-4.
- Use spare tape to check the transport and confirm the tape is not scratched or damaged.

### 1. Tilt

- (1) Use spare tape and set for playback.
- (2) Turn screw (3) clockwise to where the tape curls just slightly at the TU guide pole bottom flange as shown in Fig. 2-7-5.
- (3) Then slowly turn screw (3) counterclockwise to where the curling ceases.

### 2. Height

- (1) Connect CH-1 of a dual trace oscilloscope to Audio Out.
- (2) Connect CH-2 to TP401 (CTL PULSE) of the Main board assy and use the ALT mode.
- (3) Playback the SP stairstep portion of the alignment tape [MHPE].
- (4) Adjust screws (1), (2) and (3) for maximum audio output and control pulse level.

### 3. Azimuth

- (1) Connect the oscilloscope to Audio Out.
- (2) Playback the SP stairstep portion of the alignment tape [MHPE].
- (3) Adjust screw (2) so that the audio output is both maximum and with minimum fluctuation.




Fig. 2-7-5

### 2.7.3 A/C head phase(X-value)

- (1) Connect the oscilloscope to TP6(PB FM) on the PRE/REC board. Use TP11(D.FF) on the PRE/REC board as a trigger.
- (2) Playback the SP stairstep portion of the alignment tape [MHPE].
- (3) Set the neutral manual tracking position by pressing the **///** button on the remote controller or TV PROG **^-** and **^+** buttons simultaneously.
- (4) If adjustment is required, slightly loosen screws (4) and (5). Set A/C head positioning tool on the A/C head adjusting boss as indicated in Fig.2-7-6.
- (5) Turn the tool first to position the A/C head fully toward the capstan. Then gradually return it toward the drum and stop at the position of maximum FM waveform output level as shown in Fig.2-7-7.
- (6) Tighten screw (5). Remove the tool and tighten screw (4).
- (7) Eject the SP alignment tape [MHPE] and then re-insert the LP alignment tape [MHPE-L].
- (8) Playback the LP stairstep portion of the alignment tape [MHPE-L].
- (9) Set the neutral manual tracking position by pressing the **///** button on the remote controller or TV PROG **^-** and **^+** buttons simultaneously.
- (10) Confirm maximum playback FM waveform output level as shown in Fig.2-7-7.
- (11) If not maximum, slightly loosen the screws (4) and (5). Use the tool and adjust the head position for the nearest maximum point. Then tighten screws (4) and (5).




Fig. 2-7-6




Fig. 2-7-7

### 2.7.4 LP mode auto tracking

**NOTE :** Set VCR to the mode A by remote controller.

- (1) Playback the LP stairstep portion of the alignment tape [MHPE-L].
- (2) Confirm that the Automatic tracking indication[AT] stops flashing and remains on.
- (3) Press the 'D' button on the presetting unit[PTU94008] to turn off the Automatic tracking indication[AT].
- (4) Press the 'D' button again to change the mode to the LP interchangeability adjustment mode and confirm that Automatic tracking indication[AT] stops flashing and goes off.
- (5) If the alignment tape ejects automatically, repeat the A/C head phase adjustment(X-value).

### 2.7.5 Tension pole position

- (1) Set for playback mode using MECHANISM SERVICE MODE(See SECTION 1 DISASSEMBLY).
- (2) Slightly loosen the screw (A).
- (3) Turn the adjust pin so that the tension arm assy does not touch  $\phi 2.5$  pole on the outside.
- (4) Tighten the screw (A).
- (5) After adjustment, use the back tension cassette gauge and set for the playback mode.
- (6) Confirm reading of 35 to 48 g $\cdot$ cm.




Fig. 2-7-8

### 2.7.6 Take-up torque

- (1) Use the back tension cassette gauge and set for the playback mode.
- (2) Confirm reading of 60 to 100 g $\cdot$ cm.

## SECTION 3 ELECTRICAL ADJUSTMENT




### 3.1 PRECAUTION

Electrical adjustment are required after replacing circuit components and certain mechanical parts. It is important to perform these adjustments only after all repairs and replacements have been completed. Also do not attempt these adjustments unless the proper equipments is available.

#### 3.1.1 Required test equipment

- ① Colour television or monitor
- ② Oscilloscope: wide-band,dual-trace,triggered delayed sweep
- ③ Frequency counter
- ④ Digital voltmeter
- ⑤ Signal generator: RF/IF sweep/maker
- ⑥ Signal generator: PAL colour bar, staircase
- ⑦ Recording tape
- ⑧ Digit-key remote controller(provided)

#### 3.1.2 Required adjustment tools

Alignment tape (SP,stairstep) MHPE	Alignment tape (SP,colour bar) MHVE-2
	
Presetting unit PTU94008	
	

#### 3.1.3 Colour bar signal,colour bar pattern

##### ● Colour bar signal




Fig.3-1-1 Colour bar signal waveform

##### ● Colour bar pattern

White	Yellow	Cyan	Green	Magenta	Red	Blue
(75%)						
V	U	White 100%		Black		

Fig.3-1-2 Colour bar pattern

### 3.2 SERVO CIRCUIT

**Notes:** • Unless otherwise specified, all measurement point and adjustment parts are located on the MAIN BOARD.

- Set VCR to the mode A by remote controller.
- Use only buttons "E" and "F", depressing other buttons during adjustment may cause adjustment errors.

#### 1. PB switching point

Signal	• Alignment tape [MHPE], Stairstep
Mode	• PB, Automatic tracking OFF
Equipment	• Oscilloscope
Measurement point	• JA501- pin 19 (VIDEO OUT)
Trigger slope (-)	• TP11(DRUM FF) , [PRE/REC BOARD]
Adjustment tool	• Presetting unit [PTU94008]
Specification	• $6.5 \pm 0.5H$

- (1) Connect an oscilloscope to JA501- pin 19 (VIDEO OUT) and external trigger from TP11 (negative slope).
- (2) Playback the stairstep signal of the alignment tape.
- (3) Set the tracking control to the centre position by simultaneously pressing the TV PROG "+" and "-" buttons or pressing the **///** button on the remote controller.
- (4) Adjust by pressing "E" or "F" buttons of the presetting unit to position the trigger point  $6.5 \pm 0.5 H$  from V.sync.
- (5) Depress the STOP button.

#### Alternate method

- (1) Playback the stairstep signal of the alignment tape.
- (2) Press the "O" button of the presetting unit.
- (3) Confirm that VCR mode becomes STOP mode.




Fig.3-2-1 Presetting unit




Fig.3-2-2 PB switching point

#### 2. Slow tracking preset

Signal	• Tuner or colour bar
Mode	• SP/LP, REC → PB(SLOW)
Equipment	• TV-Monitor
Adjustment tool	• Presetting unit [PTU94008]
Specification	• Minimum noise

**Note :** Set VCR to the mode A by remote controller. Use only buttons "B" and "C", depressing other buttons during adjustment may cause adjustment errors.

- (1) Record a colour bar signal in the SP mode.
- (2) Playback recorded signal on the FWD slow mode.
- (3) Observe the display on the TV monitor and adjust for optimum noise condition (best tracking) by depressing "B" or "C" buttons of the presetting unit.
- (4) Depress the STOP button.
- (5) Confirm that the bar noise is not visible on the TV monitor in the slow mode.
- (6) Repeat steps (2) to (5) in the LP mode.




Fig.3-2-3 Presetting unit

### 3.3 VIDEO CIRCUIT

- Notes:**
- Unless otherwise specified, all measurement point and adjustment parts are located on the MAIN BOARD.
  - VIDEO circuit adjustments is performed by the EVR system using presetting unit and numeric-key remote controller.
  - Set VCR to the mode A by remote controller.




Fig.3-3-1 Presetting unit




Fig.3-3-2 EVR mode

#### 3.3.1 EE Y LEVEL

Signal	• Colour bar
Mode	• EE
Equipment	• Oscilloscope
Measurement point	• JA501- pin 19(VIDEO OUT) [TERMINAL BOARD]
Adjustment tool	• Presetting unit [PTU94008], • Numeric-key remote controller
EVR mode	• A : 11
Specification	• $1.00 \pm 0.05V_{p-p}$ (terminated)

- 1) Connect an oscilloscope to JA501- pin 19(VIDEO OUT).
- 2) Set EVR mode by pressing "K" button of the presetting unit more than 2 seconds.
- 3) Set "A : 11" pressing 1 numeric key twice of the remote controller.
- 4) Adjust TV PROG "-" or "+" button for  $1.00 \pm 0.05V_{p-p}$ .
- 5) Set normal VCR mode by pressing "K" button of the pre-setting unit again so adjustment data is memorized.




Fig. 3-3-3 EE Y level

#### 3.3.2 WHITE/DARK CLIP

Signal	• Colour bar
Mode	• EE
Equipment	• Oscilloscope
Measurement point	• IC201 pin 13
Adjustment tool	• Presetting unit [PTU94008], • Numeric-key remote controller
EVR mode	• A : 14
Specification	• WHITE CLIP : $90 \pm 4\%$ • DARK CLIP : $45 \pm 8\%$

- 1) Connect an oscilloscope to IC201 pin 13.
- 2) Set EVR mode by pressing "K" button of the presetting unit more than 2 seconds.
- 3) Set "A : 14" pressing 1 and 4 numeric key of the remote controller.
- 4) Adjust TV PROG "-" or "+" button for  $90 \pm 4\%$  white clip and  $45 \pm 8\%$  dark clip as shown in Fig.3-3-4.
- 5) Set normal VCR mode by pressing "K" button of the pre-setting unit again so adjustment data is memorized.




Fig.3-3-4 White/dark clip

### 3.3.3 CARRIER

Signal	• No signal
Mode	• EE
Equipment	• Frequency counter
Measurement point	• IC201 pin 19
Adjustment tool	• Presetting unit [PTU94008], • Numeric-key remote controller
EVR mode	• A : 12
Specification	• 3.80MHz $\pm$ 0.04MHz

- (1) Connect an oscilloscope to IC201 pin 19.
- (2) Set EVR mode by pressing "K" button of the presetting unit more than 2 seconds.
- (3) Set "A : 12" pressing 1 and 2 numeric key of the remote controller.
- (4) Adjust TV PROG "-" or "+" button for 3.80MHz  $\pm$  0.04MHz.
- (5) Set normal VCR mode by pressing "K" button of the pre-setting unit again so adjustment data is memorized.

### 3.3.4 DEVIATION

Signal	• Colour bar
Mode	• REC then PB
Equipment	• Oscilloscope
Measurement point	• JA501- pin 19 (VIDEO OUT)
Adjustment tool	• Presetting unit [PTU94008], • Numeric-key remote controller
EVR mode	• A : 13
Specification	• 1.00 $\pm$ 0.05Vp-p (terminated)

- (1) Connect an oscilloscope to JA501- pin 19(VIDEO OUT).
- (2) Set EVR mode by pressing "K" button of the presetting unit more than 2 seconds.
- (3) Set "A : 13" pressing 1 and 3 numeric key of the remote controller.
- (4) Record and playback a colour bar signal.
- (5) Before recording, Adjust TV PROG "-" or "+" button so that Y level becomes 1.00  $\pm$  0.05Vp-p during playback as shown in Fig.3-3-5.
- (6) Set normal VCR mode by pressing "K" button of the pre-setting unit again so adjustment data is memorized.




Fig.3-3-5 Deviation

### 3.3.5 REC COLOUR LEVEL

Signal	• Colour bar
Mode	• REC
Equipment	• Oscilloscope
Measurement point	• IC201 pin 33
Adjustment tool	• Presetting unit [PTU94008], • Numeric-key remote controller
EVR mode	• A : 2
Specification	• 250 $\pm$ 15mVp-p

- (1) Connect an oscilloscope to IC201 pin 33.
- (2) Set EVR mode by pressing "K" button of the presetting unit more than 2 seconds.
- (3) Set "A : 2" pressing 2 numeric key of the remote controller.
- (4) Adjust TV PROG "-" or "+" button for 250  $\pm$  15mVp-p.
- (5) Set normal VCR mode by pressing "K" button of the pre-setting unit again so adjustment data is memorized.




Fig.3-3-6 REC colour level

### 3.3.6 PB Y LEVEL

Signal	• Colour bar
Mode	• REC then PB
Equipment	• Oscilloscope
Measurement point	• JA 501- pin 19 (VIDEO OUT)
Adjustment tool	• Presetting unit [PTU94008], • Numeric-key remote controller
EVR mode	• A : 11
Specification	• 1.00 $\pm$ 0.05Vp-p (terminated)

- (1) Connect an oscilloscope to JA501- pin 19(VIDEO OUT).
- (2) Set EVR mode by pressing "K" button of the presetting unit more than 2 seconds.
- (3) Set "A : 11" pressing 1 numeric key twice of the remote controller.
- (4) Record and playback a colour bar signal.
- (5) Adjust TV PROG "-" or "+" button for 1.00  $\pm$  0.05Vp-p as shown in Fig.3-3-7.
- (6) Set normal VCR mode by pressing "K" button of the pre-setting unit again so adjustment data is memorized.






Fig.3-3-7 PB Y level

### 3.4 SYSCON CIRCUIT

- Notes:**
- Unless otherwise specified, all measurement point and adjustment parts are located on the MAIN BOARD.
  - When perform this adjustment, remove the MECHANISM assy.

#### 3.4.1 Timer clock

Signal	• No signal
Mode	• EE
Equipment	• Frequency counter
Measurement point	• IC601 pin 64
Adjustment part	• C601 (TIMER CLOCK)
Specification	• $1024.008 \pm 0.001$ Hz [ $976.5549 \pm 0.0010$ usec]

- (1) Connect the frequency counter to IC601 pin 64 and GND.
- (2) Connect the short wire between IC601 pin 33 and IC601 pin 63.
- (3) Short the leads of capacitor C604 once in order to reset IC601.
- (4) Disconnect the short wire then connect it again quickly.
- (5) Adjust C601 for  $1024.008 \pm 0.001$  Hz.  
( $976.5549 \pm 0.0010$  usec)

### 3.5 TUNER CIRCUIT

**Note:** Unless otherwise specified, all measurement points and adjustment parts are located on the IF UNIT.

#### 3.5.1 RF AGC

Signal	• TV broadcasting
Mode	• Tuner
Equipment	• TV monitor
Measurement point	• IF UNIT
Adjustment part	• IF VR
Specification	• Minimum noise


**Note:** Adjust IF VR (RF AGC) to correct for excess noise in the picture or when streaks cross interference occurs due to strong electrical fields.

- (1) Adjust IF VR to minimize noise or streaks on the TV screen.
- (2) Adjust for noisy picture with strong signal. Then adjust until noise just disappears. Select other channels to confirm proper pick-up of channels.

## SECTION 4 CHARTS AND DIAGRAMS

### SCHEMATIC DIAGRAM NOTES

#### Safety precautions

The Components identified by the symbol  are critical for safety. For continued safety, replace safety critical components only with manufactures recommended parts.

#### 1. Schematic diagram values


Unless otherwise specified.

- 1) All resistance values are in ohms, 1/6 W, 1/8 W (refer to parts list).  
Chip resistors are 1/16 W.  
K: K $\Omega$  (1000 $\Omega$ ), M: M $\Omega$  (1000K $\Omega$ )
- 2) All capacitance values are in  $\mu$ F, (P: PF).
- 3) All inductance values in  $\mu$ H, (m: mH).
- 4) All diodes are 1SS133 or MA165, (refer to parts list).

#### 2. Indications


AUX : Active only at high.

$\overline{\text{AUX}}$  : Active only at low.




#### Digital transistor :

The digital transistor includes built in resistors. It features small size and high reliability.



#### 3. Interpreting Connector indications



#### 4. Voltage measurement

##### 1) Video circuits

REC: Colour bar signal in SP mode, normal VHS mode.

PB : Alignment tape, colour bar SP mode, normal VHS mode.

— : Unmeasurable or unnecessary to measure.

##### 2) Audio circuits

REC: 1KHz, -8 dBs sine wave signal in SP mode, Normal VHS mode.


PB : REC then playback it.

##### 3) Movie Camera circuits

Measured using a correctly illuminated grey scale or colour bar test charts in the E-E mode.

##### 4) Indication on schematic diagram


Voltage Indications for REC and PB modes on the schematic diagram are as shown below.




**Note:** If do not indicate for voltage measurement on the schematic diagram, refer to the voltage charts.

## 5. Waveform measurement

- 1) Video circuits  
REC: Colour bar signal in SP mode, normal VHS mode.  
PB : Alignment tape, colour bar SP mode, normal VHS mode.
- 2) Audio circuits  
REC: 1KHz, -8 dBs sine wave signal in SP mode, normal VHS mode.  
PB : REC then playback it.
- 3) Movie Camera circuits  
Measured using a correctly illuminated grey scale or colour bar test charts in the E-E mode.
- 4) Indication on schematic diagram  
Waveform indications on the schematic diagram are as shown below.



## 5) Waveform indications



## 6. Signal path Symbols

The arrows indicate the signal path as follows.

- Playback signal path
- Playback and recording signal path
- Recording signal path (including E-E signal path)
- Y signal path
- Colour (Chroma) signal path
- R or R-Y signal path
- B or B-Y signal path
- Capstan servo path
- Drum servo path
- Reel servo path

## CIRCUIT BOARD NOTES

### 1. Colour indications

- 1) Foil side :  
Foil side patterns are indicated at GREY shading.
- 2) Component side :  
Component side patterns are indicated at RED shading.

### 2. Foil and Component sides

- 1) Foil side (B side) :  
Parts on the foil side seen from foil face (pattern face) are indicated.
- 2) Component side (A side) :  
Parts on the component side seen from component face (parts face) are indicated.

### 3. Parts location guides

Parts location are indicated by guide scale on the circuit board.

#### 1) Signal pattern :

REF No.	LOCATION
TRANSISTOR	
Q101	2A

Reference number: Q101

Horizontal "A" zone: 2A

Vertical "2" zone: 2A

#### 2) Double pattern :

REF No.	LOCATION
IC	
IC101	B-5C

B: Foil side (A: Component side)


Horizontal "C" zone: B-5C

Vertical "5" zone: B-5C


### Notes:

- 1) For general information in service manual, please refer to the Service Manual of GENERAL INFORMATION Edition 4 No. 82054D (January 1994).
- 2) For repairing SMC (Surface Mounted Components), please refer to the VIDEO SERVICE GUIDE No. VTS81001.


# 4.1 BOARD INTERCONNECTIONS




## 5




# 4.3 SYSCON/SERVO BLOCK DIAGRAM



# 4.4 TUNER SCHEMATIC DIAGRAM



# 4.5 AUDIO SCHEMATIC DIAGRAM



NOTES: 1 For AUDIO waveforms, please refer to page4-21.  
2 Mark(\*) is not used.


03 MAIN(AUDIO)




#### 4.6 VIDEO SCHEMATIC DIAGRAM

NOTES : 1 Mark (\*) is not used.  
: 2 For VIDEO waveforms,  
please refer to page 4-21.  
: 3 COMPARISON CHART OF  
MODELS & MARKS (#)

REF. NO	MODELS	
	HR-J425E	HR-J425A
L282	SHORT	USED
L283	SHORT	USED



# 4.7 SERVO SCHEMATIC DIAGRAM



A

B

C

D

4-15

4-16


E

F

G

H


#### 4.8 SYSTEM CONTROL SCHEMATIC DIAGRAM



# 4.9 SWITCHING REGULATOR SCHEMATIC DIAGRAM

NOTES : 1 Mark(\*) is not used.  
2 COMPARISON CHART OF MODELS & MARKS (#)
















REF. NO.	MODELS	
	HR-J425E	HR-J425EG
C801	0.068	0.033
C802	USED	OPEN
C814	USED	OPEN













# 4.10 MAIN AND A/C HEAD CIRCUIT BOARDS

## WAVEFORMS

### —VIDEO—



### —AUDIO—




## LEADLESS COMPONENT PARTS LOCATION GUIDE <MAIN PWB>

REF. No.	LOCATION	REF. No.	LOCATION	REF. No.	LOCATION	REF. No.	LOCATION	REF. No.	LOCATION	REF. No.	LOCATION	MAIN COMPONENT	REF. No.	LOCATION	
IC												PARTS LOCATION		D807	2K
IC1	7M	R36	8N	R356	19F	R653	9D	C15	9L	C377	18D	GUIDE	D808	4K	
TRANSISTOR												REF. No. LOCATION		D809	4K
Q1	9N	R39	6K	R359	21E	R656	7G	C20	10L	C382	20D	IC	D810	2I	
Q2	9M	R40	6K	R360	18F	R657	7F	C21	10L	C384	21D	IC1	D811	3I	
Q3	10L	R41	9L	R361	21E	R658	8G	C24	6M	C387	19H	IC2	D851	2G	
Q4	11N	R42	9L	R363	18H	R660	18C	C34	8M	C388	19J	IC3	D852	4F	
Q5	10L	R43	15O	R364	20G	R661	17D	C36	7O	C389	20I	IC201	D853	3F	
Q6	6N	R44	10O	R365	19G	R662	10B	C37	7M	C390	19F	IC202	D854	2G	
Q7	8M	R45	12O	R366	19G	R663	9B	C38	7N	C391	19G	IC301	D855	3G	
Q8	6M	R46	9O	R367	18G	R665	12D	C39	7M	C392	19H	IC401	D856	4G	
Q201	16H	R47	10N	R368	21G	R666	8H	C201	17I	C401	7L	IC601	D858	1E	
Q202	15H	R48	10O	R369	18G	R667	7F	C202	17H	C403	9K	IC602	D859	3O	
Q203	13J	R49	10N	R370	20H	R668	18B	C203	17I	C404	9K	IC603	D862	1O	
Q204	14K	R50	10O	R371	19H	R669	7E	C204	16G	C405	10K	IC604	D863	1C	
Q205	14H	R51	6P	R372	19H	R670	7E	C205	16I	C406	8K	IC607	D864	3C	
Q206	17G	R52	6P	R373	19H	R672	14B	C208	16H	C414	9K	IC751	D865	3E	
Q207	15N	R53	7O	R374	19E	R674	8E	C209	16I	C415	7J	TRANSISTOR	D866	2F	
Q208	16N	R54	6O	R375	21E	R675	10D	C210	16I	C416	7J	Q1	D867	2F	
Q209	16H	R55	6O	R376	19D	R676	10E	C211	15H	C417	7J	Q2	D868	2F	
Q210	20O	R56	6O	R378	20I	R677	10E	C212	15H	C418	7I	Q3	D869	1H	
Q211	16G	R57	6O	R379	19J	R678	2B	C213	15G	C419	7I	Q4	D870	1G	
Q212	17M	R58	6P	R380	20I	R679	2B	C214	15H	C501	15P	Q5	D901	19M	
Q301	14M	R59	6O	R381	18I	R680	7B	C215	15I	C502	15P	Q6	D903	21N	
Q302	14M	R201	17I	R382	19J	R681	7B	C217	17H	C503	15P	Q7	D904	22O	
Q303	16M	R202	17H	R384	19I	R682	6B	C218	12H	C504	16O	Q8	D905	22O	
Q304	15L	R203	16G	R385	19I	R683	4E	C219	13I	C505	15O	Q202	15H	CONNECTOR	
Q305	16L	R204	16H	R386	19I	R684	18E	C220	12I	C506	16P	CN1	8L		
Q351	19E	R205	15H	R387	19I	R685	15B	C221	13I	C602	8F	CN2	11N		
Q352	19H	R206	15H	R388	19I	R686	11D	C222	13J	C603	9E	CN201	14L		
Q353	19H	R207	15H	R402	8K	R687	8B	C223	12J	C605	11D	CN202	13L		
Q354	19H	R208	16H	R404	10L	R688	19E	C224	14I	C606	10G	Q207	15N		
Q355	18D	R209	15G	R405	10L	R692	17D	C225	15H	C607	11I	Q208	16N		
Q356	20I	R210	15I	R406	8J	R693	13F	C227	14H	C608	12E	Q210	20O		
Q357	19H	R211	15I	R407	8J	R696	11E	C229	13G	C609	9H	Q213	17M		
Q358	18J	R212	13I	R408	8I	R697	11D	C231	14I	C610	11H	Q301	14M		
Q359	19J	R213	12I	R409	8G	R698	9B	C232	13H	C611	11H	Q302	14M		
Q401	17I	R214	12J	R410	9J	R700	1B	C233	13I	C612	10H	Q303	16M		
Q503	17O	R215	12J	R411	8G	R701	1B	C234	13I	C613	8F	Q401	17I		
Q601	7E	R216	14H	R412	7K	R702	5C	C238	16J	C614	10B	Q501	16O		
Q602	12E	R217	13G	R413	7J	R703	5B	C240	16J	C615	10B	Q502	12P		
Q603	12E	R218	12J	R414	8K	R704	5B	C242	15J	C616	10B	Q601	7E		
Q607	11F	R219	13G	R416	8I	R705	19C	C243	15K	C620	14B	Q602	12E		
Q608	7D	R220	13G	R504	12P	R706	20C	C244	15J	C622	4E	Q604	4E		
Q609	11E	R221	15J	R506	13P	R707	20C	C245	15K	C623	18D	Q605	18E		
Q610	12M	R222	14J	R511	16P	R709	7F	C246	15J	C624	11G	Q607	11F		
Q611	9D	R223	15K	R512	16P	R751	17C	C248	14J	C625	13C	Q608	7D		
Q854	2D	R224	14J	R601	8F	R752	16C	C249	14K	C626	13B	Q609	11E		
Q857	3C	R226	13K	R602	8F	R753	18C	C250	14J	C627	13C	Q611	9D		
Q901	21I	R227	17I	R603	8F	R859	2C	C253	15I	C631	7G	Q801	2J		
Q904	21N	R228	17I	R605	8E	R860	1D	C254	17F	C632	2A	Q802	3K		
Q905	22N	R229	17G	R606	8E	R861	1D	C255	17F	C633	1B	Q851	1E		
Q906	21O	R230	17F	R607	8D	R865	3C	C256	17F	C634	21D	Q852	1D		
Q907	21M	R231	17F	R608	8E	R866	3D	C257	16F	C635	19C	Q853	3D		
Q908	21M	R232	17F	R609	8D	R867	3B	C258	16G	C636	6L	Q854	2D		
Q909	21J	R233	16F	R611	12F	R868	3B	C260	16G	C637	1B	Q855	4C		
DIODE												ADJUSTMENT		C601	8E
D351	19J	R234	16F	R612	11F	R872	3D	C261	16F	C639	11L	Q856	3C		
RESISTOR												TEST POINT		TP33	6L
R1	6M	R235	15F	R613	9E	R874	4F	C263	16F	C640	11F	Q857	3C		
R2	6M	R237	14O	R614	9E	R875	2D	C264	15F	C641	4B	Q858	4H		
R6	8M	R238	15N	R615	10D	R901	18L	C265	15F	C643	9H	Q859	4D		
R8	8M	R240	15N	R616	10D	R902	19L	C266	15F	C644	7G	Q901	21I		
R9	8N	R241	17N	R617	10E	R903	19M	C269	16M	C645	7H	Q902	19L		
R10	8N	R245	14L	R620	11E	R904	18M	C271	14L	C751	17C	Q903	19M		
R11	8M	R246	16H	R621	11E	R905	12O	C272	17G	C752	17C	Q904	21N		
R12	8M	R247	17J	R622	10B	R907	22N	C275	14H	C754	17C	Q905	22N		
R13	9M	R248	12L	R624	12F	R908	22N	C276	17G	C755	18B	Q906	21O		
R14	7L	R249	14L	R625	11E	R909	22M	C277	13L	C757	17C	Q909	21J		
R15	8L	R250	15H	R626	9G	R910	21N	C278	16F	C902	20L	DIODE			
R16	7L	R251	16J	R627	12D	R913	21N	C279	15I	C904	19K	D1	7K		
R17	6M	R252	17M	R628	9D	R914	21M	C280	12L	C905	22N	D202	14K		
R18	10L	R253	14I	R629	11G	R915	21M	C281	16F	C908	19K	D203	14L		
R19	9M	R254	14I	R630	10I	R916	21M	C302	13M	C909	21O	D204	13K		
R20	10L	R271	14I	R631	9E	R917	20P	C309	16L	C950	19K	D205	15E		
R21	9N	R272	14H	R632	11G	R918	21P	C312	16L	C951	21L	D208	12H		
R22	7N	R301	13N	R633	11G	R919	21P	C316	14M	C952	21L	D601	7F		
R23	9M	R303	12M	R635	10G	R920	19O	C352	18G	C953	21K	D602	4B		
R24	6N	R304	16M	R636	12E	R930	22K	C353	21E	C954	19O	D603	7H		
R26	11N	R305	15M	R637	12F	R931	22J	C356	20F	C955	19O	D604	4B		
R27	6N	R306	16N	R638	10G	R932	21J	C358	19G	FERRITE BEADS		D605	10I		
R28	10L	R307	16L	R639	11H	R933	22K	C359	20G	L501	15P	D606	10I		
R29	10L	R308	16K	R640	11H	R934	22J	C360	18F	L502	16P	D607	11I		
R30	10M	R309	15L	R641	11H	R935	21J	C361	20F	L503	16P	D609	10D		
R31	7N	R310	15L	R642	10H	R936	21J	C362	20E	L505	15O	D610	11E		
R32	6M	R311	16L	R643	11F	CAPACITOR		C365	20H			D612	2B		
R33	8L	R312	15L	R646	12N	C2	6M	C367	21G			D613	2C		
R34	8L	R352	20E	R647	8I	C3	7N	C368	21G			D801	4L		
R35	9M	R353	20F	R648	11G	C5	7N	C371	20D			D802	4L		
		R354	20F	R649	8G	C6	7N	C372	21G			D803	3L		
		R355	19F	R650	20B	C13	6L	C375	20E			D804	2I		






#### 4.11 TERMINAL & MAIN (TERMINAL) SCHEMATIC DIAGRAMS



# 4.12 TERMINAL CIRCUIT BOARD










# 4.13 DISPLAY/SW & SW/JACK SCHEMATIC DIAGRAMS (for HR-J425E)

29 DISPLAY/SW

## - FDP GRID ASSIGNMENT -




36 SW/JACK



NOTE: Mark 1 is not used.




# 4.15 DISPLAY & SW/JACK SCHEMATIC DIAGRAMS (for HR-J425EG)




4.16 DISPLAY, SW/JACK, REC SAFETY AND CASSETTE SW CIRCUIT BOARDS (for HR-J425EG)


— REC SAFETY —




— CASSETTE SW —



— SW/JACK —




— DISPLAY —




MAIN COMPONENT PARTS LOCATION GUIDE <DISPLAY/SW/JACK>

REF.No.	LOCATION	REF.No.	LOCATION	REF.No.	LOCATION
IC		D12	9A	CONNECTOR	
IC1	2A	D13	4A	CN1	1C
IC2	5A	D14	4A	CN2	10A
DIODE		D19	9A	TEST POINT	
D1	9A	D20	8A	TP1	2B
D2	2A	D24	7A	TP2	2C
D4	5A	D25	9A		
D7	6A	D27	7A		
D8	6B	D29	8A		
D11	1C	D33	1B		

# 4.17 PRE/REC SCHEMATIC DIAGRAM




# 4.18 PRE/REC CIRCUIT BOARD




## WAVEFORMS — PRE/REC —

WF1 IC101-34



REC0.2Vp-p  
10mV/5msec/DIV

WF2 CN1-5




REC1.7Vp-p  
50mV/5msec/DIV

WF3 TP6  
PB FM



PB0.36Vp-p  
10mV/5msec/DIV

WF4 TP11  
D,FF



REC/PB5.0Vp-p  
0.2V/10msec/DIV

## LEADLESS COMPONENT PARTS LOCATION GUIDE <PRE/REC PWB>

REF No.	LOCATION	REF No.	LOCATION	REF No.	LOCATION	REF No.	LOCATION	REF No.	LOCATION	REF No.	LOCATION	REF No.	LOCATION
IC101	6C	R1	5C	R33	3D	R210	8B	C39	1D	C117	7C	IC101	6C
TRANSISTOR		R2	5C	R34	3D	R212	9B	C40	2C	C118	7D	TRANSISTOR	
Q1	5C	R3	5B	R35	3C	R213	8B	C41	1B	C119	5D	Q1	5C
Q2	2D	R4	5C	R36	2C	C1	5B	C42	2C	C120	6D	Q2	2D
Q3	1C	R5	5C	R37	3B	C2	5C	C43	2D	C122	5B	Q3	1C
Q4	2B	R6	5C	R38	1B	C3	5D	C45	2C	C201	9C	Q4	2B
Q5	3C	R11	6D	R101	5C	C6	4D	C46	2D	C202	9C	Q6	3D
Q6	3D	R13	2D	R102	7D	C7	4D	C47	1B	C203	8B	Q8	2C
Q7	2D	R14	2D	R103	5C	C8	3C	C48	1C	C204	8B	Q9	1B
Q8	2C	R15	2C	R106	7D	C9	2D	C101	5D	C205	8B	Q10	2C
Q9	1B	R16	2D	R107	5C	C10	1D	C103	7D	C206	8B		
Q10	2C	R17	2C	R108	5C	C11	1D	C104	7D	C207	9C		
Q12	3B	R18	1C	R109	7C	C12	2C	C105	5C	C208	8B		
Q13	3B	R19	1D	R110	7D	C13	1C	C106	5C	C210	8C		
Q14	1B	R20	2C	R111	7C	C14	1C	C107	5B	C212	9C		
Q201	9B	R21	1C	R112	7C	C15	2B	C108	5C	C213	9D		
Q202	9B	R22	1C	R116	5C	C32	4C	C109	5C	C214	8D		
Q203	9C	R23	1C	R201	9C	C33	3D	C110	6C	C215	9D		
Q204	9D	R24	1B	R202	9B	C34	3C	C111	5C	C216	9C		
DIODE		R26	3B	R203	9B	C35	3C	C112	7D				
D103	4C	R27	3B	R204	9C	C36	3C	C113	6B				
		R31	3D	R205	8D	C37	2C	C114	7D				
		R32	3C	R206	9D	C38	2D	C115	7D				
				R207	9C			C116	6C				


## MAIN COMPONENT PARTS LOCATION GUIDE

REF No.	LOCATION	REF No.	LOCATION	REF No.	LOCATION	REF No.	LOCATION
IC		IC		IC		IC	
IC101	6C	IC101	6C	IC101	6C	IC101	6C
TRANSISTOR		TRANSISTOR		TRANSISTOR		TRANSISTOR	
Q1	5C	Q1	5C	Q1	5C	Q1	5C
Q2	2D	Q2	2D	Q2	2D	Q2	2D
Q3	1C	Q3	1C	Q3	1C	Q3	1C
Q4	2B	Q4	2B	Q4	2B	Q4	2B
Q6	3D	Q6	3D	Q6	3D	Q6	3D
Q8	2C	Q8	2C	Q8	2C	Q8	2C
Q9	1B	Q9	1B	Q9	1B	Q9	1B
Q10	2C	Q10	2C	Q10	2C	Q10	2C
DIODE		DIODE		DIODE		DIODE	
D1	5B	D1	5B	D1	5B	D1	5B
D101	4D	D101	4D	D101	4D	D101	4D
D103	4C	D103	4C	D103	4C	D103	4C
CONNECTOR		CONNECTOR		CONNECTOR		CONNECTOR	
CN1	6B	CN1	6B	CN1	6B	CN1	6B
CN2	6A	CN2	6A	CN2	6A	CN2	6A
CN3	4A	CN3	4A	CN3	4A	CN3	4A
TEST POINT		TEST POINT		TEST POINT		TEST POINT	
TP6	2D	TP6	2D	TP6	2D	TP6	2D
TP11	3D	TP11	3D	TP11	3D	TP11	3D




4.19 VPS SCHEMATIC DIAGRAM

— for HR-J425EG only —



4.20 REMOTE CONTROL SCHEMATIC DIAGRAM

- NOTE:
1. All parts shown in this schematic are critical for safety.
  2. This schematic is only for reference.  
Avoid replacing individual parts.  
Replace the entire unit only.




## SECTION 5 PARTS LIST

### SAFETY PRECAUTION

Parts identified by the  $\Delta$  symbol are critical for safety. Replace only with specified part numbers.

#### 5.1 PACKING AND ACCESSORY ASSEMBLY <M1>



# $\Delta$  REF No. PART No. PART NAME, DESCRIPTION  
\*\*\*\*\*

#### PACKING AND ACCESSORY ASSEMBLY <M1>

	101	PQ35370-2	PACKING CASE,J425E
		PQ35336-16-1	PACKING CASE,J425EG
	102	PQ35362A	CUSHION ASSEMBLY,J425E
		PQ35331A	CUSHION ASSEMBLY,J425EG
	103	PQM30021-91	POLY BAG
	104	PQ41026-43	PROTECT SHEET
$\Delta$	105	PEAC0300-02	RF CABLE
$\Delta$	106	PQ21831B	REMOTE CONTROLLER,J425EG
$\Delta$		PQ21831D	REMOTE CONTROLLER,J425E

# $\Delta$  REF No. PART No. PART NAME, DESCRIPTION


	107	R03BPA-2ST	BATTERY,X2
	108	PQ35364	POLY BAG
	109	PQ35274-1-1	SHEET,ACCESSORY
$\Delta$	110	PU30425-1588	INSTRUCTIONS,J425EG
$\Delta$		PU30425-1701	INSTRUCTIONS,J425E
	111	PQ35364-4	POLY BAG
	112	BT-20135	WARRANTY CARD
	113	PQ33909	POLY BAG
	114	PQ34978-15	SHEET(S.V.)
	115	PQ35231	SHEET(G.PROG.),J425E
	116	PQ45146-81	SHEET(SPAIN),J425E
$\Delta$	117	PU30425-1702	INSTRUCTIONS,J425E



## 5.2 CABINET AND CHASSIS ASSEMBLY <M2>

### BEWARE OF BOGUS PARTS

Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine JVC parts be used.




#△ REF No. PART No. PART NAME, DESCRIPTION  
 \*\*\*\*\*

**CABINET AND CHASSIS ASSEMBLY < M2 >**

150	PQ11775J	FRONT PANEL ASSEMBLY,J425EG
	PQ11802F-2	FRONT PANEL ASSEMBLY,J425E
150A	PQ21778	CASSETTE DOOR,J425EG
	PQ21818-4	CASSETTE DOOR,J425E
150B	PQ46448	TORSION SPRING
150C	PQ35277	COVER(JACK)
△ 151	PQ11676-7	TOP COVER
152	SDSF3010M	SCREW,X4 TOP COVER
153	SDSF3010M	SCREW,TOP COVER
154	PQ35247	KNOB(JOG)
155	PQ35295-2	KNOB(SHUTTLE),J425E
	PQ35248-2-2	KNOB(SHUTTLE),J425EG
156	PEME0757-03	JOG SHUTTLE ASSEMBLY
157	SDSF2608Z	SCREW,X3
159	PDV2355A	DRUM ASSEMBLY
159A	PDM2261M	DRUM SUB ASSEMBLY
159B	PDM3353U-14	UPPER DRUM ASSEMBLY
159C	PDM4343A	BRUSH ASSEMBLY
159D	PDM4345A	COLLAR ASSEMBLY
159E	PDZ0141-2	ROTOR ASSEMBLY
159F	SPSH2660Z	SCREW,X2
159G	PDM4311A-1	ROLLER ASSEMBLY
△ 159H	PDZ0141-1-2	STATOR ASSEMBLY
159J	SPSP2606Z	SCREW,X2
159K	PDM4050-9	WASHER
△ 160	PQ11666-1-9	BOTTOM CHASSIS
△ 161	PQ11668-1-7	BOTTOM COVER
162	SDSF3010M	SCREW,TERMINAL
163	SPST2608Z	SCREW,X3 DRUM
164	SPST2612Z	SCREW,X2 CASS HOUSING ASSY
165	PQ21740-1-1	SHIELD CASE,PRE
166	SDST2606Z	SCREW,X2 PRE
167	SDSF4012Z	SCREW,X2 MECH
168	SDSF3010Z	SCREW,X2 CASS HOUSING ASSY
169	SDSF3010Z	SCREW,X2 TERMINAL
171	PQ43013-3	FOOT,X2
172	PQ45160	INERTIA PLATE
△ 173	QMP4A10-170	POWER CORD
△ 174	PQ46485	SPACER,SAFETY
175	PQ41556	EARTH PLATE
176	PUS29724B	CASSETTE HOUSING ASSEMBLY
178	PQM30029-245	SPACER
WR1	PW30802-1114	WIRE,DISP/SW
WR2	PW30803-0414	WIRE,DRUM
WR3	PW30101-C0HH887	WIRE,AUDIO CONTROL HEAD
WR4	PW30101-P0HH882	WIRE, FE HEAD
WR5	PW30218-0771613	WIRE, JOG
WR6	PW30802-0914	WIRE, SW/JACK

### 5.3 MECHANISM ASSEMBLY <M4>



Category	Part number	MARK
Grease	KYODO-SH-P	AA
Oil	COSMO-HV56	BB

**NOTE:** The section marked in AA and BB indicate lubrication and greasing areas.

#△ REF No. PART No. PART NAME, DESCRIPTION  
\*\*\*\*\*

**MECHANISM ASSEMBLY <M4>**

1	PQ46298A-3	TENSION BAND ASSEMBLY
2	SDST2608Z	SCREW
3	PQ35012	TENSION ARM LEVER
4	PQM30001-385	TENSION SPRING
5	PQ46302	ADJUST PIN
6	PQ46303A-1	TENSION ARM ASSEMBLY
7	PQM30017-47	SLIT WASHER
8	PQ46305B-3	MAIN BRAKE ASSEMBLY(SUPPLY)
9	PQ46306A-3	SUB BRAKE ASSEMBLY(SUPPLY)
10	PQM30001-393	TENSION SPRING
11	PQ46308A-2	MAIN BRAKE ASSEMBLY(TAKE UP)
12	PQ46309A-4	SUB BRAKE ASSEMBLY(TAKE UP)
13	PQM30001-389102	TENSION SPRING
14	PQ21683-1-3	REEL DISK,X2
15	PQ35014-1-1	SLIT DISK(SUPPLY)
16	PQ35015-1-1	SLIT DISK(TAKE UP)
17	PQM30018-69	SPECER,X2
18	PQM30003-33	BELT(CAPSTAN)
19	PQ35016-1-3	PULLEY
20	PQM30002-227-22	COMPRESSION SPRING
21	PQ46311	SPRING CAP
22	PQM30018-69	SPACER
23	PQ46312A-3	IDLER ARM ASSEMBLY
24	PQ46316A-1	CLUTCH UNIT(SUPPLY)
25	PQ46323A-1	CLUTCH UNIT(TAKE UP)
26	PQ46325A-6	GUIDE ARM ASSEMBLY
27	PQ46326-1-2	TORSION SPRING
28	PQ46327A	PINCH ROLLER ARM ASSEMBLY
29	PQM30017-24	SLIT WASHER
30	PEHE0182	AUDIO/CONTROL HEAD
31	PQ35206	HEAD BASE
32	PQ43687A	SPECIAL SCREW,X3
33	PQM30002-192	COMPRESSION SPRING,X3
34	SDST2604Z	SCREW,X2
35	PQ46330A	POLE BASE ASSY(SUPPLY)
36	PQ46331A	POLE BASE ASSY(TAKE UP)
37	PQ46332A-2	LOADING ARM ASSY(SUPPLY)
38	PQ46337A-3	LOADING ARM ASSY(TAKE UP)
39	PQ11657-1-5	GUIDE RAIL
40	SPST2608Z	SCREW,X5
41	SDST2612Z	SCREW
42	PQ21684-1-3	CONTROL CAM

#△ REF No. PART No. PART NAME, DESCRIPTION

43	PQ35138-1-2	CONTROL BRACKET
44	PQ46423	EARTH PLATE
45	PQ11658-1-5	CONTROL PLATE
46	PQM30017-8	SLIT WASHER
47	PQ21685-2-6	PINCH PLATE
48	SPST2606Z	SCREW,X2
49	SPSF2608M	SCREW
50	PQ46342A-6	LEVER ASSY
51	PQM30017-8	SLIT WASHER
52	PQ35083-1-2	REEL BRACKET
53	PQM30017-51	SLIT WASHER,X2
54	Q03093-830	WASHER
55	PQ35026-1-2	IDLER LEVER
56	PQ11659-1-6	SLIDE PLATE
57	PQ46344A-2	CHANGE LEVER ASSEMBLY
58	PQ21686	TAKE UP LEVER ASSEMBLY
59	PQ46345	TAKE UP HEAD
60	PQM30001-387106	TENSION SPRING
△ 61	PU60628-3-2	MODE MOTOR
62	SPSP3003Z	SCREW,X2
63	PW30101-80AJ632	WIRE
64	PQM30003-34-17	BELT
65	PQ46395A	WORM GEAR ASSMBLY
66	PQ21699	WORM BEARING
67	SPST2606Z	SCREW
△ 68	PU61435	CAPSTAN MOTOR
69	PQ46347B-8	SUB DECK ASSEMBLY
70	SPSG2608Z	SCREW,X3
71	PQ46356A-1	CAPSTAN BRAKE ASSEMBLY
72	SPST2606Z	SCREW,X3
73	PQM30001-384101	TENSION SPRING,C.BRAKE
74	PQ46353A-1	CHANGE ARM ASSEMBLY
75	PQ46354	CHANGE GEAR
76	PQM30001-386	TENSION SPRING
77	PQM30003-35	BELT
78	PQ46355	CASSETTE GEAR
79	PQ35030	LID GUIDE
80	PQ21689	LED PRISM
81	PEHE0237	FULL ERASE HEAD
82	SDST2610Z	SCREW
83	PU61432-1-1	ROTARY ENCODER
86	PQ43546-1-2	MOTOR PULLEY
87	PQ35217-1-2	CONTROL BRACKET 2
99	PQ21680B-11	MAIN DECK ASSEMBLY

## SECTION 6

### TECHNICAL INFORMATION

#### 6.1 SYSCON CIRCUIT

##### 6.1.1 Syscon CPU pin function (IC601) 1/2

PIN NO.	LABEL	IN/OUT	NOTE
1	S. CURVE	IN	TUNING CHECK
2	AVRGFM	IN	AUTO TRACKING DATA(AVERAGE VOLTAGE OF PB FM LEVEL)INPUT
3	P. DOWN	IN	POWER DOWN DETECT(POWER DOWN:H → L)
4	6.5H DET	IN	PB SWITCHING POINT ADJUST PULSE
5	AVSS	-	GND
6	TEST	-	GND
7	X2	-	TIMER CLOCK(32.768KHz)
8	X1	-	TIMER CLOCK(32.768KHz)
9	VSS	-	GND
10	OSC1	IN	SYSTEM CLOCK(10MHz)
11	OSC2	OUT	SYSTEM CLOCK(10MHz)
12	RESET	IN	RESET AT CONNECT VCR TO AC
13	(NMI)	-	NC
14	LSC	IN	MECHANISM MODE DETECT(C)
15	LSB	IN	MECHANISM MODE DETECT(B)
16	LSA	IN	MECHANISM MODE DETECT(A)
17	C. L. END	IN	CASSETTE TAPE LOAD SWITCH(CASSETTE IN: L)
18	RECSF	IN	REC SAFETY SW DETECT (SW ON:L)
19	STTS	IN	LEADER TAPE DETECT(DETECT ON:L)
20	PER12	OUT	PERI-2 CONNECTOR SELECT
21	P. CTL	OUT	POWER CONTROL(POWER ON:H)
22	TU FG	IN	TAKE-UP REEL ROTATION DET/TAPE REMAIN
23	SUP FG	IN	SUPPLY REEL ROTATION DET/TAPE REMAIN
24	A. MUTE	OUT	AUDIO MUTE CONTROL(MUTE ON:H)
25	SHUTTLE	IN	SHUTTLE SWITCH
26	JSB	IN	JOG PULSE INPUT(B)
27	JSA	IN	JOG PULSE INPUT(A)
28	SERVO	OUT	CAPSTAN MOTOR CONTROL(SERVO:L/SYSCON:H)
29	LOCK DET	IN	TUNING LOCK CHECK
30	PLL CE	OUT	TUNING CONTROL CHIP ENABLE
31	RECST	OUT	REC START:H
32	PLL DATA	OUT	TUNING CONTROL SERIAL DATA OUTPUT
33	TUCTL	OUT	TUNER MODE:H
34	RAE OUT	OUT	REMOTE PAUSE CONTROL OUTPUT
35	P. MUTE	OUT	PICTURE MUTE CONTROL(MUTE ON:L)
36	HSEL	OUT	HEAD SELECT CONTROL(SP:L/LP:M/EP:H)
37	A/M/S	OUT	PRE/REC CIRCUIT CONTROL(AUTO:M/MANUAL:H/S&S:L)
38	V. REC	OUT	VIDEO REC MODE:H
39	R. PAUSE	IN	REMOTE PAUSE CONTROL(PAUSE ON:L)
40	M. DATA	IN/OUT	MEMORY IC DATA

Table 6-1-1-A SYSCON CPU pin function (1/2)

## 6.1.2 Syscon CPU pin function (IC601) 2/2

PIN NO.	LABEL	IN/OUT	NOTE
41	M. CE	OUT	MEMORY IC CHIP ENABLE
42	SCR-IN	-	NC
43	VP-SCL	OUT	VPS DATA TRANSFER CLOCK
44	VP-SDA	OUT	VPS SERIAL DATA OUTPUT(for PROGRAMING CONTROL)
45	VPCTL	OUT	V. PULSE ADDITION TIMING CONTROL
46	MODE 1/DAV	-	NC
47	MODE 2	-	NC
48	EXP DATA	OUT	EXPANDER DATA
49	ENDS	IN	TRAILER TAPE DETECT(DETECT ON:L)
50	RC IN	IN	REMOTE CONTROL DATA INPUT
51	EE	OUT	EE MODE:L
52	CTL C/D	IN	CTL PULSE INPUT(MODE DETECT/BLANK PORTION DET)
53	NTSC	OUT	NTSC MODE:L
54	CH+ DATA	OUT	IIL LOGIC CTL DATA
55	PB SPE	OUT	SPECIAL PB MODE:L
56	COM CLOCK	OUT	MEMORY IC DATA TRANSFER CLOCK
57	S-OUT	OUT	ON SCREEN CONTROL DATA
58	S-IN	IN	ON SCREEN/FDP CONTROL DATA
59	S-CLK	OUT	DATA TRANSFER CLOCK
60	H DATA	OUT	VIDEO IC CONTROL DATA
61	STB	OUT	CLOCK OUTPUT PERMISSION
62	H CLK	OUT	VIDEO IC DATA TRANSFER CLOCK
63	VCC	-	SYSTEM POWER
64	CAP REV	OUT	CAPSTAN MOTOR CONTROL (FWD:H/REV:L)
65	S-DATA	OUT	SERVO IC CONTROL DATA
66	PAUSE	OUT	CAPSTAN MOTOR CONTROL(PAUSE:L)
67	CTL CLOCK	IN	INDEX CONTROL
68	LCM2	OUT	LOADING MOTOR DRIVE(2)
69	CAP FG	IN	TAPE SPEED DETECT/BACK SPACE COUNT
70	LCM1	OUT	LOADING MOTOR DRIVE(1)
71	D. FF	IN	DRUM ROTATION DETECT/REC TIMING CONTROL
72	AVCC	-	SYSTEM POWER(for ANALOG)
73	AV2/CH+	IN	AV2 SELECT SWITCH
74	DUTY I/O	IN/OUT	IN/OUT INDEX DATA CONTROL
75	DRUM V	OUT	DRUM MOTOR CONTROL
76	CAP V	OUT	CAPSTAN MOTOR CONTROL
77	D. V. DET	IN	DRUM DRIVE VOLTAGE DETECT
78	PROTECT	IN	SWD5V/12V DETECT
79	IF AGC	-	NC
80	SYNC DET	IN	SYNC DETECT(NO SYNC:H)

Table 6-1-1-B SYSCON CPU pin function (2/2)

E. &amp; O. E. No. 82461