

SAMSUNG

DIGITAL LASER PRINT ML-4550 Series

ML-4550 / ML-4551N / ML-4551ND

ML-4551NR / ML-4551NDR

Basic Model : ML-4550

***SERVICE* Manual**

DIGITAL LASER PRINT



CONTENTS

[The keynote of Product]

- Series Model: ML-4550 / 4551N / 4551ND
- High speed Laser Printer:
 - Up to 43 ppm in A4 (45 ppm in Letter),
 - Duplex: 29 ipm (A4); 30 ipm (Letter)
- Resolution: Up to 1200 x 1200 dpi
- Marvell 500Mhz
- Memory: 128 MB (Max. 512 MB)
128, or 256 MB optional memory available.
Use only the Samsung-approved DIMM.
128 MB: ML-MEM150, 256 MB: ML-MEM160
- Option:
ML-4550:500-sheet trays, ethernet 10/100 Base
TX wired LAN, ethernet 10/100 Base
hard disk, duplex unit, DIMM
- Toner cartridge:
 - Starter: 10K or 20K pages
 - Consumable: 10K or 20K pages
- Duty cycle: Monthly Up to 150,000 pages

Contents

1. Precautions

1.1 Safety Warning	1-1
1.2 Caution for safety	1-2
1.2.1 Toxic material	1-2
1.2.2 Electric Shock and Fire Safety Precautions	1-2
1.2.3 Handling Precautions	1-3
1.2.4 Assembly / Disassembly Precautions	1-3
1.2.5 Disregarding this warning may cause bodily injury	1-4
1.3 ESD Precautions	1-5

2. Product Specifications

2.1 Product Overview	2-1
2.2 Specifications	2-1
2.2.1 General Specifications	2-1
2.2.2 Controller & S/W	2-2
2.2.3 Paper Handling	2-3
2.2.4 Consumables	2-4
2.2.5 Reliability & Service	2-4
2.2.6 Environment	2-4
2.2.7 Options	2-5
2.2.8 Others	2-5
2.3 Model Comparison Table	2-6

3. Summary of Product

3.1 Printer Components	3-1
3.1.1 Front View	3-1
3.1.2 Rear View	3-2
3.1.3 Control Panel	3-3
3.2 System Layout	3-7
3.2.1 Feeding	3-8
3.2.2 Transfer	3-9
3.2.3 Driver Ass'y	3-9
3.2.4 Fuser	3-9
3.2.5 LSU (Laser Scanner Unit)	3-9

Continue...

3.2.6 Print Cartridge	3-10
3.3 Engine H/W Specifications	3-11
3.3.1 ML-4550 (PCL) Main Board	3-11
3.3.2 SMPS & HVPS board	3-16
3.3.3 Engine F/W	3-20

4. Alignment and Adjustments

4.1 How to use EDC (Engine Diagnostic Control) Mode	4-1
4.1.1 EDC Setup	4-1
4.1.2 Entrance method for EDC	4-1
4.1.3 Cover Status	4-2
4.1.4 Sensor Status	4-3
4.1.5 Motor Test	4-5
4.1.6 Fan Test	4-5
4.1.7 Clutch / Sol	4-6
4.1.8 Fuser Ctrl	4-7
4.1.9 LSU	4-7
4.1.10 Deve Control	4-8
4.1.11 Print Test and Option version	4-9
4.2 Paper Path	4-10
4.2.1 Clearing Paper Jams	4-12
4.3 Sample Pattern	4-17
4.3.1 Information Pages	4-17
4.3.2 Demo Pages	4-17
4.4 Periodic Defective Image	4-18
4.5 Error Messages	4-19

5. Disassembly and Reassembly

5.1 General Precautions on Disassembly	5-1
5.2 Transfer Roller	5-2
5.3 MPF Ass'y	5-3
5.4 Holder Pad Ass'y	5-4
5.5 Retard Ass'y	5-5
5.6 Feed2 Idle Unit	5-6
5.7 Cover Right	5-7

Continue...

5.8 Main PBA	5-8
5.9 Main Drive Ass'y	5-9
5.10 DEVE Drive Ass'y	5-10
5.11 Connector PBA	5-11
5.12 Solenoid	5-12
5.13 Rear Cover	5-13
5.14 Cover Left	5-14
5.15 Top Cover	5-15
5.16 Open Cover	5-16
5.17 Inner Cover	5-17
5.18 Fuser Ass'y	5-18
5.19 Duplex Solenoid Ass'y	5-20
5.20 Exit Roller	5-21
5.21 LSU	5-22
5.22 DC Fan	5-23
5.23 Toner Sensor PBA	5-24
5.24 REGI Ass'y	5-25
5.25 MP Pick Up Ass'y	5-26
5.26 Pick Up & Feed2 Assy	5-28
5.27 Engine Shield	5-31

6. Troubleshooting

6.1 The cause and solution of Bad image	6-1
6.2 The cause and solution of the bad discharge	6-8
6.3 The cause and solution of the malfunction	6-13
6.4 Maintaining the toner cartridge	6-17
6.5 The cause and solutions of bad environment of the software	6-22

7. Exploded Views & Parts List

7.1 Main Assembly	7-2
7.2 Cover Assembly	7-5
7.3 Frame Assembly	7-7
7.4 Fuser Unit	7-12
7.5 REGI Assembly	7-14

Continue...

7.6 Main Motor Assembly	7-16
7.7 Deve Motor Assembly	7-18
7.8 Exit Sorenoid Assembly	7-20
7.9 Cassette Assembly	7-22
7.10 Duplex Unit	7-24
7.11 SCF Unit	7-26

8. Block diagram

8.1 System Block Diagram	8-1
------------------------------------	-----

9. Connection Diagram

9.1 Connection Diagram	9-1
----------------------------------	-----

10. Schematic Diagram

10.1 Main Board	10-1
10.2 DIMM board	10-17
10.3 CRUM board	10-19
10.4 EMPTY board	10-20
10.5 HVPS	10-21
10.6 Panel	10-25
10.7 SCF	10-26
10.8 Toner sensor	10-29
10.9 HDD.eps	10-30

11. Reference Information

11.1 Troubleshooting Tools	11-1
11.2 Acronyms and Abbreviations	11-2
11.3 Select a location for the printer	11-4
11.4 Sample Tests Patterns	11-5

1. Precautions

In order to prevent accidents and to prevent damage to the equipment please read the precautions listed below carefully before servicing the printer and follow them closely.

1.1 Safety Warning

- (1) Only to be serviced by appropriately qualified service engineers.

High voltages and lasers inside this product are dangerous. This printer should only be serviced by a suitably trained and qualified service engineer.

- (2) Use only Samsung replacement parts

There are no user serviceable parts inside the printer. Do not make any unauthorized changes or additions to the printer, these could cause the printer to malfunction and create electric shock or fire hazards.

- (3) Laser Safety Statement

The Printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR, chapter 1 Subchapter J for Class 1(1) laser products, and elsewhere, it is certified as a Class I laser product conforming to the requirements of IEC 825. Class I laser products are not considered to be hazardous. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance, or prescribed service condition.

Warning >> Never operate or service the printer with the protective cover removed from Laser/Scanner assembly. The reflected beam, although invisible, can damage your eyes. When using this product, these basic safety pre-cautions should always be followed to reduce risk of fire, electric shock, and injury to persons.



CAUTION - INVISIBLE LASER RADIATION
WHEN THIS COVER OPEN.
DO NOT OPEN THIS COVER.

VORSICHT - UNSICHTBARE LASERSTRAHLUNG,
WENN ABDECKUNG GEFFNET.
NICHT DEM STRAHL AUSSETZEN.

ATTENTION - RAYONNEMENT LASER INVISIBLE EN CAS
D'OUVERTURE. EXPOSITION DANGEREUSE
AU FAISCEAU.

ATTENZIONE - RADIAZIONE LASER INVISIBILE IN CASO DI
APERTURA. EVITARE L'ESPOSIZIONE AL
FASCIO.

PRECAUCION - RADIACION LASER INVISIBLE CUANDO SE ABRE.
EVITAR EXPONERSE AL RAYO.

ADVARSEL. - USYNLIG LASERSTRÅLING VED ÅBNING, NÅR
SIKKERHEDSBRYDERE ER UDE AF FUNKTION.
UNDG. UDSÆTTELSE FOR STRÅLING.

ADVARSEL. - USYNLIG LASERSTRÅLING NÅR DEKSEL
ÅPNES. STIRR IKKE INN I STRÅLEN.
UNNG. EKSPONERING FOR STRÅLEN.

VARNING - OSYNLIG LASERSTRÅLING NÅR DENNA DEL
ÅPPNAD OCH SPÄRRAD ÅR URKOPPLAD.
BETRÄKTA EJ STRÅLEN. STRÅLEN ÅR FARLIG.

VARO! - AVATTAESSA JA SUOJALUKITUS OHITETTAESSA
OLET ALTTIINA NÄYTTÄMÄLLE LASER-
SÄTEILYLLE. LÄHETÄÄ SUOJELUVAIKUTUKSEN.

注 意 - 严禁揭开此盖, 以免激光泄露灼伤

주 의 - 이 덮개를 열면 레이저광에 노출될 수 있으므로
주의하십시오.

1.2 Caution for safety

1.2.1 Toxic material

This product contains toxic materials that could cause illness if ingested.

- (1) If the LCD control panel is damaged it is possible for the liquid inside to leak. This liquid is toxic. Contact with the skin should be avoided, wash any splashes from eyes or skin immediately and contact your doctor. If the liquid gets into the mouth or is swallowed see a doctor immediately.
- (2) Please keep toner cartridges away from children. The toner powder contained in the toner cartridge may be harmful and if swallowed you should contact a doctor.

1.2.2 Electric Shock and Fire Safety Precautions

Failure to follow the following instructions could cause electric shock or potentially cause a fire.

- (1) Use only the correct voltage, failure to do so could damage the printer and potentially cause a fire or electric shock.
- (2) Use only the power cable supplied with the printer. Use of an incorrectly specified cable could cause the cable to overheat and potentially cause a fire.
- (3) Do not overload the power socket, this could lead to overheating of the cables inside the wall and could lead to a fire.
- (4) Do not allow water or other liquids to spill into the printer, this can cause electric shock. Do not allow paper clips, pins or other foreign objects to fall into the printer these could cause a short circuit leading to an electric shock or fire hazard..
- (5) Never touch the plugs on either end of the power cable with wet hands, this can cause electric shock. When servicing the printer remove the power plug from the wall socket.
- (6) Use caution when inserting or removing the power connector. The power connector must be inserted completely otherwise a poor contact could cause overheating possibly leading to a fire. When removing the power connector grip it firmly and pull.
- (7) Take care of the power cable. Do not allow it to become twisted, bent sharply round corners or other wise damaged. Do not place objects on top of the power cable. If the power cable is damaged it could overheat and cause a fire or exposed cables could cause an electric shock. Replace a damaged power cable immediately, do not reuse or repair the damaged cable. Some chemicals can attack the coating on the power cable, weakening the cover or exposing cables causing fire and shock risks.
- (8) Ensure that the power sockets and plugs are not cracked or broken in any way. Any such defects should be repaired immediately. Take care not to cut or damage the power cable or plugs when moving the machine.
- (9) Use caution during thunder or lightening storms. Samsung recommends that this machine be disconnected from the power source when such weather conditions are expected. Do not touch the machine or the power cord if it is still connected to the wall socket in these weather conditions.
- (10) Avoid damp or dusty areas, install the printer in a clean well ventilated location. Do not position the machine near a humidifier. Damp and dust build up inside the machine can lead to overheating and cause a fire.
- (11) Do not position the printer in direct sunlight. This will cause the temperature inside the printer to rise possibly leading to the printer failing to work properly and in extreme conditions could lead to a fire.
- (12) Do not insert any metal objects into the machine through the ventilator fan or other part of the casing, it could make contact with a high voltage conductor inside the machine and cause an electric shock.

1.2.3 Handling Precautions

The following instructions are for your own personal safety, to avoid injury and so as not to damage the printer

- (1) Ensure the printer is installed on a level surface, capable of supporting its weight. Failure to do so could cause the printer to tip or fall.
- (2) The printer contains many rollers, gears and fans. Take great care to ensure that you do not catch your fingers, hair or clothing in any of these rotating devices.
- (3) Do not place any small metal objects, containers of water, chemicals or other liquids close to the printer which if spilled could get into the machine and cause damage or a shock or fire hazard.
- (4) Do not install the machine in areas with high dust or moisture levels, beside an open window or close to a humidifier or heater. Damage could be caused to the printer in such areas.
- (5) Do not place candles, burning cigarettes, etc on the printer, These could cause a fire.

1.2.4 Assembly / Disassembly Precautions

Replace parts carefully, always use Samsung parts. Take care to note the exact location of parts and also cable routing before dismantling any part of the machine. Ensure all parts and cables are replaced correctly. Please carry out the following procedures before dismantling the printer or replacing any parts.

- (1) Check the contents of the machine memory and make a note of any user settings. These will be erased if the mainboard or network card is replaced.
- (2) Ensure that power is disconnected before servicing or replacing any electrical parts.
- (3) Disconnect printer interface cables and power cables.
- (4) Only use approved spare parts. Ensure that part number, product name, any voltage, current or temperature rating are correct.
- (5) When removing or re-fitting any parts do not use excessive force, especially when fitting screws into plastic.
- (6) Take care not to drop any small parts into the machine.
- (7) Handling of the OPC Drum
 - The OPC Drum can be irreparably damaged if it is exposed to light.
Take care not to expose the OPC Drum either to direct sunlight or to fluorescent or incandescent room lighting. Exposure for as little as 5 mins can damage the surface's photoconductive properties and will result in print quality degradation. Take extra care when servicing the printer. Remove the OPC Drum and store it in a black bag or other lightproof container. Take care when working with the covers (especially the top cover) open as light is admitted to the OPC area and can damage the OPC Drum.
 - Take care not to scratch the green surface of the OPC Drum Unit.
If the green surface of the Drum Cartridge is scratched or touched the print quality will be compromised.

1.2.5 Disregarding this warning may cause bodily injury

(1) Be careful with the high temperature part.


The fuser unit works at a high temperature. Use caution when working on the printer. Wait for the fuser to cool down before disassembly.

(2) Do not put finger or hair into the rotating parts.

When operating a printer, do not put hand or hair into the rotating parts (Paper feeding entrance, motor, fan, etc.). If do, you can get harm.

(3) When you move the printer.

This printer weighs 22kg including toner cartridge and cassette. Use safe lifting and handling techniques. Use the lifting handles located on each side of the machine. Back injury could be caused if you do not lift carefully.



(4) Ensure the printer is installed safely.

The printer weighs 22Kg, ensure the printer is installed on a level surface, capable of supporting its weight.

Failure to do so could cause the printer to tip or fall possibly causing personal injury or damaging the printer.

(5) Do not install the printer on a sloping or unstable surface. After installation, double check that the printer is stable.

1.3 ESD Precautions

Certain semiconductor devices can be easily damaged by static electricity. Such components are commonly called “Electrostatically Sensitive (ES) Devices”, or ESDs. Examples of typical ESDs are: integrated circuits, some field effect transistors, and semiconductor “chip” components.

The techniques outlined below should be followed to help reduce the incidence of component damage caused by static electricity.

Caution >>Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.

1. Immediately before handling a semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, employ a commercially available wrist strap device, which should be removed for your personal safety reasons prior to applying power to the unit under test.
2. After removing an electrical assembly equipped with ESDs, place the assembly on a conductive surface, such as aluminum or copper foil, or conductive foam, to prevent electrostatic charge buildup in the vicinity of the assembly.
3. Use only a grounded tip soldering iron to solder or desolder ESDs.
4. Use only an “anti-static” solder removal device. Some solder removal devices not classified as “anti-static” can generate electrical charges sufficient to damage ESDs.
5. Do not use Freon-propelled chemicals. When sprayed, these can generate electrical charges sufficient to damage ESDs.
6. Do not remove a replacement ESD from its protective packaging until immediately before installing it. Most replacement ESDs are packaged with all leads shorted together by conductive foam, aluminum foil, or a comparable conductive material.
7. Immediately before removing the protective shorting material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.
8. Maintain continuous electrical contact between the ESD and the assembly into which it will be installed, until completely plugged or soldered into the circuit.
9. Minimize bodily motions when handling unpackaged replacement ESDs. Normal motions, such as the brushing together of clothing fabric and lifting one’s foot from a carpeted floor, can generate static electricity sufficient to damage an ESD.

2. Product Specifications

2.1 Product Overview

Item	Descriptions	Remark
Basic Model	ML-4550	
Series Model	ML-4550, ML-4551N, ML-4551ND, ML-4551NDG(Kor.)	
Market of Sales	Office user Laser printer. (Network for work Group)	
Specification	<ul style="list-style-type: none"> · 43ppm(Ltr. 45ppm), 500MHz Processor, 128MB Memory · 10K(initial), 20K(sales) · USB(High Speed USB 2.0), Network Option, ML-4551N, ML-4551ND(Network base) · Face Down(250 sheets), Face Up(100 sheets) 	

2.2 Specifications

· Product Specifications are subject to without notice. See below for product specifications.

2.2.1 General Specifications

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Engine Speed	Simplex	Up to 43 ppm in A4 (45 ppm in Letter)		
	Duplex	Option : 29 ipm in A4 (30 ipm in Letter)		
Warmup time	-	Less than 45 sec : Power-on boot		
FPOT	From Ready	Less than 8.5 sec		
	From Idle	Less than 43.5 sec		
	From Coldboot	Less than 53.5 sec		
Resolution	-	Up to 1200 x 1200 dpi effective output		

2.2.2. Controller & S/W

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Processor		Marvell 500Mhz		
Memory	Std.	128 MB		
	Max.	512MB(256+256)		
Printer Languages	-	PostScript3, PCL6, IBM ProPrinter, EPSON, PDF Direct(only HDD installed)		
Fonts	-	45 scalable, 1 bitmap, 136 PostScript 3 fonts, OCR Fonts		
Driver	Default Driver	PCL6 : Win 95/98/NT4.0/2000/Me/XP(32/64bits)/2003 Server(32/64bits) PS : Linux & Mac		
	Supporting OS	Windows 95/98/NT4.0/2000/Me/XP(32/62bits)/2003 Server(32/62bits)		
		Various Linux OS including Red Hat 8~9, Fedora Core 1~3, Mandrake 9.2~10.1 and SuSE 8.2~9.2		
		Mac OS 8.6~9.2/10.1~10.4		
	WHQL	Windows 2000, XP, 2003 Server		
Wired Network	Protocol	N/A	SPX/IPX, TCP/IP, SNMP, HTTP 1.1, AppleTalk	
	Supporting OS	N/A	Windows 98/ME/NT4.0/2000/XP(32/64bits)/2003 Server(32/64bits) Netware 4.x, 5.x, 6.x Mac OS 8.6~9.2, 10.1~10.4 Various Linux OS including Red Hat 8.0~9.2, Fedora Core 1~3, Mandrake 9.2~10.1 and SuSE 8.2~9.2	
Wireless Network	Protocol	N/A		
	Supporting OS	N/A		
Application	RCP	N/A		
	Status Monitor	N/A		
	Smart Panel	YES (Include RCP and SM)		
	Network Management	N/A		
Interface				
Parallel	-	IEEE 1284		
USB	-	High Speed USB 2.0		
Wired Network	-	Optional	10/100 Base TX	
Wireless Network	-	N/A		
User Interface				
LCD	-	16 x 12 Character LCD		
LED	-	2LED(Status LED, Save Button LED)		
Key	-	8 Key: Menu , ◀ , OK (*) , ▶ , Back Toner Save , Demo , Stop		

2.2.3. Paper Handling

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Standard Capacity	-	500-sheet Cassette Tray, 100-sheet Multi Purpose Tray @75g/ m²		
Max. Capacity	-	2,100 sheets @75g/ m²		
Printing	Max. Size	216 x 356 mm (8.5" x 14")		
	Min. Size	76 x 127 mm (3.0" x 5.0")(>105g)		
Multi-purpose tray				
Capacity	-	100 sheets @75g/ m²		
Media sizes	-	A4, A5, A6, Letter, Legal, Oficio, Folio, Executive,ISO B5, JIS B5, 3"x5", Monarch, No.10, DL, C5, C6		
Media type	-	Transparencies, Envelopes, Labels, Card stock		
Media weight	-	16~43 lb (60 to176g/ m²)		
Sensing	-	Paper empty sensor		
Standard Cassette Tray				
Capacity	-	500 sheets @ 75g/ m²		
Media sizes	-	A4, A5, Letter, Legal, Executive, Folio, Oficio, ISO B5, JIS B5		
Media types	-	Plain Paper		
Media weight	-	16~28lb (60 to 105g/ m²)		
Sensing	-	Paper empty sensor, Paper Size Sensor		
Second Cassette Tray	Optional			
Capacity	-	500 sheets @ 75g/ m²		
Media sizes	-	A4, A5, Letter, Legal, Executive, Folio, Oficio, ISO B5, JIS B5		
Media types	-	Plain Paper		
Media weight	-	16~28lb (60 to 105g/ m²)		
Sensing	-	Paper empty sensor, Paper Size Sensor		
Third Cassette Tray	Optional			
Capacity	-	500 sheets @ 75g/ m²		
Media sizes	-	A4, A5, Letter, Legal, Executive, Folio, Oficio, ISO B5, JIS B5		
Media types	-	Plain Paper		
Media weight	-	16~28lb (60 to 105g/ m²)		
Sensing	-	Paper empty sensor, Paper Size Sensor		
Output Stacking				
Capacity	Face-Down	250 sheets @ 75g/ m²		
	Face-Up	100 sheets @ 75g/ m²		
Output Full sensing	-	Paper full Sensor		
Optional Stacker				
Capacity	Face-Down	N/A		
Duplex Supporting	-	Optional		Built-in
Media sizes	-	A4, Letter, Legal, Folio, Oficio		
Media types	-	Plain Paper		
Media weight	-	20~24lb (75~90g/ m²)		

2.2.4. Consumables

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Toner	Black	Standard 10K pages @ ISO 19752 standard Coverage High Yield 20K pages @ ISO 19752 standard Coverage		
	Key	Electronic key(CRUM)		
	Life detect	Toner remaining volume would be traced via software		
Drum	Yield	Same as consumables		

2.2.5. Reliability & Service

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Printing Volume (SET AMPV)	-	5,000 sheets / month		
Max. Monthly Duty	-	150,000 sheets		
MPBF	-	150,000 sheets		
MTTR	-	20 min.		
SET Life Cycle	-	500,000 sheets or 5 years (whichever comes first)		

2.2.6. Environment

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Acoustic Noise Level(Sound Power/Pressure)	Printing	Less than 57.0 dBA		
	Standby	Less than 35.0 dBA		
	Sleep	Back Ground Level		
Power Consumption	AVG.	Less than 650W		
	Sleep/Power Off	Less than 13W		
Dimension (W x D x H)	SET	396 x 453 x 353 mm (15.6" x 17.8" x 13.9")		396 x 501 x 353 mm (15.6" x 19.7" x 13.9")
	SET Packing	518 x 566 x 568 mm (External)		
	CRU	314 x 242 x 138 mm		
	Toner Packing	370 x 286 x 180 mm (External)		
Weight	SET	17.8kg(39.2 lb)		19.1kg
	Toner(10K)	10K : 1.85kg(4.08 lbs), 20K : 2.06kg(4.54 lbs)		
	Gross	21.6kg(47.62 lbs)		23.5kg(51.81 lbs)






2.2.7. Options

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Memory	-	128MB/512MB (256MB+256MB)		
Second Cassette	-	500 sheet Cassette Tray		
Third Cassette	-	500 sheet Cassette Tray		
Stacker	-	N/A		
Stapler		N/A		
PostScript	-	Default		
Wired Network	-	Ethernet 10/100 Base TX (Internal)	Default	Default
Hard Disk	-	40GB		
Duplex Unit	-	Optional		Default

2.2.8. Others

ITEM		ML-4550 SERIES		
		ML-4550	ML-4551N	ML-4551ND
Performance Requirement	Jam Rate	Base Line Paper : 1/12K		
		Standard Paper : 1/10K		
		Stress Paper : 1/1500		

2.3 Model Comparison Table

Project	SEC	HP	Lexmark	Brother	Dell
Model Name	ML-4550	LJ-4250	T642	HL-8050N	W5200N
					
Engine					
FPOT	8.5 sec	8 sec	8.5 sec	9 sec	8.5 sec
Speed(ppm)	43ppm (Ltr. 45ppm)	43ppm (Ltr. 45ppm)	43ppm (Ltr. 45ppm)	34ppm (Ltr. 35ppm)	43ppm (Ltr. 45ppm)
Resolution	1200 dpi	1200 dpi	1200 dpi x 1200 dpi	1200dpi x 1200 dpi	1200 dpi x 1200 dpi
Noise(dB)	57dB(Printing), 35dB(Idle)	not_inform	55dB(Printing), 30dB(Idle)	54dB(Printing), 27dB(Idle)	55dB(Printing), 34dB(Idle)
Weight	17.83kg	20.2kg (45 lbs)	23.1Kg (51lbs)	20.6Kg (45.2 lbs)	45lbs
Demension(W*D*H)	15.6" x 17.8" x 13.9" 396 x 453 x 353 mm	16.5"x17.8"x14.8" 418x451x377mm	436x523x406mm (17.2"x20.6"x16")	16.6" x 18.3" x 15.9"	(17.2"x20.2"x16")
Control					
Processor	500MHz	460MHz	457 MHz RISC	300MHz	500 MHz RISC
Ram(Std.)	128MB	48MB	64MB	64MB	80MB
Ram(Max.)	512MB	512MB	576MB	576MB	336MB
Emulation	PCL6, PS3	PCL6, PS3	PCL6, PS3	PCL6, PS3, 10/100 Base TX	PCL6, PS3, 10/100 Base TX
Interface	IEEE1284, USB 2.0	IEEE1284, USB 2.0	IEEE1284, USB 1.1	IEEE1284, USB 2.010/100 Base TX	IEEE1284, USB 2.010/100 Base TX
Optional Interface	10/100 Base TX	10/100 Base TX	10/100 Base TX	N/A	N/A
Paper Handling					
Paper Input(Capa./Type)	500 Sheets Cassette100 MP Tray	500 Sheets Cassette100 MP Tray	500 Sheets Cassette100 MP Tray	550 Sheets Cassette 150 Sheets Cassette	500 Sheets Cassette100 MP Tray
Paper Output	250 Sheets Face down 100 Sheets Face up	250 Sheets Face down	500 Sheets Face Down	500 Sheet Face down 70 Sheet Face up	250 Sheets Face Down
Others					
Max.Monthly Duty	150,000 sheets	200,000 sheets	225,000 sheets	-	225,000 sheets
Consumable Yeild	Standard 10K High Yield 20K	Standard 10K High Yield 20K	Standard 6K High Yield 21K	17K	Standard 18K High Yield 27K
Power Consumption	Printing : Less than 650 W Sleep : under 13 W	Printing : 680 W Sleep : under 20 W	not_inform	Printing: < 593W Sleep:< 12W	not_inform
Duplex	Option	Option	Option	Option	NO
Options	- Memory (128MB/256MB) - 3x500 sheet SCF - Duplex - 40GB HD	- Memory - 500 sheet SCF - Duplex - HP Jetdirect - 20GB HD - Stacker & Stapler	- 250 sh duplexer - 3x250 sh drawer - 2000 sh drawer(Max.3850) - 85 sh envelope feeder - 650 sh output expander - 1850 sh High capacity output stacker - 40 sheet staple - 5 bin mailbox (5x120 sh)	- SCF - Memory - Stand - Sorter/Mail box	- duplexer - 85 envelope feeder - 500 sheet cassette - 250 sheet cassette

2.4 ACCESSORY


Item	Code	Quantity
INA-ACCESSORY	JC99-01974E	1
CBF-POWER CORD	3903-000042	1
BAG PE	6902-000288	1
S/W APPLICATION-CD	JC46-00280A	1
S/W APPLICATION-CD	JC46-00293A	1
MANUAL-(CARD)WARRANTY CARD	JC68-00690A	1
MANUAL-NETWORK GUIDE	JC68-01579A	1
LABEL(P)-BLANK 90*25	JC68-01584A	1

3. Summary of Product


This chapter describes the functions and operating principal of the main component.

3.1 Printer Components

3.1.1 Front View




1	output tray	8	handle
2	control panel	9	paper level indicator
3	control board cover	10	multi-purpose tray
4	tray 1	11	top cover
5	optional tray 2	12	multi-purpose tray paper width guides
6	optional tray 3	13	multi-purpose tray extension
7	optional tray 4		



The figure above shows an ML-4551ND with all available options.

3.1.2 Rear View




* The figure above shows an ML-4551ND with all available options.

1	power switch	5	parallel port
2	rear cover	6	USB port
3	duplex unit	7	network port
4	power receptacle		

3.1.3 Control Panel

The control panel on the top right side of your printer has the display and the nine buttons.




3.1.3.1 Display

1	Menu: Enters Menu mode and scrolls through the available menus.
2	Scroll buttons: Scroll through the options available in the selected menu, and increase or decrease values.
3	OK: Confirms the selection on the display.
4	Back: Sends you back to the upper menu level.
5	Toner Save: Allows you to save on toner by using less toner in printing.
6	Demo: Prints a demo page.
7	Stop: Stops an operation at any time.
8	Status: Indicates the status of your printer.

3.1.3.2 Overview of Control Panel Menus

The control panel menus are used to configure the printer for your environment.
The control panel provides access to the following menus.



a. Available with an optional hard disk.

b. Available with an optional duplex unit in the ML-4550 or ML-4551N.

c. Available with an optional network interface card for the ML-4550.

3.1.3.3 Special Features

Your new printer is equipped with special features that improve the print quality, giving you a competitive edge.


You can:

Print with excellent quality and high speed




- You can print up to 1200 x 1200 dpi effective output. See the Software Section.
- Your printer prints A4-sized paper at up to 43 ppm a and letter-sized paper at up to 45 ppm. For duplex printing, your printer prints A4-sized paper at up to 29 ipm b and letter-sized paper at up to 30 ipm.

Handle paper flexibly



- The multi-purpose tray supports letterheads, envelopes, labels, transparencies, custom-sized materials, postcards, and heavy paper. The multi-purpose tray holds up to 100 sheets of plain paper.
- The 500-sheet standard tray 1 supports plain paper in various sizes.
- The 500-sheet optional tray support plain paper in various sizes. You can install up to 3 additional trays.
- Two output tray; select either the output tray (face-down) or the rear cover (face-up) for the most convenient access.
- Straight-through paper path capability from the multi-purpose tray to the rear cover.

Create professional documents




- Print Watermarks. You can customize your documents with words, such as "Confidential." See the Software Section.
- Print Posters. The text and pictures of each page of your document are magnified and printed across the sheet of paper and can then be taped together to form a poster. See the Software Section.

a. pages per minute


b. images per minute

Save your time and money



- This printer allows you to use toner save mode to save toner.
- You can print on both sides of the paper to save paper (double-sided printing) if you use the ML-4551ND or install the optional duplex unit in the ML-4550 and ML-4551N.
- You can print multiple pages on a single sheet of paper to save paper (N-Up printing). See the Software Section.
- You can use preprinted forms and letterhead with plain paper. See the Software Section.
- This printer automatically conserves electricity by substantially reducing power consumption when not in use.

Expand the printer capacity



- Your printer has 128 MB of memory which can be expanded to 512 MB.
- A Network interface enables network printing. You can add an optional network interface card to the ML-4550. The ML-4551N and ML-4551ND come with a built-in network interface, 10/100 Base TX.
- You can add 500-sheet optional trays to your printer. These trays let you add paper to the printer less often.
- A PostScript 3 Emulation* (PS) enables PS printing.

Use the optional hard disk

You can install an optional hard disk in your printer.

- The 40 GB hard disk can store the data from your computer in the print queue. This decreases the workload of the computer.
- You can use various print features, such as storing a job in the hard disk, proofing a job, and printing private documents.
- You can manage the print jobs in the print queue of the printer hard disk. For details.

Print in various environments

- You can print in Windows 98/Me/NT 4.0/2000/XP/2003.
- Your printer is compatible with Linux and Macintosh.
- Your printer comes with both Parallel and USB interfaces.
- You can also use a network interface. The ML-4551N and ML-4551ND come with a built-in network interface, 10/100 Base TX. However, you need to install the optional wired network interface card to the ML-4550.


Printer Features

The table below lists a general overview of features supported by your printer.

(I: Installed, O: Option)

Features	ML-4550	ML-4551N	ML-4551ND
IEEE 1284 Parallel	I	I	I
USB 2.0	I	I	I
Network Interface (Ethernet 10/100 Base TX)	O	I	I
Hard Disk	O	O	O
PostScript* Emulation	I	I	I
Duplex Unit	O	O	I
Optional Tray 2	O	O	O
Optional Tray 3	O	O	O
Optional Tray 4	O	O	O

3.2 System Layout



- | | |
|---------------------|-------------------|
| ❶ Cassette | ❷ Duplex |
| ❸ MPF | ❹ Print Cartridge |
| ❺ LSU | ❻ Fuser |
| ❼ SMPS & HVPS Board | ❽ Duplex Solenoid |

3.2.1 Feeding

It consists of a basic cassette, an MP tray for supplying different types of media : envelope, label special paper, duplex unit, and parts related to paper transferring.

1) Separation method

Separate it from the friction pad mounted to the center of the cassette and apply retard roller that uses a spring clutch. A feed roller uses an electronic clutch to control driving power.

2) Basic cassette

It takes a center loading method and applies 'friction pad separating method.' It means that there is a paper sensor, but a paper size is detected after detecting the first paper by software.

Both the side guide and the rear guide can be adjusted for various types of papers from A5 to legal size paper.

It has a paper existence sensing function (Capacity: 500 sheets of general paper), paper arranging function, various size papers accepting function, SCF paper path function, and displaying function of paper remaining amount.

In the front side, there is a paper level indicator.

3) Pick-up roller

It has functions such as a paper pickup function, driving control function, paper feeding function, and removing electronic static function.

4) Retard roller

It takes an arrangement method which uses a stopper roller and a weight without electric actuator.

It has paper separating function, driving control function, and multi feeding prevention function.

6) Registration roller

It has a paper arranging function, paper transferring function, paper detecting function, jam removing function, and so on.

7) MP tray

It has a paper arranging function, paper transferring function, jam removing function, and so on.

It uses rubbing pad method to feed 100 sheets of general papers and 10 envelopes.

It is possible to extend to 300mm for accepting a legal size paper.

8) Duplex unit

It has paper transferring function, paper guide function, jam removing function, paper sensing function, and main board supporting function.

It is designed for basic attachment, and the duplex feeding takes a side feeding method. Usable papers are A4, letter, and legal size paper.

For removing a jam occurred in a front part, it is designed to open a cassette and a guide.

It is designed to open a rear cover to remove a jam in a rear part.

If a face up tray is open, the duplex option cannot be used.

9) SCF (Second Cassette Feeder)

It is the same method with the main cassette, and the capacity is 500 sheets.

It has a separate driving mechanism. It is designed for a common use with a main cassette.

3.2.2 Transfer

It consists of a PTL (Pre-transfer Lamp) and a transfer roller. A PTL sheds light on an OPC drum, lowers an electric potential of an OPC drum's surface, and improves the efficiency of the transfer.

A transfer roller transfers toner on an OPC drum to the paper.

Life span: Print over 150,000 sheets (In 16~27 °C)

3.2.3 Driver Ass'y

By driving the motor, the system takes power. It consists of a main motor for feeding fuser and duplex reverse turn, and a deve-motor for a toner cartridge.

- Main Motor : DC 24V, Rated RPM : 1604rpm
- Deve Motor : DC 24V, Rated RPM : 1424 rpm

3.2.4 Fuser

It is consisted of a heat lamp, heat roller, pressure roller, thermistor and thermostat. It sticks the toner on a paper by heat and pressure to complete the printing job.

- E-coil Heater : 1,300 Watt \pm 50W

1) Thermostat

When a heat lamp is overheated, a Thermostat cuts off the main power to prevent over-heating.

- Non-Contact type Thermostat

3) Heat roller

The heat roller transfers the heat from the e-coil to apply a heat on the paper. The surface of a heat roller is coated with Teflon, so toner does not stick to the surface.

4) Pressure roller

A pressure roller mounted under a heat roller is made of a silicon resin, and the surface also is coated with Teflon. When a paper passes between a heat roller and a pressure roller, toner adheres to the surface of a paper permanently.

5) Items for safety

Protecting device for overheating

- 1st protection device: Hardware cuts off when overheated
- 2nd protection device: Software cuts off when overheated
- 3rd protection device: Thermostat cuts off main power.

Safety device

- A fuser power is cut off when a front cover is opened
- Maintain a temperature of fuser cover's surface under 80°C for user, and attach a caution label at where customer can see easily when customer open a rear cover.


3.2.5 LSU (Laser Scanner Unit)

It is the core part of the LBP which switches from the video data received to the controller to the electro-static latent image on the OPC drum by controlling laser beam, exposing OPC drum, and turning principle of polygon mirror. The OPC drum is turned with the paper feeding speed. The /HSYNC signal is created when the laser beam from LSU reaches the end of the polygon mirror, and the signal is sent to the controller. The controller detects the /HSYNC signal to adjust the vertical line of the image on paper. In other words, after the /HSYNC signal is detected, the image data is sent to the LSU to adjust the left margin on paper. The one side of the polygon mirror is one line for scanning.

3.2.6 Print Cartridge

By using the electronic photo process, it creates a visual image. In the print cartridge, the OPC unit and the toner cartridge unit are in a body. The OPC unit has OPC drum and charging roller, and the toner cartridge unit has toner, supply roller, developing roller, and blade (Doctor blade)

- Developing Method: Non-contacting method
- Toner : Non magnetic 1 component pulverized type toner
- The life span of toner : 10,000 or 20,000 pages (LSA Pattern/A4 standard)
- Toner remaining amount detecting sensor : Yes
- OPC Cleaning : Cleaning blade type
- Management of disusable toner : Collect the toner by using Cleaning Blade
- OPC Drum protecting Shutter : Yes
- Classifying device for toner cartridge : ID is classified by CRUM.



<Toner Cartridge Layout>

3.3 Engine H/W Specifications

3.3.1 ML-4550 (PCL) Main Board

The Engine Board and the Controller Board are in one united board, and it is consisted of CPU part and print part in functional aspect. The CPU is functioned as the bus control, O/O handling, drivers, and PC interface. The main board sends the Current Image by Video data to the LSU and manages the conduct of Electrophotography for printing. It is consisted of the circuits of the motor (paper feed, pass) driving, clutch driving, pre-transfer lamp driving, current driving, and fan driving. The signals from the paper feed jam sensor and paper empty sensor are directly inputted to the main board.



3.3.1.1 Asic (ORION 2)

- **Marvell Feroceon 2850 ARM Compatoble (I-Cache: 32KB, D-Cache-32KB)**
- **64-bit RISC embedded processor core**
- **Dual bus architecture for bus traffic distribution**
 - AMBA High performance Bus (AHB)
 - System Bus with SDRAM
 - 64-bit Mbus Crossbar extension Interface with Flash and Device port
- **SDRAMC**
 - 32 Bits Dual mode DDR-II, 200MHz
 - 4 Banks (Up to 256MB per Bank)
- **Device Controller**
 - Boot Flash 1 Bank (Up to 128MB)
 - Device/NOR Flash 3 Banks (Up to 128MB per Bank)
- **No Graphic Execution Unit and Image processor**
- **No Codec (Encoding / Decoding)**
- **Printer Video Controller Interface for LBP engines**
 - Hyper-C : Printer Video Controller with RET algorithm
(Line Memory & Lookup Table Memory : 512 x 8 , 4096 x 16)
Dual / Single Beam, LVDS Pad (VDO, HSYNC)
- **PCI Controller**
 - 32Bits, 66MHz (PCI) / 133MHz (PCI-X)
 - PCI Local Bus Specification rev. 2.2 compliant
 - PCI Express Specification beta 1.0a compliant
 - Host /Agent Mode (Support 3+4 Express Devices in Host Mode)
- **Engine Controller (LPEC1)**
 - LSU Interface unit
 - Step Motor: 2 Channels
 - PWM: 8 Channels
 - ADC: 6 Channels
- **USB 2.0 Interface with Embedded USB 2.0 PHY**
- **Gigabit Ethernet Controller**
 - IEEE 802.3 compliant with 10/100/1000 Mbps full-duplex GbE port
 - Support GMII,MII and RGMII interface with external PHY/SERDES device
- **Package** : 496pins PBGA
- **Power** : 1.2V(Core), 3.3V(IO) power operation
- **Speed** : 600MHz core(ARM9 Compatible) operation, 200MHz bus operation


3.3.1.2 Memory

- **NOR Flash Memory** : It stores System Program and downloads the System Program through PC Interface, and in case of model for export it compresses the PCL font, then stores it.
 - Capacity : 128M Byte
 - Access Time : 70 nsec
- **DDR SDRAM** : It is used as Swath Buffer, System Working Memory Area, etc. when printing.
It stores Font List, compressed into Flash memory, on DRAM and uses it as PCL font in case of model for export.
 - Capacity : 128 Byte(Basic), up to 512Mbyte (User Option)
 - Type : DDR-II SDRAM 200MHz , 32bit

3.3.1.3 Others

The Option PBA can be mounted for supporting the serial communication.

3.3.1.4. 88F5281 Internal Block Diagram



3.3.1.5 Sensor Input Circuit

3.3.1.5.1 Paper Empty Sensing

The Paper empty sensor (Photo Interruptor) on the engine board informs the state of paper to CPU whether it is empty or not with operation of the actuator.

When cassette is empty, it detects the fact by reading the D0 Bit of CPU, and then informs the fact by selecting the second LED(yellow) among the panel LEDs.

3.3.1.5.2 MP Sensing

By operation of Actuator on the frame, MP Sensor (Photo interruptor) on the engine board informs the state of paper to CPU whether it is empty or not. It reads the D0 Bit of CPU for recognizing paper in MP, and paper is fed from MP if there is.

3.3.1.5.3 Paper Feeding/Width Toner Cartridge Sensing

When paper passes the actuator (feed sensor part), it detects the signal of Photo interrupter, informs the paper feeding state to CPU, and then sprays the image data after certain time.

If it doesn't detect the feed sensor within 1sec. after paper is fed, paper Jam0 (CPU #_) is occurred (Red and Yellow will be turned on among the OP panel LEDs), and the fact whether the developer is inserted or not is detected with the same principle. After the developer is mounted, the actuator is operated. The signal from the photo interrupter is detected when it is passing the actuator of the sensor part. That is the developer ID sensing.

3.3.1.5.4 Paper Exit Sensing

It detects paper state whether paper gets out from the set with operation of exit sensor on the engine board and actuator on the frame. Paper detects the on/off time of exit sensor by reading D2 Bit of CPU, and the normal operation or jam information is informed to the CPU.

The paper JAM2 is informed. (Red, Yellow LED will be turned on among the OP panel LEDs)

3.3.1.5.5 Cover Open Sensing

The Cover open sensor is located on the front cover. After the front cover is opened, +24V (DC fan, Solenoid, Main Motor, Polygon motor part of LSU and HVPS), which is supplied to the each unit, is cut off. The cover-open sensing is operated by the D0 bit of CPU, and the developer ID sensing is operated by D7 bit of CPU.

In case, the red LED among OP panel LEDs will be ON for informing the facts to user.

3.3.1.5.6 DC FAN / SOLENOID Driving

It is driven by transistor and controlled by D6 bit of CPU.

When it is high, the fan is driving by turning on the TR, and it is off when the sleep mode is selected. There are two solenoids, and they are driven by paper pick-up and MP signal. It is turned on or off by D4 bit of CPU, and its driving time is 300ms. The diode protects the driving TR from the noise pulse, which is flown when the solenoid id de-energizing.

FAN Driving Circuit is driven by Transistor, and controlled by D6 Bit of


3.3.1.5.7 Motor Driving

The motor driving circuit is formed when the Driver IC is selected in the first place. The A3977 Motor Driver IC is used in this case. But resistance Rs value of sensing and voltage value of the V reference can be changed by motor driving voltage value. The motor driving voltage is calculated with the following formula.

$I = V_{ref} / R_s$, wherein V_{ref} is $(R1 \times 5V) / (R1 + R2)$.

3.3.2 SMPS & HVPS board

Outputs 5V, 24V to supply the power to the main board and Optional Board(SCF, Duplex) (Not ADF Board)



3.3.2.1 HVPS (High Voltage Power Supply)

• Transfer High Voltage (THV+)

- Input Voltage : 24 V DC $\pm 15\%$
- Output Voltage : MAX +5.0KV $\pm 5\%$, (Duty Variable, no loading)
-1.2KV $\pm 15\%$ (when cleaning, 200 M Ω)
- Output Voltage Trigger : 6.5 μ A
- Input contrast of the Voltage stability degree : under $\pm 5\%$ (fluctuating input 21.6V ~ 26.4V)
Loading contrast : $\pm 5\%$ or less
- Output Voltage Rising Time : 100 ms Max
- Output Voltage Falling Time : 100 ms Max
- Fluctuating transfer voltage with environmental various : +650 V(Duty 10%) ~ 5 KV (Duty 90%)
- Environment Recognition Control Method : The THV-PWM ACTIVE is transfer active signal. It detects the resistance by recognizing the voltage value, F/B, while permits the environmental recognition voltage.
- Output Voltage Control Method : Transfer Output Voltage is outputted and controlled by changing Duty of THVPWM Signal. 10% Duty : +650V, 90%
Duty : +5KV $\pm 5\%$

• Fuser Voltage

- Input Voltage : 24 V DC $\pm 15\%$
- Output Voltage : 30V~1000V DC $\pm 30V$
- Output Voltage Rising Time : 50 ms Max
- Output Voltage Falling Time : 50 ms Max
- Output Loading range : 30 M Ω ~ 1000 M Ω
- Output Control Signal(MHV-PWM) : CPU is HV output when PWM is Low

• Cleaning Voltage (THV-)

- The (+) Transfer Voltage is not outputted because the THV PWM is controlled with high.
- The (-) Transfer Voltage is outputted because the THV-Enable Signal is controlled with low
- The output fluctuation range is big because there is no Feedback control.

• Developing Voltage (DEV)

- Input Voltage : 24 V DC $\pm 15\%$
- Output Voltage: -200V ~ -600V DC $\pm 20V$
- Output Voltage Fluctuation range: PWM Control
- Input contrast of the output stability degree : $\pm 5\%$ or less
Loading contrast : $\pm 5\%$ or less
- Output Voltage Rising Time : 50 ms Max
- Output Voltage Falling Time : 50 ms Max
- Output Loading range : 10M Ω ~ 1000 M Ω
- Output Control Signal (BIAS-PWM) : the CPU output is HV output when PWM is low.

• Supply

- Output Voltage : -400V~ -800V DC $\pm 50V$ (ZENER using, DEV)
- Input contrast of the output stability degree : under $\pm 5\%$
Loading contrast : $\pm 5\%$ or less
- Output Voltage Rising Time : 50 ms Max
- Output Voltage Falling Time : 50 ms Max
- Output Loading range : 10 M Ω ~ 1000 M Ω
- Output Control Signal (BIAS-PWM) : the CPU is HV output when PWM is low.

3.3.2.2 SMPS (Switching Mode Power Supply)

It is the power source of entire system. It is assembled by an independent module, so it is possible to use for common use. It is mounted at the bottom of the set.

It is consisted of the AMPS part, which supplies the DC power for driving the system, and the AC heater control part, which supplies the power to fuser. SMPS has two output channels. Which are 3.3V and +24V.

• AC Input

- Input Rated Voltage : AC 220V ~ 240V AC 120V / AC 220V(EXP version)
- Input Voltage fluctuating range : AC 198V ~ 264V AC 90V ~ 135V / AC 198V ~ 264V (EXP version)
- Rated Frequency : 50/60 Hz
- Frequency Fluctuating range : 47 ~ 63 Hz
- Input Current : Under 4.0Arms / 2.0Arms (But, the status when lamp is off or rated voltage is inputted/outputted)

• Rated Output Power

NO	ITEM	CH1	CH2	CH3
1	CHANNEL NAME	+5V	+24V1 + +24V2	
2	CONNECTOR PIN	CON 21 5V PIN: 12, 14, 16, 18 GND PIN: 20, 22, 24	CON 21 24V PIN : 2, 4, 6, 8 GND PIN : 26, 27, 28	
3	Rated Output	+5.0V \pm 5% (+4.75V ~ +5.25V)	+24.0V \pm 5% (+21.6V \pm 26.4V)	
4	Max.Output Current	4.0A	7.5A	
5	Peak Loading Current	4.4A	8.0 A	
6	RIPPLE NOISE Voltage	Under 100mVp-p	Under 100mVp-p	
7	Maximum output	16.0W	127.2W	
8	Peak output	20.0W	180.0W	
9	Protection for loading shortage and overflowing current	-	-	

• Power Consumption

NO	ITEM	CH1(+3.3V)	CH2(+5V)	CH3(24V)	System
1	Stand-By	1.0 A	0.07A	0.4 A	AVG : 55 Wh
2	PRINTING	1.0 A	0.14A	2.0 A	AVG : 280 Wh
3	Sleep-Mode	0.8A	0.01A	0.4A	AVG : 10 Wh

• Length of Power Cord : 1830 \pm 50mm

• Power Switch : Use

• Feature

- Insulating Resistance : 50MΩ or more (at DC 500V)
- Insulating revisiting pressure : Must be no problem within 1 min. (at 1500Vac, 10mA)
- Leaking Current : under 3.5mA
- Running Current : under 40A PEAK (AT 25°C, COLD START)
under 60A PEAK (In other conditions)
- Rising Time : within 2Sec
- Falling Time : over 20ms
- Surge : Ring Wave 6KV-500A (Normal, Common)

• Environment Condition

- Operating temperature range : 0°C ~ 40°C
- Maintaining temperature range : -25°C ~ 85°C
- Preserving Humidity Condition : 30% ~ 90% RH
- Operating atmospheric pressure range :

3.3.2.3 FUSER AC POWER CONTROL

Fuser(HEAT LAMP) gets heat from AC power. The AV power controls the switch with the Triac, a semiconductor switch. The ON/OFF control is operated when the gate of the Triac is turned on/off by Photo triac (insulating part).

In other words, the AC control part is passive circuit, so it turns the heater on/off with taking signal from engine control part.

When the HEATER ON signal is turned on at engine, the LED of PC1 (Photo Triac) takes the voltage and flashes. From the flashing light, the Triac part (light receiving part) takes the voltage, and the voltage is supplied to the gate of Triac and flows into the Triac. As a result, the AC current flows in the heat lamp, and heat is occurred.

On the other hand, when the signal is off, the PC1 is off, the voltage is cut off at the gate of Triac, the Triac becomes off, and then the heat lamp is turned off.

- Triac (THY1) feature : 12A, 600V SWITCHING
- Phototriac Coupler (PC3)
 - Turn On If Current : 15mA ~ 50mA (Design : 16mA)
 - High Repetive Peak Off State Voltage : Min 600V

3.3.3 Engine F/W

3.3.3.1. Control Algorithm

• Feeding

If feeding from a cassette, the drive of the pickup roller is controlled by controlling the solenoid. The on/off of the solenoid is controlled by controlling the general output port or the external output port. If feeding from a manual feeder, decide to insert the paper according to the operation of the manual sensor, and by driving the main motor, insert the paper in front of the feed sensor. While paper moves, occurrence of Jam is judged as below.

ITEM	Description
JAM 0	<ul style="list-style-type: none"> - After picking up, paper cannot be entered due to paper is not fed. - After picking up, paper entered but it cannot reach to the feed sensor in certain time due to slip, etc. - After picking up, if the feed sensor is not on, re-pick up. After re-picking up, if the feed sensor is not on after certain time, it is JAM 0. * It is a status that the leading edge of the paper doesn't pass the feed sensor. - Even though the paper reaches to the feed sensor, the feed sensor doesn't be ON. * It is a status that the leading edge of the paper already passes the feed sensor.
JAM 1	<ul style="list-style-type: none"> - After the leading edge of the paper passes the feed sensor, the trailing edge of the paper cannot pass the feed sensor after a certain time. (The feed sensor cannot be OFF) - After the leading edge of the paper passes the feed sensor, the paper cannot reach the exit sensor after certain time. (The exit sensor cannot be ON) * The paper exists between the feed sensor and the exit sensor.
JAM 2	<ul style="list-style-type: none"> - After the trailing edge of the paper passes the feed sensor, the paper cannot pass the exit sensor after certain time.
DUPLEX JAM 1	<ul style="list-style-type: none"> - After the trailing edge of the paper passes the exit sensor, the leading edge of the paper cannot reach the duplex sensor after certain time.
DUPLEX JAM 0	<ul style="list-style-type: none"> - After the leading edge of the paper passes the duplex sensor, the leading edge of the paper cannot reach the feed sensor after certain time.

3.3.3.1.2 Driver

By gearing, the main motor drives the rollers such as feeding roller, developing roller, fuser roller, and exiting roller. The step motor is controlled for the such acceleration section and steady section. In the initial stage of the motor run, appoint the acceleration section to prevent the step-out of the motor. It is controlled by the A 3977 motor driver IC. The step signal and the enable signal are sent to make the phase for driving the motor in CPU.

3.3.3.1.3 Transfer

The charging voltage, developing voltage and the transfer voltage are controlled by PWM (Pulse Width Modulation). The each output voltage is changeable due to the PWM duty. The transfer voltage admitted when the paper passes the transfer roller is decided by environment recognition. The resistance value of the transfer roller is changed due to the surrounding environment or the environment of the set, and the voltage value, which changes due to the environments, is changed through AD converter. The voltage value for impressing to the transfer roller is decided by the changed value. Each voltage value is controlled according to 3.3.4.2 Timing Chart.

3.3.3.1.4 Fusing

The temperature change of the heat roller's surface is changed to the resistance value through the thermistor. By converting the voltage value, which is impressed to the resistance, to the digital value through the AD converter, the temperature is decided. The AC power is controlled by comparing the target temperature to the value from the thermistor. If the value from the thermistor is out of the controlling range while controlling the fusing, the error stated in the below table occurs.

• Lamp Method

Error	Description	LCD Display
OPEN HEAT ERROR	- When warming up, it has been lower than 60 °C over 35 seconds	"ENGINE FUSER ERROR"
LOW HEAT ERROR	- Standby It has been lower than 130 °C over 10 seconds - Printing Up to 2 consecutive pages : It has been lower than 155 °C over 7 seconds. From 3 consecutive pages : It has been 25 °C lower than the fixed fusing temperature over 7 seconds.	"ENGINE LOW HEAT ERROR"
OVER HEAT ERROR	It has been higher than 230 °C over 10 seconds	"ENGINE OVERHEAT ERROR"

=>This can be changed in the future.

3.3.3.1.5 LSU

The LSU is consisted of the LD (Laser Diode) and the polygon motor control. When the printing signal occurs, it turns on the LD and drives the polygon motor. When the detector detects the beam, Hsync occurs. When the polygon motor speed becomes steady, Lready occurs. If two conditions are satisfied, the status are not satisfied, the error shown in below occurs.

Error Type	Description	LCD Display
Polygon Motor Error	When the polygon motor speed doesn't become steady	"LSU NOT READY"
Hsync Error	The polygon motor speed is steady but the Hsync is not generated	"HSYNC ERROR"

4. Alignment and Adjustments

This chapter describes the main functions for service, such as the product maintenance method, the test output related to maintenance and repair, DCU using method, Jam removing method, and so on. It includes the contents of manual.

4.1 How to use EDC (Engine Diagnostic Control) Mode

4.1.1 EDC Setup

EDC(Engine Diagnostic Control, EDC will be used below) is considered to test and check whether each functions of machinery and h/w module are normal or not. All of the test function are able to be controlled by the keys and LCD window on the panel without any other kits. It's developed for related engineers, not for users.

4.1.2 Entrance method for EDC

In order to enter the “EDC” mode, the entering method should be special because this mode is developed for engineers related, not for end users.

- Entering the mode, the message, “COMPONENT TEST/Press Menu Key” is displayed.
- In this mode, an engineer should press the “Menu Key” to search each function he would like to test.

- **Usage**

1. Check printer is powered on.
2. Wait until the printer becomes a ready mode.
3. Press “Menu -> Stop -> Left -> Back -> Ok -> Right” in order.
4. Confirm the message “COMPONENT TEST/Press Menu Key” is displayed.
5. Press “Menu” key.
6. Follow a usage for a function you would like to use.

* The procedure and content above can be changed according to the situation.

4.1.3 Cover Status

This function is to check all cover and all doors status.

- **Usage**

1. Press the "Arrow Keys (◀/▶)" until finding "Component Test / 1.Cover Status" message on the panel.
2. Press the "OK Key", when it is found.
3. Press the "Arrow keys" until finding a suitable function (Refer to the table below).
4. Press the "OK Key", when it is found.
5. Press the "OK Key" for execution or the "Back key" for return.

- **Function**

Function Name	Description	Display(LCD)	Remarks
Top Cover	If the cover is opened, "Open" message will be displayed and if not, "Closed" displayed.	Top Cover [Closed]/[Open]	
Tray1 Cassette	If the Tray is opened, "Open" message will be displayed and if not, "Closed" displayed.	Tray1 Cassette [Closed]/[Open]	
Tray2 Cassette	If the Tray is opened, "Open" message will be displayed and if not, "Closed" displayed.	Tray2 Cassette [Closed]/[Open]	
Tray3 Cassette	If the Tray is opened, "Open" message will be displayed and if not, "Closed" displayed.	Tray3 Cassette [Closed]/[Open]	
Tray4 Cassette	If the Tray is opened, "Open" message will be displayed and if not, "Closed" displayed.	Tray4 Cassette [Closed]/[Open]	
Fuser Door	If the Door is opened, "Open" message will be displayed and if not, "Closed" displayed.	Fuser Door [Closed]/[Open]	

- The procedure and content above can be changed according to the situation.

4.1.4 Sensor Status

These Functions are to check a current state (normal or not) of each Sensor.

• Usage

- The other sensors

1. Press the "Arrow Keys (◀/▶)" until finding "Component Test / 2.Sensor Status" message on the panel.
2. Press the "OK Key", when it is found.
3. Press the "Arrow keys" until finding a suitable function. (Refer to the table below)
4. Press the "OK Key", when it is found.
3. Touch a sensor you would like to test.
4. Check the message on the LCD window for the state of it.

• Function

Sensor	Description	Display (LCD)		Remarks
		Before touching	After touching	
RegiSensor	See the message after touching the sensor.	Regi. Sensor [Without Paper]	Regi. Sensor [With Paper]	
T1 FeedSensor	See the message after touching the sensor.	T1 Feed Sensor [Without Paper]	T1 Feed Sensor [With Paper]	
T2 FeedSensor	See the message after touching the sensor.	T2 Feed Sensor [Without Paper]	T2 Feed Sensor [With Paper]	
T3 FeedSensor	See the message after touching the sensor.	T3 Feed Sensor [Without Paper]	T3 Feed Sensor [With Paper]	
T4 FeedSensor	See the message after touching the sensor.	T4 Feed Sensor [Without Paper]	T4 Feed Sensor [With Paper]	
ExitSensor	See the message after touching the sensor.	Exit Sensor [Without Paper]	Exit Sensor [With Paper]	
DJam1Sensor	See the message after touching the sensor.	DJam1 Sensor [Without Paper]	Djam1 Sensor [With Paper]	
Out Bin Sensor	See the message after touching the sensor.	OutBin. Sensor [Normal]	OutBin Sensor [Full]	
Bypass Empty	See the message after touching the sensor.	Bypass Empty [Empty]	Bypass Empty [Present]	
T1 Paper Empty	See the message after touching the sensor.	T1 Paper Empty [Empty]	T1 Paper Empty [Present]	
T2 Paper Empty	See the message after touching the sensor.	T2 Paper Empty [Empty]	T2 Paper Empty [Present]	
T3 Paper Empty	See the message after touching the sensor.	T3 Paper Empty [Empty]	T3 Paper Empty [Present]	

Sensor	Description	Display (LCD)		Remarks
		Before touching	After touching	
T4 Paper Empty	See the message after touching the sensor.	T4 Paper Empty [Empty]	T4 Paper Empty [Present]	
T1 PSize0 Sen.	See the message after touching the sensor.	T1 Psize0 Sen. [Low]	T1 Psize0 Sen. [High]	
T1 PSize1 Sen.	See the message after touching the sensor.	T1 Psize1 Sen. [Low]	T1 Psize1 Sen. [High]	
T1 PSize2 Sen.	See the message after touching the sensor.	T1 Psize2 Sen. [Low]	T1 Psize2 Sen. [High]	
T2 PSize0 Sen.	See the message after touching the sensor.	T2 Psize0 Sen. [Low]	T2 Psize0 Sen. [High]	
T2 PSize1 Sen.	See the message after touching the sensor.	T2 Psize1 Sen. [Low]	T2 Psize1 Sen. [High]	
T2 PSize2 Sen.	See the message after touching the sensor.	T2 Psize2 Sen. [Low]	T2 Psize2 Sen. [High]	
T3 PSize0 Sen.	See the message after touching the sensor.	T3 Psize0 Sen. [Low]	T3 Psize0 Sen. [High]	
T3 PSize1 Sen.	See the message after touching the sensor.	T3 Psize1 Sen. [Low]	T3 Psize1 Sen. [High]	
T3 PSize2 Sen.	See the message after touching the sensor.	T3 Psize2 Sen. [Low]	T3 Psize2 Sen. [High]	
T4 PSize0 Sen.	See the message after touching the sensor.	T4 Psize0 Sen. [Low]	T4 Psize0 Sen. [High]	
T4 PSize1 Sen.	See the message after touching the sensor.	T4 Psize1 Sen. [Low]	T4 Psize1 Sen. [High]	
T4 PSize2 Sen.	See the message after touching the sensor.	T4 Psize2 Sen. [Low]	T4 Psize2 Sen. [High]	
TOP Margin Sen	See the message after touching the sensor.	TOP Margin Sen. [Without Paper]	TOP Margin Sen. [With Paper]	
DPX Detect Sen	See the message after touching the sensor.	DPX Detect Sen [Low]	DPX Detect Sen [High]	

* The procedure and content above can be changed according to the situation.

4.1.5 Motor Test

These functions are to check a current state (normal or not) of all motors.

• Usage

1. Press the “Arrow Keys (◀/▶)” until finding “Component Test / 3.Motor Test” message on the panel.
2. Press the “OK Key”, when it is found.
3. Press the “Arrow keys” until finding a suitable function (Refer to the table below).
4. Press the “OK Key”, when it is found.
5. Press the “OK Key” for execution or the “Back key” for return.

• Function

Function Name	Description	Display(LCD)
Main Mtr Fwd.	The motor will run on the forward direction or stop.	Main Mtr Fwd. [ON] / [OFF]
Main Mtr Bwd.	The motor will run on the backward direction or stop.	Main Mtr Bwd. [ON] / [OFF]
Main Mtr Slow.	The motor will run on the forwarding direction by half speed.	Main Mtr Slow. [ON] / [OFF]
Dev Mtr Nor.	The motor will run on the forwarding direction by normal speed.	Dev Mtr Slow. [ON] / [OFF]
Dev Mtr Slow.	The motor will run on the forwarding direction by half speed.	Dev Mtr Slow. [ON] / [OFF]
Duplex Mtr Fwd.	The motor will run on the forwarding direction.	Duplex Mtr Fwd. [ON] / [OFF]
T2 Feed Motor	The motor will run on the forward direction or stop.	T2 Feed Motor [ON] / [OFF]
T3 Feed Motor	The motor will run on the forward direction or stop.	T3 Feed Motor [ON] / [OFF]
T4 Feed Motor	The tray2 motor will run on the forward direction or stop.	T Feed Motor [ON] / [OFF]

* The procedure and content above can be changed according to the situation.

4.1.6 Fan Test

These functions are to check a current state (normal or not) of all fans.

• Usage

1. Press the “Arrow Keys (◀/▶)” until finding “Component Test / 4.Fan Test” message on the panel.
2. Press the “OK Key”, when it is found.
3. Press the “Arrow keys” until finding a suitable function (Refer to the table below).
4. Press the “OK Key”, when it is found.
5. Press the “OK Key” for execution or the “Back key” for return.

• Function

Function Name	Description	Display(LCD)
Fuser Fan	The fan will run or stop.	Fuser Fan [ON] / [OFF]
Fuser Fan Rdy	Check whether the fan is in locked state.	Fuser Fan Rdy. [Ready] / [Not Ready]
SMPS Fan	The fan will run or stop.	SMPS Fan [ON] / [OFF]
SMPS Fan Rdy	Check whether the fan is in locked state.	SMPS Fan Rdy. [Ready] / [Not Ready]
Duplex Fan	The fan will run or stop.	Duplex Fan [ON] / [OFF]

* The procedure and content above can be changed according to the situation.

4.1.7 Clutch / Sol

These functions are to check a current state (normal or not) of the solenoids and clutches.

• Usage

1. Press the "Arrow Keys (◀/▶)" until finding "Component Test / 5.Clutch/Sol Test" message on the panel.
2. Press the "OK Key", when it is found.
3. Press the "Arrow keys" until finding a suitable function. (Refer to the table below)
4. Press the "OK Key", when it is found.
5. Press the "OK Key" for execution or the "Back key" for return.

• Function

Function Name	Description	Display(LCD)
T1 P-up Clutch	The clutch will run or stop.	T1 P-up Clutch [ON] / [OFF]
T2 P-up Clutch	The clutch will run or stop.	T2 P-up Clutch [ON] / [OFF]
T3 P-up Clutch	The clutch will run or stop.	T3 P-up Clutch [ON] / [OFF]
T4 P-up Clutch	The clutch will run or stop.	T4 P-up Clutch [ON] / [OFF]
Bypass Clutch	The clutch will run or stop.	Bypass Clutch [ON] / [OFF]
Duplex Sol.	The solenoid will run or stop.	Duplex Sol. [ON] / [OFF]

* The procedure and content above can be changed according to the situation.

4.1.8 Fuser Ctrl

This function is to check a current state (normal or not) of the fuser unit.

• Usage

1. Press the "Arrow Keys (◀/▶)" until finding "Component Test / 6.Fuser Ctrl" message on the panel.
2. Press the "OK Key", when it is found.
3. Press the "Arrow keys" until finding a suitable function. (Refer to the table below)
4. Press the "OK Key", when it is found.
5. Press the "OK Key" for execution or the "Back key" for return.

• Function

Function Name	Description	Display(LCD)	Remarks
Fuser Bias	The bias will have the saved value previously	Fuser Bias [ON] / [OFF]	
Temp Control	The fuser unit will control the power for fixing and display the current temperature on the panel. The target temperature is 160℃.	Temp Control [OFF] / [ON] [xxx]	[xxx] is a current temperature.
Fuser Temp	The ADC will be displayed on the panel.	Fuser Temp [xxx]	[xxx] is it's ADC.
Inner Temp	The ADC will be displayed on the panel.	Inner Temp [xxx]	[xxx] is it's ADC.

* The procedure and content above can be changed according to the situation

4.1.9 LSU

These functions are to check a current state (normal or not) of the Laser Scanning Unit.

• Usage

1. Press the "Arrow Keys (◀/▶)" until finding "Component Test / 7.LSU Control" message on the panel.
2. Press the "OK Key", when it is found.
3. Press the "arrow keys" until finding a suitable function. (Refer to the table below)
4. Press the "OK Key", when it is found.
5. Press the "OK Key" for execution or the "Cancel key" for stop.

• Function

Function Name	Description	Display(LCD)	Remarks
LD Power 1&2	The LD will have the saved value previously	LD Power 1&2 [ON] / [OFF]	
Laser Motor	The motor will run or stop.	Laser Motor [ON] / [OFF]	
Laser Ready	When Laser Scanning Unit is ready to print (Laser diode on, Stable polygon motor speed) the message, "Normal" is displayed. On the other case "Fault"	Laser Ready [Normal]	

* The procedure and content above can be changed according to the situation.

4.1.10 Deve Control

These functions are to check whether the control for HVPS is normal or not.

• Usage

1. Press the "Arrow Keys (◀/▶)" until finding "Component Test / 8.Deve Control" message on the panel.
2. Press the "OK Key", when it is found.
3. Press the "arrow keys" until finding a suitable function. (Refer to the table below)
4. Press the "OK Key", when it is found.
5. Press the "OK Key" for execution or the "Cancel key" for stop.

• Function

Function Name	Description	Display(LCD)	Remarks
THV Plus Bias	The bias will have the previously saved value.	THV Plus Bias [ON] / [OFF]	
THV Minus Bias	The bias will have the previously saved value.	THV Minus Bias [ON] / [OFF]	
DEV Bias	The bias will have the previously saved value.	DEV Bias [ON] / [OFF]	
DEV AC Bias	The bias will have the previously saved value.	DEV AC Bias [ON] / [OFF]	
DEV Vpp Bias	The bias will have the previously saved value.	DEV Vpp Bias [ON] / [OFF]	
MHV Bias	The bias will have the previously saved value.	MHV Bias [ON] / [OFF]	
PTL	The lamp will be lighted or not.	PTL [ON] / [OFF]	

Function Name	Description	Display(LCD)	Remarks
Erase Lamp	The lamp will be lighted or not.	Erase Lamp [ON] / [OFF]	
THV Read	The Adc will be displayed on the panel.	THV Read [xxx]	[xxx] is it's ADC
MHV Read	The Adc will be displayed on the panel.	MHV Read [xxx]	xxx] is it's ADC

* The procedure and content above can be changed according to the situation.

4.1.11 Print Test and Option version

These functions are to check a total print process state and the option s' version.

• Usage


1. Press the "Arrow Keys (◀/▶)" until finding "Component Test / 10.Print Test" message on the panel.
2. Press the "OK Key", when it is found.
3. Press the "arrow keys" until finding a suitable function. (Refer to the table below)
4. Press the "OK Key", when it is found.
5. Press the "OK Key" for execution or the "Cancel key" for stop.

• Function


Function Name	Description	Display(LCD)	Remarks
Pattern Print	The printer can print the previously saved mode (Simplex or Duplex / Copy/ pattern kind)	Pattern Print [ON]	
T2 Version	This is the version for Tray2	T2 Version [x.xx]	x.xx is version.
T3 Version	This is the version for Tray3	T3 Version [x.xx]	x.xx is version.
T4 Version	This is the version for Tray4	T4 Version [x.xx]	x.xx is version.
Duplex Version	This is the version for Duplex	Duplex Version [x.xx]	x.xx is version.

* The procedure and content above can be changed according to the situation.


4.2 Paper Path




- | | |
|---------------------|-------------------|
| ❶ Cassette | ❷ Duplex |
| ❸ MPF | ❹ Print Cartridge |
| ❺ LSU | ❻ Fuser |
| ❼ SMPS & HVPS Board | ❽ Duplex Solenoid |




<Jam 0>




<Jam 1>



<Jam 2>



<Jam Duplex 1>



<Jam Duplex 0>

• Simplex

- 1) A paper is fed from a cassette or MPF by a printing order.
- 2) The fed paper passes a paper feeding sensor.
 - If the sensor does not operate after feeding the paper, the Jam0 occurs.
- 3) The paper passes a paper exit sensor, and it comes out from a machine.
 - If the trailing edge of the paper does not come out from a machine after the leading edge of the paper passes the sensor, then certain time later, a Jam2 occurs.

• Duplex

- 1) A paper is fad from a cassette or MPF by a printing order.
- 2) The fed paper passes a paper feeding sensor.
 - If the sensor does not operate after feeding the paper, a Jam0 occurs.
- 3) The paper that passes a paper exit sensor takes several printing processes, and moves to a paper exit sensor.
 - If the sensor does not operate after certain time, a Jam 1 occurs.
- 4) If the paper does not discharge until the paper passes an exit roller and a Roller-Exit-F/Down, a Jam 2 occurs.
- 5) The printing paper starts to be printed for duplex only by reversing rotation by an exit motor. The printing paper enters to a machine through an exit roller, and reaches to duplex sensor.
 - If the printing paper cannot reach to the duplex sensor after certain time, a duplex Jam 1 occurs.
- 6) The printing paper that passes the duplex sensor reaches to a feed sensor again and a printing operation is tried over again.
 - If the printing paper cannot reach to a feed sensor after certain time later, a duplex Jam 2 occurs.

4.2.1 Clearing Paper Jams


Note : When removing paper that is jammed in the printer, if possible always pull the paper in the direction that it normally moves so as not to damage internal components. Always pull firmly and evenly; do not jerk the paper. If the paper tears, ensure that all fragments of paper are removed; otherwise a jam will occur again.

When a paper jam occurs, the Status LED lights red. Open and close the top cover. The jammed paper automatically exits the printer. If the paper does not exit, check the display on the control panel. The message indicating the corresponding location of the paper jam appears. Refer to the table below to locate the paper jam and to clear it:


4.2.1.1 In the paper feed area

• In the Tray1

1. Pull the tray 1 open.



2. Remove the jammed paper by gently pulling it straight out. Make sure that all of the paper is properly aligned in the tray 1.




If the paper does not move when you pull, or if you do not see the paper in this area, check the fuser area around the toner cartridge.


3. Insert the tray 1 into the printer until it snaps into place. Printing automatically resumes.

• In the optional tray

1. Pull the optional tray open.
2. Remove the jammed paper from the printer.
3. Pull the upper tray half way out.
4. Pull the jammed paper straight up and out.




If the paper does not move when you pull, or if you do not see the paper in this area, stop and go to step 3.



5. Fully insert the trays back into the printer. Printing automatically resumes.

• In the multi-purpose tray

1. If the paper is not feeding properly, pull the paper out of the printer.




2. Open and close the top cover to resume printing.
3. Open and close the top cover. Printing can be resumed.

4.2.1.2 Around the printer cartridge

Note : The fuser area is hot. Take care when removing paper from the printer.


1. Open the top cover and pull the printer cartridge out.




Caution :

- To prevent damage to the printer cartridge, do not expose it to light for more than a few minutes. Cover it with a piece of paper, if necessary.
- Do not touch the green surface underside of the printer cartridge. Use the handle on the cartridge to avoid touching this area.

2. Carefully lift up the guide feed.




3. Remove the jammed paper by gently pulling it straight out.



If you do not see the jammed paper or if there is any resistance removing the paper, stop pulling and go to the paper exit area.

4. Flip down the guide feed.




5. Replace the printer cartridge and close the top cover. Printing automatically resumes.

Note : If it is difficult to reinstall the printer cartridge, make sure that the guide feed has been flipped back down into position.


4.2.1.3 In the paper exit area

1. Open and close the top cover. The jammed paper is automatically ejected from the printer.
2. Gently pull the paper out of the output tray.



If you do not see the jammed paper or if there is any resistance when you pull, stop and go to the next step.


3. Open the rear cover.
4. By pushing the fuser levers upwards, loosen the jammed paper. Then gently pull the paper straight out.




4.2.1.4 In the duplex unit area

• Duplex jam 0

1. Pull the duplex unit out of the printer.




2. Locate the jammed paper and remove it.




3. Insert the duplex unit into the slot.
4. Open and close the top cover. The printer will resume printing.

• Duplex jam 1

1. Open the rear cover.



2. Gently pull the jammed paper straight up.



3. Close the rear cover.

4. Open and close the top cover. The printer will resume printing.

4.3 Sample Pattern

This product has the several sample patterns for maintenance. With the sample patterns, check the existence of the abnormality. The patterns help to regularly maintain the product.

4.3.1 Information Pages

Your printer comes with a set of information pages that helps you solve printing problems and obtain the best results from your printer. You can access these pages from the printer's front panel.

To print information pages:

1. On the printer's front panel, press the Menu button, then press the Enter button to select Information.
2. Select Info Pages, then press the Enter button.
 - ① Select key(◀/▶), find to information menu.
 - ② Press Enter key, switch to information page.
 - ③ Press Enter key, the printing.
- * 3. Select the appropriate information page, then press the Enter button to print.

* If installed The HDD, select press(1~3 times), then display information menu.

Note : Print the "Menu Map" to see other information pages available for printing.

4.3.2 Demo Pages

Your printer comes with a set of sample pages which demonstrate different functions.


To print sample pages:

1. On the printer's front panel, press the Menu button, then press the OK button to select Information.
2. Select Demo Pages, then press the OK button.
3. Select the desired sample page, then press the OK button to print.

4.4 Periodic Defective Image

If the delinquent image regularly occurs in the printed-paper, it is due to delinquent or damaged roller. Refer to the table in below and check the condition of the roller.

No	Roller	Defective image	Typical defect
1	OPC Drum	95 mm	white spot on black image or black spot, image ghost
2	Charge Roller	38 mm	black spot
3	Supply Roller	45 mm	light or dark horizontal image band
4	Developing Roller	43 mm	horizontal image band, image ghost
5	Transfer Roller	55 mm	image ghost
6	Heat Roller	126 mm	Black spot and image ghost
7	Pressure Roller	126 mm	black spot on the backside



<Rollers Layout>

4.5 Error Messages

Messages appear on the Smart Panel program window or the control panel display to indicate the printer's status or errors. Refer to the tables below to understand the messages' meaning and correct the problem if necessary. Messages and their meanings are listed in alphabetical order.

Message	Meaning	Suggested solutions
ADC Not Confirm Error	There is a problem in your printer system.	Unplug the power cord and plug it back in. If the problem persists, please call for service.
Door Open	The top cover or rear cover is not securely latched.	Close the cover until it locks into place.
Duplex Jam 0 Check Inside	Paper has jammed during duplex printing.	Clear the jam.
Duplex Jam 1 Open/Close Door	Paper has jammed during duplex printing.	Clear the jam.
Fuser Door Open	The fuser door is not securely latched.	Open the rear cover and close the fuser door until it locks into place.
Fuser is Cleaning	Your printer is printing a leaning sheet now.	Please wait a few minutes.
Inner Temp. Open Cycle Power	There is a problem in your printer system.	Unplug the power cord and plug it back in. If the problem persists, please call for service.
Inner Temp. Short Cycle Power	There is a problem in your printer system.	Unplug the power cord and plug it back in. If the problem persists, please call for service.
Install Toner	① A toner cartridge is not installed. ② View of when the inner terminal of the set and the DEVE is not connected properly.	① Install a toner cartridge. ② Check if there is any deformity at the inner terminal of the set, or check the CRUM at the DEVE for any polluted areas.
Invalid Toner	The toner cartridge you have installed is not for your printer.	Install a Samsung-genuine toner cartridge, designed for your printer.
Load [Size] In [Tray]	The paper size specified in the printer properties does not match the paper you are loading.	Load the correct paper in the tray.
Load Manual Press Cont Key	The multi-purpose tray is empty in manual feed mode.	Load a sheet of print media and press OK. You need to press OK each page to be printed.
Low Heat Error Cycle Power	There is a problem in the fuser unit.	Unplug the power cord and plug it back in. If the problem persists, please call for service.

Message	Meaning	Suggested solutions
LSU Motor Error Cycle Power	A problem has occurred in the LSU (Laser Scanning Unit).	Unplug the power cord and plug it back in. If the problem persists, please call for service.
MP Tray Paper Empty	There is no paper in the multi-purpose tray.	Load paper in the multi-purpose tray.
OPC is Cleaning	Your printer is printing a cleaning sheet now.	Please wait a few minutes.
Open Heat Error Cycle Power	There is a problem in the fuser unit.	Unplug the power cord and plug it back in. If the problem persists, please call for service.
Out-Bin Full	The output tray is full.	It can hold up to 250 sheets of plain paper. Once the paper is removed from the output tray, the printer resumes printing.
Over Heat Error Cycle Power	There is a problem in the fuser unit.	Unplug the power cord and plug it back in. If the problem persists, please call for service.
Paper Exit Jam 1 Open/Close Door	Paper has jammed before reaching to the exit sensor.	Clear the jam.
Paper Jam 0 Open/Close Door	Paper has jammed in the feeding area of the tray.	Clear the jam.
Paper Jam 1 Open/Close Door	Paper has jammed in the fuser area.	Clear the jam.
Paper Jam 2 Check Inside	Paper has jammed in the paper exit area.	Clear the jam.
Paper [Tray] Jam Open [Tray]	Paper has jammed in the displayed optional tray.	Clear the jam.
Printing...	The printer is printing jobs.	Complete your printing.
Ready	The printer is on-line and ready to print.	Use your printer.
Replace Toner	This message appears between the Toner Empty status.	Replace the toner cartridge with a new one.
Self Diagnostic LSU	The LSU (Laser Scanning Unit) in your printer is checking some problems detected.	Please wait a few minutes.
Self Diagnostic Temperature	The engine in your printer is checking some problems detected.	Please wait a few minutes.
Sleeping...	The printer is in power save mode.	When data is received, it switches to on-line automatically.

Message	Meaning	Suggested solutions
Toner Emhaust	The life of the toner cartridge in end.	Replace the toner cartridge with a new one
Toner Low	The displayed toner cartridge is almost empty.	Take out the toner cartridge and thoroughly shake it. By doing this, you can temporarily reestablish printing operations.
[Tray] Cassette Out	The displayed tray is open.	Close the tray until it locks into place.
[Tray] Paper Empty	There is no paper in the tray.	Load paper in the tray.
Warming Up Please Wait...	Your printer is warming up now.	Please wait a few minutes.

5. Disassembly and Reassembly

5.1 General Precautions on Disassembly

When you disassemble and reassemble components, you must use extreme caution. The close proximity of cables to moving parts makes proper routing a must.

If components are removed, any cables disturbed by the procedure must be restored as close as possible to their original positions. Before removing any component from the machine, note the cable routing that will be affected.


Whenever servicing the machine, you must perform as follows:

1. Check to verify that documents are not stored in memory.
2. Be sure to remove the print cartridge before you disassemble parts.
3. Unplug the power cord.
4. Use a flat and clean surface.
5. Replace only with authorized components.
6. Do not force plastic-material components.
7. Make sure all components are in their proper position.

Releasing Plastic Latches


Many of the parts are held in place with plastic latches. The latches break easily; release them carefully.

To remove such parts, press the hook end of the latch away from the part to which it is latched.




5.2 Transfer Roller

1. Open the Open Cover.




2. Hold the lever at both ends of the roller, then remove the roller.




<Cautions When Replacing a Transfer Roller>

- * Do not grab the Transfer Roller shown in picture (A). It may cause a malfunction due to a foreign object.
- * Hold the both side of the Transfer Roller shown in picture (B) when replacing it.




(A)




(B)

5.3 MPF Ass'y


1. Open the MPF Ass'y.




3. Remove the Tray Link from the MP Cover.




2. Remove two springs from the Knock Up Plate Ass'y.




4. Push the MP Cover and remove it, as shown below.



5. Remove MP Cover in the direction of arrow, as shown below.




*** NOTICE :** Do not separate the spring from the MP Pick Up Rack for convenience of assembling. Locate the hook section of the spring that is connected to the Knock Up Plate Ass'y as shown in the outside for convenience of assembling.




5.4 Holder Pad Ass'y

- Before you remove the Holder Pad Ass'y, you should remove : -MPF Ass'y (Refer to the 5.3)
- Unplug the connector and remove the three screws, as shown below.




- Remove the Photo Interrupter and the MP Actuator, as shown below.




5.5 Roller Idle ASS'Y

1. Remove the Roller Ass'y, as shown below.




2. Release the lock as shown below and take out the retard Ass'y.



5.6 Feed2 Idle Unit


1. Before you remove the Feed2 Idle Unit, you should remove :
 - Holder Pad Ass'y (Refer to the 5.4)

2. Remove four screws. Then lift the Idle Unit, as shown below.




5.7 Cover Right


1. Pull the Cassette out of the printer.



2. Remove the Cover Dummy and Cover Control Box.




3. Remove two screws and take out the right side, as shown below.




5.8 Main PBA

1. Before you remove the Main PBA, you should remove: - Cover Right (Refer to the 5.7)


2. Unplug the all Connectors, as shown below.




3. The Connectors are located, as shown below.



4. Remove two screws and take out the Dummy Bracket.




5. Remove six screws and take out the Main PBA.



5.9 Main Drive Ass'y


- Before you remove the Main Drive Ass'y, you should remove :
- Cover Right (Refer to the 5.7)

- Unplug the Connector from the Main Motor Ass'y, as shown below.




Notice : Make sure the Power Switch is turned off before disassembling the Motor Connector.


- Remove the Feed1 Gear, as shown below.



- Remove five screws and take out the Main Drive Ass'y.




- When separating the Main Motor Ass'y, disconnect the Connector from the Main Motor Ass'y, remove four screws, and then remove the Main Motor Ass'y.




5.10 DEVE Drive Ass'y

1. Before you remove the DEVE Drive Ass'y, you should remove : - Cover Right (Refer to the 5.7)
2. Unplug the Connector from the DEVE Motor Ass'y, as shown below.




Notice : Make sure the Power Switch is turned off before disassembling the Motor Connector.

3. Remove four screws and take out the DEVE Drive Ass'y.




4. When separating the DEVE Motor Ass'y, disconnect the Connector from the DEVE Motor Ass'y, remove three screws, and then remove the DEVE Motor Ass'y.




5.11 Connector PBA

1. Before you remove the Connector PBA, you should remove : - Cover Right (Refer to the 5.7)
2. Unplug the all Connectors from the Connector PBA and take it out.




3. The Connectors are located, as shown below.




5.12 Solenoid

1. Before you remove the Solenoid, you should remove:
 - Cover Right (Refer to the 5.7)
 - Main Drive Ass'y (Refer to the 5.9)
2. Unplug the MP Solenoid Harness and the Main Solenoid Harness from the Connector PBA.




4. Remove one screws and take out the Main Solenoid.




***NOTICE :** It is not necessary to disassemble the Main Drive Ass'y to remove the MP Solenoid.

3. Remove one screws and take out the MP Solenoid.




5.13 Rear Cover

1. Open the Rear Cover, and then take out the Stopper.




2. Remove the Rear Cover in the direction of arrow




5.14 Cover Left


1. Pull the Cassette out of the printer.



3. Take out the Cover Left.




2. Remove two screws and take out the left side.




5.15 Top Cover


- Before you remove the Top Cover, you should remove:
 - Rear Cover (Refer to the 5.14)
 - Cover Right (Refer to the 5.7)
 - Cover Left (Refer to the 5.13)
- Open the MPF Ass'y, the Rear Cover, the Open Cover.




- Unplug the two Connectors after you remove the three screws from the Main PBA.




- Unlatch both ends of the Top Cover.



- Unlatch the hook and take out the Top Cover.




6. Remove seven screws and then take out the LCD Panel and the Key Panel.




5.16 Open Cover

- Before you remove the Open Cover, you should remove:
 - Top Cover (Refer to the 5.15)
- Remove two screws and take out the Stopper.




- Take out the Open Cover, as shown below.




5.17 Inner Cover

1. Before you remove the Inner Cover, you should remove:
 - MPF Ass'y (Refer to the 5.3)
 - Top Cover (Refer to the 5.15)
2. Remove two screws and take out the Inner Cover.




5.18 Fuser Ass'y



- Before you remove the Fuser Ass'y, you should remove:
- Rear Cover (Refer to the 5.14)
- Pull the Locking Lever. Then take out the Fuser Ass'y, as shown below.




- Remove two screws and take the Thermostat out of the Fuser Ass'y.




- Remove two screws securing the Electrode L, R and remove it, as shown below.




- Remove two screws securing the Fuser Upper Unit and remove it, as shown below.




6. Remove two screws securing the Release Lever L,R and remove it, as shown below.




7. Remove two screws and take out the Gear Bracket.



8. Take out the Heat Roller Ass'y, as shown below.




9. Remove the screw securing the Thermistor and remove it, as shown below.




5.19 Duplex Solenoid Ass'y


1. Before you remove the Exit Solenoid Ass'y, you should remove:
 - Top Cover (Refer to the 5.15)
2. Unplug the Duplex Solenoid Harness from the Main PBA.



4. Remove spring pin and remove two screws and take out the Exit Solenoid.



3. Remove three screws and take out the Exit Solenoid Ass'y.




5.20 Exit Roller


1. Before you remove the Exit Roller, you should remove:

- Top Cover (Refer to the 5.15)


2. Take out the Actuator.




3. Remove the Exit Roller and Bearing, as shown below.




4. Release the Exit Gear, as shown below.



5. Remove the Duplex Exit Roller as same method.



6. Release the Duplex Exit Gear, as shown below.




5.21 LSU

1. Before you remove the LSU, you should remove:


- Rear Cover (Refer to the 5.14)
- Cover Right (Refer to the 5.7)
- Cover Left (Refer to the 5.13)
- Top Cover (Refer to the 5.15)

2. Remove the Cover-Frame Exit and unplug the



Connector from the Main PBA, as shown below.


3. Remove three screws and take out the LSU.




5.22 DC Fan

1. Before you remove the DC Fan, you should remove:
 - Cover Right (Refer to the 5.7)
 - Cover Left (Refer to the 5.13)
 - Cover Rear (Refer to the 5.14)

2. Unplug the two Connectors from the Toner Sensor PBA.




3. Remove the screw for taking out the Stopper, and then take out the DC Fan.




5.23 Toner Sensor PBA

- Before you remove the LSU, you should remove:
 - Top Cover (Refer to the 5.15)
 - LSU (Refer to the 5.21)


- Unplug the all Connectors from the Toner Sensor PBA.




- Remove two screws and take out the Toner Sensor PBA.



- Remove the screw securing the Cover Open PBA and remove it. Then unplug the Connector from the Main PBA, as shown below.




- Remove three screws and take out the LSU Lower Cover.




5.24 REGI Ass'y

- Before you remove the REGI Ass'y, you should remove:
- Top Cover (Refer to the 5.15)


- Unplug the Harness and remove four screws, as shown below.




- Release the lock as shown below and lift up the Gear Cap.



- Take out the REGI Ass'y, as shown below.




- Unplug the Harness, remove the screw and take out the PTL PBA.




5.25 MP Pick Up Ass'y


- Before you remove the MP Pick Up Ass'y, you should remove:
 - MPFAss'y (Refer to the 5.3)
 - Main Drive Ass'y (Refer to the 5.9)
 - Top Cover (Refer to the 5.15)
 - Inner Cover (Refer to the 5.17)
- First of all remove two screws. Lift up the MP Pick Up Shaft for taking out the MP Pick Up Rack.




- Remove the locking equipment rotate the Bearing in the direction of arrow.




- Remove the screw securing the Bracket and remove the Gear Ass'y, as shown below.




- Slide the Cam to the right by pulling on the MP Pick Up Shaft, as shown below.



6. First lift the left side of the Shaft and then remove the Shaft.



7. Push the Idle toward the ends of Shaft then take out the Housing, as shown below.




5.26 Pick Up & Feed2 Ass'y


1. Before you remove the Pick Up Ass'y, you should remove:

- Main Drive Ass'y (Refer to the 5.9)
- Right Cover (Refer to the 5.7)


2. Remove the Gear-Pick Up Cam, as shown below.




3. Release the Pick Up Gear and remove the locking equipment rotate the Bearing in the direction of arrow, as shown below.




4. Remove four screws securing the Bottom Cross Bar and remove it.




5. Remove the Actuator as shown below.




6. Remove four screws securing the Guide-P-Front. Then take out the Pick Up Unit, as shown below.




7. Remove two screws securing the Guide-M-Support and remove it.




8. Remove the Feed1 Ass'y, as shown below.




9. Remove the Feed2 Ass'y, as shown below.



10. Remove four screws securing the Feed2 Unit and remove it, as shown below.




11. Remove the Roller Unit, as shown below.




5.27 Engine Shield


1. Remove the Guide-P-Front.(Refer to the 5.16.7)
2. Remove six screws and slightly lift the Engine Shield, as shown below.




3. Remove the Duplex Guide L, R, as shown below.



4. Unplug the all Connectors from the Engine PBA. Then take out the Engine Shield Ass'y.




5. Remove four screws and take out the Engine PBA out of the Shield.



6. Troubleshooting

6.1 Procedure of Checking the Symptoms

Before attempting to repair the printer first obtain a detailed description of the problem from the customer.



6.2 The cause and solution of Bad image

6.2.1 Vertical Black Line and Band

- **Description** 1. Straight thin black vertical line occurs in the printing.
2. Dark black vertical band occur in the printing.



Check and Cause	Solution
1. Deformed Doctor-blade or cleaning-blade, in print cartridge	1. If causes 1 and 2 occur in the print cartridge, replace the print cartridge and try to print out.
2. Scratched surface of the charge roller in the print cartridge.	2. Replace the transfer roller if occurred as No. 3.
3. Partly depression or deformation on the surface of the transfer roller.	

6.2.2 Vertical White Line

- **Description** White vertical voids in the image.



Check and Cause	Solution
1. Foreign matter stuck onto the window of internal lenses of LSU mirror.	1. Foreign matter stuck onto the window : Clean the LSU window with recommended cleaner(IPA) Clean the window with a clean cotton swab.
2. Foreign matter or toner particles between the print cartridge roller and blade. (In case the life of the print cartridge has been expired, white lines or light image occur in front of the image.)	2.. Replace the print cartridge.
3. It may occur when Burr and foreign substances are on the window of the print cartridge frame.	3. No 3. : Remove the foreign matter and burr of the exposure window. (print cartridge)
4. If the fuser is defective, voids occur periodically at the top of a black image.	4. No. 4. : Open the front cover and check ribs that corresponds to the position of the voids. Remove if found.
5. It may occur when foreign substances are on the OPC Drum.	5. If the problems are not solved, replace the print cartridge.
6. Partly depression or deformation on the surface of the transfer roller	6. Replace the transfer roller if occurred as NO.6

6.2.3 Horizontal Black Band

- **Description**
1. Dark or blurry horizontal stripes occur in the printing periodically.
(They may not occur periodically.)

Digital Printer Digital Printer Digital Printer Digital Printer Digital Printer	Check and Cause	Solution
	1. Bad contacts of the voltage terminals to print cartridge.	1. Clean each voltage terminal of the Charge, Supply, Develop and Transfer roller. (remove the toner particles and paper particles)
	2. The rollers of print cartridge may be stained. Charge roller = 38mm Develop roller = 45mm Transfer roller = 55mm OPC Drum = 95mm	2. Clean the right Gear that has relatively small gap of the teeth in the OPC.
		3. If the malfunction persists, replace the print cartridge.

6.2.4 Black/White Spot

- **Description**
1. Dark or blurry black spots occur periodically in the printing.
 2. White spots occur periodically in the printing.

Digital Printer Digital Printer Digital Printer Digital Printer Digital Printer	Check and Cause	Solution
	1. If dark or blurry black spots occur periodically, the rollers in the print cartridge may be contaminated with foreign matter or paper particles. (Charge roller : 38 mm interval OPC drum : 95 mm interval)	1. Run OPC cleaning Mode Print and run the Self-test 2 or 3 times.
	2. If faded areas or voids occur in a black image at intervals of 95 mm, or black spots occur elsewhere, the OPC drum surface is damaged.	2. In case of 95 mm interval unremovable in 1, cleanly remove foreign substances stuck on the OPC location equivalent to black spots and white spots with a dry duster.
	3. If a black image is partially broken, the transfer voltage is abnormal or the transfer roller's life has expired.	3. The transfer roller guarantees 150,000 sheets printing in normal environment. If the roller's life is expired, replace it.
		4. In case of 38 mm interval unremovable in 1, take measures as to replace the print cartridge and try to print out. 5. Clean the inside of the set against the paper particles and foreign matter in order not to cause the trouble.

6.2.5 Light Image

- **Description** The printed image is light, with no ghost.

Digital Printer
Digital Printer
Digital Printer
Digital Printer
Digital Printer

Check and Cause	Solution
1. Develop roller is stained when the toner of print cartridge is almost consumed.	1. Check if the Toner Save mode is off. Check if the density is light.
2. Ambient temperature is below than 10°C.	2. No 1 : Replace the print cartridge and try to print out.
3. Bad contact caused by the toner stains between the high voltage terminal in the HVPS and the one in the set.	3. No 2 : Wait 30 minutes after printer is powered on before you start printing.
4. Abnormal output from the HVPS. (Run self-test and check 1~4)	4. No3 : Clean up the contaminated area by the toner.
5. Check warranty out.	5. Replace the HVPS if the problems are not solved by the above four instructions.
	6. Replace print cartridge.

6.2.6 Dark Image or a Black Page

- **Description** The printed image is dark.



Check and Cause	Solution
1. No charge voltage in the engine board.	1. Check the state of the connector which connects the engine board and HVPS.
2. Charge voltage is not turned on due to the bad contacts between power supply in the side of the print cartridge and charge terminal of HVPS.	2. Clean the high voltage charge terminal.
3. VD0 signal of the Main PBA is Low state.	3. Replace the HVPS if not solved by the above direction 1 and 2.
4. Case back side the cleaning blade of print cartridge.	4. Replace the LSU Unit or Main PBA.
	5. Replace print cartridge.

6.2.7 Uneven Density

- **Description** Print density is uneven between left and right.

Digital Printer
Digital Printer
Digital Printer
Digital Printer
Digital Printer

Check and Cause	Solution
1. The pressure force on the left and right springs of the transfer roller is not even, the springs are damaged, the transfer roller is improperly installed, or the transfer roller bushing or holder is damaged.	1. Replace both the left and right Spring Holder.
2. The life of the print cartridge has expired.	2. Occur in the print cartridge gently shake the print cartridge.
3. The toner level is not even on the print cartridge roller due to the bad blade.	3. Replace the print cartridge and try to print out.

6.2.8 Background


- **Description** Light dark background appears in whole area of the printing.

Digital Printer
Digital Printer
Digital Printer
Digital Printer
Digital Printer

Check and Cause	Solution
1. Does character exist less than 2% coverage per a page, and hasn't it been used long time? (see the configuration sheet)	1. The print cartridge is basically designed to print 20,000 pages with 5% coverage. If it prints more than 23,000 pages with 2% coverage, a background can occur.
2. Is a recycled print cartridge be used?	2. The A/S is not guaranteed if using a recycled the print cartridge.
3. Has the life span of the print cartridge ended?	3. Replace the print cartridge when the life span of it has been ended.
4. Is the movement(Up and Down) of the transfer roller smooth?	4. Clean the bushing part of the transfer roller.
5. Is the HVPS normal?	5. If the problem is still not solved, replace the print cartridge.

6.2.9 Ghost (1)


- **Description** Ghost occurs at 95 mm intervals of the OPC drum in the whole printing.



Check and Cause	Solution
1. Bad contacts caused by contamination from toner particles between high voltage terminal in the main body and the electrode of the print cartridge.	1. Clean the terminals when contaminated by toner particles.
2. Bad contacts caused by contamination from toner particles between high voltage terminal in the main body and the one in the HVPS board.	2. Occur in the print cartridge, replace the print cartridge and try to print out.
3. The life of print cartridge is expired.	3. Replace the engine board if not solved by the above directions 1-2.
4. Transfer roller lifetime(150,000 sheets) has expired.	4. If not solved by the direction 3, check the transfer roller lifetime and replace it.
5. Abnormal low temperature(below 10°C).	5. Wait about 1 hour after power on before using printer.
6. Damaged cleaning blade in the print cartridge.	6. Occur in the print cartridge, replace the print cartridge and try to print out.

6.2.10 Ghost (2)


- **Description** Ghost occurs at 95 mm intervals of the OPC drum in the whole printing. (When printing on card stock or transparencies using manual feeder)



Check and Cause	Solution
When printing on card stock thicker than normal paper or transparencies such as OHP, higher transfer voltage is required.	Select Card stock or OHP Film on paper type menu from the software application and after using returning to the original mode is recommended.

6.2.11 Ghost (3) : Fuser

- **Description** Ghost occurs at 126 mm intervals.



Check and Cause	Solution
The temperature of the fuser is maintained high.	1. Disassemble the fuser and remove the contaminated toner particles on the roller and clean the foreign matter between Thermistor and Heat roller. (Caution: can be deformed)

6.2.12 Stains on the Face of Page


- **Description** The background on the face of the printed page is stained.



Check and Cause	Solution
1. Toner leakage due to improperly sealed print cartridge. 2. If the transfer roller is contaminated, stains on the face of page will occur.	1. Replace the print cartridge, and clean to the toner powder of machine. 2. If the transfer roller is contaminated, run OPC Cleaning Mode Print 2 or 3 times. And perform Self-Test 2 or 3 times to remove contamination.

6.2.13 Stains on the Back of Page


- **Description** The back of the page is stained at 55 or 126 mm intervals.



Check and Cause	Solution
1. 55mm : Transfer roller is contaminated.	1.1. Perform the OPC Cleaning Mode Print 2 or 3 times. Run Self-Test to remove the contamination of the transfer roller. 1.2. Replace the transfer roller if contaminated severely.
2. 126mm : Pressure roller is contaminated.	2.1. Perform the fuser cleaning mode print 2 or 3 times. 2.2. Disassemble the fuser and clean the H/R(Heat Roller) and P/R(Pressure roller). And check the area between H/R and Thermistor. If contaminated, clean the area not to be deformed.

6.2.14 Blank Page Print out (1)


- **Description** Blank page is printed.



Check and Cause	Solution
Bad ground contacts in OPC and/or print cartridge.	1. Check if the Ground-OPC is defective(set inside left side). 2. Remove contamination of the terminals of the print cartridge and the unit.

6.2.15 Blank Page Print out (2)

- **Description**
 1. Blank page is printed.
 2. One or several blank pages are printed.
 3. When the printer turns on, several blank pages print.



Check and Cause	Solution
1. Bad ground contacts in OPC and/or print cartridge.	1. Remove contamination of the terminals of the print cartridge.
2. Abnormal solenoid.	2. Perform the engine self test using EDC Mode to check if the Solenoid is normal. 3. If not solved by the above directions 1-2, Replace the engine board. 4. Turn the power off, delete the data of PC and try printing again.

6.3 The cause and solution of the bad discharge


6.3.1 Wrong Print Position

- **Description** Printing begins at wrong position on the paper.

Check and Cause	Solution
Wrong sense time caused by defective feed sensor actuator.	Replace the defective actuator

6.3.2 JAM 0

- **Description**
1. Paper is not exited from the cassette.
 2. Jam-0 occurs if the paper feeds into the printer.




Check and Cause	Solution
<ol style="list-style-type: none"> 1. Check the Main clutch by using EDC Mode. 2. Check if the pad is loose due to bad sealing of the side-pad. 3. Check the surface of the roller-pick-up for foreign matter. 4. If continuous clusters occur, check whether the assembly slot between shaft-pickup and housing-pickup opens or is broken away. 5. If the paper feeds into the printer and Jam 0 occurs, perform EDC Mode to check feed-sensor of the engine board. 	<ol style="list-style-type: none"> 1. Replace the Main clutch. 2. Replace the side-pad Assembly L or R, if necessary. 3. Clean with soft cloth dampened with IPA(Isopropyl Alcohol) or water. 4. Replace the Main PBA and/or Sensor.

6.3.3 JAM 1

• **Description**

1. Recording paper is jammed in front of or inside the fuser.
2. Recording paper is stuck in the discharge roller and in the fuser just after passing through the Actuator-Feed.




Check and Cause	Solution
1. If the recording paper is jammed in front of or inside the fuser.	1. Replace the SMPS or Exit-Sensor.
	2. Replace the Main PBA.
2. If the recording paper is stuck in the discharge roller and the fuser just after passing through the Actuator-Feed, Feed Actuator may be defective.	3. Reassemble the Actuator-Feed and Spring-Actuator if the movement is bad.

6.3.4 JAM 2

• **Description**


1. Recording paper is jammed in front of or inside the fuser.
2. Recording paper is stuck in the discharge roller and in the fuser just after passing through the Actuator-Feed.



Check and Cause	Solution
1. If the paper is completely fed out of the printer, but Jam 2 occurs : Exit sensor is defective. <ul style="list-style-type: none"> • After the paper is completely discharged, actuator Exit should return to the original position to shut the photo-sensor. Sometimes it takes longer hour than it should and does not return. 	1. Check if the exit sensor actuator is defective. <ul style="list-style-type: none"> • Check if the actuator exit is deformed (Check if the lever part is deformed in shape). • Check whether burrs occur in the assembly part of the actuator exit or not and if the actuator is smoothly operated. • Check if foreign matter and wire get caught in the actuator exit's operation.
2. If the paper is rolled in the Fuser Roller: <ul style="list-style-type: none"> • This occurs when a Guide claw is broken away or transformed. • It occurs when the Spring of a Guide claw is broken away or transformed. • It occurs when the Heat-Roller or Pressure-Roller is seriously contaminated with the toner. 	2. If the paper is stuck in the fuser : disassemble the fuser and remove the jammed paper, and clean the surface of the pressure roller with dry gauze.
3. Paper is accordion in the fuser.	3. Remove the jammed paper after disassembling the fuser : Clean the surface of the pressure roller with dry gauze. <ul style="list-style-type: none"> • Remove the toner particles stained on the rib. • Check the assemblage and performance of the exit.

6.3.5 Duplex Jam 1


- **Description** A message 'Duplex Jam 1' is displayed in a LCD window.



Check and Cause	Solution
<ol style="list-style-type: none"> 1. It is a case when a paper cannot operate a duplex sensor. 2. It is a case when a paper cannot reach to a duplex sensor due to a paper jam on a duplex path. 	<ol style="list-style-type: none"> 1. Replace a SMPS or main PBA 2. A case that a paper jam occurs on (A) after it is reversed: replace a 2nd exit roller after checking its operation. 3. A case that a paper jam occurs on (B) after it is reversed: replace a duplex roller after checking its operation

6.3.6 Duplex Jam 0

- **Description** A message 'Duplex Jam 2' is displayed in a LCD window.



Check and Cause	Solution
<ol style="list-style-type: none"> 1. It is a case that a paper cannot pass a duplex sensor. 2. It is a case that a paper cannot reach to a registration sensor after it is passed a duplex sensor. 	<ol style="list-style-type: none"> 1. Replace a SMPS or main PBA. 2. A case that a leading edge of a paper is jammed on (A) check an operation of a guide front. If it is worn or defective, replace it. 3. Check an operation of a feed roller and a registration roller. If they are worn or defective replace them.

6.3.7 Multi-Feeding

- **Description** Multiple sheets of paper are fed at once.

Check and Cause	Solution
1. Check the Guide side L/R or Guide Rear in the Cassette, if the position is correct.	1. Replace the solenoid if necessary.
2. Solenoid malfunction(the solenoid does not work properly): Perform EDC Mode.	2. Replace the Main PBA.
3. Pad-Friction is contaminated with foreign matter.(oil...)	3. Clean the pad friction with soft cloth dampened with IPA(Isopropyl Alcohol).
4. The face of paper is blended.	4. Use the smooth paper.

6.3.8 Paper rolled in the fuser

- **Description** If contaminated at intervals of 57mm on the back of a paper.

Check and Cause	Solution
1. Contamination of the pressure roller or heat roller (Background, Hot off set).	1. After disassembling the fuser, clean contamination between the heat roller and the thermostat and remove the contamination of the pressure roller.
2. Check the claw of the fuser whether it is deformed.	2. If there is heavy background, repair it by the background troubleshooting method.
	3. Clean the surface of the heat roller with IPA or water
	4. Check the warp or separation of the print claw and the holder plate claw, and then manage it.

6.3.9 Paper rolled on the OPC Drum

- **Description** Paper is rolled up in the OPC.

Check and Cause	Solution
1. Paper is too much thin. 2. The face of paper is curled.	1. Recommend to use normal paper. 2. How to remove the rolled paper in the OPC. <ul style="list-style-type: none">• Remove the paper while turning the OPC against the ongoing direction.• Clean fingerprints on the OPC softly with soft cloth dampened with tissue.

6.4 The cause and solution of the malfunction

6.4.1 Fuser Error

- **Description** A message "Engine Fuser Low Heat Error/Engine Fuser Over Heat Error" is displayed in a LCD panel.

Check and Cause	Solution
1. Check whether a thermostat, open or not.	1. Replace the fuser if a thermostat is open.
2. Check whether a thermistor is open or not.	2. Replace the fuser if a thermistor sensor is located deep inside of a sponge.
3. Heat lamp ON/OFF test	3. Check whether the overheat mode circuit operates normally or not.
4. It could not operate due to a gear of a fuser is melted.	4. Replace the fuser.

6.4.2 LSU Error

- **Description** A message "Engine Hsyne Error" is displayed in a LCD panel.

Check and Cause	Solution
1. Check whether the LSU connector is disconnected or not.	1. Connect the LSU harness properly.
2. Check whether the LSU motor is rotating or not.	2. Replace a LSU.
3. Check the HSYNC signal.	3. Replace a main board if the same error occurs again after replacing a LSU.

6.4.3 Not function of the gear of the fuser due to melting away

- **Description** The motor breaks away from its place due to gear melting away.

Check and Cause	Solution
1. Check the Fuser Unit.	1. Replace the Fuser. 2. Replace the Main PBA. 2. Replace the SMPS.

6.4.4 Paper Empty

- **Description** The paper lamp on the operator panel is on even when paper is loaded in the cassette.

Check and Cause	Solution
1. Bending or deformation of the actuator of the paper sensor.	1. Replace the defective actuator.
2. The function of the engine board is defective	2. Replace the empty sensor PBA.
3. Check the connector and harness.	

6.4.5 Paper Empty without indication

- **Description** A message "Paper Empty" is displayed in a LCD panel.
The paper lamp on the operator panel does not come on when the paper cassette is empty.

Check and Cause	Solution
1. Bending or deformation of the actuator of the paper sensor.	1. Replace the defective actuator.
2. Check the Main board.	2. Replace the board which has a trouble.
3. Check the empty sensor board.	
4. Check the toner sensor board.	

6.4.6 Cover Open

- **Description** A message "Close Top Cover" is displayed in a LCD panel.
The ERROR lamp is on even when the print cover is closed.

Check and Cause	Solution
1. The hook lever in the top cover may be defective.	1. Replace the hook lever, if defective.
2. Check the main board	2. Check the insertion of the cover open S/W connect.
3. Check the cover open board.	3. Replace the main board or cover open board.
4. Check the harness and connection.	

6.4.7 No error message when the cover is open

- **Description** The ERROR message does not come on even when the printer cover is open

Check and Cause	Solution
1. Check the cover open circuit on the main board. 2. Check the cover open board.	1. Check the insertion of the cover open S/W connect. 2. Replace the main control board or cover open board.

6.4.8 Defective motor operation

- **Description** Main motor is not driving when printing, and paper does not feed into the printer, resulting 'Jam 0'.

Check and Cause	Solution
1. The motor harness or motor PCB may be defective.	1. Replace the motor unit.
2. Check the motor operation in the EDC mode.	2. Replace the main PBA.

6.4.9 No Power

- **Description** When system power is turned on, all lamps on the operator panel do not come on.

Check and Cause	Solution
1. Check if the power input and SMPS output are normal.	1. Replace the SMPS.
2. Check the inferiority of LED-Panel or LDC window on the front-cover if the OP panel does not appear after normal warming-up.	2. Replace the control board.

6.4.10 Vertical Line Getting Curved

- **Description** When printing, vertical line gets curved.

Check and Cause	Solution
1. If the supply of +24v is unstable in the main control board linking with LSU, check drive by EDC mode: LSU check.	1. Replace LSU.
2. Check the drive PBA in the print cartridge.	2. Replace the toner sensor PBA. 2. Replace the main PBA.

6.5 Maintaining the toner cartridge

Toner cartridge storage

To get the most from the toner cartridge, keep the following guidelines in mind:

- Do not remove the toner cartridge from its package until ready for use.
- Do not refill the toner cartridge. The printer warranty does not cover damage caused by using a refilled cartridge.
- Store toner cartridge in the same environment as the printer.
- To prevent damage to the toner cartridge, do not expose it to light for more than a few minute.

Expected cartridge life

The life of the toner cartridge depends on the amount of toner that print jobs require. When printing text at ISO 19752 5% coverage, a new toner cartridge lasts an average of either 20,000 or 10,000 pages. (The original toner cartridge supplied with the printer lasts an average of 10,000 pages.) The actual number may also be different depending on the print density of the pages you print on, and the number of pages may be affected by operating environment, printing interval, media type, and media size. If you print a lot of graphics, you may need to change the cartridge more often.

Saving toner

To save toner, press Toner Save on the control panel. The button backlight turns on.

Using this feature extends the life of the toner cartridge and reduce your cost per page, but it also reduces print quality.

6.5.1 Checking the remaining toner

You can check the level of toner left in the cartridge.

If you are having print quality problems, this can help you determine if the problem is caused by low toner.

Following the key formation at the panel, note the toner remaining level on the cartridge information after taking out the configuration sheet. In other way to check, follow the TECH mode and out put the cartridge information.


The display shows the percentage of the remaining toner.

6.5.2 Redistributing toner cartridge

When the toner cartridge is near the end of its life:

- White streaks and light printing occur.
- Toner Low appears on the display.
- The Smart Panel program window appears on the computer telling you that the toner level is low.
- The Status LED blinks red. If this happens, you can temporarily reestablish print quality by redistributing the remaining toner in the cartridge. In some cases, white streaks or light printing will still occur even after you have redistributed the toner.


1. Open the top cover.
2. Pull the toner cartridge out.



Caution :


- Avoid reaching too far into the printer. The fusing area may be hot.
- To prevent damage to the toner cartridge, do not expose it to light for more than a few minutes. Cover it with a piece of paper, if necessary.
- Do not touch the green surface underside of the toner cartridge. Use the handle on the cartridge to avoid touching this area.

3. Thoroughly shake the cartridge 5 or 6 times to distribute the toner evenly inside the cartridge.



Note : If toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets toner into fabric.

4. Hold the toner cartridge by the handle and slowly insert the cartridge into the opening in the printer. Tabs on the sides of the cartridge and corresponding grooves within the printer will guide the cartridge into the correct position until it locks into place completely.



5. Close the top cover. Make sure that the cover is securely closed.

6.5.3 Replacing the toner cartridge


When the toner cartridge is completely empty:

- Replace Toner appears on the display.
- The Smart Panel program window appears on the computer telling you that the toner cartridge is empty.
- The Status LED lights red.


At this stage, the toner cartridge needs to be replaced. For order information for toner cartridges,

Note : This feature does not work for the Toner Empty message.

1. Open the top cover.
2. Pull the toner cartridge out.




3. Remove the new toner cartridge from its bag.



Caution : Do not use sharp objects, such as a knife or scissors, to open the toner cartridge package. They might scratch the drum of the cartridge.


4. Locate the sealing tape at the end of the toner cartridge. Carefully pull the tape completely out of the cartridge and discard it.




Note : • The sealing tape should be longer than 60 cm when correctly removed.

- Holding the toner cartridge, pull the sealing tape straight to remove it from the cartridge. Be careful not to cut the tape. If this happens, you cannot use the toner cartridge.
- Refer to the helpful pictures on the cartridge wrapping paper.

5. Remove the flexible plastic holder out of the toner cartridge.




6. Thoroughly shake the cartridge 5 or 6 times to distribute the toner evenly inside the cartridge.



Thoroughly roll the cartridge to assure maximum copies per cartridge. Save the box and the plastic bag for shipping.

- Caution :**
- If toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets toner into fabric.
 - To prevent damage to the toner cartridge, do not expose it to light for more than a few minutes. Cover it with a piece of paper, if necessary.
 - Do not touch the green surface underside of the toner cartridge. Use the handle on the cartridge to avoid touching this area.

7. Hold the toner cartridge by the handle and slowly insert the cartridge into the opening in the printer. Tabs on the sides of the cartridge and corresponding grooves within the printer will guide the cartridge into the correct position until it locks into place completely.



8. Close the top cover. Make sure that the cover is securely closed.

6.5.4 Toner Cartridge-related messages

Message	Meaning	Suggested solutions
Install Toner	A toner cartridge is not installed.	Install a toner cartridge.
Invalid Toner	The toner cartridge you have installed is not for your printer.	Install a Samsung -genuine toner cartridge ,designed for your printer.
Toner Low	The toner cartridge is almost empty.	Take out the toner cartridge and thoroughly shake it.By doing this,you can temporarily reestablish printing operations.
NonGenuine Toner ◀ Stop ▶	The toner cartridge installed is not a genuine cartridge.	You can select either Stop or Continue.If you do not select any,the printer will work as Stop is selected. If you select Stop, you cannot print until the genuine cartridge is installed.However, you can still print any kind of reports. If you select Continue, you can keep printing but the quality cannot be guaranteed, and the product support is no longer provided. If you want to change the selection, turn the printer off and on to have this message appear again, and then re-select Stop or Continue.
NonGenuine Toner Replace Toner1	The toner cartridge installed is not a genuine cartridge.	This message appears when you selected Stop at the NonGenuine Toner prompt. Install the genuine toner cartridge.
NonGenuine Toner Replace Toner	The toner cartridge installed is not a genuine cartridge.	This message appears when you selected Continue at the NonGenuine Toner prompt. Install the genuine toner cartridge.
Toner Low Replace Toner	The toner in the cartridge has run out.	Install a new genuine toner cartridge. You can keep printing but the quality cannot be guaranteed, and the product support is no longer provided. You can configure not to see the Toner Low Replace Toner message.
Replace Toner	The toner cartridge installed is not a genuine cartridge.	This message appears when you turned off the Toner Low Replace Toner message. Install a new genuine toner cartridge. You can keep printing but the quality cannot be guaranteed, and the product support is no longer provided.
Toner Exhausted ◀ Stop ▶	The lifespan of the toner cartridge is reached.	You can select either Stop or Continue. If you do not select any, the printer will work as Stop is selected. If you select Stop, you cannot print until the genuine cartridge is installed. If you select Continue, you can keep printing but the quality cannot be guaranteed, and the product support is no longer provided. If you want to change the selection, turn the printer off and on to have this message appear again, and then re-select Stop or Continue.
Toner Exhausted Replace Toner1	The lifespan of the toner cartridge is reached.	This message appears when you selected Stop at the Toner Exhausted prompt. Install the genuine toner cartridge.
Toner Exhausted Replace Toner	The lifespan of the toner cartridge is reached.	This message appears when you selected Continue at the Toner Exhausted prompt. Install the genuine toner cartridge.

6.6 The cause and solutions of bad environment of the software

6.6.1 The printer is not working (1)

- **Description** While Power turned on, the printer is not working in the printing mode.

Check and Cause	Solution
1. Run Self-Test Mode: Turn the power on while pressing the test printing button for 2 or 3 seconds before printing works.	1. Check the power of the printer and perform the Self-Test. If the test printing works, that means no problems in the printer itself. If the test printing does not work, that means bad functioning of the printer (not because of software).
2. Check if the PC and the printer is properly connected and the print cartridge installed.	2. Replace the printer cable. If the problems not solved even after the cable replaced, check the amount of the remaining tone. (refer to print cartridge Service 4-5)
3. Printing is not working in the Windows.	3. Check if the connection between PC and printer port is proper. If you use windows, check if the printer driver in the controller is set up. If the printer driver is properly set up, check in which program the printing is not working. The best way to find out is to open the memo pad to check the function of printing. If it is not working in a certain program, adjust the setup the program requires. Sometimes, the printout is normal within the Windows basic programs, but it's not working in a particular program. In such case, install the new driver again. If not working in the Windows basic program, Check the setup of the port of CMOS is on ECP. And check the address of IRQ 7 and 378
4. Check if the printer cable is directly connected to peripheral devices	4. If the scanner needs to be connected to the printer, first the remove the scanner from the PC to see if the printer is properly working alone.

6.6.2 The printer is not working (2)

- **Description** After receiving the printing order, no response at all or the low speed of printing occurs due to wrong setup of the environment rather than malfunction of the printer itself.

Check and Cause	Solution
1. Secure more space of the hard disk.	1. Not working with the message 'insufficient printer memory' means hard disk space problem rather than the RAM problem. In this case, provide more space for the hard disk. Secure more space using the disk utilities program.
2. Printing error occurs even if there is enough space in the hard disk.	2. The connection of the cable and printer port is not proper. Check if the connection is properly done and if the parallel port in CMOS is rightly set up.
3. Check the parallel-port-related items in the CMOS Setup.	3. As a printer port, Select ECP or SPP among SPP(Normal), ECP, and EPP modes(increase printing speed) SPP normal mode support 8-bit data transfer, while ECP Mode transfer the 12-bit data.
4. Reboot the system to print.	4. If the regular font is not printing, the cable or the printer driver may be defective. Turn the PC and printer off, and reboot the system to print again. If not solved, double-click the printer in my computer If the regular fonts are not printed this time again. the cable must be defective so replace the cable with new one.

6.6.3 Abnormal Printing

• **Description**

The printing is not working properly even when the cable has no problem.
(even after the cable is replaced)

If the printer won't work at all or the strange fonts are repeated, the printer driver may be defective or wrong setup in the CMOS Setup.

Check and Cause	Solution
1. Set up the parallel port in the CMOS SETUP.	1. Select SPP(Normal) or ECP LPT Port the among ECP, EPP or SPP in the CMOS Setup.
2. Printer Driver Error.	2. Check the printer in My Computer.(to see if the printer driver is compatible to the present driver or delete the old driver, if defective and reinstall the new driver)
3. Error message from insufficient memory. (The printing job sometimes stops or due to insufficient virtual memory, but it actually comes from the insufficient space of the hard disk.)	3. Delete the unnecessary files to secure enough space of the hard disk and start printing job again.

6.6.4 SPOOL Error

• Description

To spool which stands for "simultaneous peripheral operations online" a computer document or task list (or "job") is to read it in and store it, usually on a hard disk or larger storage medium so that it can be printed or otherwise processed at a more convenient time (for example, when a printer is finished printing its current document).

Check and Cause	Solution
1. Insufficient space of the hard disk in the directory assigned for the basic spool.	1. Delete the unnecessary files to provide more space to start printing job.
2. If the previous printing error not solved.	2. If there are some files with the extension name of ****.jnl, Delete them and Reboot the Windows to restart printing job.
3. When expected to collide with other program.	3. Shut down all other programs except the current one, if possible.
4. When an application program or the printer driver is damaged.	4. Delete the printer driver completely and reinstall it.
5. When some files related to OS are damaged or virus infected.	5. After rebooting the computer, check for viruses, restore the damaged files and reinstall the program to do the printing job.
6. Memory is less than suggested one.	6. Add up enough memory to the PC.

How to delete the data in the spool manager.

In the spool manager, the installed drivers and the list of the documents waiting to be printed are shown. Select the document to be deleted and check the delete menu.


If you intend to delete the current document being printed, the data being transferred to the printer will be put out and then the document is removed. Before choosing the document, the menu is still inactive.

Or put the document out of the list and repeat the routine as in the above or finish the spool manager.

6. Troubleshooting

6.1 Procedure of Checking the Symptoms

Before attempting to repair the printer first obtain a detailed description of the problem from the customer.



6.2 The cause and solution of Bad image

6.2.1 Vertical Black Line and Band

- **Description** 1. Straight thin black vertical line occurs in the printing.
2. Dark black vertical band occur in the printing.



Check and Cause	Solution
1. Deformed Doctor-blade or cleaning-blade, in print cartridge	1. If causes 1 and 2 occur in the print cartridge, replace the print cartridge and try to print out.
2. Scratched surface of the charge roller in the print cartridge.	2. Replace the transfer roller if occurred as No. 3.
3. Partly depression or deformation on the surface of the transfer roller.	

6.2.2 Vertical White Line

- **Description** White vertical voids in the image.



Check and Cause	Solution
1. Foreign matter stuck onto the window of internal lenses of LSU mirror.	1. Foreign matter stuck onto the window : Clean the LSU window with recommended cleaner(IPA) Clean the window with a clean cotton swab.
2. Foreign matter or toner particles between the print cartridge roller and blade. (In case the life of the print cartridge has been expired, white lines or light image occur in front of the image.)	2.. Replace the print cartridge.
3. It may occur when Burr and foreign substances are on the window of the print cartridge frame.	3. No 3. : Remove the foreign matter and burr of the exposure window. (print cartridge)
4. If the fuser is defective, voids occur periodically at the top of a black image.	4. No. 4. : Open the front cover and check ribs that corresponds to the position of the voids. Remove if found.
5. It may occur when foreign substances are on the OPC Drum.	5. If the problems are not solved, replace the print cartridge.
6. Partly depression or deformation on the surface of the transfer roller	6. Replace the transfer roller if occurred as NO.6

6.2.3 Horizontal Black Band

- **Description**
1. Dark or blurry horizontal stripes occur in the printing periodically.
(They may not occur periodically.)

Digital Printer Digital Printer Digital Printer Digital Printer Digital Printer	Check and Cause	Solution
	1. Bad contacts of the voltage terminals to print cartridge.	1. Clean each voltage terminal of the Charge, Supply, Develop and Transfer roller. (remove the toner particles and paper particles)
	2. The rollers of print cartridge may be stained. Charge roller = 38mm Develop roller = 45mm Transfer roller = 55mm OPC Drum = 95mm	2. Clean the right Gear that has relatively small gap of the teeth in the OPC. 3. If the malfunction persists, replace the print cartridge.

6.2.4 Black/White Spot

- **Description**
1. Dark or blurry black spots occur periodically in the printing.
 2. White spots occur periodically in the printing.

Digital Printer Digital Printer Digital Printer Digital Printer Digital Printer	Check and Cause	Solution
	1. If dark or blurry black spots occur periodically, the rollers in the print cartridge may be contaminated with foreign matter or paper particles. (Charge roller : 38 mm interval OPC drum : 95 mm interval)	1. Run OPC cleaning Mode Print and run the Self-test 2 or 3 times.
	2. If faded areas or voids occur in a black image at intervals of 95 mm, or black spots occur elsewhere, the OPC drum surface is damaged.	2. In case of 95 mm interval unremovable in 1, cleanly remove foreign substances stuck on the OPC location equivalent to black spots and white spots with a dry duster.
	3. If a black image is partially broken, the transfer voltage is abnormal or the transfer roller's life has expired.	3. The transfer roller guarantees 150,000 sheets printing in normal environment. If the roller's life is expired, replace it. 4. In case of 38 mm interval unremovable in 1, take measures as to replace the print cartridge and try to print out. 5. Clean the inside of the set against the paper particles and foreign matter in order not to cause the trouble.

6.2.5 Light Image

- **Description** The printed image is light, with no ghost.

Digital Printer
Digital Printer
Digital Printer
Digital Printer
Digital Printer

Check and Cause	Solution
1. Develop roller is stained when the toner of print cartridge is almost consumed.	1. Check if the Toner Save mode is off. Check if the density is light.
2. Ambient temperature is below than 10°C.	2. No 1 : Replace the print cartridge and try to print out.
3. Bad contact caused by the toner stains between the high voltage terminal in the HVPS and the one in the set.	3. No 2 : Wait 30 minutes after printer is powered on before you start printing.
4. Abnormal output from the HVPS. (Run self-test and check 1~4)	4. No3 : Clean up the contaminated area by the toner.
5. Check warranty out.	5. Replace the HVPS if the problems are not solved by the above four instructions.
	6. Replace print cartridge.

6.2.6 Dark Image or a Black Page

- **Description** The printed image is dark.



Check and Cause	Solution
1. No charge voltage in the engine board.	1. Check the state of the connector which connects the engine board and HVPS.
2. Charge voltage is not turned on due to the bad contacts between power supply in the side of the print cartridge and charge terminal of HVPS.	2. Clean the high voltage charge terminal.
3. VD0 signal of the Main PBA is Low state.	3. Replace the HVPS if not solved by the above direction 1 and 2.
4. Case back side the cleaning blade of print cartridge.	4. Replace the LSU Unit or Main PBA.
	5. Replace print cartridge.

6.2.7 Uneven Density

- **Description** Print density is uneven between left and right.

Digital Printer
Digital Printer
Digital Printer
Digital Printer
Digital Printer

Check and Cause	Solution
1. The pressure force on the left and right springs of the transfer roller is not even, the springs are damaged, the transfer roller is improperly installed, or the transfer roller bushing or holder is damaged.	1. Replace both the left and right Spring Holder.
2. The life of the print cartridge has expired.	2. Occur in the print cartridge gently shake the print cartridge.
3. The toner level is not even on the print cartridge roller due to the bad blade.	3. Replace the print cartridge and try to print out.

6.2.8 Background


- **Description** Light dark background appears in whole area of the printing.

Digital Printer
Digital Printer
Digital Printer
Digital Printer
Digital Printer

Check and Cause	Solution
1. Does character exist less than 2% coverage per a page, and hasn't it been used long time? (see the configuration sheet)	1. The print cartridge is basically designed to print 20,000 pages with 5% coverage. If it prints more than 23,000 pages with 2% coverage, a background can occur.
2. Is a recycled print cartridge be used?	2. The A/S is not guaranteed if using a recycled the print cartridge.
3. Has the life span of the print cartridge ended?	3. Replace the print cartridge when the life span of it has been ended.
4. Is the movement(Up and Down) of the transfer roller smooth?	4. Clean the bushing part of the transfer roller.
5. Is the HVPS normal?	5. If the problem is still not solved, replace the print cartridge.

6.2.9 Ghost (1)


- **Description** Ghost occurs at 95 mm intervals of the OPC drum in the whole printing.



Check and Cause	Solution
1. Bad contacts caused by contamination from toner particles between high voltage terminal in the main body and the electrode of the print cartridge.	1. Clean the terminals when contaminated by toner particles.
2. Bad contacts caused by contamination from toner particles between high voltage terminal in the main body and the one in the HVPS board.	2. Occur in the print cartridge, replace the print cartridge and try to print out.
3. The life of print cartridge is expired.	3. Replace the engine board if not solved by the above directions 1-2.
4. Transfer roller lifetime(150,000 sheets) has expired.	4. If not solved by the direction 3, check the transfer roller lifetime and replace it.
5. Abnormal low temperature(below 10°C).	5. Wait about 1 hour after power on before using printer.
6. Damaged cleaning blade in the print cartridge.	6. Occur in the print cartridge, replace the print cartridge and try to print out.

6.2.10 Ghost (2)


- **Description** Ghost occurs at 95 mm intervals of the OPC drum in the whole printing. (When printing on card stock or transparencies using manual feeder)



Check and Cause	Solution
When printing on card stock thicker than normal paper or transparencies such as OHP, higher transfer voltage is required.	Select Card stock or OHP Film on paper type menu from the software application and after using returning to the original mode is recommended.

6.2.11 Ghost (3) : Fuser


- **Description** Ghost occurs at 126 mm intervals.



Check and Cause	Solution
The temperature of the fuser is maintained high.	1. Disassemble the fuser and remove the contaminated toner particles on the roller and clean the foreign matter between Thermistor and Heat roller. (Caution: can be deformed)

6.2.12 Stains on the Face of Page


- **Description** The background on the face of the printed page is stained.



Check and Cause	Solution
1. Toner leakage due to improperly sealed print cartridge. 2. If the transfer roller is contaminated, stains on the face of page will occur.	1. Replace the print cartridge, and clean to the toner powder of machine. 2. If the transfer roller is contaminated, run OPC Cleaning Mode Print 2 or 3 times. And perform Self-Test 2 or 3 times to remove contamination.

6.2.13 Stains on the Back of Page


- **Description** The back of the page is stained at 55 or 126 mm intervals.



Check and Cause	Solution
1. 55mm : Transfer roller is contaminated.	1.1. Perform the OPC Cleaning Mode Print 2 or 3 times. Run Self-Test to remove the contamination of the transfer roller. 1.2. Replace the transfer roller if contaminated severely.
2. 126mm : Pressure roller is contaminated.	2.1. Perform the fuser cleaning mode print 2 or 3 times. 2.2. Disassemble the fuser and clean the H/R(Heat Roller) and P/R(Pressure roller). And check the area between H/R and Thermistor. If contaminated, clean the area not to be deformed.

6.2.14 Blank Page Print out (1)


- **Description** Blank page is printed.



Check and Cause	Solution
Bad ground contacts in OPC and/or print cartridge.	1. Check if the Ground-OPC is defective(set inside left side). 2. Remove contamination of the terminals of the print cartridge and the unit.

6.2.15 Blank Page Print out (2)

- **Description**
 1. Blank page is printed.
 2. One or several blank pages are printed.
 3. When the printer turns on, several blank pages print.



Check and Cause	Solution
1. Bad ground contacts in OPC and/or print cartridge.	1. Remove contamination of the terminals of the print cartridge.
2. Abnormal solenoid.	2. Perform the engine self test using EDC Mode to check if the Solenoid is normal. 3. If not solved by the above directions 1-2, Replace the engine board. 4. Turn the power off, delete the data of PC and try printing again.

6.3 The cause and solution of the bad discharge


6.3.1 Wrong Print Position

- **Description** Printing begins at wrong position on the paper.

Check and Cause	Solution
Wrong sense time caused by defective feed sensor actuator.	Replace the defective actuator

6.3.2 JAM 0

- **Description**
1. Paper is not exited from the cassette.
 2. Jam-0 occurs if the paper feeds into the printer.




Check and Cause	Solution
<ol style="list-style-type: none"> 1. Check the Main clutch by using EDC Mode. 2. Check if the pad is loose due to bad sealing of the side-pad. 3. Check the surface of the roller-pick-up for foreign matter. 4. If continuous clusters occur, check whether the assembly slot between shaft-pickup and housing-pickup opens or is broken away. 5. If the paper feeds into the printer and Jam 0 occurs, perform EDC Mode to check feed-sensor of the engine board. 	<ol style="list-style-type: none"> 1. Replace the Main clutch. 2. Replace the side-pad Assembly L or R, if necessary. 3. Clean with soft cloth dampened with IPA(Isopropyl Alcohol) or water. 4. Replace the Main PBA and/or Sensor.

6.3.3 JAM 1

• **Description**

1. Recording paper is jammed in front of or inside the fuser.
2. Recording paper is stuck in the discharge roller and in the fuser just after passing through the Actuator-Feed.




Check and Cause	Solution
1. If the recording paper is jammed in front of or inside the fuser.	1. Replace the SMPS or Exit-Sensor.
	2. Replace the Main PBA.
2. If the recording paper is stuck in the discharge roller and the fuser just after passing through the Actuator-Feed, Feed Actuator may be defective.	3. Reassemble the Actuator-Feed and Spring-Actuator if the movement is bad.

6.3.4 JAM 2

• **Description**


1. Recording paper is jammed in front of or inside the fuser.
2. Recording paper is stuck in the discharge roller and in the fuser just after passing through the Actuator-Feed.



Check and Cause	Solution
1. If the paper is completely fed out of the printer, but Jam 2 occurs : Exit sensor is defective. <ul style="list-style-type: none"> • After the paper is completely discharged, actuator Exit should return to the original position to shut the photo-sensor. Sometimes it takes longer hour than it should and does not return. 	1. Check if the exit sensor actuator is defective. <ul style="list-style-type: none"> • Check if the actuator exit is deformed (Check if the lever part is deformed in shape). • Check whether burrs occur in the assembly part of the actuator exit or not and if the actuator is smoothly operated. • Check if foreign matter and wire get caught in the actuator exit's operation.
2. If the paper is rolled in the Fuser Roller: <ul style="list-style-type: none"> • This occurs when a Guide claw is broken away or transformed. • It occurs when the Spring of a Guide claw is broken away or transformed. • It occurs when the Heat-Roller or Pressure-Roller is seriously contaminated with the toner. 	2. If the paper is stuck in the fuser : disassemble the fuser and remove the jammed paper, and clean the surface of the pressure roller with dry gauze.
3. Paper is accordion in the fuser.	3. Remove the jammed paper after disassembling the fuser : Clean the surface of the pressure roller with dry gauze. <ul style="list-style-type: none"> • Remove the toner particles stained on the rib. • Check the assemblage and performance of the exit.

6.3.5 Duplex Jam 1


- **Description** A message 'Duplex Jam 1' is displayed in a LCD window.



Check and Cause	Solution
<ol style="list-style-type: none"> 1. It is a case when a paper cannot operate a duplex sensor. 2. It is a case when a paper cannot reach to a duplex sensor due to a paper jam on a duplex path. 	<ol style="list-style-type: none"> 1. Replace a SMPS or main PBA 2. A case that a paper jam occurs on (A) after it is reversed: replace a 2nd exit roller after checking its operation. 3. A case that a paper jam occurs on (B) after it is reversed: replace a duplex roller after checking its operation

6.3.6 Duplex Jam 0

- **Description** A message 'Duplex Jam 2' is displayed in a LCD window.



Check and Cause	Solution
<ol style="list-style-type: none"> 1. It is a case that a paper cannot pass a duplex sensor. 2. It is a case that a paper cannot reach to a registration sensor after it is passed a duplex sensor. 	<ol style="list-style-type: none"> 1. Replace a SMPS or main PBA. 2. A case that a leading edge of a paper is jammed on (A) check an operation of a guide front. If it is worn or defective, replace it. 3. Check an operation of a feed roller and a registration roller. If they are worn or defective replace them.

6.3.7 Multi-Feeding

- **Description** Multiple sheets of paper are fed at once.

Check and Cause	Solution
1. Check the Guide side L/R or Guide Rear in the Cassette, if the position is correct.	1. Replace the solenoid if necessary.
2. Solenoid malfunction(the solenoid does not work properly): Perform EDC Mode.	2. Replace the Main PBA.
3. Pad-Friction is contaminated with foreign matter.(oil...)	3. Clean the pad friction with soft cloth dampened with IPA(Isopropyl Alcohol).
4. The face of paper is blended.	4. Use the smooth paper.

6.3.8 Paper rolled in the fuser

- **Description** If contaminated at intervals of 57mm on the back of a paper.

Check and Cause	Solution
1. Contamination of the pressure roller or heat roller (Background, Hot off set).	1. After disassembling the fuser, clean contamination between the heat roller and the thermostat and remove the contamination of the pressure roller.
2. Check the claw of the fuser whether it is deformed.	2. If there is heavy background, repair it by the background troubleshooting method.
	3. Clean the surface of the heat roller with IPA or water
	4. Check the warp or separation of the print claw and the holder plate claw, and then manage it.

6.3.9 Paper rolled on the OPC Drum

- **Description** Paper is rolled up in the OPC.

Check and Cause	Solution
1. Paper is too much thin. 2. The face of paper is curled.	1. Recommend to use normal paper. 2. How to remove the rolled paper in the OPC. <ul style="list-style-type: none">• Remove the paper while turning the OPC against the ongoing direction.• Clean fingerprints on the OPC softly with soft cloth dampened with tissue.

6.4 The cause and solution of the malfunction

6.4.1 Fuser Error

- **Description** A message "Engine Fuser Low Heat Error/Engine Fuser Over Heat Error" is displayed in a LCD panel.

Check and Cause	Solution
1. Check whether a thermostat, open or not.	1. Replace the fuser if a thermostat is open.
2. Check whether a thermistor is open or not.	2. Replace the fuser if a thermistor sensor is located deep inside of a sponge.
3. Heat lamp ON/OFF test	3. Check whether the overheat mode circuit operates normally or not.
4. It could not operate due to a gear of a fuser is melted.	4. Replace the fuser.

6.4.2 LSU Error

- **Description** A message "Engine Hsyne Error" is displayed in a LCD panel.

Check and Cause	Solution
1. Check whether the LSU connector is disconnected or not.	1. Connect the LSU harness properly.
2. Check whether the LSU motor is rotating or not.	2. Replace a LSU.
3. Check the HSYNC signal.	3. Replace a main board if the same error occurs again after replacing a LSU.

6.4.3 Not function of the gear of the fuser due to melting away

- **Description** The motor breaks away from its place due to gear melting away.

Check and Cause	Solution
1. Check the Fuser Unit.	1. Replace the Fuser. 2. Replace the Main PBA. 2. Replace the SMPS.

6.4.4 Paper Empty

- **Description** The paper lamp on the operator panel is on even when paper is loaded in the cassette.

Check and Cause	Solution
1. Bending or deformation of the actuator of the paper sensor.	1. Replace the defective actuator.
2. The function of the engine board is defective	2. Replace the empty sensor PBA.
3. Check the connector and harness.	

6.4.5 Paper Empty without indication

- **Description** A message "Paper Empty" is displayed in a LCD panel.
The paper lamp on the operator panel does not come on when the paper cassette is empty.

Check and Cause	Solution
1. Bending or deformation of the actuator of the paper sensor.	1. Replace the defective actuator.
2. Check the Main board.	2. Replace the board which has a trouble.
3. Check the empty sensor board.	
4. Check the toner sensor board.	

6.4.6 Cover Open

- **Description** A message "Close Top Cover" is displayed in a LCD panel.
The ERROR lamp is on even when the print cover is closed.

Check and Cause	Solution
1. The hook lever in the top cover may be defective.	1. Replace the hook lever, if defective.
2. Check the main board	2. Check the insertion of the cover open S/W connect.
3. Check the cover open board.	3. Replace the main board or cover open board.
4. Check the harness and connection.	

6.4.7 No error message when the cover is open

- **Description** The ERROR message does not come on even when the printer cover is open

Check and Cause	Solution
1. Check the cover open circuit on the main board. 2. Check the cover open board.	1. Check the insertion of the cover open S/W connect. 2. Replace the main control board or cover open board.

6.4.8 Defective motor operation

- **Description** Main motor is not driving when printing, and paper does not feed into the printer, resulting 'Jam 0'.

Check and Cause	Solution
1. The motor harness or motor PCB may be defective.	1. Replace the motor unit.
2. Check the motor operation in the EDC mode.	2. Replace the main PBA.

6.4.9 No Power

- **Description** When system power is turned on, all lamps on the operator panel do not come on.

Check and Cause	Solution
1. Check if the power input and SMPS output are normal.	1. Replace the SMPS.
2. Check the inferiority of LED-Panel or LDC window on the front-cover if the OP panel does not appear after normal warming-up.	2. Replace the control board.

6.4.10 Vertical Line Getting Curved

- **Description** When printing, vertical line gets curved.

Check and Cause	Solution
1. If the supply of +24v is unstable in the main control board linking with LSU, check drive by EDC mode: LSU check.	1. Replace LSU.
2. Check the deve PBA in the print cartridge.	2. Replace the toner sensor PBA. 2. Replace the main PBA.

6.5 Maintaining the toner cartridge

Toner cartridge storage

To get the most from the toner cartridge, keep the following guidelines in mind:

- Do not remove the toner cartridge from its package until ready for use.
- Do not refill the toner cartridge. The printer warranty does not cover damage caused by using a refilled cartridge.
- Store toner cartridge in the same environment as the printer.
- To prevent damage to the toner cartridge, do not expose it to light for more than a few minute.

Expected cartridge life

The life of the toner cartridge depends on the amount of toner that print jobs require. When printing text at ISO 19752 5% coverage, a new toner cartridge lasts an average of either 20,000 or 10,000 pages. (The original toner cartridge supplied with the printer lasts an average of 10,000 pages.) The actual number may also be different depending on the print density of the pages you print on, and the number of pages may be affected by operating environment, printing interval, media type, and media size. If you print a lot of graphics, you may need to change the cartridge more often.

Saving toner

To save toner, press Toner Save on the control panel. The button backlight turns on.

Using this feature extends the life of the toner cartridge and reduce your cost per page, but it also reduces print quality.

6.5.1 Checking the remaining toner

You can check the level of toner left in the cartridge.

If you are having print quality problems, this can help you determine if the problem is caused by low toner.

Following the key formation at the panel, note the toner remaining level on the cartridge information after taking out the configuration sheet. In other way to check, follow the TECH mode and out put the cartridge information.


The display shows the percentage of the remaining toner.

6.5.2 Redistributing toner cartridge

When the toner cartridge is near the end of its life:

- White streaks and light printing occur.
- Toner Low appears on the display.
- The Smart Panel program window appears on the computer telling you that the toner level is low.
- The Status LED blinks red. If this happens, you can temporarily reestablish print quality by redistributing the remaining toner in the cartridge. In some cases, white streaks or light printing will still occur even after you have redistributed the toner.


1. Open the top cover.
2. Pull the toner cartridge out.



Caution :


- Avoid reaching too far into the printer. The fusing area may be hot.
- To prevent damage to the toner cartridge, do not expose it to light for more than a few minutes. Cover it with a piece of paper, if necessary.
- Do not touch the green surface underside of the toner cartridge. Use the handle on the cartridge to avoid touching this area.

3. Thoroughly shake the cartridge 5 or 6 times to distribute the toner evenly inside the cartridge.



Note : If toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets toner into fabric.

4. Hold the toner cartridge by the handle and slowly insert the cartridge into the opening in the printer. Tabs on the sides of the cartridge and corresponding grooves within the printer will guide the cartridge into the correct position until it locks into place completely.



5. Close the top cover. Make sure that the cover is securely closed.

6.5.3 Replacing the toner cartridge


When the toner cartridge is completely empty:

- Replace Toner appears on the display.
- The Smart Panel program window appears on the computer telling you that the toner cartridge is empty.
- The Status LED lights red.


At this stage, the toner cartridge needs to be replaced. For order information for toner cartridges,

Note : This feature does not work for the Toner Empty message.

1. Open the top cover.
2. Pull the toner cartridge out.




3. Remove the new toner cartridge from its bag.



Caution : Do not use sharp objects, such as a knife or scissors, to open the toner cartridge package. They might scratch the drum of the cartridge.


4. Locate the sealing tape at the end of the toner cartridge. Carefully pull the tape completely out of the cartridge and discard it.




Note : • The sealing tape should be longer than 60 cm when correctly removed.

- Holding the toner cartridge, pull the sealing tape straight to remove it from the cartridge. Be careful not to cut the tape. If this happens, you cannot use the toner cartridge.
- Refer to the helpful pictures on the cartridge wrapping paper.

5. Remove the flexible plastic holder out of the toner cartridge.




6. Thoroughly shake the cartridge 5 or 6 times to distribute the toner evenly inside the cartridge.



Thoroughly roll the cartridge to assure maximum copies per cartridge. Save the box and the plastic bag for shipping.

- Caution :**
- If toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets toner into fabric.
 - To prevent damage to the toner cartridge, do not expose it to light for more than a few minutes. Cover it with a piece of paper, if necessary.
 - Do not touch the green surface underside of the toner cartridge. Use the handle on the cartridge to avoid touching this area.

7. Hold the toner cartridge by the handle and slowly insert the cartridge into the opening in the printer. Tabs on the sides of the cartridge and corresponding grooves within the printer will guide the cartridge into the correct position until it locks into place completely.



8. Close the top cover. Make sure that the cover is securely closed.

6.5.4 Toner Cartridge-related messages

Message	Meaning	Suggested solutions
Install Toner	A toner cartridge is not installed.	Install a toner cartridge.
Invalid Toner	The toner cartridge you have installed is not for your printer.	Install a Samsung -genuine toner cartridge ,designed for your printer.
Toner Low	The toner cartridge is almost empty.	Take out the toner cartridge and thoroughly shake it.By doing this,you can temporarily reestablish printing operations.
NonGenuine Toner ◀ Stop ▶	The toner cartridge installed is not a genuine cartridge.	You can select either Stop or Continue.If you do not select any,the printer will work as Stop is selected. If you select Stop, you cannot print until the genuine cartridge is installed.However, you can still print any kind of reports. If you select Continue, you can keep printing but the quality cannot be guaranteed, and the product support is no longer provided. If you want to change the selection, turn the printer off and on to have this message appear again, and then re-select Stop or Continue.
NonGenuine Toner Replace Toner1	The toner cartridge installed is not a genuine cartridge.	This message appears when you selected Stop at the NonGenuine Toner prompt. Install the genuine toner cartridge.
NonGenuine Toner Replace Toner	The toner cartridge installed is not a genuine cartridge.	This message appears when you selected Continue at the NonGenuine Toner prompt. Install the genuine toner cartridge.
Toner Low Replace Toner	The toner in the cartridge has run out.	Install a new genuine toner cartridge. You can keep printing but the quality cannot be guaranteed, and the product support is no longer provided. You can configure not to see the Toner Low Replace Toner message.
Replace Toner	The toner cartridge installed is not a genuine cartridge.	This message appears when you turned off the Toner Low Replace Toner message. Install a new genuine toner cartridge. You can keep printing but the quality cannot be guaranteed, and the product support is no longer provided.
Toner Exhausted ◀ Stop ▶	The lifespan of the toner cartridge is reached.	You can select either Stop or Continue. If you do not select any, the printer will work as Stop is selected. If you select Stop, you cannot print until the genuine cartridge is installed. If you select Continue, you can keep printing but the quality cannot be guaranteed, and the product support is no longer provided. If you want to change the selection, turn the printer off and on to have this message appear again, and then re-select Stop or Continue.
Toner Exhausted Replace Toner1	The lifespan of the toner cartridge is reached.	This message appears when you selected Stop at the Toner Exhausted prompt. Install the genuine toner cartridge.
Toner Exhausted Replace Toner	The lifespan of the toner cartridge is reached.	This message appears when you selected Continue at the Toner Exhausted prompt. Install the genuine toner cartridge.

6.6 The cause and solutions of bad environment of the software

6.6.1 The printer is not working (1)

- **Description** While Power turned on, the printer is not working in the printing mode.

Check and Cause	Solution
1. Run Self-Test Mode: Turn the power on while pressing the test printing button for 2 or 3 seconds before printing works.	1. Check the power of the printer and perform the Self-Test. If the test printing works, that means no problems in the printer itself. If the test printing does not work, that means bad functioning of the printer (not because of software).
2. Check if the PC and the printer is properly connected and the print cartridge installed.	2. Replace the printer cable. If the problems not solved even after the cable replaced, check the amount of the remaining tone. (refer to print cartridge Service 4-5)
3. Printing is not working in the Windows.	3. Check if the connection between PC and printer port is proper. If you use windows, check if the printer driver in the controller is set up. If the printer driver is properly set up, check in which program the printing is not working. The best way to find out is to open the memo pad to check the function of printing. If it is not working in a certain program, adjust the setup the program requires. Sometimes, the printout is normal within the Windows basic programs, but it's not working in a particular program. In such case, install the new driver again. If not working in the Windows basic program, Check the setup of the port of CMOS is on ECP. And check the address of IRQ 7 and 378
4. Check if the printer cable is directly connected to peripheral devices	4. If the scanner needs to be connected to the printer, first the remove the scanner from the PC to see if the printer is properly working alone.

6.6.2 The printer is not working (2)

- **Description** After receiving the printing order, no response at all or the low speed of printing occurs due to wrong setup of the environment rather than malfunction of the printer itself.

Check and Cause	Solution
1. Secure more space of the hard disk.	1. Not working with the message 'insufficient printer memory' means hard disk space problem rather than the RAM problem. In this case, provide more space for the hard disk. Secure more space using the disk utilities program.
2. Printing error occurs even if there is enough space in the hard disk.	2. The connection of the cable and printer port is not proper. Check if the connection is properly done and if the parallel port in CMOS is rightly set up.
3. Check the parallel-port-related items in the CMOS Setup.	3. As a printer port, Select ECP or SPP among SPP(Normal), ECP, and EPP modes(increase printing speed) SPP normal mode support 8-bit data transfer, while ECP Mode transfer the 12-bit data.
4. Reboot the system to print.	4. If the regular font is not printing, the cable or the printer driver may be defective. Turn the PC and printer off, and reboot the system to print again. If not solved, double-click the printer in my computer If the regular fonts are not printed this time again. the cable must be defective so replace the cable with new one.

6.6.3 Abnormal Printing

• **Description**

The printing is not working properly even when the cable has no problem.
(even after the cable is replaced)

If the printer won't work at all or the strange fonts are repeated, the printer driver may be defective or wrong setup in the CMOS Setup.

Check and Cause	Solution
1. Set up the parallel port in the CMOS SETUP.	1. Select SPP(Normal) or ECP LPT Port the among ECP, EPP or SPP in the CMOS Setup.
2. Printer Driver Error.	2. Check the printer in My Computer.(to see if the printer driver is compatible to the present driver or delete the old driver, if defective and reinstall the new driver)
3. Error message from insufficient memory. (The printing job sometimes stops or due to insufficient virtual memory, but it actually comes from the insufficient space of the hard disk.)	3. Delete the unnecessary files to secure enough space of the hard disk and start printing job again.

6.6.4 SPOOL Error

• Description

To spool which stands for "simultaneous peripheral operations online" a computer document or task list (or "job") is to read it in and store it, usually on a hard disk or larger storage medium so that it can be printed or otherwise processed at a more convenient time (for example, when a printer is finished printing its current document).

Check and Cause	Solution
1. Insufficient space of the hard disk in the directory assigned for the basic spool.	1. Delete the unnecessary files to provide more space to start printing job.
2. If the previous printing error not solved.	2. If there are some files with the extension name of ****.jnl, Delete them and Reboot the Windows to restart printing job.
3. When expected to collide with other program.	3. Shut down all other programs except the current one, if possible.
4. When an application program or the printer driver is damaged.	4. Delete the printer driver completely and reinstall it.
5. When some files related to OS are damaged or virus infected.	5. After rebooting the computer, check for viruses, restore the damaged files and reinstall the program to do the printing job.
6. Memory is less than suggested one.	6. Add up enough memory to the PC.

How to delete the data in the spool manager.

In the spool manager, the installed drivers and the list of the documents waiting to be printed are shown. Select the document to be deleted and check the delete menu.

If you intend to delete the current document being printed, the data being transferred to the printer will be put out and then the document is removed. Before choosing the document, the menu is still inactive.

Or put the document out of the list and repeat the routine as in the above or finish the spool manager.

7. Exploded Views and Parts List (ML-4550 Series)

Contents

- 7.1 Main Assembly
- 7.2 Cover Assembly
- 7.3 Frame Assembly
- 7.4 Fuser Unit
- 7.5 REGI Assembly
- 7.6 Main Motor Assembly
- 7.7 Deve Motor Assembly
- 7.8 Exit Sorenoid Assembly
- 7.9 Cassette Assembly
- 7.10 Duplex Unit
- 7.11 SCF Unit

DIGITAL LASER PRINT




CONTENTS

[The keynote of Product]

- Series Model: ML-4550 / 4551N / 4551ND
- High speed Laser Printer:
Up to 43 ppm in A4 (45 ppm in Letter),
Duplex: 29 ipm (A4); 30 ipm (Letter)
- Resolution: Up to 1200 x 1200 dpi
- Marvell 500Mhz
- Memory: 128 MB (Max. 512 MB)
128, or 256 MB optional memory available.
Use only the Samsung-approved DIMM.
128 MB: ML-MEM150, 256 MB: ML-MEM160
- Option:
ML-4550:500-sheet trays, ethernet 10/100 Base
TX wired LAN, ethernet 10/100 Base
hard disk, duplex unit, DIMM
- Toner cartridge:
. Starter: 10K or 20K pages
. Consumable: 10K or 20K pages
- Duty cycle: Monthly Up to 150,000 pages

7.1 Main Assembly



Service Parts List(ML-4551N/ND/NDR)


Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.1-0	ML-4550	MONO LASER,43PPM/A4		1	-	
7.1-0	ML-4551N	MONO LASER,43PPM/A4,NETWORK		1	-	
7.1-0	ML-4551ND	MONO LASER,43PPM/A4,NETWORK,DUPLEX		1	-	
7.1-1	JC96-04004A	ELA UNIT-FRAME BASE		1	SA	110V
7.1-1	JC96-04004B	ELA UNIT-FRAME BASE	Z4398	1	SA	220V
7.1-2	JC96-04064A	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4551N
7.1-2	JC96-04064B	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4551ND
7.1-2	JC96-04064E	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4551NDR
7.1-2	JC96-04064C	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4550R,4551NR
7.1-3	JC97-02230B	MEA UNIT-KNOCK UP MP	G0470	1	SA	
7.1-3	JC97-02230D	MEA UNIT-KNOCK UP MP	G0470	1	SA	ML-4551NDR
7.1-3-1	JC61-01251B	PLATE-M KNOCK UP MP	W3027	1	SA	
7.1-3-1	JC61-01251C	PLATE-M KNOCKUP MP	W3027	1	SA	ML-4551NDR
7.1-3-2	JC74-00011A	MPR-PAD KNOCK UP MP	O1109	1	SA	
7.1-3-3	JC72-01006B	PMO-SIDE GUIDE MP(R)	G2301	1	SA	
7.1-3-4	JC72-01005B	PMO-SIDE GUIDE MP(L)	G2299	1	SA	
7.1-3-5	JG66-40003A	GEAR-PINION	O1127	1	SA	
7.1-3-6	JC66-00895A	SHAFT-REINFORCEMENT	Z4400	1	SNA	
7.1-4	JC97-02231A	MEA UNIT-COVER MP SEC	E4062	1	SA	
7.1-4	JC97-02231D	MEA UNIT-COVER MP	E4062	1	SA	ML-4551NDR
7.1-4-1	JC63-00695A	COVER-M-MP SEC	Z4401	1	SNA	
7.1-4-1	JC63-00695D	COVER-M_MP	Z4401	1	SNA	ML-4551NDR
7.1-4-2	JC63-00691B	TRAY-M EXTEND MP	K4281	1	SA	
7.1-4-2	JC63-00691C	TRAY-M EXTEND_MP	K4281	1	SA	ML-4551NDR
7.1-5	JC63-00694B	TRAY-M LINK MP(L)	K4282	1	SA	
7.1-6	JC63-00689B	TRAY-M LINK MP(R)	K4283	1	SA	
7.1-5	JC63-00694C	TRAY-M LINK MP(L)	K4282	1	SA	ML-4551NDR
7.1-6	JC63-00689C	TRAY-M LINK MP(R)	K4283	1	SA	ML-4551NDR
7.1-7	JC66-00540B	ROLLER-TRANSFER	Z4402	1	SA	
7.1-8	JC96-01729A	ELA UNIT-HOLDER TR R	K3139	1	SA	
7.1-8-1	JC72-41142A	PMO-BUSHING TR	Z4403	1	SNA	
7.1-8-2	JC61-00046A	SPRING ETC-TR R HAWK	Z4404	1	SNA	
7.1-8-3	JC72-41145C	PMO-TRANSFER HOLDER R	Z4405	1	SNA	
7.1-8-4	JC70-11053A	IPR-PLATE TR	Z4406	1	SNA	
7.1-9	JC96-01730B	ELA UNIT-HOLDER TR L	Z6106	1	SA	
7.1-9-1	JC72-41142A	PMO-BUSHING TR	Z4403	1	SNA	
7.1-9-2	JC61-00046A	SPRING ETC-TR R HAWK	Z4404	1	SNA	
7.1-9-3	JC72-41145F	PMO-TRANSFER HOLDER L	Z4407	1	SA	
7.1-10	JC72-41292B	PMO-CAP TR	Z0015	1	SA	
7.1-11	JC66-00039A	GEAR-TR29	G0439	1	SA	
7.1-12	JC96-03959A	ELA UNIT-REGI	Z4408	1	SA	
7.1-13	JC66-00420A	GEAR-REGI Z25	G0415	1	SA	
7.1-14	JC67-00039A	CAP-M-GEAR	C1013	1	SA	
7.1-15	JC96-04066A	ELA UNIT-LSU	Z4409	1	SA	
7.1-16	JC96-03426A	ELA UNIT-EXIT SOL	K3059	1	SA	
7.1-17	JC96-03408A	ELA UNIT-DEVE MOTOR	K3057	1	SA	
7.1-18	JC96-04063A	ELA UNIT-MAIN	Z4410	1	SA	
7.1-19	JC96-04109A	ELA HOU-MAIN	Z4411	1	SNA	
7.1-19-1	JC92-01823A	PBA MAIN-CONTROLLER	Z4412	1	SA	
7.1-19-2	JC92-01824A	PBA MAIN-DIMM	Z4413	1	SA	
7.1-20	JC97-02226A	MEA UNIT-GEAR PICK UP	G0468	1	SA	
7.1-20-1	JC66-00870A	GEAR-M-PICK UP CAM	Z4414	1	SNA	
7.1-20-2	JC66-00876A	GEAR-M-PICK UP	Z4415	1	SNA	
7.1-20-3	JC61-00003A	SPRING ETC--CAM MP	S0020	1	SA	
7.1-21	JC97-01738A	MEA UNIT-GEAR P/UP MP CARDINA	G0467	1	SA	
7.1-21-1	JC66-00424A	GEAR-MP HOLDER CAM	H4008	1	SA	
7.1-21-2	JC66-00423A	GEAR-MP PICK UP	P2055	1	SA	
7.1-21-3	JC61-00003A	SPRING ETC--CAM MP	S0020	1	SA	
7.1-22	JC66-10202A	BEARING-PICK UP	B0003	1	SA	
7.1-23	JC61-00755A	BRACKET-P-SHAFT MP	S4013	1	SA	
7.1-24	JC61-01735A	HOLDER-FAN	Z4416	1	SA	
7.1-25	JC33-00012A	SOLENOID-MAIN	S8015	1	SA	
7.1-26	JC33-00016A	SOLENOID-MP	S8016	1	SA	
7.1-27	JC96-04121A	ELA UNIT-DEVE ERASER	Z4417	1	SA	
7.1-28	JC63-01133A	SHIELD-SMPS	Z4418	1	SNA	
7.1-29	JC96-04003B	ELA HOU-SMPS HVPS V2	Z4419	1	SA	220V

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QT'Y	Service	Remark
7.1-29	JC96-04003A	ELA HOU-SMPS_HVPS_V1	Z4419	1	SA	110V
7.1-30	JC71-00042A	BAR-P_CROSS BOTTOM	K2861	2	SA	
7.1-31	JC31-00050A	FAN	Z4425	1	SA	
7.1-32	JC61-00667A	STOPPER-M-FAN80	F5029	1	SA	
7.1-33	JC61-01760A	HOLDER-ERASER	Z4421	1	SA	
7.1-34	JC96-03963A	ELA UNIT-DEVE	Z4422	1	SNA	
7.1-35	JC96-04015A	ELA UNIT-CASSETTE	Z4423	1	SA	
7.1-35	JC96-04015B	ELA UNIT-CASSETTE	Z4423	1	SA	ML-4551NDR
7.1-36	JC92-01839A	PBA-ERASE_LAMP	Z4424	1	SA	
7.1-37	JC96-03412C	ELA UNIT-DUPLEX	Z6089	1	SA	
7.1-37	JC96-03412E	ELA UNIT-DUPLEX	Z6089	1	SA	ML-4551NDR
7.1-38	JC31-00050A	FAN	Z4425	1	SA	
7.1-39	JC96-03586A	ELA HOU-EMBEDDED_MAC	Z4426	1	SNA	
7.1-39-1	JC92-01700B	PBA SUB-NPC_PRT	Z4427	1	SA	
7.1-39-2	JC61-00809A	BRACKET_M_NPC	B0005	1	SNA	
Replacement	-	CBF-POWER CORD			SA	
Replacement	-	BOX-MAIN			SA	


7.2 Cover Assembly




Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.2-0	JC96-04064A	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4550
7.2-0	JC96-04064B	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4551NR
7.2-0	JC96-04064E	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4551NR
7.2-0	JC96-04064C	ELA HOU BASE-HOUSING	Z4399	1	SNA	ML-4550R,4551NR
7.2-1	JC96-03978A	ELA UNIT-COVER TOP	Z6090	1	SA	ML-4550
7.2-1	JC96-03978B	ELA UNIT-COVER TOP	Z6090	1	SA	ML-4550
7.2-1	JC96-03978C	ELA UNIT-COVER TOP	Z6090	1	SA	ML-4551NR
7.2-1	JC96-03978W	ELA UNIT-COVER TOP	Z6090	1	SA	ML-4551NR
7.2-1	JC96-03978U	ELA UNIT-COVER TOP	Z6090	1	SA	ML-4551NR
7.2-1	JC96-03978Q	ELA UNIT-COVER TOP	Z6090	1	SA	ML-4550R
7.2-1-1	JC63-00699B	COVER-M TOP	Z4429	1	SNA	
7.2-1-1	JC63-00699B	COVER-M TOP	Z4429	1	SNA	
7.2-1-1	JC63-00699C	COVER-TOP	Z4429	1	SNA	ML-4551NR
7.2-1-2	JC63-01101A	COVER-M_OPEN	Z4430	1	SA	
7.2-1-2	JC63-01101B	COVER-M_OPEN	Z4430	1	SA	ML-4551NR
7.2-1-3	JC72-01367B	PMO-STACKER_RX	L6055	1	SA	
7.2-1-3	JC72-01367C	PMO-STACKER_RX	L6055	1	SA	ML-4551NR
7.2-1-4	JC66-00902B	LEVER-M_STACKING 38	L3019	2	SA	
7.2-1-4	JC66-00902C	LEVER-STACKING	L3019	2	SA	ML-4551NR
7.2-1-5	JC61-00656A	STOPPER-M-HINGE OPEN	H3073	2	SA	
7.2-1-6	JC63-01100C	COVER-OP PANEL	Z6100	1	SA	
7.2-1-6	JC63-01445C	COVER-OP PANEL	Z6100	1	SA	ML-4551NR
7.2-1-6	JC63-01445A	COVER-OP PANEL	Z6100	1	SA	ML-4551NR
7.2-1-6	JC63-01100W	COVER-OP PANEL	Z6100	1	SA	ML-4550R
7.2-1-7	JC67-00147A	LENS LED-M_STATUS	Z4432	1	SNA	
7.2-1-8	JC75-00095A	MEC-BRUSH ANTISTATIC	M0022	1	SA	
7.2-1-9	JC92-01825B	PBA SUB-PANEL	Z4433	1	SA	
7.2-1-10	JC64-00265A	KEY-M_BUTTON	Z4434	1	SA	
7.2-1-10	JC64-00265B	KEY-M_BUTTON	Z4434	1	SA	ML-4551NR
7.2-1-11	JC64-00236A	KEY-M_STOP	Z4435	1	SNA	
7.2-1-12	JC64-00047A	KEY-M-SAVE MODE	K0049	1	SA	
7.2-1-13	JC64-00194A	WINDOW-M-LCD	K4285	1	SA	
7.2-1-14	JC63-00836A	GROUND-P-TOP_COVER	G0440	1	SA	
7.2-2	JC63-00684B	COVER-M_LEFT	H1292	1	SA	
7.2-2	JC63-00684C	COVER-M_LEFT	H1292	1	SA	ML-4551NR
7.2-3	JC63-00701B	COVER-M_RIGHT	H1294	1	SA	
7.2-3	JC63-00701C	COVER-M_RIGHT	H1294	1	SA	ML-4551NR
7.2-4	JC63-00702B	COVER-M_CONTROL BOX	H1288	1	SA	
7.2-4	JC63-00702C	COVER-M_CONTROL BOX	H1288	1	SA	ML-4551NR
7.2-5	JC63-00685B	COVER-M_FRONT INNER	H1291	1	SA	
7.2-5	JC63-00685C	COVER-M_FRONT INNER	H1291	1	SA	ML-4551NR
7.2-6	JC97-02232B	MEA UNIT-COVER REAR	E4063	1	SA	
7.2-6	JC97-02232C	MEA UNIT-COVER REAR	E4063	1	SA	ML-4551NR
7.2-6-1	JC63-00703B	COVER-M_REAR	H1293	1	SA	
7.2-6-1	JC63-00703C	COVER-M_REAR	H1293	1	SA	ML-4551NR
7.2-6-2	JC72-01357A	PMO-STACKER REAR	L6054	1	SA	
7.2-6-2	JC72-01357B	PMO-STACKER REAR	L6054	1	SA	ML-4551NR
7.2-6-3	JC70-00007A	ICT-BRKT REAR COVER	Z4436	1	SNA	
7.2-6-4	JC61-01217A	GUIDE-M_EXIT	G0441	1	SA	
7.2-6-5	JC72-01359A	PMO-STRIFE	L6056	1	SA	
7.2-6-6	JC70-20901A	IEX-SHAFT IDLE,F/UP	D2149	2	SA	
7.2-6-7	JC72-20902A	PEX-ROLLER F/UP(2)	O1106	2	SA	
7.2-6-8	JC61-01774A	SPRING ETC-SEPERATION	Z6115	5	SA	
7.2-6-9	JC68-01526A	LABEL(P)-JAM REMOVAL	Z4438	1	SNA	
7.2-7	JC97-02389B	MEA UNIT-COVER DUMMY	Z4420	1	SA	ML-4550
7.2-7	JC97-02389C	MEA UNIT-COVER DUMMY	Z4420	1	SA	ML-4550R
7.2-7-1	JC72-01374A	SPONGE-COVER DUMMY	Z4421	1	SNA	ML-4550
7.2-7-2	JC63-00697B	COVER-M_DUMMY DUP	Z4422	1	SA	ML-4550
7.2-7	JC97-02389C	MEA UNIT-COVER DUMMY	Z4420	1	SA	ML-4551NR
7.2-7-2	JC63-00697C	COVER-M_DUMMY DUP	Z4422	1	SA	ML-4550R,4551NR
7.2-8	JC63-00696B	COVER-M_FRAME EXIT	H1290	1	SA	
7.2-8	JC63-00696C	COVER-M_FRAME EXIT	H1290	1	SA	ML-4551NR

7.3 Frame Assembly(1/2)



Frame Assembly(2/2)



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.3-0	JC96-04004A	ELA UNIT-FRAME BASE	Z4398	1	SA	110V
7.3-0	JC96-04004B	ELA UNIT-FRAME BASE	Z4398	1	SA	220V
7.3-1	JC61-01206A	FRAME-M_BASE	Z4440	1	SNA	
7.3-2	JC97-02649A	MEA UNIT-PICK UP MP	Z4441	1	SA	
7.3-2-1	JC66-01265A	SHAFT-PICK UP MP	Z4442	1	SA	
7.3-2-2	JC72-01003A	PMO-IDLE PICK UP MP	P0042	2	SA	
7.3-2-3	JC66-00893A	CAM-M-SHAFT	P2043	1	SA	
7.3-2-4	JC96-02686B	ELA UNIT-ROLLER P/UP MP	K3144	1	SA	
7.3-2-4-1	JC61-00705A	HOLDER-M-PICKUP MP	P2062	1	SA	
7.3-2-4-2	JC61-00685A	HOUSING-M-PICK UP MP	H0025	1	SA	
7.3-2-4-3	JC73-00224A	RUBBER-PICK UP MP	C4024	1	SA	
7.3-3	JC97-02238A	MEA UNIT-GEAR IDLE	E4065	1	SA	
7.3-3-1	JC61-01200A	BRACKET-P-GEAR IDLE	Z4443	1	SNA	
7.3-3-2	JC66-00872A	GEAR-FUSER IDLE 3	Z4444	1	SNA	
7.3-3-3	JC66-00859A	GEAR-M-FUSER IDLE 2	Z4445	1	SNA	
7.3-3-4	JC66-00858A	GEAR-M-FUSER DRV IN		1	SNA	
7.3-3-5	JC66-00868A	CLUTCH-M-HUB	Z4446	1	SNA	
7.3-3-6	JC66-01155A	GEAR-FUSER RDCN OUT V	Z4536	1	SNA	
7.3-3-7	6044-000231	RING-E	R0006	2	SA	
7.3-4	JC96-03403A	ELA HOU BASE-HOLDER	H1297	1	SA	
7.3-4-1	JC61-01248A	FRAME-M-HOLDER PAD	Z4448	1	SNA	
7.3-4-2	JC61-00684A	HOLDER-M-PAD	H4029	1	SA	
7.3-4-3	JC73-00132A	RPR-FRICTION PAD MP	R0019	1	SA	
7.3-4-4	JC61-00387A	SPRING ETC-PAD	S0028	1	SA	
7.3-4-5	JC72-01365A	PMO-ACTUATOR EMPTY MP	W3028	1	SA	
7.3-4-6	JC61-70965A	SPRING ETC-EMPTY	O1099	1	SA	
7.3-4-7	0604-001095	PHOTO-INTERRUPTER	P0013	1	SA	
7.3-4-8	JC39-00451A	CBF HARNESS-MP EMPTY	H1253	1	SA	
7.3-5	JC97-01034A	MEA RACK-EXIT ROLLER	E4060	4	SA	
7.3-5-1	JC72-41006A	PMO-HOLDER EXIT ROLL	E4126	1	SA	
7.3-5-2	JC72-41007A	PMO-ROLLER FD F	P0048	1	SA	
7.3-5-3	JC72-41008A	PMO-ROLLER FD R	P0049	1	SA	
7.3-5-4	JC61-70911A	SPRING ETC-EXIT ROLL FD	O1053	1	SA	
7.3-6	JC66-00883A	ROLLER-EXIT_F/DOWN	D4089	1	SA	
7.3-8	JC72-01310A	PMO-ACTUATOR OUTFULL	K3819	1	SA	
7.3-9	JC66-00674A	GEAR-M-EXIT Z17	G0331	1	SA	
7.3-12	JC61-01262A	BUSH-M_EXIT D7	S4014	2	SA	
7.3-13	JC66-00854A	GEAR-M-EXIT DUP Z21	G0200	1	SA	
7.3-14	JC96-02127A	ELA HOU-CST SENSOR HAWK16	Z2263	1	SA	
7.3-14-1	JC92-01336A	PBA SUB-CASSETTE	Z4451	1	SA	
7.3-14-2	JC70-00192A	IPR-PLATE SENSOR	S3058	1	SA	
7.3-14-3	JC70-00195A	IPR-BRACKET SENSOR	S3055	1	SA	
7.3-15	JC39-00261A	CBF HARNESS-SENSOR	H1242	1	SA	
7.3-16	JC61-00675A	GUIDE-P_REGI UPPER	G2082	1	SA	
7.3-17	JC61-70918A	SPRING ETC-LEVER	L4097	2	SA	
7.3-19	JC61-00691A	GUIDE-PLATE PAPER	G2091	1	SA	
7.3-20	JC70-00339A	IPR-P_GROUND PLATE PAPER	P5064	1	SA	
7.3-21	0604-001095	PHOTO-INTERRUPTER	P0013	1	SA	
7.3-23	JC39-00458A	CBF HARNESS-THERM	H1256	1	SA	
7.3-24	JC61-01581A	HOUSING-M_TERMINAL	Z4452	1	SNA	
7.3-25	JC65-00013A	TERMINAL-P-FUSER	K4277	1	SA	
7.3-26	JC39-00456A	CBF HARNESS-FUSER	H1249	1	SA	
7.3-27	JC67-00099A	CAP-M-HOUS TERM	Z4453	1	SNA	
7.3-28	JC63-01132A	SHIELD-CTRL	Z4454	1	SA	
7.3-29	JC63-00677A	GROUND-P-MOTOR_DEVE	Z4455	1	SNA	
7.3-30	JC63-00669A	GROUND-P_GUIDE TR	Z4456	1	SNA	
7.3-31	JC63-00672A	GROUND-P-REGI_ROLLER	Z4457	1	SNA	
7.3-32	JC63-00678A	GROUND-P-PICK_UP_MP	Z4458	1	SNA	
7.3-33	JC63-00673A	GROUND-P-SCF_MAIN	Z4459	1	SNA	
7.3-34	JC63-00671A	GROUND-P-MOTOR_MAIN	Z4460	1	SNA	
7.3-35	JC63-00680A	GROUND-P-GUIDE_DUP	Z4461	1	SNA	
7.3-36	JC67-00093A	CAP-M-GUIDE_HARNESS	Z4462	1	SNA	
7.3-37	JC72-01356A	PMO-DUMMY_DEVE	Z0016	1	SA	
7.3-38	JC96-01772A	ELA HOU-VARISTOR	K3053	1	SA	
7.3-39	JC61-40001A	FOOT-ML80	F0003	2	SA	
7.3-40	JC72-01355A	PMO-REMOVE_LOCK_CST	L6040	1	SA	
7.3-43	JC72-41191B	PMO-BEARING SHAFT	P0032	6	SA	
7.3-47	JC96-03960A	ELA HOU-FRAME_LSU_LO	Z4463	1	SA	
7.3-47-1	JC61-01732A	FRAME-PART_UPPER	Z4464	1	SNA	
7.3-47-2	JC92-01807A	PBA SUB-TONER_SENSOR	Z4465	1	SA	
7.3-47-3	JC65-00004A	TERMINAL-P_DEVE	T2175	4	SA	
7.3-47-4	JC92-01730A	PBA SUB-COVER OEPN	M0443	1	SA	


Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.3-47-5	JC67-00095A	CAP-M COVER_OPEN	Z4466	1	SNA	
7.3-48	JC96-03425A	ELA UNIT-FEED3X5	K3062	1	SA	
7.3-48-1	JC61-01240A	HOLDER-M-SAW	Z4467	1	SNA	
7.3-48-2	JC61-01235A	GUIDE-P-TRANSFER_FRONT	Z4468	1	SNA	
7.3-48-3	JC61-01236A	PLATE-P-SAW	Z4469	1	SNA	
7.3-48-4	JC66-00889A	SHAFT-M ROLLER BELT	Z4470	1	SNA	
7.3-48-5	JC66-00887A	ROLLER-M IDLE BELT	Z4471	2	SNA	
7.3-48-6	JC70-20901A	IEX-SHAFT IDLE F/UP	D2149	2	SA	
7.3-48-7	JC73-00206A	RUBBER-BELT_FEED	C4020	2	SA	
7.3-48-8	JC61-01239A	GUIDE-M SHAFT BELT	Z4472	1	SNA	
7.3-49	JC96-04016A	ELA UNIT-ROLLER IDLE	Z4473	1	SA	
7.3-49-2	JC61-00635A	HOUSING-M-RETARD	H6035	1	SA	
7.3-49-3	JC73-00207A	RUBBER-RETARD	C4026	1	SA	
7.3-49-4	JC72-00993A	PMO-HUB OUT RETARD	K4021	1	SA	
7.3-49-5	JC66-01273A	SHAFT-IDLE FEED	Z4474	1	SA	
7.3-49-6	JC64-00271A	SHUTTER-PATH_FEED	Z4475	1	SA	
7.3-49-7	JC61-01550A	STOPPER-SPACE	Z4476	2	SNA	
7.3-49-8	JC64-00272A	SHUTTER-CLAW		2	SNA	
7.3-49-9	JC61-01741A	HOLD-IDLE FRONT	Z4477	1	SA	
7.3-49-10	JC61-00652A	BUSH-M-RETARD	K2883	2	SA	
7.3-49-11	JC61-00387A	SPRING ETC-PAD	S0028	2	SA	
7.3-49-12	JC61-01739A	HOLD-IDLE REAR	Z4479	1	SA	
7.3-49-14	JC64-00270A	SHUTTER-TENSION	Z4480	2	SA	
7.3-50	JC96-03421A	ELA UNIT-FEED2 IDLE	K3060	2	SA	
7.3-50-1	JC61-01242A	HOLDER-IDLE_FEED2	Z4481	1	SNA	
7.3-50-2	JC67-00105A	CAP-M IDLE_FEED2	Z4482	2	SNA	
7.3-50-3	JC61-00387A	SPRING ETC-PAD	S0028	2	SA	
7.3-50-4	JC61-00652A	BUSH-M-RETARD	K2883	2	SA	
7.3-50-5	JC66-00912A	SHAFT-IDLE_FEED2	S4108	1	SA	
7.3-50-6	6044-000231	RING-E	R0006	2	SA	
7.3-50-7	JC66-00892A	ROLLER-M IDLE_FEED2	Z4483	1	SNA	
7.3-51	JC61-01250A	STOPPER-M-KNOCK UP MP_L	H3074	1	SA	
7.3-52	JC61-01249A	STOPPER-M-KNOCK UP MP_R	H3075	1	SA	
7.3-53	JC61-01252A	RAIL-M-LEFT_DUP	L6057	1	SA	
7.3-54	JC61-01253A	RAIL-M-RIGHT_DUP	L6058	1	SA	
7.3-55	JC72-41191B	PMO-BEARING SHAFT	P0032	1	SA	
7.3-56	JC66-01262A	GEAR-FEED	Z4484	1	SNA	
7.3-57	JC72-01362A	PMO- M CAM_PICK UP	Z4485	1	SNA	
7.3-58	JC72-00991A	PMO-ACTUATOR EMPTY	K3816	1	SA	
7.3-59	JC96-03422A	ELA UNIT-PICK UP	K3141	1	SA	
7.3-59-1	JC66-00910A	SHAFT-PICK UP	S4118	1	SA	
7.3-59-2	JC97-02233A	MEA UNIT-P/UP HOUSING	G0471	1	SA	
7.3-59-2-1	JC72-01361A	PMO-M IDLE-PICK UP	L6039	2	SA	
7.3-59-2-2	JC61-01238A	HOUSING-M-PICK UP	Z4486	1	SNA	
7.3-59-2-3	JC73-00223A	RUBBER-PICK UP	C4025	1	SA	
7.3-59-3	JC61-01579A	HOLDER-P-REGI	Z4487	1	SNA	
7.3-59-4	JC66-00911A	SHAFT-FEED1	C4028	1	SA	
7.3-59-5	JC81-03458A	AS-UNIT_FEED1	K2860	1	SA	
7.3-59-5-1	JC61-01237A	HOUSING-M-FEED1	Z4488	1	SNA	
7.3-59-5-2	JC73-00208A	RUBBER-FEED1	C4022	1	SA	
7.3-59-6	JC63-00674A	GROUND-P-PICK UP_MAIN	Z4489	1	SNA	
7.3-59-7	JC61-01579A	HOLDER-P-REGI	Z4487	1	SNA	
7.3-59-8	JC72-00382B	PMO-BUSHING FEED	O1102	2	SA	
7.3-59-9	JC61-01234A	GUIDE-P-FRONT-DUP-PICKUP	Z4490	1	SNA	
7.3-59-10	JC61-01233A	GUIDE-M SUPPORT-PICKUP	Z4491	1	SNA	
7.3-60	JC96-04119A	ELA UNIT-FEED	Z4492	1	SA	
7.3-61	JC92-01704A	PBA SUB-JOINT	M0448	1	SA	
7.3-62	JC39-00441A	CBF HARNESS-TRAY OUT	H1257	1	SA	
7.3-63	JC67-00094A	CAP-M POWER	Z4493	1	SNA	
7.3-64	JC39-00624A	HARNESS-INLET	Z4494	1	SA	
7.3-65	JC66-00888A	SHAFT-M BELT_GEAR	Z4495	1	SNA	
7.3-66	JC72-41191B	PMO-BEARING SHAFT	P0032	1	SA	
7.3-67	JC66-00674A	GEAR-M-EXIT Z17	G0331	1	SA	
7.3-68	JC67-00092A	CAP-M-DEVE MOTOR	Z4496	1	SNA	
7.3-69	JC39-00449A	CBF HARNESS-DUPLEX	Z4497	1	SNA	
7.3-71	JC67-00036A	CAP-M-WIRE PTL LOWER	C1015	1	SA	
7.3-72	JC65-00001A	TERMINAL-P_PTL	K4276	2	SA	
7.3-73	JC92-01516A	PBA SUB-PTL2	M0411	1	SA	
7.3-76	JC92-01512B	PBA SUB-EXIT SENSOR	M0445	1	SA	
7.3-77	JC92-01261C	PBA SUB-FUSER SW	M0447	1	SA	
7.3-78	JC61-01218A	GUIDE-M-FRONT	G0442	1	SA	
7.3-79	JC65-00010B	TERMINAL-GUIDE_FRONT		1	SNA	

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QT'Y	Service	Remark
7.3-81	JC72-00317A	PMO-GUIDE DEVE L	T2158	1	SA	
7.3-82	JC72-00318A	PMO-GUIDE DEVE R	T2159	1	SA	
7.3-83	JC61-70932A	SPRING ETC-GUIDE DEVE	Z4159	2	SA	
7.3-84	JC65-00008A	TERMINAL-P-TR_KESTREL	K4278	1	SA	
7.3-86	JC65-00009A	TERMINAL-SPRING_TR	K4279	1	SA	
7.3-89	JC63-00679A	GROUND-P-ZENER	Z4498	1	SNA	
7.3-90	JC63-00676A	GROUND-P-FUSER	Z4499	1	SNA	
7.3-91	JC65-00006A	TERMINAL-P_HV CARDINAL	K4272	4	SA	
7.3-92	JC97-01401A	MEA UNIT-TERMINAL:TR	Z4500	4	SA	
7.3-93	JC39-00625A	HARNESS-HVPS	Z4501	1	SA	
7.3-94	JC70-00332A	IPR-P_GROUND OPC	O0020	1	SA	
7.3-95	JC92-01831A	PBA SUB-EMPTY	Z4502	1	SA	
7.3-96	JC39-00620A	HARNESS-SENSOR	Z4503	1	SA	
7.3-97	JC92-01262C	PBA SUB-FEED SENSOR	M0446	1	SA	
7.3-98	JC67-00098A	CAP-M_HV	Z4504	1	SNA	
7.3-99	JC67-00097A	CAP-M_SENSOR FEED	Z4505	1	SNA	


7.4 Fuser Unit



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.4-0	JC96-03957B	ELA UNIT-FUSER_220V	Z4506	1	SA	220V
7.4-0	JC96-03957A	ELA UNIT-FUSER_110V	Z4506	1	SA	110V
7.4-1	JC96-03958A	ELA UNIT-FUSER_UPPER	Z4507	1	SNA	110V
7.4-1	JC96-03958B	ELA UNIT-FUSER_UPPER	Z4507	1	SNA	220V
7.4-1-2	JC71-00056A	ELECTRODE-P-FU_L_08	Z4508	1	SNA	
7.4-1-4	JC72-41012C	PMO-GUIDE CLAW GREEN	Z0018	5	SA	
7.4-1-5	6107-001165	SPRING-TS		2	SA	
7.4-1-8	JC61-01215A	HOLDER-M-LEVER_L	Z4509	1	SNA	
7.4-1-9	JC61-00785A	HOLDER-M-IDLE ROLLER	H4027	3	SA	
7.4-1-10	JC72-40981A	PMO-ROLLER UPPER DP	K4068	3	SA	
7.4-1-12	JC61-01216A	HOLDER-M-LEVER_R	Z4510	1	SNA	
7.4-1-13	JC71-00052A	ELECTRODE-P-SUPPORT	Z4511	2	SNA	
7.4-1-15	6003-000196	SCREW-TAPTITE	Z4397	31	SA	
7.4-1-KIT	JC96-04058A	ELA UNIT-HEAT	Z6118	1	SNA	110V
7.4-1-KIT	JC96-04058B	ELA UNIT-HEAT	Z6118	1	SNA	220V
7.4-1-16	JC66-01268A	ROLLER-HEAT	Z4518	1	SNA	110V
7.4-1-16	JC66-01268B	ROLLER-HEAT	Z4518	1	SNA	220V
7.4-1-17	6601-001384	BEARING-BALL	Z4519	2	SNA	
7.4-1-19	JC61-01260A	BUSH-M_HR	S4015	2	SA	
7.4-1-21	JC61-01550A	STOPPER-SPACER	Z4476	4	SNA	
7.4-1-22	JC71-00051A	ELECTRODE-FU	Z4521	2	SNA	
7.4-1-24	JC67-00111A	CAP-M_ACTUATOR_UP	Z4522	1	SNA	
7.4-1-25	JC63-00726A	COVER-M-REAR GUIDE UP	Z4523	1	SNA	
7.4-1-26	JC71-00055A	ELECTRODE-P-SU CARBON	Z4524	1	SNA	
7.4-1-28	JC61-01284A	HOLDER-P-SL CONNECTOR	Z4525	1	SNA	
7.4-2-1	JC61-01213A	BRACKET-P-FUSER	Z4526	1	SNA	
7.4-2-3	JC66-00869A	GEAR-M-IDLE 25	Z4527	2	SNA	
7.4-3	JC97-02630A	MEA UNIT-FUSER_LOWER	Z4528	1	SNA	
7.4-3-1	JC66-00931A	ROLLER-PRESSURE	K4222	1	SA	
7.4-3-3	6107-001304	SPRING-CS	Z4530	1	SA	
7.4-3-5	JC66-00880A	LEVER-P-RELEASE_L	Z4532	1	SNA	
7.4-3-6	6107-001304	SPRING-CS	Z4530	1	SA	
7.4-3-7	JC67-00102A	CAP-M-FUSER LOCK	Z4533	2	SNA	
7.4-3-8	JC66-00881A	LEVER-P-RELEASE_R	Z4534	1	SNA	
7.4-3-10	JC63-00683A	GROUND-P-HR	Z4535	1	SNA	
7.4-3-11	JC61-70903A	SPRING ETC-ACTUATOR	Z4132	1	SA	
7.4-3-12	JC72-01358A	PMO-ACTUATOR EXIT	Z4536	1	SNA	
7.4-3-13	JC67-00103A	CAP-M-ACTUATOR	Z4537	1	SNA	
7.4-3-14	6003-000196	SCREW-TAPTITE	Z4397	2	SA	
7.4-4	JC97-02631A	MEA UNIT-FUSER_GU_R	Z4539	1	SNA	
7.4-4-1	JC61-01226B	GUIDE-M_REAR	Z4540	1	SNA	
7.4-4-2	JC72-00382A	PMO-BUSHING TX	Z4606	2	SNA	
7.4-4-6	JC61-01549A	HOLDER-M REAR_LEVER	Z4542	1	SNA	


7.5 REGI Assembly



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.5-0	JC96-03959A	ELA UNIT-REGI	Z4408	1	SA	
7.5-1	JC61-00674A	GUIDE-P_REGI LOWER	G2080	1	SA	
7.5-2	JC66-00450A	ROLLER-REGI LOWER L	Z4543	1	SNA	
7.5-3	JC66-00446A	SHAFT-REGI UPPER	S0010	1	SA	
7.5-4	JC66-00647A	ROLLER-M_REGI IDLE L25	R0014	2	SA	
7.5-5	JC66-00648A	ROLLER-M_REGI IDLE S25	R0015	2	SA	
7.5-6	6044-000231	RING-E	R0006	4	SA	
7.5-7	6107-001165	SPRING-TS		1	SA	
7.5-8	JC72-00998A	PMO-ACTUATOR REGISHUTTER	P0030	1	SA	
7.5-9	JC61-00670A	GUIDE-P_REGI PLATE	G2081	1	SA	
7.5-10	JC75-00095A	MEC-BRUSH ANTISTATIC	M0022	1	SA	
7.5-11	JC61-00669A	BUSH-M-ROLLER REGI U	B0029	2	SA	
7.5-12	JC66-00420A	GEAR-REGI Z25	G0415	1	SA	
7.5-13	JC61-00669A	BUSH-M-ROLLER REGI U	B0029	2	SA	
7.5-14	6107-001155	SPRING-ES	Z4544	2	SA	


7.6 Main Motor Assembly



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QT'Y	Service	Remark
7.6-0	JC96-04063A	ELA UNIT-MAIN	Z4410	1	SA	
7.6-1	JC61-01204A	BRACKET-P-MAIN	Z4545	1	SNA	
7.6-2	JC31-00040A	MOTOR DC-BLDC MAIN	B5013	1	SA	
7.6-3	6031-001255	WASHER-PLAIN	W0004	2	SA	
7.6-4	JC66-00867A	GEAR-M-OPC DRV	Z4546	1	SNA	
7.6-5	JC66-00864A	GEAR-M-REGI DRV	Z4547	1	SNA	
7.6-6	JC66-00860A	GEAR-M-RDCN FUSER	Z4548	1	SNA	
7.6-7	JC66-00875A	GEAR-M-FUSER IDLE 1	Z4549	1	SNA	
7.6-8	JC66-00865A	GEAR-M-RDCN REGI	Z4550	1	SNA	
7.6-9	JC66-00866A	GEAR-M-RDCN PICK UP	Z4551	1	SNA	
7.6-10	JC66-00861A	GEAR-M-MP DRV	Z4552	1	SNA	
7.6-11	JC66-00862A	GEAR-M-FEED DRV	Z4553	1	SNA	
7.6-12	JC66-00873A	GEAR-M-RDCN MP	Z4554	1	SNA	
7.6-14	JC66-00863A	GEAR-M-PICK UP DRV	Z4555	1	SNA	


7.7 Deve Motor Assembly



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.7-0	JC96-03408A	ELA UNIT-DEVE MOTOR	K3057	1	SA	
7.7-1	JC31-00039A	MOTOR DC-BLDC DEVE	B5012	1	SA	
7.7-2	JC61-01201A	BRACKET-P-DEVE	Z4556	1	SNA	
7.7-3	JC61-01203A	BRACKET-P-SWING	Z4557	1	SNA	
7.7-4	JC66-00915A	SHAFT-SWING DEVE	Z4558	1	SNA	
7.7-5	JC66-00871A	GEAR-M-RDCN DEVE	Z4559	1	SNA	
7.7-6	JC66-00857A	GEAR-M-SWING	Z4560	1	SNA	


7.8 Duplex Sorenoid Assembly



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QT'Y	Service	Remark
7.8-0	JC96-03426A	ELA UNIT-EXIT SOL	K3059	1	SA	
7.8-1	JC61-01205A	BRACKET-P-EXIT	Z4561	1	SNA	
7.8-2	JC66-00869A	GEAR-M-IDLE 25	Z4527	1	SNA	
7.8-3	JC66-00869A	GEAR-M-IDLE 25	Z4527	1	SNA	
7.8-4	JC66-40911A	GEAR-DP,IDLE	G0198	1	SA	
7.8-5	JC66-00100A	GEAR-6	Z4562	3	SNA	
7.8-6	6031-001255	WASHER-PLAIN	W0004	4	SA	
7.8-8	JC33-00008A	SOLENOID-DUPLEX	S8014	1	SA	
7.8-9	JC61-01202A	BRACKET-P-LINK SWING	Z4563	1	SNA	
7.8-10	JC66-00855A	GEAR-M-SWING DUPLEX	Z4564	1	SNA	
7.8-11	JC66-00856A	GEAR-M-RDCN EXIT	Z4565	1	SNA	
7.8-12	JC66-00916A	SHAFT-SWING DUPLEX	Z4566	1	SNA	


7.9 Cassette Assembly



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.9-0	JC96-04015A	ELA UNIT-CASSETTE	Z4423	1	SA	
7.9-0	JC96-04015B	ELA UNIT-CASSETTE	Z4423	1	SA	ML-4551NDR
7.9-1	6002-000440	SCREW-TAPPING	Z4418	8	SA	
7.9-2	JC64-00189B	INDICATOR-M_EMPTY	Z4569	1	SNA	
7.9-3	JC61-01244A	GUIDE-P-SIDE_R	Z4573	1	SNA	
7.9-4	JC61-01225B	GUIDE-M_SIDE LOCK	Z4572	1	SNA	
7.9-5	JC61-01220B	FRAME-M_CASSETTE	Z4567	1	SNA	
7.9-5	JC61-01220C	FRAME-M_CASSETTE	Z4567	1	SNA	ML-4551NDR
7.9-6	JC61-00751A	GUIDE-P-REAR PAPER CST	G2088	1	SA	
7.9-7	JC61-01226B	GUIDE-M_REAR	Z4540	1	SNA	
7.9-8	JC61-00267B	GUIDE-M-LOCK A	G2068	1	SA	
7.9-9	JC61-00414A	SPRING ETC-GUIDE PAPER	Z4247	1	SA	
7.9-10	JC64-00190B	KNOB-M_REAR		1	SNA	
7.9-11	JC61-01224B	GUIDE-M_EXTENSION CST	Z4574	1	SNA	
7.9-11	JC61-01224C	GUIDE-M_EXTENSION CST	Z4574	1	SNA	ML-4551NDR
7.9-12	JC61-01223A	BRACKET-P-EXTENTION	Z4575	1	SNA	
7.9-13	JG61-70531A	SPRING ETC-LOCKER,PLATE	S0025	1	SA	
7.9-14	JG66-40003A	GEAR-PINION	O1127	1	SA	
7.9-15	JC67-00037A	CAP-M-GUIDE SIDE,L	C1014	1	SA	
7.9-16	JC61-01222A	GUIDE-P-SIDE_L	Z4571	1	SNA	
7.9-17	JC72-41210A	PMO-LOCKER PLATE	L6038	1	SA	
7.9-18	JC61-01227A	GUIDE-M-PAPER SIZE	Z4579	1	SNA	
7.9-19	JC97-02234A	MEA UNIT-HOLDER PAD	G0469	1	SA	
7.9-20	JC61-70911A	SPRING ETC-EXIT ROLL FD	O1053	1	SA	
7.9-21	JC61-01228A	HOLDER-M-PAD_HOUSING	Z4576	1	SNA	
7.9-22	JC61-01724A	GUIDE-PAPER		1	SNA	
7.9-23	JC64-00268A	SHUTTER-PATH		1	SNA	
7.9-24	JC61-00455A	SPRING ETC-PLATE K/UP	Z4228	2	SA	
7.9-25	JC61-01245A	PLATE-P-KNOCK UP	Z4570	1	SNA	
7.9-26	JC73-00141A	RPR-PAD CASSETTE	R0020	1	SA	
7.9-27	JC61-01221B	GUIDE-M_HANDLE	Z4568	1	SNA	
7.9-27	JC61-01221C	GUIDE-M_HANDLE	Z4568	1	SNA	ML-4551NDR
7.9-28	JC68-01552A	LABEL(R)-CASSETTE		1	SNA	


7.10 Duplex Unit



Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.10-0	JC96-03412C	ELA UNIT-DUPLEX	Z6089	1	SA	
7.10-0	JC96-03412E	ELA UNIT-DUPLEX	Z6089	1	SA	ML-4551NDR
7.10-1	JC61-01254A	FRAME-M-DUPLEX	Z6096	1	SA	
7.10-2	JC61-01255A	GUIDE-M-UPPER_DUP	Z6097	1	SA	
7.10-3	JC63-00693B	COVER-M REAR_DUP	Z6099	1	SA	
7.10-3	JC63-00693C	COVER-M REAR_DUP	Z6099	1	SA	ML-4551NDR
7.10-4	JC61-01697A	GUIDE-M ALIGN_DPX		1	SNA	
7.10-5	JC67-00107A	CAP-M-CONNECTOR_DUP	Z4412	1	SA	
7.10-6	JC67-00106A	DUCT-M-FAN_DUP	Z4413	1	SA	
7.10-7	JC31-00004A	FAN-DC_HAWK	F5018	1	SA	
7.10-8	JC92-01679A	PBA SUB-DUPLEX	Z6105	1	SA	
7.10-8	JC92-01883A	PBA-DPX	Z6105	1	SA	ML-4551NDR
7.10-10	JC70-00512A	IPR-TERMINAL GND_DUP	Z6104	1	SA	
7.10-11	JC64-00191A	LOCKER-M-DUP	Z6102	1	SA	
7.10-12	JC63-00706A	SHEET-FRAME_DUP	Z4619	1	SA	
7.10-13	6107-001165	SPRING-TS		1	SA	
7.10-14	JC72-01366A	PMO-ACTUATOR FEED DUP	Z4483	1	SA	
7.10-15	JC92-01362A	PBA SUB-MP SEN	M0395	1	SA	
7.10-16	JB39-00103A	CBF HARNESS-LIU GND	L5004	1	SA	
7.10-17	JC31-00009A	MOTOR STEP	M2150	1	SA	
7.10-18	JC61-01257A	BRACKET-P-MOTOR_DUP	Z4547	1	SA	
7.10-19	JC66-00897A	PULLEY-M-30_DUP	Z6103	1	SA	
7.10-20	6602-00108A	BELT-TIMING GEAR	Z6091	2	SA	
7.10-21	JC66-00898A	PULLEY-M-30-DUMMY_DUP	Z4419	1	SA	
7.10-22	6044-000231	RING-E	R0006	1	SA	
7.10-23	JC39-00450A	CBF HARNESS-D JOINT	Z6093	1	SA	
7.10-24	JC66-00444A	SHAFT-IDLE ROLL_DUP	S4108	2	SA	
7.10-25	JC66-00896A	ROLLER-M-IDLE_DUP	D2117	2	SA	
7.10-26	JK72-00058A	PCT-SILP WASHER		4	SNA	
7.10-27	JC61-01277A	SPRING ETC-DUP	Z4553	2	SA	
7.10-28	JC66-00900A	PULLEY-M-18-DUMMY_DUP	D2119	4	SA	
7.10-29	JC66-00899A	PULLEY-18_DUP	D2118	2	SA	
7.10-30	JC61-00665A	BUSH-M-FEED_DUP	F6042	4	SA	
7.10-32	JC66-00901A	ROLLER-FEED_DUP	D2145	1	SA	
7.10-33	6044-000107	RING-C	Z4396	1	SA	
7.10-34	JC70-00457A	ICT-STUD PAPER GUIDE_DP	G2098	3	SA	

7.11 SCF Unit





Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	Location	QTY	Service	Remark
7.11-0	JC96-04015D	ELA UNIT-CASSETTE	Z4423	1	SA	
7.11-0	JC96-04015E	ELA UNIT-CASSETTE	Z4423	1	SA	ML-4551NDR
7.11-1	6002-000440	SCREW-TAPPING	Z4418	8	SA	
7.11-2	JC64-00189B	INDICATOR-M_EMPTY	Z4569	1	SNA	
7.11-3	JC61-01244A	GUIDE-P-SIDE_R	Z4573	1	SNA	
7.11-4	JC61-01225C	GUIDE-M_SIDE LOCK		1	SNA	
7.11-5	JC61-01220B	FRAME-M_CASSETTE	Z4567	1	SNA	
7.11-5	JC61-01220C	FRAME-M_CASSETTE	Z4567	1	SNA	ML-4551NDR
7.11-6	JC61-00751A	GUIDE-P-REAR PAPER CST	G2088	1	SA	
7.11-7	JC61-01226C	GUIDE-M_REAR		1	SNA	
7.11-8	JC61-00267D	GUIDE-M_LOCK A		1	SNA	
7.11-9	JC61-00414A	SPRING ETC-GUIDE PAPER	Z4247	1	SA	
7.11-10	JC64-00190C	KNOB-M_REAR		1	SNA	
7.11-11	JC61-01224B	GUIDE-M_EXTENSION CST	Z4574	1	SNA	
7.11-11	JC61-01224C	GUIDE-M_EXTENSION CST	Z4574	1	SNA	ML-4551NDR
7.11-12	JC61-01223A	BRACKET-P-EXTENTION	Z4575	1	SNA	
7.11-13	JG61-70531A	SPRING ETC-LOCKER,PLATE	S0025	1	SA	
7.11-14	JG66-40003A	GEAR-PINION	O1127	1	SA	
7.11-15	JC67-00037A	CAP-M-GUIDE SIDE,L	C1014	1	SA	
7.11-16	JC61-01222A	GUIDE-P-SIDE_L	Z4571	1	SNA	
7.11-17	JC72-41210A	PMO-LOCKER PLATE	L6038	1	SA	
7.11-18	JC61-01227A	GUIDE-M-PAPER SIZE	Z4579	1	SNA	
7.11-19	JC97-02844A	MEA-UNIT HOLDER PAD	Z4424	1	SA	
7.11-20	JC61-70911A	SPRING ETC-EXIT ROLL FD	O1053	1	SA	
7.11-21	JC61-01228A	HOLDER-M-PAD_HOUSING	Z4576	1	SNA	
7.11-22	JC61-01724A	GUIDE-PAPER		1	SNA	
7.11-23	JC64-00268A	SHUTTER-PATH		1	SNA	
7.11-24	JC61-00455A	SPRING ETC-PLATE K/UP	Z4228	2	SA	
7.11-25	JC61-01245A	PLATE-P-KNOCK UP	Z4570	1	SNA	
7.11-26	JC73-00141A	RPR-PAD CASSETTE	R0020	1	SA	
7.11-27	JC61-01221B	GUIDE-M_HANDLE	Z4568	1	SNA	
7.11-27	JC61-01221C	GUIDE-M_HANDLE	Z4568	1	SNA	ML-4551NDR
7.11-28	JC68-01552A	LABEL(R)-CASSETTE		1	SNA	
7.11-30	JC61-00064A	SPRING ETC-CLAW	O1032	1	SA	
7.11-32	JC63-01206A	GROUND-CASSETTE	Z6101	1	SA	


8. Block Diagram

8.1 System Block Diagram





9. Connection Diagram



[Signal Description Table]

CN 18 (POWER) Main ↔ SMPS/HVPS			
Pin	Signal Name	Pin	Signal Name
1	DEVE_AC-PWM	2	←
2	24V	1	←
3	DEVE_AC_Vpp	4	←
4	24V	3	←
5	DEVE_AC_CON	6	←
6	24V	5	←
7	DEVE_VDC-PWM	8	←
8	24VS	7	←
9	FUSER_BAIS_PWM	10	←
10	3.3V	9	←
11	MHV_PWM	12	←
12	3.3V	11	←
13	FAN_SMPS	14	←
14	3.3V	13	←
15	THV_PWM	16	←
16	VCC	15	←
17	THV_READ	18	←
18	VCC	17	←
19	nTHV_EN	20	←
20	FAN_FEEDBACK	19	←
21	FUSER COVER	22	←
22	GND	21	←
23	GND	24	←
24	GND	23	←
25	FUSER_ON	26	←
26	GND	25	←
27	GND	28	←

28	GND	27	GND
----	-----	----	-----

CN 16 (DUPLEX) MAIN ↔ DUPLEX B'D			
Pin	Signal Name	Pin	Signal Name
1	24VS	1	←
2	3.3V	2	←
3	3.3V	3	←
4	DUPLEX_RXD	4	←
5	DUPLEX_DETECT	5	GND(DETECT)
6	DUPLEX_TXD	6	←
7	GND	7	←
8	GND	8	←
9	GND		←

CN 17 (EXIT SENSOR) MAIN ↔ EXITSENSOR			
Pin	Signal Name	Pin	Signal Name
1	GND	2	←
2	3.3V	1	←
3	P_EXIT	4	←

CN 21 (DC_MOT) MAIN ↔ MAIN MOTOR			
Pin	Signal Name	Pin	Signal Name
1	24VS	1	←
2	24VS	2	←
3	GND	3	←
4	GND	4	←
5	GND	5	←
6	VCC	6	←
7	nMAIN_MOT_ON	7	←

8	MAIN_MOT_READY	8	←
9	MAIN_MOT_CLK	9	←
10	NC		

CN 22 (JOINT) MAIN ↔ JOINT B'D			
Pin	Signal Name	Pin	Signal Name
1	24VS	1	←
2	MAIN CLUTCH	2	←
3	MP_CLUTCH	3	←
4	REGI_CLUTCH	4	←
5	MP_EMPTY	5	←
6	3.3V	6	←
7	CASSESTE_DETECT	7	←
8	GND	8	←
9	TMEP1	9	←

CN 19 (DEV_MOT) MAIN ↔ DEVE MOTOR			
Pin	Signal Name	Pin	Signal Name
1	24VS	1	←
2	GND	2	←
3	nDEV_MOT_READY	3	←
4	nDEV_MOT_CLK	4	←
5	nDEV_MOT_ON	5	←
6	nDEV_MOT_DIR	6	←
7	NC		

CN 20 (PTL) MAIN ↔ PTL			
Pin	Signal Name	Pin	Signal Name
1	VCC	1	←
2	PTL_ON	2	←

8	3.3V	7	←
9	OUTBIN_FULL	10	←
10	CART_CLK	9	←
11	P_REGI	12	←
12	CART_DOUT/CART_DIN	11	←
13	P_EMPTY	14	←
14	GND	13	←

CN 15		(COVER_OPEN)		MAIN ↔ COVER_OPEN	
Pin	Signal Name	Pin	Signal Name		
1	24V	1	←		
2	24V	2	←		
3	24VS	3	←		
4	24VS	4	←		
5	NC	5	←		
6	COVER_OPEN	6	←		
7	NC	7	←		
8	VCC	8	←		
9	LSU_5V	9	←		

CN 5 (DPX_SOL) MAIN ↔ DUPLEX SOLENOID			
Pin	Signal Name	Pin	Signal Name
1	DUPLEX_SOL	1	←
2	24VS	2	←

CN 6		(LSU) MAIN ↔ LSU	
Pin	Signal Name	Pin	Signal Name
1	GND	2	← (LD DRIVER)
2	LSU_5V	1	←
3	LD_POWER2	4	←
4	LD_POWER1	3	←
5	VDO1_minus	6	←
6	VDO1_plus	5	←
7	VDO2_minus	8	←
8	VDO1_plus	7	←
9	nLD_EN	10	←
10	nSH1	9	←
11	nHSTNC_plus	12	←
12	nSH2	11	←
13	nHSTNC_minus	13	←
14	LSU_CLK	1	← (P-MOTOR)
15	nREADY	2	←
16	LSU_MOT_ON	3	←
17	GND	4	←
18	GND	5	←

CN 4		(CART) MAIN ↔ TONER SENSOR	
Pin	Signal Name	Pin	Signal Name
1	24V	2	←
2	P_SIZE3	1	←
3	FAN_SMPS	4	←
4	P_SIZE2	3	←
5	FAN_MAIN	6	←
6	P_SIZE1	5	←
7	GND	8	←

CN 2		(SCF) MAIN ↔ SCF B'D	
Pin	Signal Name	Pin	Signal Name
1	24V	1	←
2	3.3V	2	←
3	SCF_EMPTY	3	3.3V
4	SCF_RXD	4	←
5	SCF_DETECT	5	←
6	SCF_TXD	6	←
7	GND	7	←
8	GND	8	←
9	GND	9	←
10	GND	10	←
11	GND		

CN 23		(THERM) MAIN ↔ FUSER	
Pin	Signal Name	Pin	Signal Name
1	THERM_IN	1	←
2	FUSER_ON	2	GND
3	FUSER_EN	3	FUSER_ON

11. Reference Information


This chapter contains the tools list, list of abbreviations used in this manual, and a guide to the location space required when installing the printer. A definition of tests pages and Wireless Network information definition is also included.

11.1 Tool for Troubleshooting

The following tools are recommended safe and easy troubleshooting as described in this service manual.


• DVM (Digital Volt Meter)

Standard : Indicates more than 3 digits.



• Driver

Standard : "-" type, "+" type (M3 long, M3 short, M2 long, M2 short).



• Tweezers

Standard : For general home use, small type.




• Cotton Swab

Standard : For general home use, for medical service.




• Cleaning Equipments


Standard : An IPA(Isopropyl Alcohol)dry wipe tissue or a gentle neutral detergent and lint-free cloth.



• Vacuum Cleaner



• Software (Driver) installation CD ROM



11.2 Acronyms and Abbreviations(1)

The table below explains the abbreviations and acronyms used in this service manual. Where abbreviations or acronyms are used in the text please refer to this table.


Abbreviations	Explanation
AP	Access Point
AC	Alternating Current
APC	Auto Power Control
ASIC	Application Specific Integrated Circuit
ASSY	assembly
BIOS	Basic Input Output System
BLDC	Brush-less Direct Current
CMOS	Complementary Metal Oxide Semiconductor
CN	connector
CON	connector
CPU	Central Processing Unit
dB	decibel
dBA	decibel A
dBm	decibel milliwatt
DC	direct current
DCU	Diagnostic Control Unit
DPI	Dot Per Inch
DRAM	Dynamic Random Access Memory
DVM	Digital Voltmeter
ECP	Enhanced Capability Port
EDC	Embedded Diagnostic control
EEPROM	Electrically Erasable Programmable Read Only Memory
EMI	Electro Magnetic Interference
EP	electrophotographic
EPP	Enhanced Parallel Port
FPOT	First Printout Time
F/W	firmware
GDI	graphics device interface
GND	ground
HBP	Host Based Printing
HDD	Hard Disk Drive
H/H	High temperature and high marshy place
HV	high voltage
HVPS	High Voltage Power Supply
I/F	interface
I/O	Input and Output
IC	integrated circuit
IDE	Intelligent Drive electronics or Imbedded Drive Electronics

Acronyms and Abbreviations(2)

Abbreviations	Explanation
IEEE	Institute of Electrical and Electronics Engineers. Inc
IPA	Isopropyl Alcohol
IPM	Images Per Minute
LAN	local area network
lb	pound(s)
LBP	Laser Beam Printer
LCD	Liquid Crystal Display
LED	Light Emitting Diode
L/L	Low temperature and low marshy place
LSU	Laser Scanning Unit
MB	megabyte
MHz	megahertz
MPF	Multi Purpose Feeder
NIC	Network Interface Card
N/N	Normal temperature and normal marshy place
NVRAM	nonvolatile random access memory
OPC	Organic Photo Conductor
OP	Operation Panel Equipment
PBA	Printed Board Assembly
PCL	Printer Command Language , Printer Control Language
PDL	Page Discription Language
PPM	Page Per Minute
PPS	Pulse Per Second
PS	Post Script
PTL	Pre-Transfer Lamp
PWM	Pulse Width Modulation
Q-PID	Quick Printer Initiating Device
Q ty	quantity
RAM	Random Access Memory
ROM	Read Only Memory
SCF	Second Cassette Feeder
SMPS	Switching Mode Power Supply
SPGP	Samsung Printer Graphic Processor
SPL	Samsung Printer Language
Spool	Simultaneous Peripheral Operation Online
SW	switch
sync	synchronous or synchronization
USB	Universal Serial Bus
WECA	Wireless Ethernet Compatibility Alliance


11.3 Select a location for the printer

- Leave enough room to open the printer trays, covers, and allow for proper ventilation. (see diagram below)
- Provide the proper environment :
 - A firm, level surface
 - Away from the direct airflow of air conditioners, heaters, or ventilators
 - Free of extreme fluctuations of temperature, sunlight, or humidity
 - Clean, dry, and free of dust




11.4 Sample Tests Patterns

The sample patterns shown below are the standard test patterns used in the factory.
The life of the toner cartridge, developer cartridge and printing speed are measured with the pattern shown below. The A4 ISO 19752 standard pattern samples are reproduced reduced to 70% of the actual A4 size.



11.5 LAN (Optional Function)

- This product can be used with a wired LAN (Option)
- LED Condition and Status



[LED STATUS]

LED Condition	Status
Active LED random blink	Normal NPC & Normal packet receive
Active LED regular blink	Normal NPC & No Packet
Active LED Off/On maintenance	NPC Initial inferiority
Link LED On	The link LED On OPC, Normally linked (Red: Wireless, Green: Wire, Orange: Wire)
Link LED Off	Link LED off NPC, Link Inferiority



* This service manual is a property of Samsung Electronics Co., Ltd.
Any unauthorized use of Manual can be punished under applicable
international and/or domestic law.

© Samsung Electronics Co., Ltd. Mar. 2006
Printed in Korea.

VERSION NO. : 1.00 CODE : JC-0168R