DSC-P5

SERVICE MANUAL

Level 2



Ver 1.5 2003, 01 Cyber-shot









US Model Canadian Model AEP Model **UK Model** E Model Hong Kong Model Australian Model Chinese Model Korea Model Tourist Model Japanese Model

This service manual contains information for Japanese model as well.

When the machine needs to be repaired, please refer to page 7 to discriminate the type of IC.

On the DD-163, SY-69 boards

This service manual provides the information that is premised the circuit board replacement service and not intended repair inside the DD-163, SY-69 boards.

Therefore, schematic diagram, printed wiring board and electrical parts list of the DD-163, SY-69 boards are not shown. The following pages are not shown.

SY-69 board

Schematic diagram	Page 4-15 to 4-36
Printed wiring board	Page 4-11 to 4-14
Electrical parts list	Page 6-10 to 6-15

DD-163 board

Schematic diagram	Page 4-47 to 4-52
Printed wiring board	Page 4-43 to 4-46
Electrical parts list	Page 6-6 to 6-8

The above-described information is shown in service manual Level 3.

SPECIFICATIONS

System

Image device

8.93 mm (1/1.8 type) color

CCD

Effective pixels number of camera

Approx. 3 207 000 pixels

Lens 3× zoom lens

f = 8 - 24 mm

(11/32 - 31/32 inches)

(39 – 117 mm (1 9/10 –

4.5/8 inches) when converted

to a 35 mm still camera) F = 2.8 - 5.6

Exposure control

Automatic exposure

White balance

Automatic, Hold, Indoor, Outdoor

Data system

Movie: MPEG1 Still: JPEG, GIF (in TEXT mode, Clip Motion), TIFF Audio with still image: MPEG1 (Monaural)

Recording medium

"Memory Stick"

Flash

Recommended recording distance (ISO set to AUTO): W side: 0.5 m to 2.8 m (19 3/4 inches to 9 feet 2 1/4 inches) T side: 0.6 m to 1.4 m (19 3/4 inches to 4 feet 7 1/8 inches)

Output connector A/V OUT (Monaural)

Minijack Video: 1 Vp-p, 75 Ω , unbalanced, sync negative Audio: 327 mV (at a 47 k Ω load)

Output impedance: 2.2 k Ω **USB** jack

LCD screen

mini-B

Used LCD panel

3.8 cm (1.5 type) TFT (Thin Film Transistor active matrix)

Total number of dots

123 200 (560×220) dots

General Used battery pack

NP-FC10

Power requirements

3.6 V

Power consumption (during recording)

2.4 W/2.2 W (LCD BACKLIGHT: BRIGHT/ NORMAL) 1.5 W (LCD BACKLIGHT: OFF)

Operation temperature 0°C to 40°C (32°F to 104°F)

Storage temperature -20°C to +60°C (-4°F to +140°F)

Dimensions

112.5×53.8×36.2 mm (4 1/2×2 1/8×1 7/16 inches) (w/h/d) (excluding maximum

DIGITAL STILL CAMERA



Mass

Approx. 214 g (7.5 oz) (including battery pack NP-FC10, "Memory Stick" and wrist strap, etc.)

Built-in microphone

Electret condenser microphone

Built-in speaker

Dynamic speaker

AC-LS1A AC power adaptor

Power requirements 100 to 240 V AC, 50/60 Hz

Rated output voltage

DC 4.2 V, 1.5 A in operating mode

Operation temperature

 0°C to 40°C (32°F to 104°F)

Storage temperature

−20°C to +60°C (-4°F to +140°F)

Maximum dimensions

105×36×56 mm (4 1/4×1 7/16×2 1/4 inches) (w/h/d) (excluding maximum protrusions)

Approx. 180 g (6.4 oz)

NP-FC10 battery pack

Used battery

Lithium ion battery

Maximum voltage

DC 4.2 V

Nominal voltage

DC 3.6 V

Capacity

2.4 Wh (675 mAh)

Accessories

A/V connecting cable (1) NP-FC10 battery pack (1) AC-LS1A AC power adaptor (1)

Power cord (1)

USB cable (1) Wrist strap (1)

"Memory Stick" (8 MB) (1)

CD-ROM (USB driver

SPVD-004) (1)

Operating Instructions (1)

Design and specifications are subject to change without notice.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK A OR DOTTED LINE WITH MARK A ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUB-LISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COM-POSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer.

- 1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- 3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- 4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- 5. Check the B+ voltage to see it is at the values specified.
- 6. Flexible Circuit Board Repairing
 - Keep the temperature of the soldering iron around 270 $^{\circ}$ C during repairing.
 - Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
 - Be careful not to apply force on the conductor when soldering or unsoldering.

TABLE OF CONTENTS

<u>Sect.</u>	<u>ion</u> <u>Title</u>	<u>Page</u>	<u>Secti</u>	<u>ion</u>	<u>Title</u> <u>P</u>	ag	<u>e</u>
SER	VICE NOTE	5	5.	ΑĽ	DJUSTMENTS		
1.	GENERAL			Ad	arting Adjustment justing Items when Replacing in Parts and Boards		
Introd	duction	1_1	5-1.		mera Section Adjustment		
	fying the Parts				eparations Before Adjustment		
	aring the Power Supply				List of Service Tools		
	ng the Date and Time				Preparations		
Insert	ting the "Memory Stick"	1-4			Discharging of the Flashlight Power Supply		
Basic	Operations	1-4	1-1-		Precautions		
	rding Still Images				Setting the Switch		
	rding Moving Images				Order of Adjustments		
	ng Back Still Images				Preparing the Flash Adjustment Box		
	ng Back Moving Images		1-2.	٦. Init	ialization of B, D, E, F, 7, 9 Page Data	5-8	
	ng Images Using a Computerng Images on Windows				Initialization of D Page Data		
	ng Images on Macintosh				Initializing D Page Data		
	e File Storage Destinations and Image Files			2.	Modification of D Page Data	5-8	
	e Performing Advanced Operations				D Page Table		
	us Recording		1-2-		Initialization of B, E, F, 7, 9 Page Data		
Vario	us Playback	1-16			Initializing B, E, F, 7, 9 Page Data		
	ng				Modification of B, E, F, 7, 9 Page Data		
	ional Information	_			B Page Table		
	eleshooting				F Page Table		
	ing and Notice Messages				7 Page Table		
	diagnosis Displayay Window Indicators				9 Page Table		
	Screen Indicators		1-3.		leo System Adjustments 5		
		20	1.		leo Sync Level Adjustment		
			2.		leo Burst Level Adjustment		
2.	DISASSEMBLY		1-4.		mera System Adjustments		
			1.		inge Back Adjustment (Using the Minipattern Box) \$	5-10	j
2-1.	BT Lid	2-2	2.		inge Back Adjustment	- 4-	7
2-2.	Cabinet (Front) Assembly	2-2	3.		sing the Flange Back Adjustment Chart) { Inge Back Check {		
2-3	Cabinet (Rear) Assembly		3. 4.		ture Frame Setting		
2-4.	LCD Module		5.		No. Standard Data Input		
2-5.	Lens Block Assembly		6.		chanical Shutter Adjustment		
2-6.	Mode Dial Block Assembly		7.		ht Value Adjustment 5		
2-7. 2-8.	Cabinet (Bottom) Assembly		8.		to White Balance Standard Data Input		
2-0. 2-9.	Memory Stick Connector		9.	Au	to White Balance Adjustment	5-2	3
	ST-67 Board				to White Balance Check		
	DD-163 Board				lor Reproduction Adjustment		
2-12.	Circuit Boards Location	2-6				5-2	_
					D White Defect Compensation		
					obe White Balance Adjustment		
3.	BLOCK DIAGRAMS				D System Adjustments		
			1.		D Initial Data Input (1)		
3-1.	Overall Block Diagram		2.	LC	D Initial Data Input (2)	5-3	1
3-8.	Power Block Diagram 1		3.		O Adjustment (SY-69 Board)		
3-9.	Power Block Diagram 2	3-17	4.		ack Limit Adjustment (SY-69 Board)		
			5.		ght Adjustment (SY-69 Board)		
4.	PRINTED WIRING BOARDS AND		6. 7.		ntrast Adjustment (SY-69 Board)		
4.	SCHEMATIC DIAGRAMS		7. 8.		Center Adjustment (SY-69 Board)		
	SCHEWATIC DIAGRAMS		9.		IG Adjustment (SY-69 Board)		
4-1.	Frame Schematic Diagrams	4-3	10.		COM Adjustment (SY-69 Board)		
	Frame Schematic Diagram (1/2)		11.		nite Balance Adjustment (SY-69 Board)		
	Frame Schematic Diagram (2/2)		1-6.		stem Control System Adjustments		
4-2.	Printed Wiring Boards and Schematic Diagrams	4-7	1.		ttery Down Adjustment		
	CD-340 Printed Wiring Board		5-2.		rvice Mode		
	CD-340 Schematic Diagram		2-1.		justing Remote Commander		
	Control Switch Block Schematic Diagram		1.		ed the Adjusting Remote Commander	o-3	J
	FP-380 Schematic Diagram		2.		ecautions upon Using Adjusting Remote Commander	5-20	٥
	ST-67 Printed Wiring BoardST-67 Schematic Diagram		2-2.		ta Process		
4-4.	Parts Location		2-2. 2-3.		rvice Mode		
	. 6.10 2500001	50	1.		tting the Test Mode		
			2.		Value Discrimination		
			3.		de Dial Check (1)		
			4.		de Dial Check (2)		
			5.	Sw	ritch Check (1) 5	5-4	1

DSC-P5

<u>Sect</u>	<u>ion</u> <u>Title</u> <u>I</u>	<u>Page</u>
	Switch Check (2)	5-42
6.	REPAIR PARTS LIST	
6-1- 6-1- 6-1- 6-1-	Exploded Views 1. Cabinet (Front) Assembly 2. Cabinet (Rear) Assembly 3. Lens Block and LCD Section 4. Battery Holder Assembly Electrical Parts List	6-1 6-2 6-3 6-4
* TI	he color reproduction frame is shown on page 117.	


SERVICE NOTE


• NOTE FOR REPAIR

Make sure that the flat cable and flexible board are not cracked of bent at the terminal.


Do not insert the cable insufficiently nor crookedly.

When remove a connector, don't pull at wire of connector. It is possible that a wire is snapped.










When installing a connector, don't press down at wire of connector. It is possible that a wire is snapped.



[Discharging of the ST-67 board's charging capacitor (C008)]


The charging capacitor (C008) of the ST-67 board is charged up to the maximum 300 V potential.

There is a danger of electric shock by this high voltage when the battery is handled by hand. The electric shock is caused by the charged voltage which is kept without discharging when the main power of the unit is simply turned off. Therefore, the remaining voltage must be discharged as described below.

Preparing the Short Jig


To preparing the short jig, a small clip is attached to each end of a resistor of 1 k Ω /1 W (1-215-869-11).

Wrap insulating tape fully around the leads of the resistor to prevent electrical shock.



Discharging the Capacitor


Short-circuit between the positive and the negative terminals of charged capacitor with the short jig about 10 seconds.



[Description on Self-diagnosis Display]

Self-diagnosis display

The camera has a self-diagnosis display. This function displays the camera condition with five-digits (a combination of a letter and figures) on the LCD screen. If this occurs check the following code chart. The five-digits display informs you of the camera's current condition. The last two digits (indicated by □□) will differ depending on the state of the camera.



Self-diagnosis display

• C: □□: □□

You can reverse the camera malfunction yourself. (However, contact your Sony dealer or local authorized Sony service facility when you cannot recover from the camera malfunction.)

• E: □□: □□

Contact your Sony dealer or local authorized Sony service facility.

Display Code	Countermeasure	Cause	Caution Display During Error
C:32:□□	Turn the power off and on again.	Trouble with hardware.	SYSTEM ERROR
C:13:□□	Format the "Memory stick".	Unformatted memory stick is inserted.	FORMAT ERROR
C:13:LL	Insert a new "Memory Stick".	Memory stick is broken.	MEMORY STICK ERROR
E:61:□□	Checking of lens drive circuit.	When failed in the focus and zoom initialization.	_
E:91:□□	Checking of flash unit or replacement of flash unit.	Abnormality when flash is being charged.	

[Precaution on Replacing the Lens Block or the SY-69 Board]

The DSC-P5 uses the position sensor to detect the zoom position. Accordingly, the zoom position will vary if the position data changes due to the replacement of the lens block or the SY-69 board, thus causing the lens block to collide against the mechanism end when the power is turned off.

Though the position data is calibrated at the "Flange Back Adjustment", add the following work when making an adjustment at the replacement of lens block to prevent a collision of lens block.

When Replacing the Lens Block

- 1) With current lens block assembled, turn the power on, and set the bit value of Bit0 on Page:9, Address:65 to "0" using the adjusting remote commander, then turn the power off.
- Replace the lens block with a new one, turn the power on, and perform the "Flange Back Adjustment".
 Thus, new position data will be written.
- After the "Flange Back Adjustment", return the bit value of Bit0 on Page:9, Address:65 to "1" using the adjusting remote commander.

When Replacing the SY-69 Board

- 1) Replace the SY-69 board with a new one, set the mode dial to "PLAY", turn the power on, and set the bit value of Bit0 on Page:9, Address:65 to "0" using the adjusting remote commander, then turn the power off.
- Set the mode dial to "CAMERA", turn the power on, and perform the "Flange Back Adjustment".
 Thus, new position data will be written.
- 3) After the "Flange Back Adjustment", return the bit value of Bit0 on Page:9, Address:65 to "1" using the adjusting remote commander.

[IC type check]


By measuring the resistor value between Pin ③ of CN902 and Pin ④ of CN902 on SY-69 board, the type of IC801 (LCD drive) can be discriminated.

SY-69 board CN902

Resistor value	IC type
15 kΩ	AN12511A
22 kΩ	CXA8116R

Note 1: Don't use the 12 pin flexible board of CPC-9 jig. It causes damage to the unit.

Note 2: The old CPC-9 jig (Parts code: J-6082-393-B) cannot be used, because it cannot operate the adjustment remote commander.



Differences of mounted parts

Different types of IC801 (LCD drive) have different parts mounted on SY-69 board.

When the current IC is replaced to the different type, also replace the following parts.

IC TYPE Ref. No.	AN12511A	CXA8116R
C806	XX	2.2u
C835	1u	XX
IC801	AN12511A-BB	CXA8116R-T4
R802	0	22k
R803	2200	10k
R804	XX	100
R805	XX	100
R806	XX	100
R807	XX	100
R808	0	22k
R811	XX	33k
R812	XX	47k
R813	XX	33k
R814	XX	47k
R816	27k	39k
R817	15k	39k
R819	47k	XX
R820	10k	XX
R821	15k	22k
R824	22k	47k
R826	XX	100k
R899	XX	0

SECTION 1 **GENERAL**

This section is extracted from instruction manual.

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture

For the Customers in the





This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance

Never expose the battery pack to temperature above 60°C (140°F), such as in a car parked in the sun or under direct

If you have any questions about this product, you may call: Sony Customer Information Services Center

Sony Customer Information Services Cen 1-800-222-SONY (7669) The number below is for the FCC related

Regulatory Information

Declaration of Conformity

Trade Name: SONY
Model No.: DSC-P5
Responsible Party:Sony Electronics Inc.
Address: 680 Kinderkamack
Road, Oradell, NJ

07649 USA Telephone No.: 201-930-6972

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment

This equipment has been tested and found to comply with the limits for a Class B digital comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio compunications. However, there is no may cause nammu interference to ratio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the
- equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The supplied interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

For the Customers in the U.S.A. and Canada

DISPOSAL OF LITHIUM ION BATTERY. LITHIUM ION BATTERY. DISPOSE OF PROPERLY.

You can return your unwanted lithium ion batteries to your nearest Sony Service Center or Factory Service Center.

Note:

In some areas the disposal of lithium ion batteries in household or business trash may be prohibited.

For the Sony Service Center nearest you call 1-800-222-SONY (United States only)
For the Sony Factory Service Center nea
you call 416-499-SONY (Canada only)

Caution:

Do not handle damaged or leaking lithium ion battery.

For the Customers in Canada

CAUTION

TO PREVENT ELECTRIC SHOCK, DO NOT USE THIS POLARIZED AC PLUG WITH AN EXTENSION CORD. WITH AN EXTENSION CORD.
RECEPTACLE OR OTHER OUTLET
UNLESS THE BLADES CAN BE FULLY
INSERTED TO PREVENT BLADE
EXPOSURE.

Notice for the Customers in the United Kingdom

A moulded plug complying with BS1363 is fitted to this equipment for your safety and

convenience. Should the fuse in the plug supplied need to Should the fuse in the plug supplied need to be replaced, a 5AMP fuse approved by ASTA or BSI to BSI362, (i.e., marked with

or

mark) must be used.

If the plug supplied with this equipment has a detachable fuse cover, be sure to attach the

fuse cover after you change the fuse. Never use the plug without the fuse cover. If you should lose the cover, please contact your nearest Sony service station.

For the Customers in Germany

Directive: EMC Directive 89/336/EEC, 92/31/EEC

72/31/EEC
This equipment complies with the EMC regulations when used under the following

- circumstances: Residential area
- · Business district

Light-industry district
(This equipment complies with the EMC standard regulations EN55022 Class B.)

Attention for the Customers in Europe

This product has been tested and found pliant with the limits sets out on the EMC Directive for using connection cables shorter than 3 meters.

The electromagnetic fields at the specific frequencies may influence the picture and sound of this camera.

"Memory Stick" and Battery





For the Customers in the U.S.A.
THIS DEVICE COMPLIES WITH PART
15 OF THE FCC RULES. OPERATION IS
SUBJECT TO THE FOLLOWING TWO
CONDUCTIONS. CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED. INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

3

For the Customers in Canada THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

Be sure to read the following before using your camera

Trial recording

2

Before you record one-time events, you may want to make a trial recording to make sure that the camera is working correctly.

No compensation for contents of

the recording

Contents of the recording cannot be compensated for if recording or playback is not possible due to a malfunction of your camera or recording medium, etc.

Notes on image data compatibility

- This camera conforms with the Design rule for Camera File system universal standard established by the JEITA (Japan Electronics and Information Technology Industries Association). You cannot play Industries Association). You cannot play back on your camera still images recorded on other equipment (DCR-TRV890E/TRV900/TRV900F, DSC-D700, DSC-D770) that does not conform with this universal standard. (These models are
- inis universal standard. (I nese models are not sold in some areas.)

 Playback of images recorded with your camera on other equipment and playback of images recorded or edited with other equipment on your camera are not guaranteed.

Precaution on copyright
Television programs, films, video tapes, and
other materials may be copyrighted.
Unauthorized recording of such materials
may be contrary to the provision of the copyright laws.

Do not shake or strike the camera In addition to malfunctions and inability to record images, this may render the "Memory Stick" unusable or image data breakdown, damage or loss may occur

Do not aim the camera at the sun or other bright light

This may cause irrecoverable damage to your eyes.

LCD screen, LCD finder (only models with a finder) and lens

- models with a funder) and lens

 The LCD screen and the LCD finder are
 manufactured using extremely highprecision technology so over 99.99% of
 the pixels are operational for effective use
 However, there may be some tiny black
 points and/or bright points (white, red,
 blue or green in color) that constantly
 more are the LCD occase and the LCD. one or green in coord that constantly appear on the LCD screen and the LCD finder. These points are normal in the manufacturing process and do not affect the recording in any way.

 - Be careful when placing the camera near a window or outdoors. Exposing the LCD screen, the finder or the lens to direct
- sunlight for long periods may cause

Do not get the camera wet

When taking pictures outdoors in the rain or under similar conditions, be careful not to get the camera wet. If moisture condensation occurs, refer to page 82 and follow the instructions on how to remove it before using the camera.

Back up recommendation

To avoid the potential risk of data loss, always copy (back up) data to a disk.

Handling of the movable lens

This camera uses a movable lens.

Be careful not to strike or apply excessive force to the lens portion.


When the camera is used for long

ote that the camera body may become hot.

Introduction

Check images after recording

Recording still images: page 19 Playing back still images: Deleting images (DELETE):



Capture images with your computer

You can copy images onto your computer and view and modify images or attach images to e-mail on your computer using the supplied USB cable and application

Viewing images using a computer: page 31 Recording still images for e-mail (E-MAIL): page 55



Record moving pictures (MPEG Movie or Clip Motion)

The digital still camera can record a moving picture with audio (MPEG MOVIE): page 26




Select from various recording modes

Creating Clip Motion Files: page 59 Adding audio files to still images (VOICE): page 56 Recording text documents (TEXT): page 57 Recording still images as uncompressed files (TIFF): page 58

Identifying the parts

See the pages in parentheses for details of operation.




- 1 Shutter button (19, 27)
- 2 Mode dial (18)
 - : To record in TWILIGHT mode
 - To record still images, VOICE mode audio data
 - To playback or edit images
 - To record moving images or Clip Motion images

 SET UP: To set the setup items

 (80)
- 3 POWER button (15)
- 4 Flash (24)
- 5 Photocell window for flash
 Do not block while recording with
 the flash.

- 6 Speaker
- 7 Built-in microphone
 Do not touch while recording
- 8 Finder window
- 9 Self-timer (24, 27)/ AF illuminator (25)
- 10 Lens
- 11 Tripod receptacle (bottom surface)

Use a tripod with a screw length of less than 5.5 mm (7/32 inch). You will be unable to firmly secure the camera to tripods having longer screws, and may damage the camera.





- 13 Finder (21)
 Self-timer/recording lamp (red)
 AE/AF lock lamp (green)
 Flash charge lamp (orange)
 (22)
- 14 Display window (95)
- 15 LCD screen (96)
- 16 DSPL/LCD ON/OFF button (21)
- 17 MENU button (18, 46)
- 18 DC IN jack (11, 14)
- 19 Ψ (USB) jack (36)

- 20 POWER lamp (15)
- 21 Zoom button (for recording) (23) INDEX/zoom button (for playback) (67)

Attaching the strap

- 22 Hook for wrist strap
- 23 RESET button (86)
- 24 Battery/"Memory Stick" cover
- 25 Battery eject lever (10)
- 26 Access lamp (17)
- 27 Jack cover
- 28 A/V OUT jack (70)
 Audio output is monaural.


8

9

Preparing the power supply

Installing the battery pack

Your camera operates only with the "InfoLITHIUM" NP-FC10 battery pack* (C type) (supplied). You cannot use any other battery pack. See page 84 for more information about the "InfoLITHIUM" battery pack.



- Open the battery/"Memory Stick" cover. Slide the cover in the direction of the arrow.
- Install the battery pack.
 Insert the battery pack with the ▲ mark facing toward the battery compartment
- 3 Close the battery/"Memory Stick" cover.

To remove the battery pack

Open the battery/"Memory Stick" cover. Slide the battery eject lever downward, and remove the battery pack.


Be careful not to drop the battery pack when removing it.

* What is "InfoLITHIUM"?

"InfoLITHIUM" is a lithium ion battery pack which can exchange information such as battery consumption with compatible electronic equipment. This unit is compatible with the "infoLITHIUM" battery pack (C type). "InfoLITHIUM" C type battery packs have the powering are mark. "InfoLITHIUM" is a trademark of Sony Corporation.

Charging the battery pack

You cannot charge the battery pack while your camera is turned on. Be sure to turn off your camera.



- 1 Insert the battery pack into your camera.
- ② Open the jack cover and connect the DC connecting cable to the DC IN jack of your camera with the ▲ mark facing up.
- 3 Connect the power cord (mains lead) to the AC power adaptor and then to a wall outlet (wall socket).

 The battery indicator ☐ in the display window flashes when charging begins. When the battery indicator stops flashing, normal charge is completed. For full charge, which allows you to use the battery longer than usual, leave the battery pack inserted for about one hour after normal charge is completed until the battery remaining indicator and "Full" is displayed alternately in the display window.

alternately in the display window. After charging the battery pack

Disconnect the AC power adaptor from the DC IN jack of your camera.

Battery remaining indicator

The LCD screen on the camera shows the remaining time for which you can still record or play back images. When charging, this shows an indication of the continuous recording time (with LCD screen ON). This indication may not be entirely accurate depending on the conditions of use and the operating environment.

Recommended charging temperature

We recommend charging the battery pack in an ambient temperature of between 10°C to 30°C (50°F to 86°F).

Getting started

13

Getting started

NP-FC10 battery pack

When you record images in an extremely cold location or using the LCD screen, the operating time becomes short. When using the camera in an extremely cold location, place the battery pack in your pocket or other place to keep it warm, then insert the battery pack into the camera just before recording. When using a pocket heater, take care not to let the heater directly contact the battery.

Power save mode

When [POWER SAVE] in the SET UP screen is set to [ON], the battery life will be extended when recording still images. The factory setting is [OFF] (page 81).

When [POWER SAVE] is [ON] (page 81)

- The LCD screen turns off while the flash is being charged (while the \$ flash charge lamp is flashing*). When the camera is turned on for the first time after being left unused for a long period of time, the flash will take longer than usual to charge.

 *If the charging time is short, the \$\frac{1}{2}\$ flash charge lamp may not light.

 • The time from when you press the shutter button until the image is recorded is
- slightly longer than when [POWER SAVE] is [OFF].
- The focus is only aligned when the shutter button is pressed halfway, even when auto focusing is activated.

Charging time		
Battery pack	Full charge (min.)	Normal charge (min.)
NP-FC10 (supplied)	Approx. 150	Approx. 90

Approximate time to charge a completely discharged battery pack using the AC-LS1A AC power adaptor at a temperature of 25°C (77°F).

Battery life and number of images that can be recorded/played

Still image recording

	NP-FC10 (supplied)		
	Battery life (min.)	Number of images	
LCD screen ON	Approx. 60	Approx. 1200	
LCD screen OFF	Approx. 90	Approx. 1800	

Approximate battery life and number of images that can be recorded with a fully charged battery pack at a temperature of 25°C (77°F), 640×480 image size, standard temperature of 25°C (77°F). picture quality and in NORMAL recording mode.

* POWER SAVE mode OFF and recording at about 4-second intervals

Still image playback*

	NP-FC10 (supplied)		
	Battery life (min.)	Number of images	
LCD screen ON	Approx. 100	Approx. 2000	

Approximate battery life and number of images that can be played back with a fully charged battery pack at a temperature of 25°C (77°F), 640×480 image size, standard picture quality and in NORMAL recording mode.

** Playing back single images in order at about 3-second intervals

Moving image recording

	NP-FC10 (supplied)		
	LCD screen OFF (min.)	LCD screen ON (min.)	
Continuous recording	Approx. 90	Approx. 60	

Approximate recording time with a fully charged battery pack at a temperature of

 $25^{\circ}\mathrm{C}$ (77°F) and 160×112 image size. The recording time and playback time with a normal charge are roughly 90% of what they would be when the battery is fully charged.

Notes

- The battery life and number of images will be decreased if you use your camera at low
- temperatures, use the flash, repeatedly turn the power on/off or use the zoom.

 When LCD BACKLIGHT is set to BRIGHT, the battery life and number of images will be
- decreased.

 The numbers of images shown on tables above are a guide. The actual numbers may be less depending on conditions.

 The capacity of the "Memory Stick" is limited. The above figures are a for guide when you continuously record/play back while replacing the "Memory Stick."

 "----" appears in the display window until the battery remaining time is calculated.

 During charging, the indicators in the display window may not appear correctly or may flash in the following cases:
- in the following cases.

- in the following cases.

 When the battery pack is not installed correctly.

 When the AC power adaptor is disconnected.

 When the AC power adaptor is disconnected.


 When you turn the LCD screen on and off, it takes about one minute for the correct battery remaining time to appear.

 If sufficient battery remaining time is indicated but the power runs out soon, fully charge the battery so that the correct battery remaining time appears.

 Do not short the DC plug on the AC power adaptor with a piece of metal, and do not use the DC plug if it is dirty. Use a dry cotton swab to remove any dirt on the DC plug. Using a dirty plug or shorting the plug can result in improper charging or damage to the camera.

12

Using the AC power adaptor



Open the jack cover and connect the DC connecting cable to the DC IN jack of your camera with the \blacktriangle mark facing up.

Connect the power cord (mains lead) to the AC power adaptor and then to a wall outlet (wall socket).

Using your camera abroad


For details, see page 85

When using the AC power adaptor

Be sure to use it near the wall outlet (wall socket). If a malfunction occurs, disconnect the plug from the wall outlet (wall socket) at once.

Setting the date and time

When you first use your camera, set the date and time. If these are not set, the CLOCK SET screen will appear whenever you turn on your camera.



1 Set the mode dial to □,), ▶ or Ⅲ.

Press and hold down the POWER button for approximately one second to turn on the power.

The POWER lamp (green) lights up.

The CLOCK SET screen appears on the LCD

POWER ON/OFF(CHG)

Select the desired date display format with ▲/▼ on the control button, then press the center ●.

Select from [Y/M/D] (year/month/day), [M/D/Y] (month/day/year) or [D/M/Y] (day/month/year).



Select the year, month, day, hour or minute item you want to set with ◀/▶ on the control

The item to be set is indicated with \triangle/∇ .



Set the numeric value with △/▼ on the control button, then press the center ● to

After entering the number, ▲/▼ moves to the next

If you selected [D/M/Y] in step 3, set the time on a

Select [OK] with ▶ on the control button, then press the center ● at the desired moment to begin clock movement.

The date and time are entered.



To cancel the date and time setting


Select [CANCEL] with $\blacktriangle \lor \lor \lor \lor \lor$ on the control button, then press the center \bullet .

Set the mode dial to SET UP (page 80) and change the date and time on the CLOCK SET screen in \bigoplus (SETUP 1).

₽Note

If the rechargeable button battery is ever fully discharged (page 83), the CLOCK SET screen will appear again. When this happens, reset the date and time, by starting from step 3 above

Inserting the "Memory Stick"



Open the battery/"Memory Stick" cover. Slide the cover in the direction of the arrow.

Insert the "Memory Stick." Insert the "Memory Stick" with the ▶ mark facing toward the battery compartment as illustrated until it clicks.

Close the battery/"Memory Stick" cover.

Removing the "Memory Stick"

Open the battery/"Memory Stick" cover, then press the "Memory Stick" once lightly.

Connector · Insert the "Memory Stick" firmly until it clicks, otherwise a messa "MEMORY STICK EKKON WILL CO displayed. When the access lamp is lit up, it means data is being read or written. Never remove the "Memory Stick" or turn off the power at this time, as the data may become damaged. You cannot record or edit images on a "Memory Stick" if the erasure prevention switch is set to the LOCK position. "MEMORY STICK ERROR" will be Erasure prevention switch

* The position and shape of the erasure prevention switch may differ depending on the types of "Memory Stick" used.

17

Getting started

16

Basic operations

Basic operations

How to use the mode dial

The mode dial switches the function which is used for recording, playback, or editing. Set the dial as follows before starting to operate your camera



To record still images in TWILIGHT mode (pages 19, 54) To record still images, VOICE mode audio data

(pages 19, 56) To play back or edit images (pages 28, 29, 71) To record moving images or Clip Motion images (pages 26, 59)

SET UP: To set the setup items (page 80)

How to use the control button

When the menu is not displayed

The control button is used to perform the following operations.



When the menu or setup screen is displayed

The control button is used to select the buttons, images and menu items displayed on the LCD screen of your camera and modify the settings.





Turning on/off the operation






You can perform this operation even when the LCD screen is off.

Recording still images

Still images are recorded in JPEG format.

To record still images, press the POWER button to turn on the power and insert a "Memory Stick."



Set the mode dial to
 or
 or
 .

Press and hold the shutter button halfway down.

The beeps sound, but the image is not recorded yet. While the AE/AF lock indicator \blacksquare is flashing, the camera automatically adjusts the exposure and focus of the captured image. When the camera finishes the automatic adjustments, the AE/AF lock indicator \blacksquare changes from flashing to lighted up* and the camera is ready for recording.

If you release the shutter button, the recording will be canceled



AE/AF lock indicator (green) flashes → lights up

* If the flashing AE/AF lock indicator changes to flashing slowly, the subject may be difficult to focus on (dark, poor contrast) or the subject may be extremely close. Release the shutter button, then focus again.

18 19

1-4

Press the shutter button fully down.

The shutter sounds

"RECORDING" appears on the LCD screen, and the image will be recorded on the "Memory Stick." When "RECORDING" disappears, you can record the next image



Auto power-off function

If you do not operate the camera for about three minutes during recording or playback, the camera turns off automatically to prevent wearing down the battery. To playoack, the camera durins on automaticany to prevent wearing down the battery. To use the camera again, press the POWER button to turn on the camera again. The auto power-off function only operates when the camera is operating using a battery pack. The auto power-off function also will not operate when playing back moving images or playing back as lide show (page 68), or when a connector is plugged into the USB jack, the DC IN jack or the A/V OUT jack.

The number of images you can record on a "Memory Stick" (8 MB)

See pages 53 and 56 to 60.

Notes

- ■Notes

 Do not touch the lens portion while it is operating.

 The following phenomena may occur when AE/AF is locked, but this does not affect the recorded image.

 When recording a bright subject, the LCD screen color may change.

 When recording a dark subject, the LCD screen may brighten momentarily.

 If you press the shutter button fully down at once in step ②, the camera starts recording after the automatic adjustments are complete. However, the recording cannot be carried out while the ⁴ flash charge lamp (page 22) is flashing. (During this time, the camera is charging the flash.)

Holding the camera correctly

Hold the camera so that your fingers do not block the flash or touch the lens portion when recording images



Recording images with the finder

You can extend the battery time by turning off the LCD screen and recording using

Each time you press DSPL/LCD ON/OFF, the status of the LCD screen changes as follows:

See page 96 for a detailed description of the indicated items The LCD backlight is turned on.

(All the available indicators are turned on.)

The LCD backlight is turned on. ng messages are turned on.)

The LCD backlight is turned off.



20

Indicators in the finder




- You cannot check the entire recording range with the finder. Recording with the LCD screen is recommended when it is necessary to correctly understand the recording range.
 Because of the difference in the positions of the finder and the lens, use the LCD screen when you record a subject closer than 1 m (3 1/4 feet).
 When [DEMO] is set to [ON] in the SET UP settings, you cannot turn off the LCD screen when the present in the pres

- once the demonstration starts.

 You cannot turn off the LCD backlight in SET UP or when displaying the menu.
- . You cannot turn off the self-timer indicators and some of the indicators used in advanced
- operations.
 The indicators on the LCD screen are not recorded.

Recording with the LCD screen

When recording with the LCD screen, align the AF frame in the center of the screen with the subject



Checking the last recorded image (Quick Review)

You can check the last recorded image by clearing the menu from the screen (page 18) and pressing ◀ (⑤) on the control button.

(page 16) and promain recording mode: Press lightly on the shutter button or press ◀ (⊕) again.

To delete the image:

- 2. Select [DELETE] with ▶ on the control button, then press the center ●.
- 3. Select [OK] with ▲ on the control button, then press the center ●.

Using the zoom feature

The lens portion moves during zoom operation. Be careful not to touch the lens portion while it is operating.



Zoom button W side: for wide-angle (subject appears farther away) T)

T side: for telephoto (subject appears closer)

Minimum focal distance to the subject


W side: About 50 cm (19 3/4 inches) or more T side: About 60 cm (23 5/8 inches) or more

To record even closer subjects, see page 61.

Digital zoom function

This camera has a digital zoom function.

Digital zoom enlarges the image by digital processing and it starts to function when zoom exceeds 3×.



Using digital zoom

- The maximum zoom magnification is 6×.
- Digital zooming deteriorates the picture quality. When digital zoom is not necessary, set [DIGITAL ZOOM] to [OFF] in the SET UP settings (page 80).

Notes


- Zoom does not work for moving images.
 Use the LCD screen when using the digital zoom function. Digitally zoomed images do not appear in the finder.
 The AF frame (page 22) does not appear on the LCD screen.

22 23

25

Using the self-timer

When you use the self-timer function, the subject is recorded about 10 seconds after



- 1. Clear the menu (page 18)
- 1. Clear the instru fugge 18).

 2. Press the control button ▼ (⑤), then press the shutter button.

 The ⑥ (self-timer) indicator appears on the LCD screen, and about 10 seconds after you press the shutter button, the subject is recorded. The self-timer lamp flashes and a beep sounds after you press the shutter button until the shutter is released.

To cancel the self-timer recording

Press the control button **▼**(**⑤**) again.

Recording images with the flash

In this mode, the flash automatically strobes when the surroundings is dark. The factory setting is auto (no indicator). To change the flash mode, clear the menu (page 18), then press the control button ▲ (🍎) repeatedly so that the flash mode indicator appears on the LCD screen.



Each time you press the control button \blacktriangle (\clubsuit), the indicator changes as follows. (No indicator) $\to \clubsuit \to \textcircled{N}$ \to (No indicator)


Forced flash: The flash strobes regardless of the surrounding brightness.

You can change the brightness of the flash with [\$\pm\$=] (FLASH LEVEL) in the menu

24

Recording moving images

Moving images with audio are recorded in MPEG format (page 45). To record moving images, press the POWER button to turn on the power and insert a "Memory Stick."



- Set the mode dial to SET UP.
- ø

Select [MOVING IMAGE] with △/▼ on the control button, then press ▶.



Select [MPEG MOVIE] with ▲/▼ on the control button, then press the center ●



Set the mode dial to 🖽.

To reduce the red-eye phenomenon

Set [RED EYE REDUCTION] to [ON] in the SET UP settings (page 80). The flash pre-strobes before recording to reduce the red-eye phenomenon. When [ON] is selected and the mode dial is set to \bigcirc or \bigcirc appears on the LCD screen.

- When [ISO] is set to [AUTO] in the menu settings, the recommended shooting distance using the built-in flash is 0.5 m to 2.8 m (19 3/4 inches to 9 feet 2 1/4 inches) at the W side, and 0.6 m to 1.4 m (19 3/4 inches to 4 feet 7 1/8 inches) at the T side. When it is not set to
- and 0.6 m to 1.4 m (19.34 inches to 4 feet 7 1/8 inches) at the 1 side. When it is not set to [AUTO], the flash may be ineffective even if the flash level is changed.

 Red-eye reduction may not produce the desired effects depending on individual differences, the distance to the subject, if the subject does not see the pre-stroke, or other conditions.

 The flash effect is not obtained easily when you use \$\frac{1}{2}\$ forced flash in a bright location.

 While charging the flash, the \$\frac{1}{2}\$ flash charge lamp flashes. After the charging is complete, the long once out
- the lamp goes out.

 The flash does not function when recording moving images (excluding Clip Motion) or recording in BURST2 mode
- recording in BURS 12 mode.

 When you record images in a dark place with the camera set to

 (no flash), the shutter speed becomes slow, so using a tripod is recommended to prevent shaking.

Recording images with the AF illuminator

The AF illuminator is fill light to focus on a subject easily. Set [AF ILLUMINATOR] (page 80) to [ON] in the SET UP settings. For appears on the LCD screen and the AF illuminator emits light when the shutter button is pressed halfway until the focus is locked.



Notes

- If AF illuminator light does not reach the subject sufficiently or the subject has no contrast, focus will not be achieved. (An approximate distance up to 2.4 m (7 feet 10 1/2 inches) at the W side, up to 1.4 m (4 feet 7 1/8 inches) at the T side is recommended.)

 In TWILIGHT mode, the AF illuminator will emit light only when the flash mode is set to

 f (Forced flash).

 Focus is achieved as long as AF illuminator light reaches the subject even if its light is slightly out of the middle position of the subject.

 The AF illuminator does not operate when adjusting focus manually.

 The AF illuminator is a very bright light. Although it is safe to use, avoid shining it directly into someone's exest at a close distance.

- into someone's eyes at a close distance.

Press the shutter button fully down.

"REC" appears on the LCD screen, and recording of the image and sound on the "Memory Stick" begins

Press the shutter button fully down again to stop recording.

The recording stops. When selecting the 320 (HQ) size: The recording stops in approximately 15 $\,$ seconds (page 52).

When selecting the 320×240 or 160×112 sizes: The recording stops when the "Memory Stick" is full.

For details on the image size, see "Setting the image size (IMAGE SIZE)" on page 52.

Using the self-timer

When you use the self-timer function, the subject is recorded about 10 seconds after you press the shutter button

- 1. Clear the menu (page 18).
 2. Press the control button ▼ (⑤), then press the shutter button.
- The \mathfrak{S} (self-timer) indicator appears on the LCD screen, and the recording starts about 10 seconds after you press the shutter button. The self-timer lamp flashes and a beep sounds after you press the shutter button until the shutter is released.

To cancel the self-timer recording

Press the control button **▼** (**⑤**) again.

LCD screen indicators during recording


Each time you press DSPL/LCD ON/OFF, the status of the LCD screen changes as follows: all indicators on \rightarrow indicators off \rightarrow LCD screen off. These indicators are not recorded. See page 97 for a detailed description of the

indicators.

When using the camera for long periods, use the AC power adaptor. If you remove the battery pack or otherwise turn off the power partway through a recording, the moving image recorded thus far is not saved. When the $^{\Box}$ mark appears while operating the nera, stop the recording at this point before the battery completely runs out.

Playing back still images

To play back still images, press the POWER button to turn on the power and insert a "Memory Stick."



Set the mode dial to ▶

The last recorded image (still or moving) appears on the LCD screen.

Select the desired still image with the control button ◀/▶.

To display the preceding image
 To display the next image.



Notes

- You might not be able to correctly play back images recorded with this camera on other equipment.
 • You cannot play back images on this camera which are larger than the maximum image size
- that can be recorded with this camera
- A rough image is played back, followed by the normal image.

LCD screen indicators during still image playback

Each time you press DSPL/LCD ON/OFF, the status of the LCD screen changes as follows: all indicators on \rightarrow indicators off \rightarrow LCD screen off. See page 98 for a detailed description of the indicators.

28

30

Moving images recorded with the image of [320 (HQ)]

The images are displayed over the entire screen

Adjusting the volume


Press the control button ▲/▼ to adjust the volume.

LCD screen indicators during moving image playback

Each time you press DSPL/LCD ON/OFF, the status of the LCD screen changes as follows: all indicators on \rightarrow indicators off \rightarrow LCD screen off. See page 98 for a detailed description of the indicators.

Playing back moving images

To play back moving images, press the POWER button to turn on the power and insert a "Memory Stick."



Set the mode dial to .

The last recorded image (still or moving) appears on the LCD screen.

Select the desired moving image with the control button **◄/▶**.

Moving images are displayed one-size smaller than still images.

It odisplay the preceding image.

►: To display the next image.



Press the center ● on the control button to start the playback.
The moving image and sound are played back.
During playback, ▶ (playback) appears on the LCD



To pause playback

the center
on the control button to pause the playback.

To advance or rewind the moving image

Press the control button ◀/► during playback.
To return to normal playback, press the center ● on the control button.

29

Viewing images using a computer

You can view data recorded with your camera on a computer, and modify and attach it to e-mail using application software. This section describes the method for viewing images on a computer using the supplied USB cable.

The USB cable is used to connect the camera to a computer so that operations can be performed on image files recorded in a "Memory Stick" from the computer. In order to use the USB cable, a USB driver must be installed in the computer

Be sure to also refer to the operation manuals for your computer and the application

There are two ways to make the USB connection, which are the normal connection Inere are two ways to make use USB connection, which are the normal connection and the PTP connection. This is set using [USB CONNECT] in the SETUP settings (page 81). The factory setting is [NORMAL].

This section describes the way using the [NORMAL] setting. Users will be informed at the Sony website when PTP connection is supported.

Viewing images on Windows: page 32 Viewing images on Macintosh: page 41 Notes on using your computer: page 43

■Notes

- Data recorded with your camera is stored in the following formats. Make sure that applications that support these file formats are installed on your computer.
 Still images (other than TEXT mode and uncompressed mode): JPEG format
 Moving images/audio: MPEG format
 Uncompressed mode still images: TIFF format
 TEXT mode/Clip Motion: GIF format

- TEXT mode/Clip Motion: GIF format

 Depending on your application software, the file size may increase when you open a still image file.

 When you copy an image to the camera from your computer, which was modified with retouching software and was converted to another file format, the "FILE ERROR" message may appear and you may be unable to open the image.

 Depending on your application software, only the first frame of the Clip Motion file may be cliently be to the control of the clip Motion file may be cliently be to the control of the clip Motion file may be cliently be to the clip Motion file may be cliently be to the clip Motion file may be cliently be to the clip Motion file may be cliently be to the clip Motion file may be cliently be to the clip Motion file may be cliently be to the clip Motion file may be cliently be to the clip Motion file may be cliently as the clip of the clip Motion file may be cliently be to the clip Motion file may be cliently as the cliently as the cliently as the clip of the clip Motion file may be cliently as the clip of the clip Motion file may be cliently as the cliently as the cliently as the clip of t
- played back.

 Communications with your computer (for Windows only)

Communications between your camera and your computer may r from Suspend or Sleep. not recover after recovering

- Microsoft Corporation in the United States and/or other countries.

 Macintosh, Mac OS and QuickTime are either registered trademarks or trademarks of Apple
- Additional via the computer, Inc.

 All other product names mentioned herein may be the trademarks or registered trademarks of their respective companies. Furthermore, "TM" and "®" are not mentioned in each case in this

[·] Microsoft, Windows and Windows Media are either registered trademarks or trademarks of

Viewing images on Windows

Recommended computer environment

OS: Microsoft Windows 98, Windows 98SE, Windows 2000 Professional, Windows

Millennium Edition
The above OS must be installed at the factory.
Operation is not assured in an environment upgraded to the operating systems described

above.

CPU: MMX Pentium 200 MHz or faster
The USB connector must be provided as standard.

Windows Media Player (recommended) must be installed (to play back moving pictures).

■Notes

- If you connect two or more USB equipment to a single computer at the same time, some equipment may not operate depending on the type of USB equipment.
 Operations are not guaranteed when using a hub.
 Operations are not guaranteed when using a hub.

Installing the USB driver to the computer

Before connecting your camera to your computer, install the USB driver to the computer. The USB driver is included with the application software in the CD-ROM which is supplied with your camera.

□Caution

Be sure to complete installation of the USB driver before connecting your camera to the computer. If you connect the USB cable first, you will be unable to install the USB driver properly.

See page 35 for corrective measures if the USB cable was connected before installing the driver and the driver software could not be installed correctly.

O Turn on your computer and allow Windows to load.

Do not connect the USB cable in this step.

• Close down all applications running on the computer

Insert the supplied CD-ROM in the CD-ROM drive of your computer.



The title screen appears after a moment.

- 1 Double-click "My Computer
- Double-click the CD-ROM ("PhotoSuite (E:)").
 * The drive symbol ((E:), etc.) may differ depending on your computer



→ The title screen appears after a moment

Move the arrow (mouse pointer) to "USB Driver Installation for Windows 98/98SE/Me and Windows 2000" in the title screen and click the left button of the mouse. 0



33

Left-click "Next."

32


34



Eiect the CD-ROM from the computer.



6 Follow the on-screen messages to quit the InstallShield Wizard.



If you cannot install the USB driver

Another USB driver may already be installed. Follow the procedure on page 36 to connect the camera and then try the following steps


For Windows 98. Windows 98SE and Windows Me users:

creens shown below are taken from Windows Me.

1 Display the "System Properties" screen. The "System Properties" screen appears.



2 Check whether a USB driver is already installed.



3 If a USB driver is installed, remove it.

If the check in step 2 shows [3] Sony DSC] or [3] Sony Handycam] in "Other Devices", another USB driver is already installed in your computer. In this case, the driver must be removed and then installed again. The removal procedure is as follows.

- (a) Left-click [3] Sony DSC] or [3] Sony Handycam].

 (a) Left-click "Remove." The "Confirm Device Removal" screen appears.
- 3 Left-click the "OK" button to remove the driver.

Perform the operations starting over from step 1 (page 32) to reinstall the

37

For Windows 2000 Professional users:


Log in with the permission of administrator.

- 1 Right-click " My Computer," then left-click "Properties".

 The "System properties" screen appears.
- 2 Left-click "Hardware," then left-click "Device Manager."
- $3\,\text{Left-click}$ "View" in "Device Manager," then left-click "Devices by type."
- 4 Right-click " \P Sony DSC" in " ${\mathfrak P}$ Other devices," then left-click "Delete."

Perform the operations starting over from step **1** (page 32) to reinstall the USB driver.


Open the jack cover on the camera and insert the USB cable connector into the USB jack (mini-B) as far as it will go.



Connect the other USB cable connector to the USB jack on your computer.



Prepare your camera.



- ① Insert a "Memory Stick" into your camera.
- 2 Connect the AC power adaptor to your camera
- 3 Turn on your camera.

"USB MODE" appears on the LCD screen of your camera. When you first connect the camera, the Device Manager automatically starts twice in succession to allow your computer to recognize the camera. There is no need to operate either your computer or the camera during this period. Be sure to wait until the Device Manager has started twice.

■Note

If "USB MODE" does not appear after finishing step 3, check [USB CONNECT] in the SET UP settings, and change the setting to [NORMAL] if it is different.

■Notes

Do not connect the USB cable before the USB driver installation is completed in step 3.
In step 3, make sure that a "Memory Stick" is inserted into your camera before turning on the camera. Otherwise, you will be unable to recognize the camera.

Viewing images


36

When viewing moving images on a Windows system, Windows Media Player or other moving image playback applications must be installed.


Example: Viewing still images

The procedure is the same as for viewing moving images and other image data.

- 1 Turn on your computer and allow Windows to load.
- 2 Open the jack cover on the camera and insert the USB cable connector into the USB jack (mini-B) as far as it will go.



3 Connect the other USB cable connector to the USB jack on your



- Insert a "Memory Stick" into your camera, and connect the AC power adaptor to your camera and then to a wall outlet (wall
- Turn on the power of your camera.
 "USB MODE" appears on the LCD screen of the camera

Ouble-click "My Computer."



7 Double-click the newly recognized drive.



Double-click the "Removable Disk (F:)" folder.

→ The "Removable Disk (F:)" folder contents are displayed.

Double-click the "DCIM" folder.



9 Double-click the "100MSDCF" folder.



→ The "100MSDCF" folder contents are displayed.



Desired file type	Double-click in this order
Still image	"Dcim" folder → "100msdcf" folder → Image file
Moving image*	"Mssony" folder → "Moml0001" folder → Image file*
Audio*	"Mssony" folder → "Momlv100" folder → Audio file*
Clip Motion image	"Dcim" folder → "100msdcf" folder → Image file
E-mail image TIFF image (uncompressed)	"Mssony" folder → "Imcif100" folder → Image file

* Copying a file to the hard disk of your computer before viewing it is recommended. If you play back the file directly from the "Memory Stick", the image and sound may break off.

To copy the image data to your computer

Drag and drop the image data to the "My Document" (example) folder.



40

When "Put these items into the Extensions folder?" appears, click "OK." 0

Restart your computer. a

Viewing images

When viewing moving images on a Macintosh system, QuickTime 3.0 or later must be installed

Turn on your computer and allow the Mac OS to load. O

Open the jack cover on the camera and insert the USB cable connector into the USB jack (mini-B) as far as it will go. A

Connect the other USB cable connector to the USB jack on your computer. 0

Insert a "Memory Stick" into your camera, and connect the AC power adaptor to your camera and then to a wall outlet (wall socket). 4

Turn on the power of your camera. "USB MODE" appears on the LCD screen of the camera

Double-click the newly recognized icon on the desktop. The folders inside the "Memory Stick" are displayed. 0

Select and double-click the desired image/sound file from the folder. Ø

Viewing images on Macintosh

Recommended Computer environment

Mac OS 8.5.1/8.6/9.0/9.1, Mac OS X

The above OS must be installed at the factory

However, note that the upgrade to Mac OS 9.0/9.1 should be used for the following

models.

— i Mac with the Mac OS 8.6 factory pre-installed and a slot loading type CD-ROM drive
— iBook or Power Mac G4 with the Mac OS 8.6 factory pre-installed
The USB connector must be provided as standard.
QuickTime 3.0 or newer must be installed (to play back moving pictures).

□ Notes

- If you connect two or more USB equipment to a single computer at the same time, some equipment may not operate depending on the type of USB equipment.

 Operations are not guaranteed when using a hub.
- Operations are not guaranteed for all the recommended computer environments mentioned

Installing the USB driver to the computer

For Mac OS 9.1, Mac OS X users

It is not necessary to install the USB driver. The Macintosh recognizes the camera as a drive simply by connecting it to the Macintosh with the USB cable.

For Mac OS 8.5.1/8.6/9.0 users

Follow the procedures below to install the driver

Turn on your computer and allow the Mac OS to load. 0

Insert the supplied CD-ROM in the CD-ROM drive of your 0

Double-click the CD-ROM drive icon to open the window. 0

Double-click the icon of the hard disk containing the OS to open the window.

Move the following two files from the window opened in step ❸ to the "System Folder" icon in the window opened in step ❹ (drag and drop).
• Sony USB Driver 0

Sony USB Shim

41

Notes on using your computer

"Memory Stick"

- Operation is not guaranteed if you are using a "Memory Stick" that was formatted with a computer, or if you used a computer to format the "Memory Stick" in your camera through a USB connection.
- Do not optimize the "Memory Stick" on a Windows machine. This will shorten the 'Memory Stick" life.
- Do not compress the data on the "Memory Stick." Compressed files cannot be played back on your camera.

- · Depending on your application software, the file size may increase when you open
- When you load an image modified using the supplied retouch software from your computer to the camera or when you directly modify the image on the camera, the image format will differ so the "FILE ERROR" message may appear and you may be unable to open the file.
- Depending on your application software, only the first frame of the Clip Motion file may be played back.

For Windows Me and Windows 2000 users

The following procedures are recommended when disconnecting the USB cable from your computer or ejecting the "Memory Stick" from the camera while it is connected to your computer.

1 Stop the driver

Stop the drive by clicking on the "Unplug/Eject" icon in the task tray.

When the message appears confirming the safe removal of the hardware, disconnect the USB cable or eject the "Memory Stick."

Communications with your computer (for Windows only)
Communications between your camera and your computer may not recover after recovering from Suspend or Sleep.


For Mac OS X users

Turn off your computer before disconnecting the USB cable from the computer or removing the "Memory Stick."

Image file storage destinations and image files

Image files recorded with your camera are grouped in folders by recording mode. The meanings of the file names are as follows. □□□□ stands for any number within the range from 0001 to 9999.

For Windows Me users (The drive recognizing the camera is



Folder	File	Meaning
100MSDCF	DSC0□□□.JPG	Still image file recorded normally Still image file recorded in — E-MAIL mode (page 55) — TIFF mode (page 58) — VOICE mode (page 56) — Burst mode (page 55)
	CLP0□□□□.GIF	Clip Motion file recorded in NORMAL mode (page 59)
	CLP0□□□□.THM	Index image file of Clip Motion file recorded in NORMAL mode
	MBL0□□□□.GIF	Clip Motion file recorded in MOBILE mode (page 59)
	MBL0□□□□.THM	Index image file of Clip Motion file recorded in MOBILE mode
	TXT0□□□□.GIF	Still image file recorded in TEXT mode (page 57)
	TXT0□□□□.THM	Index image file of still image file recorded in TEXT mode

45

Advanced operations

Before performing advanced operations

The operation methods that are frequently used for advanced operations are described below. For mode dial and control button usage, see page 18.

Setting up the items in the SET UP screen

Set the mode dial to SET UP. The SET UP screen appears (page 80).



- Press $\blacktriangle/\blacktriangledown/\blacktriangleleft/\blacktriangleright$ on the control button to select the item you want to set up.
- Press the center
 on the control button to enter the item.

Setting up the items in the menu

- Set the mode dial to □, J, □ or ►.
- Press MENU.
- The menu appears (page 47).
 - When the mode dial is set to ▶:
 ① Press ◄/▶ on the control button to select the
 - item you want to set. The selected setting turns yellow.

 ② Press the center on the control button to enter



When the mode dial is set to \square , \bigcirc or \square :
Press $\triangle / / / / \triangleright$ on the control button to select the setting of the item.

The selected setting turns yellow and the setup is complete.



Folder File Meaning DSC0□□□□.JPG IMCIF100 Small-size image file recorded in E-MAIL mode (page 55) DSC0 Uncompressed image file recorded in TIFF mode (page 58) MOML0001 $MOV0\square\square\square\square.MPG$ Moving image file recorded normally MOMLV100 DSC0□□□□.MPG Audio file recorded in VOICE mode

- ■Notes

 The numerical portions of the following files are the same.

 A small-size image file recorded in E-MAIL mode and its corresponding image file

 An uncompressed image file recorded in TIFF mode and its corresponding image file

 An audio file recorded in VOICE mode and its corresponding image file

 An image file recorded in TEXT mode and its corresponding index image file

 An image file recorded with Clip Motion and its corresponding index image file

 Do not change these folder and file names on your computer. If the name is changed, the camera may be unable to open that folder or file.

The digital still camera saves recorded images as digital data. The format of the saved data is called as the file format. The formats that can be used with this camera are as follows:

Most digital still cameras, computer operating systems, and browser software adopt this format. This format is able to compress files without appreciable deterioration. However, if the image is compressed and saved on repeated occasions, the image quality will deteriorate. This camera records still images using the JPEG format for normal recording.

GIF format

Using this format, the image quality will not deteriorate even if the image is compressed and saved on repeated occasions. This format limits the number of colors to 256 colors. This camera records still images using the GIF format in Clip Motion (page 59) or TEXT mode (page 57).

TIFF format

Stores shot images without compression, so the image quality does not Stores shot images without compression, so the image quanty does not deteriorate. Most operating systems and applications support this format. This camera records still images using the TIFF format for the TIFF mode (page 58).

This format is very typical for moving images. This camera records audio using the MPEG format for the moving image recordings and the VOICE mode (page 56).

Menu settings

Menu items that can be modified differ depending on the positions of the mode dial. The LCD screen shows only the items you can operate at the moment. Factory settings are indicated with ■.

When the mode dial is set to A/

Item	Setting	Description
(EV)	+2.0EV to -2.0EV	Adjusts the exposure value. 13 steps in 1/3 EV increments. The factory setting is [0EV].
(FOCUS)	∞ (infinite) 7.0 m 3.0 m 1.0 m 0.5 m ■AUTO	Sets the distance to the subject (page 61).
WB (WHITE BAL)	HOLD AUTO IN DOOR OUT DOOR	Sets the white balance (page 63).
(SPOT METER)	ON ■OFF	Adjusts the brightness of the spot to be recorded (page 65).
ISO	400 200 100 ■ AUTO	Selects the ISO film speed. When recording under dark conditions or recording a fast-moving subject, use a high-number setting. To record high-quality images, use a low-number setting (except when the mode dial is set to
(IMAGE SIZE)	■2048×1536 2048 (3:2) 1600×1200 1280×960 640×480	Selects the image size when recording still images (page 52).
€! - (P. QUALITY)	■FINE	Records still images in the fine image quality mode.
	STANDARD	Records still images in the standard image quality mode.

Item	Setting	Description
MODE (REC	TIFF	Records a TIFF (uncompressed) file in addition to the JPEG file (page 58).
MODE)	TEXT	Records a GIF file in black-and-white (page 57).
	VOICE	Records an audio file (with a still image) in addition to the JPEG file (page 56).
	E-MAIL	Records a small-size (320×240) JPEG file in addition to the selected image size (page 55).
	BURST2	Records two images continuously (page 55).
	■NORMAL	Records an image using the normal recording mode.
\$ ±	HIGH	Makes the flash level higher than normal.
(FLASH LEVEL)	■NORMAL	Normal setting.
LL (LL)	LOW	Makes the flash level lower than normal.
PFX (P. EFFECT)	SOLARIZE B&W SEPIA NEG.ART OFF	Sets the image special effects (page 64).
(SHARPNESS)	+2 +1 ■ 0 -1 -2	Adjusts the sharpness of the image. The ① indicator appears (except when the setting is 0).

When the mode dial is set to Ξ (MOVING IMAGE is set to MPEG MOVIE in the SETUP settings.)

Item	Setting	Description
(EV)	+2.0EV to -2.0EV	Adjusts the exposure value. 13 steps in 1/3 EV increments. The factory setting is [0EV].
(FOCUS)	∞ (infinite) 7.0 m 3.0 m 1.0 m 0.5 m ■AUTO	Sets the distance to the subject (page 61).
WB (WHITE BAL)	HOLD AUTO IN DOOR OUT DOOR	Sets the white balance (page 63).
(SPOT METER)	ON ■OFF	Adjusts the brightness of the spot to be recorded (page 65).
(IMAGE SIZE)	320 (HQ) 320×240 ■160×112	Selects the MPEG image size when recording moving images (page 52).
PFX (P. EFFECT)	SOLARIZE B&W SEPIA NEG.ART	Sets the image special effects (page 64).

48 49

When the mode dial is set to ## (MOVING IMAGE is set to CLIP

Item	Setting	Description
(EV)	+2.0EV to -2.0EV	Adjusts the exposure value. 13 steps in 1/3 EV increments. The factory setting is [0EV].
(FOCUS)	∞ (infinite) 7.0 m 3.0 m 1.0 m 0.5 m ■AUTO	Sets the distance to the subject (page 61).
WB (WHITE BAL)	HOLD AUTO IN DOOR OUT DOOR	Sets the white balance (page 63).
● (SPOT METER)	ON ■ OFF	Adjusts the brightness of the spot to be recorded (page 65).
(IMAGE SIZE)	NORMAL MOBILE	Selects the Clip Motion image size (page 59).
\$ ±	HIGH	Makes the flash level higher than normal.
(FLASH LEVEL)	■NORMAL	Normal setting.
LL (LL)	LOW	Makes the flash level lower than normal.
PFX (P. EFFECT)	SOLARIZE B&W SEPIA NEG.ART OFF	Sets the image special effects (page 64).
(SHARPNESS)	+2 +1 ■ 0 -1 -2	Adjusts the sharpness of the image. The [I] indicator appears (except when the setting is 0).


When the mode dial is set to 🕨

Item	Setting	Description
DELETE	OK	Deletes the displayed image (page 71).
	CANCEL	Cancels deleting of the image.
PROTECT	-	Protects images against accidental erasure (page 72).
PRINT	-	Marks the print mark on still images (page 76).
SLIDE*	INTERVAL	Sets the slide show interval. ■3 sec/5 sec/10 sec/30 sec/1 min
	REPEAT	■ON/OFF
	START	Starts the slide show.
	CANCEL	Cancels the slide show.
COPY OK		Copies an image (page 75).
	CANCEL	Cancels copying of the image.
RESIZE*	2048×1536 1600×1200 1280×960 640×480	Changes the recorded image size (page 74).
	CANCEL	Cancels changing of the recorded image size.
ROTATE*	OK OK	Rotates the still image 90 degrees (page 69).
	CANCEL	Cancels rotation of a still image.
DIVIDE*	OK	Divides a moving image (page 78).
	CANCEL	Cancels division of a moving image.

^{*} Only in single-image mode.

53

Setting the image size (IMAGE SIZE)



Set the mode dial to ♠, J or □

0 Press MENU. The menu appears

Select [■] (IMAGE SIZE) with ◀/▶, then select the desired image size with ▲/▼.

Still image sizes: 2048×1536: 3.0 mega pixels 2048 (3:2)*

1600×1200: 2.0 mega pixels 1280×960: 1.3 mega pixels 640×480: 0.35 mega pixels

* The image is recorded in the ratio of three to two to fit the printing paper size. Using this image size, the margin of an image is not printed out. However, a slight amount of the upper and lower black portions are displayed on the LCD screen.

The larger the numbers for the image size are, the larger the file will be, and the fewer images that can be recorded on one "Memory Stick." For details on how many images can be recorded, refer to page 53.

Moving image (MPEG movie) sizes $320~(HQ)^*, 320^\circ240, 160^\circ112$

* High Quality mode

Clip Motion sizes: NORMAL (160×120), MOBILE (120×108)

Examples of use and the number of images* or the time** that you can record on a "Memory Stick" (8 MB) for each image size

Still images:

Image size	Usage	Quality	
illaye size	Usaye	STANDARD	FINE
2048×1536	Modifying images	Approx. 9	Approx. 5
2048 (3:2)	Printing in 3:2 ratio	Approx. 9	Approx. 5
1600×1200	Printing in A4 format	Approx. 15	Approx. 8
1280×960	Printing in post card size	Approx. 22	Approx. 12
640×480	Attaching to e-mail	Approx. 118	Approx. 48

Moving images:

lmage size	Usage	Number of images or time
320 (HQ)	Viewing on TV	Approx. 20 sec.
320×240	Viewing on computer	Approx. 80 sec.
160×112	Attaching to e-mail	Approx. 320 sec.
MOBILE (120×108) (2 frames)	-	Approx. 300
NORMAL (160×120) (10 frames)	-	Approx. 40

- When MODE (REC MODE) is set to NORMAL.

Number of recordable images or recordable time (page 96)

The actual number of images or recordable time may differ depending on the recording conditions.

► Various recording

Recording images according to shooting conditions (TWILIGHT mode)

Mode dial:

52

This mode is suitable for the night



Set the mode dial to

Allows you to record bright subjects in dark places without losing the dark atmosphere of the surroundings. The shutter speed becomes slower, so we recommend that you use a tripod to prevent shaking.

2 Record the image.

To cancel the TWILIGHT mode

Set the mode dial to

Notes

- Whotes

 Set 4 forced flash when you use the flash in the TWILIGHT mode.

 You cannot record moving images in the TWILIGHT mode.

 When using the TWILIGHT mode, the AF illuminator (page 25) emits light when the flash mode is set to 4 forced flash.

Tips


Tips
Under normal recording conditions, the camera automatically makes various adjustments, such as those for the focus, iris, exposure, and white balance, as it shoots. However, you may not be able to carry out your desired shooting depending on the shooting conditions. The TWILIGHT mode provides you with near-optimum adjustments to suit your shooting situation. near-optimum adjusti shooting situation.



Recording two images continuously

Mode dial:

This mode is used for a continuous recording.



- 1 Set the mode dial to or
- 2 Press MENU.
- The menu appears
- 3 Select [MODE] (REC MODE) with ◀/▶, [BURST2] with ▲/▼.
- 4 Press MENU.
- The menu disappears
- 5 Record the image.

To return to normal recording mode

Select [NORMAL] with ▲/▼ in step 3.

Notes

- Notes

 Our annot use the flash in this mode.


 During recording in this mode, the image is not displayed on the LCD screen. Make the composition before pressing the shutter button.

 The recording interval is approximately 0.6 seconds.
- 0.6 seconds

Recording still images for e-mail (E-MAIL)

Mode dial: 🗖 / 🜙

In the E-MAIL mode, a small-size image which is suitable for e-mail transmission is also recorded at the same time as recording a normal still image. (The size of the normal still image is set using [(IMAGE SIZE) in the menu settings (page 52).)



- Set the mode dial to or
- 2 Press MENU. The menu appears.
- Select [MODE] (REC MODE) with ◀/▶, [E-MAIL] with ▲/▼
- 4 Press MENU.
- The menu disappears.
- 5 Record the image.

Image size	Quality		
Illiaye Size	STANDARD	FINE	
2048×1536	Approx. 8	Approx. 4	
2048 (3:2)	Approx. 8	Approx. 4	
1600×1200	Approx. 14	Approx. 8	
1280×960	Approx. 21	Approx. 12	
640×480	Approx. 95	Approx. 43	

Number of recordable images

(page 96)
The actual number of images may differ depending on the recording conditions.

To return to normal recording mode

Select [NORMAL] with ▲/▼ in step 3.

Adding audio files to still images (VOICE)

Mode dial: d /

In the VOICE mode, the audio is also recorded at the same time as recording a still image. (The size of the normal still image is set using [I] (IMAGE SIZE) in the menu settings (page 52).)



- Set the mode dial to a or
- Press MENU. The menu appears.
- Select [MODE] (REC MODE) with **◄/▶**, [VOICE] with **▲/▼**.
- Press MENU.

The menu disappears

Record the image. If you press and release the shutter button, sound is recorded for five seconds. If you hold down the shutter button, sound is recorded until you release the shutter button for up to 40 seconds.

The number of images that you can record on a "Memory Stick" (8 MB) in VOICE mode*

Image size	Quality		
imaye size	STANDARD	FINE	
2048×1536	Approx. 8	Approx. 4	
2048 (3:2)	Approx. 8	Approx. 4	
1600×1200	Approx. 13	Approx.	
1280×960	Approx. 19	Approx.	
640×480	Approx. 56	Approx. 34	

When recording 5-second audio

To return to normal recording mode

Select [NORMAL] with \blacktriangle / \blacktriangledown in step 3.

Recording text documents (TEXT)

Mode dial:

The TEXT mode is suitable for recording a document in black and white to emphasize the character. The LCD screen also turns black and white, and the image is recorded in the GIF



- 1 Set the mode dial to
- Press MENU. The menu appears
- Select [MODE] (REC MODE) with **◄/▶**, [TEXT] with **▲/▼**.
- Press MENU. The menu disappears.
- 5 Record the image.

The number of images that you can record on a "Memory Stick" (8 MB) in TEXT mode*

Image size	Number of images*
2048×1536	14-108
2048 (3:2)	16–108
1600×1200	24-138
1280×960	36-162
640×480	121–323

* The number of recordable images depends on the document condition, such as the amount of text portions.

57

56

To return to normal recording mode

Select [NORMAL] with **△**/**▼** in step **3**.

□Notes

- If the subject is not evenly illuminated, you may be unable to record a clear image.

 • Writing and reading data take more time
- When the mode dial is set to mages can be recorded, but the image may be bleached out or may be turned.
- The remaining number of recordable
- The remaining number of recordable images is not displayed.
 The number of recordable images is the same regardless of whether [€ 1] (P. QUALITY) is set to STANDARD or FINE.

Recording still images as uncompressed files (TIFF)

Mode dial: 🗖 / 🔾

In this mode, a 2048×1536 size uncompressed image is recorded at the same time as a normal still image. (The size of the normal still image is set size of the normal still image is set using [\$\frac{1}{2}\$] (IMAGE SIZE) in the menu settings (page 52).) The uncompressed image quality does not deteriorate. Images recorded in this mode are suitable for printing with a high-quality image.



- 1 Set the mode dial to no or
- 2 Press MENU.
- The menu appears.
- 3 Select [MODE] (REC MODE) with ◄/▶, [TIFF] with ▲/▼.
- Press MENU.
 - The menu disappears

5 Record the image.
The number of images that you can record on a "Memory Stick" (16 MB) in TIFF mode is approximately 1.

To return to normal recording mode

Select [NORMAL] with ▲/▼ in step 3.


Notes

- When [2048 (3:2)] is selected for the image size, the uncompressed image is recorded in the [2048 (3:2)] format.
 Writing data takes more time than
- normal recording.
 The supplied "Memory Stick" (8 MB) does not have sufficient capacity to record uncompressed images.

Creating Clip Motion Files

Mode dial:

Clip Motion is an animation function that plays back still images in succession. The images are stored in GIF format, which is convenient for creating home pages or attaching images to an e-mail.



- 1 Set the mode dial to SET UP. The SET UP screen appears.
- Select [♣] (CAMERA) with ▲/▼, [MOVING IMAGE] with ▶/▲/▼, [CLIP MOTION] with ▲/▼, then press ●.
- 3 Set the mode dial to 間.
- 4 Press MENU.
 - The menu appears
- 5 Select [IIII] (IMAGE SIZE) with ◀/▶, the desired mode with ▲/▼.

NORMAL (160×120) Clip Motion of up to 10 frames can be recorded. This is suitable for use on home pages, etc.

MOBILE (120×108)

Clip Motion of up to 2 frames can be recorded. This is suitable for use with portable data terminals.

6 Press MENU.

The menu disappears.

59

61

Record the image for the first



Before carrying out step 9, the images are temporarily stored in the memory. These images are not recorded on the "Memory Stick"

8 Record the image for the next frame. Image recording can be repeated

up to the maximum number of recordable frames.

Press .

All the frame images are recorded on the "Memory Stick."

To delete some or all of the frame images while making a Clip Motion recording

1 Press the control button () in step 7 or 8.

The recorded frame images are played back in turn and stop at the last image.

- (2) Press MENU, and select [DELETE LAST] or [DELETE ALL] with \blacktriangleleft
- ③ Select [OK] with ▲/▼, then press

When [DELETE LAST] is selected in step ②, each time you repeat steps ① through ③, a recorded frame is deleted from the newest

The number of Clip Motion frames that you can record on a "Memory Stick" (8 MB)

Image size	Number of images
NORMAL (160×120)	Approx. 40*
MOBILE (120×108)	Approx. 300**

- * When recording 10 frames per Clip Motion file
- ** When recording 2 frames per Clip Motion file

■Notes

- You cannot change the image size partway through a Clip Motion
- Reading and writing data take more time than normal image recording.

 Due to the limitations of the GIF
- Due to the limitations of the GIF format, the number of colors for Clip Motion images is reduced to 256 colors or less. Therefore, the picture quality may deteriorate for some images.

 The file size is reduced in MOBILE
- mode, so the picture quality deteriorates.
- GIF files not created on this camera
- GIF files not created on this camera may not be displayed correctly.
 All the frame images are immediately recorded on the "Memory Stick" if the mode dial is switched or the power is turned off.

Setting the distance to the subject

Mode dial: 西/)/田

Normally the focus is automatically adjusted. This function is useful when the auto focus does not work well such as in dark places.



- 1 Set the mode dial to 🗖, 🜙 or 🖽.
- 2 Press MENU. The menu appears
- Select [♠] (FOCUS) with ◄/▶, the desired distance setting with ▲/▼.

You can select from the following 6 focus settings: AUTO, 0.5 m (1 3/4 feet), 1.0 m (3 1/4 feet), 3.0 m (9 3/4 feet), 7.0 m (23 feet), ∞ (infinite).

- 4 Press MENU. The menu disappears
- 5 Record the image.

To reactivate auto focusing

Select [AUTO] with **△**/**▼** in step **3**.

Notes

- Focal point information may not show the entirely correct distance. Use the
- the entirely correct distance. Use the information as a guide.

 If you shoot a subject within 0.6 m (23 5/8 feet) while the zoom is set to the T side, you cannot get a clear focus. In such cases, the focal point information flashes. Press the zoom W button until the indicator stops flashing.

Recording images at close range (MACRO)

Mode dial: ▲/)/田

The macro recording mode is used when zooming up a small subject, such as flowers, insects.



- 1 Set the mode dial to 🗖, 🜙
- Clear the menu, and press the control button ► (♣).
 The ♣ (macro) indicator appears

on the LCD screen. You can record a subject as close as about 10 cm (4 inches) from the lens surface with the zoom set all the way to the W side, or about 60 cm (23 5/8 inches) with the zoom set all the way to the T side.

3 Record the image.

To return to normal recording mode

Press the control button ► (🎝) again. The Tindicator disappears

Note

When recording images in macro, use the LCD screen. If you record using the finder, the range visible in the finder may differ from the actual recording range

Adjusting the exposure (EXPOSURE)

60

Mode dial: 🏚 / 🌙/脚

This adjusts the exposure value which is set in the automatic adjustment.



- 1 Set the mode dial to 🗖, 🜙 or 🎞.
- 2 Press MENU.
- The menu appears Select [☑] (EV) with ◄/▶, the desired exposure value with △/▼.

Adjust the exposure value while checking the brightness of the

background. You can select values ranging from +2.0 EV to -2.0 EV in steps of 1/3 EV.

- Press MENU.
 - The menu disappears.
- 5 Record the image.

■Note

If a subject is under extremely bright or dark conditions, or the flash is used, the exposure adjustment may not be effective.

Tips

Normally, the camera automatically adjusts the exposure. If the color of the image is too dark or bright as shown below, we recommend that you adjust the exposure manually. When recording a backlighted subject or a subject in the snow, set the exposure toward +, and when recording a subject with extremely bright illumination such as a spotlight, se ward –

Set the exposure toward 4





Set the exposure toward -






Adjusting the white balance (WHITE BALANCE)

Mode dial: ☎/)/間

Normally the white balance is automatically adjusted (AUTO). When you record with the shooting condition fixed or under a specific lighting condition, you can manually adjust the white balance.



- 1 Set the mode dial to 🗖, or 間.
- 2 Press MENU. The menu appears.
- Select [WB] (WHITE BAL) with **◄/▶**, the desired setting with **▲/▼**.

HOI D

Recording a single-colored subject or background.

AUTO (No indicator)

Adjusts the white balance automatically Under fluorescent lighting

- IN DOOR (:A:)
 Places where the lighting
- condition changes quickly
 Under bright lighting such as photography studios
- Under sodium or mercury lamps

OUT DOOR (※)

Recording a sunrise/sunset, nig scene, neon signs, or fireworks

4 Press MENU.

The menu disappears.

5 Record the image.

To reactivate auto adjustment

Select [AUTO] with **△**/**▼** in step **3**.

The image is affected by the lighting conditions. The image looks blue under sunlight in the summer, and looks red sunlight in the summer, and looks red under mercury lamps. Human eyes can resolve these problems. However, the camera cannot resolve the problem without making adjustments. Normally, the camera adjusts automatically, but if the image appears in strange colors, we recommend that you change the white balance mode.



Various recording

Mode dial: 🗖 / 🜙/坩

You can digitally process images to obtain special effects.



- Set the mode dial to 🗖, 🜙 or 🖽.
- Press MENU. The menu appears
- Select [PFX] (P. EFFECT) with ◀/▶, the desired mode with ▲/▼.

SOLARIZE

The light contrast is clearer and the picture looks like an illustration.

B&W

The picture is monochrome (black and white).

The picture is sepia-toned like an old photograph.

NEG.ART

The color and brightness of the picture are reversed as in a negative.

OFF

Does not use the picture effect function

4 Press MENU. The menu disappears

5 Record the image.

To cancel picture effect

Select [OFF] with ▲/▼ in step 3.

64

Recording the date and time on a still image (DATE/TIME)

Mode dial: ₫/ 🕽



- Set the mode dial to SET UP. The SET UP screen appears
- 3 Select the date and time setting with **△**/**▼**, then press

DAY & TIME

Superimposes the date, hour, and minute.

DATE

Superimposes the year, month, and day.

OFF

Does not superimpose the date and time

Set the mode dial to a or

Record the image.

The date and time do not appear on the LCD screen during shooting. These appear during playback only

■Notes

- Notes

 If you select [DATE] in step 3, the date is superimposed onto the image in the order selected with "Setting the date and time" (page 15).

 The date and time are not superimposed
- onto moving images or Clip Motion

Using the spot lightmetering function

Mode dial: 🗖 / 🜙/坩

Use this function when there is backlight or when there is strong contrast between the subject and the background, etc. Position the spot light-metering cross hair with the point you want to record.



- 1 Set the mode dial to 🗖, 🜙 or 🖽.
- 2 Press MENU. The menu appears.
- 3 Select [○] (SPOT METER) with ◄/►. [ON] with ▲/▼. Position the spot light-metering cross hair with the point you want

to record.

4 Record the image.

Gently press the shutter button to record the image when the automatic adjustment has been completed.



To cancel the spot lightmetering function

Select [OFF] with ▲/▼ in step 3.

65

▶ Various playback

Playing back three or nine images at once

You can display multiple images on the LCD screen at one time using the zoom buttons.



- 1 Set the mode dial to **.**
- 2 Press the zoom W button

The LCD screen display changes

as follows:
• Single (single-image) screen



· Index (nine-image) screen



• Triple-image screen



The image indicated by the yellow frame in the index screen is displayed in the middle of the triple-image screen with the recording information. To display the other information, press the control button $\blacktriangle/\blacktriangledown$.

The following marks are displayed on each image according to the image type and settings.

- ☐: Moving image file
 []: VOICE mode file
 ☐: E-mail file

: Print mark : Protect mark TEXT: TEXT file

TIFF: TIFF file CLIP: Clip Motion file (No mark): Normal recording (no

To display the next (previous) index screen

Press the control button ▲/▼/◄/▶

To return to normal playback (single-image)

- Press the zoom T button repeatedly.
- Press the control button .

■Note

When viewing an image recorded in Clip Motion or TEXT mode on the index screen, the image may appear different from the actual image.

When the triple-image screen is displayed, pressing MENU opens the menu including [PRINT], [PROTECT], and [DELETE]. For details on these items, see pages 71, 72, or 76. To close the menu, press MENU again. The menu discontinuation of the menu from the me disappears and the recording information is indicated.



Enlarging a part of a still image (Zoom and trimming)

Mode dial: ►



- Set the mode dial to ▶.
- Display the image to be enlarged.
- Zoom in/out the image with the zoom T/W buttons.
- 4 Move the image with **△**/▼/**⋖**/▶ to select the desired portion of the image.

To return to the normal size

Press the control button .

To record an enlarged image (trimming)

- Press MENU after zooming.
 Select [TRIMMING] with ▶, then
- press ●.

 3 Select the image size with ▲/▼, then press ●.

The image is recorded and the image on the LCD screen returns to the normal size after recording.

■Notes

images.

- You cannot zoom moving images and Clip Motion images. You can zoom images recorded in TEXT mode, but cannot trim them.
- Zoom scaling is up to 5× regardless of
- the original image size.

 The quality of enlarged images may be deteriorated.
- deteriorated.

 The original data is retained even if you enlarge the image.

 The enlarged image is recorded as the newest file.

 If you trim an image, the remaining
- "Memory Stick" capacity will be decreased.
- decreased.

 If the remaining "Memory Stick"
 capacity is not sufficient, you may be
 unable to trim an image.

 You cannot trim to an image size of 3:2.

 You cannot trim uncompressed (TIFF)

Playing back still images in order (SLIDE)

Mode dial: 🕨

This function is useful for checking the recorded images or for presentation



- Set the mode dial to 🕨.
- 2 Press MENU. The menu appears
- Select [SLIDE] with ◀/▶, then

Set the following items with ▲/▼/

INTERVAL

You can select from 1 min (one minute), 30 sec (30 seconds), 10 sec (10 seconds), 5 sec (5 seconds), or 3 sec (3 seconds).

REPEAT

- ON: Plays back images in a continuous loop.
- OFF: After all images have been played back, the slide show ends.
- Select [START] with ▲/▼, then press ●.

The slide show begins

To cancel the SLIDE SHOW setting

Select [CANCEL] with $\blacktriangle/\blacktriangledown/\blacktriangleleft/\blacktriangleright$ in step **3**, then press \blacksquare .

To stop the SLIDE SHOW playback

Press ●, select [EXIT] with ▶, then press ●.

To skip to the next/previous image during the SLIDE SHOW

Press ► (next) or < (previous).

The interval setting time may vary depending on the image size.

Rotating a still image (ROTATE)

Mode dial: 🕨

You can rotate the image recorded in portrait orientation and change it in landscape orientation.



- 1 Set the mode dial to **>**, and display the image to rotate.
- 2 Press MENU.
- Select [ROTATE] with **◄/▶**, then press .
- 4 Select [✓, `>] with ▲/▼, then rotate the image with ∢/▼. Select [OK] with ▲/▼, then press ●.

To cancel rotation

Select [CANCEL] with **△**/**▼** in step **4**, then press **●**.

■Notes

- Nou cannot rotate protected or uncompressed images, or images recorded in TEXT mode.
 You may not be able to rotate images recorded with other equipment.
 Also, when viewing images on a computer, the image rotation information may not be reflected.
- information may not be reflected depending on the application software.


69

Viewing images on a TV screen

Mode dial: 🕨

68

Before connecting your camera, be sure to turn off the TV.



- 1 Set the mode dial to .
- Connect the A/V connecting cable to the A/V OUT jack of your camera and to the audio/video input jacks of the TV.

If your TV has stereo type input jacks, connect the audio plug (black) of the A/V connecting cable to the Lch jack.

3 Turn on the TV and start playback on your camera. The image appears on the TV screen.

· You cannot use a TV that has an The dament and a first an antenna (aerial) connector only.

 When viewing a still image on the TV, the black band may appear around the image.

Deleting images (DELETE)

Mode dial: ▶

▶ Editing

You can delete unwanted files

In single-image or triple-image mode



- 1 Set the mode dial to **.**
- 2 In single-image mode: Display the image you want to delete with **◄**/▶.

In triple-image mode:

Press the zoom W button twice in the single-image mode to turn to the triple-image mode. Display the image you want to delete with \checkmark .

- 3 Press MENU.
- The menu appears
- Select [DELETE] with **◄/▶** in single-image mode, or with ▲/▼ in triple-image mode, then press .
- 5 Select [OK] with ▲/▼, then

press ●.
The displayed image (or the middle-positioned image in triple-image mode) is deleted.

To cancel deleting

- Press MENU in step 4 or 5 so that the menu turns off.
- Select [CANCEL] with ▲/▼ in step

In index mode



- Set the mode dial to ▶, then display the index screen with the zoom W button.
- 2 Press MENU. The menu appears
- 3 Select [DELETE] with **◄/▶**, then press **●**.
- 4 Select [ALL] or [SELECT] with **◄/▶**, then press **●**.
- 5 When you select [ALL]
 Select [ENTER] with ◀/▶, then
 press ●.

All the unprotected images are

When you select [SELECT]
①Select an image to be deleted with ▲/▼/◄/▶. The frame of the selected image turns green
Press • to toggle • on and

Repeat this step until **III** has been toggled on for all images that are to be deleted.



② Press MENU.
③ Select [OK] with ◀/▶, the press ●.

To cancel deleting

Select [CANCEL] with **√**/▶ in step **4** or [EXIT] with **√**/▶ in step **5**, then press **●**.

□ Note

If there are files on the "Memory Stick" with names having the same last 4 digits as the file name of the image to be deleted, these files are also deleted at the same time.

Preventing accidental erasure (PROTECT)

Mode dial: ▶

This function protects images against accidental erasure.

■Note

Formatting a "Memory Stick" (page 79) erases even protected images.

In single-image or triple-image mode



- 1 Set the mode dial to .
- In single-image mode Display the image you want to protect with **◄**/►.

In triple-image mode
Press the zoom W button twice in
the single-image mode to turn to the triple-image mode.

Display the image you want to protect with $\blacktriangleleft/\triangleright$.

- 3 Press MENU. The menu appears.
- Select [PROTECT] with ◀/▶ in single-image mode, or with ▲/▼ in triple-image mode, then press .

The displayed image (or the middle-positioned image in triple-image mode) is protected. The on indicator appears on the

To release protection

Press ● again in step 4. The on indicator disappears.

To cancel protection

Press MENU in step 4 so that the menu

In index mode



- Set the mode dial to **>**, then display the index screen with the zoom W button.
- 2 Press MENU.

The menu appears

- Select [PROTECT] with **◄/▶**, then press ●.
- Select [ALL] or [SELECT] with ◀/▶, then press ●.
- When you select [ALL]
 Select [ON] with ◀/▶, then press
 ●.

All the images in the "Memory Stick" are protected.

When you select [SELECT]
① Select an image to be protected with ▲/▼/◄/▶. The frame of the selected image turns green.

Press • to toggle • on and

Repeat this step until on has been toggled on for all images that are to be protected.



② Press MENU.
③ Select [OK] with ◀/▶, the press ●.

To release protection

If you selected [ALL] in step 4: Select [OFF] with ◀/▶, and then press

If you selected [SELECT] in step 4: Select the images to be unprotected with ▲/▼/◄/▶, then press ●.

- ② Repeat ① for all images that are to be unprotected.
- ③ Press the MENU button, select [OK] with ◀/▶, and then press ●

To cancel protection

Select [CANCEL] with **◄/▶** in step **4** or [EXIT] with **◄/▶** in step **5**, then press •

72

Changing the recorded still image size (RESIZE)

Mode dial:

You can change the image size of a recorded image in single mode



- Set the mode dial to ▶. then display the image of which you want to change the size.
- Press MENU. The menu appears
- 3 Select [RESIZE] with ◀/▶, then press ●.
- Select the desired size with A/▼, then press ●.

 2048×1536, 1600×1200,

 1280×960, 640×480

 The resized image is recorded.

To cancel changing the size Select [CANCEL] with △/▼ in step 4, then press ●.

■Notes

- The original image is retained even after
- The original image is retained even after resizing.
 You cannot change the size of images recorded in TEXT mode, moving images, uncompressed images, or Clip Motion images.
 The resized image is recorded as the resized image is recorded as the resized image.
- newest file.
- newest file.

 If you resize an image, the remaining
 "Memory Stick" capacity will be
 decreased.

 When you change from a small size to a
 large size, the picture quality
- deteriorates.

 If the remaining "Memory Stick" capacity is not sufficient, you may not
- be able to resize an image. You cannot resize to an image size of
- 3:2.

 When you resize a 3:2 image, the upper and lower black portions are displayed on the LCD screen.


 You cannot resize images in index mode
- or triple-image mode

Copying images (COPY)

Mode dial: 🕒

You can copy images to another "Memory Stick."

In single-image mode



- Set the mode dial to . then display the image you want to copy.
- Press MENU.
- The menu appears
- Select [COPY] with **◄/▶**, then press **●**. 3
- Select [OK] with ▲/▼, then press ●.
 "MEMORY STICK ACCESS"
- When "CHANGE MEMORY STICK" appears, eject the "Memory Stick." "INSERT MEMORY STICK"
- Insert the "Memory Stick" on which to copy the image.
 "RECORDING" appears.
 When copying is completed,
 "COMPLETE" appears.
 To end copying, select [EXIT] with $\blacktriangle/\blacktriangledown$, then press \spadesuit .


⊤o copy the image to another "Memory Stick"

Select [CONTINUE] with ▲/▼, press
●, then repeat steps **5** and **6**.

To cancel copying

Select [CANCEL] with **△**/**▼** in step **4**, then press **●**.

In index mode



- Set the mode dial to ▶, then display the index screen with the zoom W button.
- 2 Press MENU. The menu appears
- Select [COPY] with ◀/▶, then press ●. Select [Select] with ◀/▶, then press ●. The frame of the selected image
- turns green. Select the image to copy with the control button, then

press ●.Press ● to toggle ✓ on and off.



Repeat this step until 🗸 has been toggled on for all images that are to be copied.



5 Press MENU. The menu appears

When "CHANGE MEMORY

STICK" is displayed, eject the "Memory Stick."
"INSERT MEMORY STICK"

Insert another "Memory Stick."

"RECORDING" appears. When copying is completed, "COMPLETE" appears To end copying, select [EXIT] with ▲/▼, then press ●.

To copy the image to another "Memory Stick"

Select [CONTINUE] with ▲/▼ in step 8, press ●, then repeat steps 7 and 8.

To cancel copying

Select [CANCEL] with **◄**/**▶** in step **3** or [EXIT] with **◄**/**▶** in step **6**, then press •

■Notes

- You cannot copy uncompressed images
 You cannot copy images that are bigger than 5 MB at once. If "NOT ENOUGH MEMORY" appears or \$\frac{1}{2}\$ flashes on the INDEX screen, cancel some images
- the INDEA screen, cancer some images to copy and try again.

 If you do not select [EXIT] after
 "COMPLETE" appears and instead insert a new "Memory Stick," the same image is copied again.

Selecting still images to print (PRINT)

Mode dial: 🕨

You can mark a print mark on still images recorded with your camera. This mark is convenient when you have images printed at a shop that conforms with the DPOF (Digital Print Order Format) standard.

In single-image or triple-image mode



- Set the mode dial to E.
- In single-image mode Display the image you want to print with ◀/▶.

In triple-image mode
Press the zoom W button twice in the single-image mode to turn to the triple-image mode. Display the image you want to print with $\blacktriangleleft/\triangleright$.

Press MENU. The menu appears.

Select [PRINT] with **◄/▶** in single-image mode, or with **▲/▼** in triple-image mode, then press .

The (print) mark is marked on the displayed image (or the middle-positioned image in tripleimage mode).

To unmark the print mark

Press ● again in step 4. The 🍱 mark

To cancel marking the print Press MENU in step 4 so that the menu

In index mode



- Set the mode dial to F, then display the index screen with the zoom W button.
- 2 Press MENU. The menu appears
- Select [PRINT] with **◄/▶**, then press
- Select [SELECT] with **◄/▶**, then press •.
 The frame of the selected image

turns green. When marking the mark, you cannot select [ALL].

5 Select the images to be marked with the control button, then press . Press ● to toggle 🍱 on and off.

→ • (**△**)

Repeat this step until 🍱 has been toggled on for all images that are to be marked.



6 Press MENU.

The menu appears.

Select [OK] with **◄/▶**, then

To unmark selected print

Select the images to be unmarked in step **5** with the control button, then press **6**.

To unmark all the print marks

Select [ALL] with $\blacktriangleleft/\blacktriangleright$ in step **4**, then press \bullet . Select [OFF] with $\blacktriangleleft/\blacktriangleright$, then press \bullet .

To cancel marking the print

Select [CANCEL] with **◄/▶** in step **4** or select [EXIT] with **√** in step 7, then press **●**.

Notes

- You cannot mark moving images, Clip Motion images or images recorded in TEXT mode.
- If you mark an image recorded in TIFF mode with a print mark, only the uncompressed image is printed, and the JPEG image recorded at the same time
- is not printed. In E-mail mode, a print mark is marked on the normal size image that is recorded at the same time


77

Dividing a moving image file (DIVIDE)

Mode dial: 🕒

76

You can divide moving images recorded in MPEG MOVIE mode. This is convenient when there is not enough space on a "Memory Stick" or when attaching moving images to e-mails.



- Set the mode dial to ▶ and display the moving image you want to divide
- 2 Press MENU. The menu appears
- Select [DIVIDE] with ◀/▶ then press ●, select [OK] with ▲/▼, then press ●. The moving image is played back
- Press at the divide point. The following screen appears



[◀II, II▶] (frame forward,

frame reverse)
You can finely adjust the divide point using $\blacktriangleleft/\triangleright$. [CANCEL]

The moving image playback restarts and you can reselect the divide point.


- When you have decided the divide point, select [OK] with ▲/▼, then press ●
- [OK], [CANCEL] and [EXIT] appear on the screen. Select [OK] with ▲/▼, then press ●. The moving image file is divided

You cannot divide the following types of files:

- · Clip Motion files
- · Still image files
- · Moving image files that are too short to divide

The file number changes as follows when you divide a

<eg.> If you divide the MOV00003.mpg file, the divided file numbers become MOV00004.mpg and MOV00005.mpg, and MOV00003.mpg is skipped. The divided files are saved as the latest



To cancel file division

Press [EXIT]. The image playback screen appears.

Notes

You cannot recombine divided files.
 The original undivided file is not saved.

To delete unwanted portions of a moving image

<eg.> To delete the unwanted scenes A and B from the file MOV00002.mpg:

Step 1: Divide

(1) Divide the unwanted scene A



2 Divide the unwanted scene B.



Step 2:Delete

1) Delete the unwanted scenes A and



2 Only the desired scene remains.



Formatting the "Memory Štick" (FORMAT)

Mode dial: SET UP

When you format a "Memory Stick." all data stored on the "Memory Stick" will be deleted. Check the contents of the "Memory Stick" before formatting.

Even if images are protected, these images will be deleted.



- 1 Insert the "Memory Stick" you want to format.
- 2 Set the mode dial to SET UP. The SET UP screen appears.
- 3 Select [♣] (SETUP 1) with ▲/▼, [FORMAT] with ▶/▲/▼, then press ▶.
- 4 Select [OK] with ▲/▼, then

To cancel formatting

Select [CANCEL] with ▲/▼ in step 4.

■Notes

- Format the "Memory Stick" only using this camera. You cannot format the "Memory Stick" using a computer via the USB cable.
- the USB cable.
 When you format, be sure to use a fully charged battery pack or the AC power adaptor as the power source.

78

Changing the setup settings (SETUP)

The SET UP position changes the settings of infrequently-used items. Set the mode dial to SET UP. The SET UP screen appears. You can set up the following items with the control button. Factory settings are indicated with

CAMERA		
Item	Setting	Description
MOVING	■MPEG MOVIE	Records a MPEG movie file (page 26).
IMAGE	CLIP MOTION	Records a Clip Motion file (page 59).
DATE/TIME	DAY & TIME DATE ■ OFF	Sets whether to superimpose the date and time onto the image (page 64).
DIGITAL ZOOM	■ON OFF	Uses digital zoom (page 23).
RED EYE REDUCTION	ON ■OFF	Reduces the red-eye phenomenon (page 25).
AF ILLUMINATOR	■ON OFF	Uses when it is difficult to focus on the subject under dark conditions (page 25).

음 SETUP 1

Item	Settina	Description
FORMAT	OK	Formats the "Memory Stick." Note that formatting erases all the information recorded on the "Memory Stick", including even erasure protected images.
	CANCEL	Cancels formatting of the "Memory Stick."
FILE NUMBER	■ SERIES	Assigns numbers to files in sequence even if the "Memory Stick" is changed.
	RESET	Resets the file numbering each time the "Memory Stick" is changed.
言語/	■ENGLISH	Displays the menu items in English.
LANGUAGE	日本語/JPN	Displays the menu items in Japanese.
CLOCK SET	OK CANCEL	Sets the date and time (Perform the procedure from step 3 on page 15).

Notes on [DATE/TIME]

- The date and time do not appear on the LCD screen during shooting. These appear only during
- playback.
 The date and time are not superimposed onto moving images and Clip Motion images.

SETUP 2

Item	Setting	Description
LCD BRIGHTNESS	BRIGHT ■NORMAL DARK	Selects the LCD brightness. This has no effect on the recorded images.
LCD BACKLIGHT	BRIGHT ■NORMAL	Displayed only when using your camera with the battery pack: Selects the brightness of the LCD backlight. Selecting [BRIGHT] makes the screen bright and easy to see when using the camera outdoors or in other bright locations, but also uses up the battery charge faster.
BEEP	SHUTTER	Turns on the shutter sound only. (The shutter sound is heard when you press the shutter button.)
	■ON	Turns on the beep/shutter sound (when you press the control button/shutter button).
	OFF	Turns off the beep/shutter sound.
VIDEO OUT	NTSC	Sets the video output signal to NTSC mode (e.g., Japan, USA) (page 85).
	PAL	Sets the video output signal to PAL mode (e.g., Europe) (page 85).
USB CONNECT	PTP ■NORMAL	Switches the USB mode (page 31). Users will be informed at the Sony website when PTP connection is supported.
POWER SAVE	ON ■OFF	Displayed only when using your camera with the battery pack: Set to [ON] to extend the battery life. When [POWER SAVE] is set to [ON], the time from when you press the shutter button until the image is recorded is longer than normal (page 12).
DEMO	■ON/STBY OFF	Displayed only when you use your camera with the AC power adaptor. [DEMO] is set to [STBY] at the factory, and the demonstration starts about 10 minutes after you have set the mode dial to do . To cancel the demonstration, turn off the power.

80 81

Additional information

Precautions

On cleaning

Cleaning the LCD screen

Wipe the screen surface with a cleaning cloth (not supplied) or a LCD cleaning kit (not supplied) to remove fingerprints, dust, etc.

Cleaning the camera surface

Clean the camera surface Clean the camera surface with a soft cloth slightly moistened with water, then wipe the surface dry. Do not use any type of solvent such as thinner, alcohol or benzine as this may damage the finish or the casing.

After using your camera at the seashore or other dusty locations

Clean your camera carefully. Otherwise, the salty air may corrode the metal fittings or dust may enter the inside of your camera. causing a malfunction

Note on operating temperature

Your camera is designed for use between the temperatures of 0°C and 40°C (32°F and 104°F). Recording in extremely cold or hot places that exceed this range is not recommended.

On moisture condensation

If the camera is brought directly from a cold damp room, moisture may condense inside or outside the camera. Should this occur, the camera will not operate properly.

Moisture condensation occurs

- The camera is brought from a cold location such as a ski slope into a warmly heated
- room.

 The camera is taken from an airconditioned room or car interior to the hot outdoors, etc.

How to prevent moisture condensation

condensation. When bringing the camera from a cold place to a warm place, seal the camera in a plastic bag and allow it to adapt to conditions at the new location over a period of time (about an hour).

If moisture condensation occurs

Turn off the camera and wait about an hour for the moisture to evaporate. Note that if you attempt to record with moisture remaining inside the lens, you will be unable to record clear images.

On AC power adaptor

- The unit is not disconnected from the AC power source as long as it is connected to the wall outlet (wall socket), even if the
- unit itself has been turned off.

 Unplug the unit from the wall outlet (wall socket) when you are not using the unit for
- socket) when you are not using the unit for a long time.

 To disconnect the power cord (mains lead), pull it out by the plug. Never pull on the power cord (mains lead) itself.

 Do not operate the unit with a damaged
- power cord (mains lead) or if the unit has been dropped or damaged.

 Do not bend the power cord (mains lead)
- Do not bend the power cord (mains lead) forcibly, or place a heavy object on it. This will damage the cord (mains lead) and may cause fire or electrical shock.
 Prevent metallic objects from coming into contact with the metal parts of the
- connecting section. If this happens, a short may occur and the unit may be damaged.

 Always keep the metal contacts clean.

 Do not disassemble the unit.
- Do not apply mechanical shock or drop the
- unit.
 While the unit is in use, particularly during charging, keep it away from AM receivers and video equipment. AM reception and video operation will be disturbed.
 The unit becomes warm during use. This is not a confidence.
- not a malfunction.
- Do not place the unit in locations that are:
 Extremely hot or cold
 Dusty or dirty
- Very humid
 Vibrating

On battery pack

- Use only the specified charger with the charging function.
 To prevent accident from a short circuit, do

- To prevent accident from a snort circuit, do not allow metal objects to come into contact with the battery terminals.
 Keep the battery pack away from fire.
 Never expose the battery pack to temperatures above 60°C (140°F), such as in a car parked in the sun or under direct sundight. sunlight
- Keep the battery pack dry
- Do not expose the battery pack to any mechanical shock.
 Do not disassemble or modify the battery
- pack.

 Install the battery pack in the camera
- Securely.
 Charging while some capacity remains does not affect the original battery
- capacity.

If any problem occurs, unplug your camera and contact your nearest Sony dealer.

On internal rechargeable button battery

This camera has an internal rechargeable button battery for maintaining the date and time and other settings regardless of whether the power is on or off. This rechargeable the power is on or oil. This rechargeaint button battery is constantly charged as long as you are using the camera. However, if you use the camera for only short periods it discharges gradually, and if you do not use the camera at all for about one month it becomes completely discharged. In this case, be sure to charge this rechargeable button battery before using the camera. button battery before using the camera. However, even if this rechargeable button battery is not charged, you can still use the camera as long as you do not record the date

Charging method

Connect the camera to a wall outlet (wall socket) with the AC power adaptor, or install a charged battery pack, and leave the camera for 24 hours or more with the POWER button set to OFF.

On "Memory Sticks"

"Memory Stick" is a new compact, portable and versatile IC recording medium with a data capacity that exceeds a floppy disk. "Memory Stick" is specially designed for exchanging and sharing digital data among "Memory Stick" compatible products. Because it is removable, "Memory Stick" can also be used for external data storage.

There are two types of "Memory Sticks": general "Memory Sticks" and "MagicGate Memory Sticks" that are equipped with the MagicGate* copyright protection

technology. You can use both types of "Memory Stick" with your camera. However, because your camera does not support the MagicGate standards, data recorded with your camera not subject to MagicGate copyright protection.

* MagicGate is copyright protection technology that uses encryption technology.

"MagicGate" and MAGICGATE are trademarks of Sony Corporation.

information

■Notes

- Data may be damaged if:
 you remove the "Memory Stick" or turn off your camera while reading or
- urin off your camera while reading writing data.

 —you use the "Memory Stick" in a location subject to the effects of static electricity or noise.

 Do not attach any other material than the supplied label on the labeling
- Attach the label so that it does not stick
- Attach the label so that it does not stick out from the proper attachment location
 When you carry or store the "Memory Stick," put it in its supplied case.
 Do not touch the terminals of the "Memory Stick" with your hand or a weed being the supplied case.
- metal object.

 Do not strike, bend or drop the "Memory Stick.
- Do not disassemble or modify the
- "Memory Stick."
 Do not allow the "Memory Stick" to get

On "InfoLITHIUM" battery pack



What is the "InfoLITHIUM" battery

pack?
The "InfoLITHIUM" battery pack is a lithium-ion battery pack that has functions for communicating information related to for communicating information related to operating conditions of your camera. The "InfoLITHIUM" battery pack calculates the power consumption according to the operating conditions of your camera, and displays the remaining battery time in minutes.

- Charging the battery pack

 Be sure to charge the battery pack before you start using your camera.

 We recommend charging the battery pack
- in an ambient temperature of between 10°C to 30°C (50°F to 86°F) until the "Full" indicator appears, indicating that the battery pack is fully charged. If you charge

- the battery pack outside of this temperature range, you may not be able to efficiently charge the battery pack. After charging is completed, disconnect
- the AC power adaptor from the DC IN jack on your camera or remove the battery
- pack. When the camera temperature is high (60°C), "HI" appears in the LCD screen and the battery pack cannot be charged. However, the camera can be left in this state without problem. When the camera temperature drops and the "HI" indicator disappears, charging starts.

Effective use of the battery pack

- Battery performance decreases in low-temperature surroundings. So, the time that the battery pack can be used is shorter in cold places. We recommend the following
- cold places. We recommend the following to ensure longer battery pack use:

 Put the battery pack in a pocket close to your body to warm it up, and insert it in your camera immediately before you start shooting.

 Frequently using the LCD panel or
- frequently operating wears out the zoom the battery pack faster.

 Be certain to turn off the power when not
- taking shots or playing back on your
- taking shots or playing back on your camera.

 We recommend having spare batteries handy for two or three times the expected shooting time, and making trial shots before taking the actual shots.
- Do not expose the battery pack to water. The battery pack is not water-resistant.

Remaining battery time indicator

Remaining battery time indicator if the power goes off although the battery remaining indicator indicates that the battery pack has enough power to operate, charge the battery pack fully again so that the indication on the battery remaining indicator is correct. Note, however, that the correct battery indication sometimes will not be restored if it is used in high not be restored if it is used in high temperatures for a long time or left in a fully charged state, or the battery pack is frequently used. Regard the remaining battery time indication as the approxim shooting time.

How to store the battery pack

How to store the battery pack
If the battery pack is not used for a long
time, do the following procedure once per
year to maintain proper function.

1. Fully charge the battery.

2. Discharge on your camera.

3. Remove the battery from your camera
and store it in a dry cool place.

- and store it in a dry, cool place.


- Battery life
 The battery life is limited. Battery capacity decreases little by little as you use it more and more, and as time passes. When the and more, and as time passes. When the battery operating time is shortened considerably, a probable cause is that the battery pack has reached the end of its life. Please buy a new battery pack.

 The battery life varies according to how it is stored and operating conditions and environment for each battery pack.

Using your camera abroad

Power sources

You can use your camera in any country or area with the supplied battery charger within 100 V to 240 V AC, 50/60 Hz. Use a commercially available AC plug adaptor [a], if necessary, depending on the design of the wall outlet (wall socket) [b].



Watching the playback picture on

If you want to view the playback picture on a TV, you need a TV having a video input jack and a video connecting cable.

The color system of the TV must be the same as that of your digital still camera. Check the following list:

NTSC system

Bahama Islands, Bolivia, Canada, Central America, Chile, Columbia, Ecuador, Jamaica, Japan, Korea, Mexico, Peru, Surinam, Taiwan, the Philippines, the U.S.A., Venezuela, etc.

PAL system

Australia, Austria, Belgium, China, Denmark, Finland, Germany, Great Britain, Holland, Hong Kong, Italy, Kuwait, Malaysia, New Zealand, Norway, Portugal, Singapore, Spain, Sweden, Switzerland, Thailand, etc.

PAL-M system

Brazil

PAL-N system Argentina, Paraguay, Uruguay

SECAM system

Bulgaria, Czech Republic, France, Guiana, Hungary, Iran, Iraq, Monaco, Poland, Russia, Slovak Republic, Ukraine, etc.

Additional information

85

Troubleshooting

84

If you experience trouble with your camera, first check the following items. Should your camera still not operate properly after you have made these checks, press the RESET button. (If you press the RESET button, all settings including the date and time are cleared.) Should your camera still not operate properly, consult your Sony dealer or local authorized Sony service facility. If code displays (C: \(\subseteq \subseteq appear on the LCD screen, the self-diagnosis display function is working (page 93).

Symptom	Cause and/or Solution
The power does not turn on when you press the POWER button.	→ Press and hold down the POWER button for approximately one second.
Your camera does not work.	You are not using an "InfoLITHIUM" battery pack. → Use an "InfoLITHIUM" battery pack (page 10). The battery level is low (the □ indicator appears on the LCD screen). → Charge the battery pack (page 11). * The AC power adaptor is not connected securely. → Connect it firmly to the DC IN jack of your camera and a wall outlet (wall socket) (pages 11, 14). * The built-in microcomputer is not working properly. → Disconnect and then reconnect all power sources after one minute. Then turn the power on and check that the camera works properly. Press the RESET button using a sharp-pointed object.
Your camera cannot record images.	• You cannot record images while charging the flash. • The mode dial is set to ▶ or SET UP. → Set it to ▶, ✓ or ₩ (pages 19, 26). • No "Memory Stick" has been inserted into your camera. → Insert a "Memory Stick" (page 17). • The erasure prevention switch on the "Memory Stick" is set to LOCK. → Set it to the recording position.
The LCD screen does not light when the power is turned on.	The power was turned off with the LCD screen set to OFF the last time the camera was used. →The camera retains the settings from the last time it was used. If you turn the power off with the LCD screen set to OFF, the LCD is still set to OFF the next time you turn the power on.

Symptom Cause and/or Solution Your camera is not in macro recording mode when you shoot a subject that is about 10 to 60 cm (4 to 23 5/8 inches) from the lens. The picture is out of focus. → Set the macro recording (page 61). The focus preset is selected. →Cancel the function (page 61). The resizing function does · You cannot resize moving images, text images, Clip not work. Motion and uncompressed images. · Light is not striking the subject evenly. Images recorded in TEXT mode are blurry →Adjust so that the lighting strikes the subject evenly You cannot record images in TEXT mode. • The mode dial is set to → Set the mode dial to You cannot display a print · You cannot display print marks on moving images, text images and Clip Motion images. Your camera is placed near a TV or other The picture is noisy. equipment that uses strong magnets → Move your camera away from the TV, etc. The picture is too dark. You are shooting a subject with a light source behind the subject. →Adjust the exposure (page 62). The brightness of the LCD screen is too low. →Adjust the brightness of the LCD screen (page 81). You are shooting a spotlighted subject in a dark location such as on a stage. The picture is too bright. →Adjust the exposure (page 62).
 The LCD screen is too bright. →Adjust the brightness of the LCD screen (page 81). • The flash is set to 3 no flash. The flash does not work. → Set the flash to auto (no indicator) or \$ forced flash (page 24).

• The mode dial is set to → Set the flash to \$ forced flash • The mode dial is set to 🕟, SET UP or 🖽 (MPEG MOVIE). → Set it to • [MODE] (REC MODE) is set to [BURST2] in the → Set it to other modes.

Symptom	Cause and/or Solution
The date and time are recorded incorrectly.	The date and time are not set correctly. → Set the correct date and time (page 15).
Vertical streaks appear when you are shooting a very bright subject.	The smear phenomenon is happening. → This is not a malfunction.
The battery life is short.	You are recording/playing back images under extremely cold temperatures. The battery pack is not charged enough. → Charge the battery pack fully. The battery pack is dead. → Replace the battery pack with a new one (page 85).
The battery remaining indicator is incorrect.	• You have used the camera for a long time in an extremely hot or an extremely cold location. • The battery pack is dead. — Replace the battery pack with a new one (page 85). • The battery pack is discharged. — Install a charged battery pack (pages 10, 11).
Sufficient battery remaining indicator is displayed but the power runs out soon.	A deviation has occurred in the remaining battery time. →Fully charge the battery pack (page 11).
The indicators flash during charging.	The battery pack is not installed correctly. Install the battery pack correctly (page 10). The battery pack has malfunctioned. Contact your Sony dealer or local authorized Sony service facility.
You cannot charge the battery, or nothing appears in the display window.	The camera is turned on. → Turn the camera off (page 11). The AC power adaptor is disconnected. → Firmly connect the power cord to the wall outlet (wall socket) (page 11).
The zoom does not work.	The zoom cannot be used when recording a moving image with [MOVING IMAGE] set to [MPEG MOVIE].

Symptom	Cause and/or Solution
Digital zoom does not function.	The digital zoom cannot be used when recording a moving image with [MOVING IMAGE] set to [MPEG MOVIE], or the LCD screen is OFF. [DIGITAL ZOOM] is set to [OFF]. →Set [DIGITAL ZOOM] to [ON] in the menu settings.
Your camera cannot play back images.	The mode dial is set to □, Ⅲ, → or SET UP. Set it to □ (pages 28, 29). Your camera cannot play back image files copied to the hard disk of your computer if the file name has been changed or the image has been modified.
The image and sound are interrupted by noise when you play back an image on a computer.	You are playing back the file directly from the "Memory Stick." → Copy the file to the hard disk of the computer and then play back the file from the hard disk (page 40).
The image cannot be played back on a computer.	→Consult the computer or software manufacturer.
Your camera cannot delete an image.	• The image is protected. →Cancel the protection (page 72).
The power turns off suddenly.	The auto-power off function (page 20) is activated. →Turn on the camera or use the AC power adaptor. The battery is discharged. →Replace it with a charged battery.
The image does not appear on the TV screen.	The video output signal setting of your camera is incorrect. → Change the setting (page 81).
A file error occurs when you play back a file.	Your camera cannot play back files with an image size larger than 2048×1536 that were recorded by another camera.
The picture is monochrome (black and white).	The camera is set to TEXT mode. → Cancel TEXT mode (page 57). P. EFFECT is set to B&W mode. → Cancel B&W mode (page 64).
The lens does not retract even when the power is turned off.	The battery is discharged. →Replace it with a fully charged battery or use the AC power adaptor.

88 89

Symptom	Cause and/or Solution
Your computer does not recognize your camera.	The battery level is low. →Use the AC power adaptor (page 14). The camera is turned off. →Turn on the camera. The USB cable is not connected firmly. →Disconnect the USB cable, and connect it again firmly. Make sure that "USB MODE" is displayed on the LCD screen (pages 37, 38). [USB CONNECT] is set to [PTP] in the setup settings. →Set it to [NORMAL] (page 81). The USB connectors on your computer are connected to other equipment besides the keyboard, the mouse, and your camera. →Disconnect the USB cables except for the ones connected to the keyboard, the mouse, and your camera. The USB driver is not installed. →Install the USB driver (page 32). Since the camera is connected to a computer with the USB cable before installing the USB driver, the drive is not recognized by the computer. →Delete the drive which is not recognized, then install the USB driver. For details, see the procedure on page 35.
No function works though the power is on.	→ Remove the battery pack, then install it again after about one minute. If the functions still do not work, press the RESET button (page 9) using a sharp-pointed object. (If you press the RESET button, all settings including the date and time are cleared.)

Warning and notice messages


Various messages appear on the LCD screen. Check the corresponding descriptions in the following list.

Message	Meaning
NO MEMORY STICK	No "Memory Stick" has been inserted.
SYSTEM ERROR	Turn the power off and on again.
MEMORY STICK ERROR	The inserted "Memory Stick" cannot be used with your camera, or is damaged. The "Memory Stick" is not inserted correctly.
FORMAT ERROR	Failed to format the "Memory Stick."
MEMORY STICK LOCKED	The write-protect tab on the "Memory Stick" is set to the LOCK position.
NO MEMORY SPACE	The capacity of the "Memory Stick" is full, and you cannot record or copy images.
NO FILE	No image has been recorded on the "Memory Stick."
FILE ERROR	An error occurred while playing back th image.
FILE PROTECT	The image is protected against erasure.
for "InfoLITHIUM" battery only	The battery is not the "InfoLITHIUM" type.
NOT ENOUGH MEMORY	The images you want to copy are too bit to copy with your camera.
COPY ERROR	Copying was not performed correctly, of the "Memory Stick" was removed durin copying.
DIRECTORY ERROR	A directory with the same name already exists on the "Memory Stick."
IMAGE SIZE OVER	You are playing back an image of a size that cannot be played back with your camera.
INVALID OPERATION	You are playing back a file that was created on equipment other than your camera.

Message	Meaning
e2	The battery level is low. Depending on the conditions of use or the type of battery pack, the indicator may flash even though there is still 5 to 10 minutes of remaining battery time left.
CANNOT DIVIDE	The file is not long enough to be divided. The file is not a moving image.
₩.	The amount of light is not sufficient or the shutter speed is too slow. (Mount the camera on a tripod or otherwise secure the camera in place.)
TURN THE POWER OFF AND ON AGAIN	The power did not turn on properly.

Self-diagnosis display

Your camera has a self-diagnosis display. This function displays the camera condition on the LCD screen with a combination of a letter and four digits of numbers. If this occurs, check the following code chart. The code informs you of the camera's current condition. The last two digits (indicated by $\square\square$) will differ depending on the state of the camera.



Self-diagnosis display

• C:□□:□□

You can reverse the camera malfunction yourself

malfunction yourself.
• E:□□:□□
Contact your Sony dealer or local authorized Sony service facility.

First three digits	Cause and/or Corrective Action
C:32:□□	There is trouble with your camera's hardware or zooming function. → Turn the power off and on again.
C:13:□□	The camera cannot read or write data on the "Memory Stick." → Re-insert the "Memory Stick" several times. An unformatted "Memory Stick" is inserted. → Format the "Memory Stick" (page 79). The inserted "Memory Stick" cannot be used with your camera, or is damaged. → Insert a new "Memory Stick" (page 17).
E:61:□□ E:91:□□	A camera malfunction that you cannot reverse has occurred. → Contact your Sony dealer or local authorized Sony service facility and inform them of the 5-digit service code (example: E:61:10).

If you are unable to solve the problem even after trying the corrective actions a few times, or if the camera is not reset even if you press the RESET button, contact your Sony dealer or local authorized Sony service facility.

92 93


Display window indicators



- 1 Self-timer indicator
- 2 Macro mode indicator
- 3 Flash mode indicator
- 4 Battery remaining indicator
- 5 "Memory Stick" mark
- 6 Remaining number of recordable images indicator (+999 is displayed for 999 or more images)/Battery usable time indicator (displayed only during charging)/Minutes indicator for the remaining recordable time of moving images

LCD screen indicators

The indicators during recording still images



- 1 Battery remaining indicator
- 2 Flash mode/red eye reduction/ white balance/AF illuminator indicator
- 3 Date/time/ISO number indicator
- 4 Sharpness indicator
- 5 Picture effect indicator
- 6 AF frame
- 7 Spot light-metering cross hair
- 8 AE/AF lock indicator
- 9 Recording mode indicator
- 10 Image size indicator11 Image quality indicator
- 12 TWILIGHT mode indicator


[3] Remaining number of recordable images indicator/ Self-diagnosis function indicator

The actual number of remaining images may differ depending on the recording conditions.

- [14] Remaining memory capacity indicator
- 15 Macro **♥**/focus mode **⑤** indicator/Focus preset value
- 16 EV level indicator
- 17 Aperture value indicator
- 18 Shutter speed indicator
- 19 Self-timer indicator
- 20 Light amount warning indicator
- 21 Menu and guide menu
 Pressing MENU switches the menu on/off.

Additional information

The indicators during recording moving images




- Battery remaining indicator
- 2 White balance indicator
- 3 Picture effect indicator
- 4 Recording mode indicator
- 5 Image size indicator
- 6 Recording time [maximum recordable time] indicator/ Self-diagnosis function indicator
- 7 Remaining memory capacity indicator
- 8 Macro ♥/focus mode € indicator/Focus preset value
- 9 EV level indicator
- 10 Self-timer indicator
- 11 Spot light-metering cross hair
- 12 Menu and guide menu
 Pressing MENU switches the menu on/off.

When playing back still images



- 1 Protect/print mark indicator
- 2 Zoom scaling indicator
- 3 File name
- 4 Recording mode indicator
- 5 Image size indicator
- 6 Image number/number of stored images in "Memory Stick"
- 7 Remaining memory capacity indicator
- 8 Recording date of the playback image/menu and guide menu

When playing back moving images




- 1 VOL. (Volume) indicator
- 2 Recording mode indicator
- 3 Image size indicator
- 4 Image number/number of stored images in "Memory Stick"
- 5 Remaining memory capacity indicator
- 6 Counter
- 7 Playback image
- 8 Play bar
- 9 Menu and guide menu

97

Additional information

SECTION 2 DISASSEMBLY


• This set can be disassembled in the order shown below.




Note: Follow the disassembly procedure in the numerical order given.

2-1. BT LID


When removing the BT lid, destroy and do it. When two claws of the BT main frame assembly have bent, it becomes not possible to use.






2-2. CABINET (FRONT) ASSEMBLY

2-3. CABINET (REAR) ASSEMBLY




2-4. LCD MODULE


2-5. LENS BLOCK ASSEMBLY




[SERVICE POSITION (SY-69 BOARD: side A)]




2-6. MODE DIAL BLOCK ASSEMBLY




2-8. SY-69 BOARD



2-7. CABINET (BOTTOM) ASSEMBLY




2-9. MEMORY STICK CONNECTOR




2-10. ST-67 BOARD


2-11. DD-163 BOARD




[SERVICE POSITION (SY-69 BOARD: side B)]




2-12. CIRCUIT BOARDS LOCATION



SECTION 3 BLOCK DIAGRAMS




3-8. POWER BLOCK DIAGRAM 1



3-15

3-9. POWER BLOCK DIAGRAM 2



DSC-P5

SECTION 4 PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS


THIS NOTE IS COMMON FOR WIRING BOARDS AND SCHEMATIC DIAGRAMS (In addition to this, the necessary note is printed in each block)

(For printed wiring boards)

Pattern from the side which enables seeing.
(The other layers' patterns are not indicated)


- Through hole is omitted.
- · Circled numbers refer to waveforms.
- There are a few cases that the part printed on diagram isn't mounted in this model.

Chip parts.



(For schematic diagrams)

- All capacitors are in μF unless otherwise noted. pF : μ μF . 50 V or less are not indicated except for electrolytics and tantalums.
- Chip resistors are 1/10 W unless otherwise noted. $k\Omega$ =1000 Ω , $M\Omega$ =1000 $k\Omega$.
- Caution when replacing chip parts.
 New parts must be attached after removal of chip.
 Be careful not to heat the minus side of tantalum capacitor, Because it is damaged by the heat.
- · Some chip part will be indicated as follows.



- Constants of resistors, capacitors, ICs and etc with XX indicate that they are not used.
- In such cases, the unused circuits may be indicated.
- Parts with ★ differ according to the model/destination.
 Refer to the mount table for each function.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Signal name


 $XEDIT \rightarrow \overline{EDIT}$ PB/XREC \rightarrow PB/REC

- -: non flammable resistor
- + : fusible resistor
- ____: panel designation
- ===: B+ Line *
- ===: B- Line *
- IN/OUT direction of (+,−) B LINE. *
- : adjustment for repair. *
- $\bullet\,$ Circled numbers refer to waveforms. *
- * Indicated by the color red.

Note: The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.

(Measuring conditions voltage and waveform)

- Voltages and waveforms are measured between the measurement points and ground when camera shoots color bar chart of pattern box. They are reference values and reference waveforms.
- (VOM of DC 10 M Ω input impedance is used)
- Voltage values change depending upon input impedance of VOM used.)
- 1. Connection



Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.





Fig. a (Video output terminal output waveform)





When indicating parts by reference number, please include the board name.

4-1

4-1. FRAME SCHEMATIC DIAGRAMS

FRAME SCHEMATIC DIAGRAM (1/2)






FRAME (2/2)

4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

CD-340 (CCD IMAGER) PRINTED WIRING BOARD

- Ref. No.: CD-340 board; 2,000 series is printed on this diagram. Chip parts CD-340 BOARD(SIDE A) Transistor Q501 IC501 1-682-670-B 2 5 3 6 05


CD-340 BOARD(SIDE B)



4-7

• For Printed Wiring Board.


• There are a few cases that the part isn't mounted in this model



CONTROL SWITCH BLOCK, FP-380 (FLEXIBLE BOARD) SCHEMATIC DIAGRAM 3 CONTROL SWITCH BLOCK Α CONTROL SWITCH BLOCK is replaced as a block, so that PRINTED WIRING BOARD is omitted. S005 MODE DIAL В S004 POWER ON/OFF(CHG) (5 POSITION MODE_DIAL) C **(** D XPWR_LED_VCC MODE_DIAL D_3ZV NOCE_DIAL NCC NOCE_DIAL NCC NCC NCC XMDVIE XSET_UP XSET_U Ε SY-69 BOARD (7/11) CN905 (SEE PAGE 4-27) 3 5 4 6 7 FP-380 FLEXIBLE BOARD FP-380 FLEXIBLE BOARD is replaced as a block, so that this PRINTED WIRING BOARD is omitted. 1 VSS LND009 2 VCC LND010 LND001 1 VSS 3 SCLK LND011 В LND002 2 VCC LND003 3 SCLK 4 N.C. LND012 SY-69 BOARD (5/11) CN501 (SEE PAGE 4-23) LND004 4 INT 5 INT LND013 MS W Digital SOCKET 6 N.C. LND014 LND005 5 DIO LND006 6 VCC 7 DIO LND015 LND007 7 BS 8 VCC LND016 С LND008 8 VSS 9 BS LND017 10 VSS LND018 SIGNAL PATH VIDEO SIGNAL AUDIO SIGNAL Y/CHROMA REC **>>>** \Rightarrow $\qquad \qquad \Longrightarrow \qquad$ РΒ \Rightarrow

ST-67 (FLASH DIVE) PRINTED WIRING BOARD

- Ref. No.: ST-67 board; 3,000 series -



ST-67 (FLASH DIVE) SCHEMATIC DIAGRAM • See page 4-39 for ST-67 printed wiring board. 3 5 6 8 9 10 11 D002 HAU140C029TP ST-67 BOARD Α XE_A N FLASH DRIVE(ST BLOCK) D001 MA2S111-(K8).SQ R018 -REF.NO.:3,000 SERIES- Λ LND002 XX MARK:NO MOUNT TRIGGER FLASH Q005 2SB1073-R-TX TRANS DRIVE NO MARK:REC/PB MODE UNIT C008 120u 310V В CHARGING CAPACITOR XE K R005 47 C010 0.047u 250V T001 \triangle ₹ R009 2700 R017 1M C D COM4
COM3
COM1
SEG9
SEG8
SEG8 COM4 14 LND114 COM4 LCD902 сомз 13 LND113 COM3 COM2 BT101 COM2 12 LND112 LITHIUM BATTERY COM1 COM1 11 LND111 Ε SEG9 LCD 10) LND110 SEG9 (BACK UP) SEG8 MODULE SEG8 9 LND109 SEG7 SEG7 8 LND108 SEG6 7 LND107 SEG6 SEG5 CHARACTER SEG5 6 LND106 DISPLAY SEG4 SEG4 5 LND105 SEG3 SEG3 4 LND104 3 LND103 SEG2 SEG1 2) LND102 1 LND101 SELF TIMER/ AF ILLUMINATOR (RED) G Q012 TPS613-BC BRIGHT LEVEL SENSOR Н The components identified by mark rianlge or dotted Les composants identifiés par une marque \triangle sont

FLASH DRIVE

critiques pour la sécurité. Ne les remplacer que

par une piéce portant le numéro spécifié.

line with mark \triangle are critical for safety.

Replace only with part number specified.

DSC-P5

4-4. PARTS LOCATION

	: SIDE A : SIDE B			
CD-340	BOARD		ST-67 B0	DARD
C502 C503	A-3 B-3	*	BT101	C-10
C504	A-3		C003	B-6
C505	A-2		C005	C-7
C506	B-2		C010	B-7
C508	A-1		0010	٥,
C509	A-1		CN102	C-12
Q501	A-3		D001	C-7
Q502	B-3		D002	B-7
R501	A-3		Q005	C-7
R502	A-3		Q011	B-6
R503	A-3	*	Q012	A-5
R504	A-3			
R505	B-3		R005	B-6
R506	B-3		R006	C-7
			R009	C-7
TH501	A-1		R010	B-7
			R016	B-6
			R017	B-5
			R018	B-7
			R102	C-7
			T001	B-6

SECTION 5 ADJUSTMENTS


Before starting adjustment

EVR Data Re-writing Procedure When Replacing Board

The data that is stored in the repair board, is not necessarily correct. Perform either procedure 1 or procedure 2 or procedure 3 when replacing board.

Procedure 1


Save the EVR data of the machine in which a board is going to be replaced. Download the saved data after a board is replaced.



Procedure 2


Remove the EEPROM from the board of the machine that is going to be repaired. Install the removed EEPROM to the replaced board.

Remove the EEPROM and install it.



Procedure 3

When the data cannot be saved due to defective EEPROM, or when the EEPROM cannot be removed or installed, save the data from the same model of the same destination, and download it.



(The same model of the same destination)

After the EVR data is saved and downloaded, check the respective items of the EVR data. (Refer to page 5-2 for the items to be checked.)

1-1. Adjusting items when replacing main parts and boards

When replacing main parts and boards, adjust the items indicated by ● in the following table.

						F	Repl	aced	l par	ts				
				ock				ount						
			replacement			replacement								
Adjustment section	Adjustment			(LCD panel)	(Back light unit)	(S/H, AGC, A/D)	(EVR)	(VIDEO AMP)	(LCD drive)	(LCD Timing generator)	(EVR)	ETE)	(COMPLETE) (Note)	EEPROM
		y (Note)		LCD901	D901	IC102	IC506	IC601	IC801	IC804	IC802	(COMPLETE)	(COMPL	IC503
		Lens block assy (Note)	Flash unit	LCD block	LCD block	SY-69 board	SY-69 board	SY-69 board	SY-69 board	SY-69 board	SY-69 board	ST-67 board	SY-69 board	SY-69 board
Initialization of B, D,	Initialization of D page data												•	•
E, F, 7, 9, page data	Initialization of B, E, F, 7, 9 page data												•	•
Video	Video sync level adj.						•	•					•	
	Video burst level adj.						•	•					•	•
Camera	Flange back adj.	•											•	•
	F No. standard data input	•												•
	Mechanical shutter adj.	•											•	•
	Light value adj.	•				•								•
	Auto white balance standard data input	•				•								•
	Auto white balance adj.	•				•							•	•
	Color reproduction adj.	•				•							•	
	CCD (white and black) defect compensation	•											•	•
	Strobe white balance adj.	•	•			•								
LCD	LCD initial data input													•
	VCO adj.									•	•		•	•
	Black limit adj.								•		•		•	•
	Bright adj.								•		•		•	•
	Contrast adj.								•		•		•	•
	Color adj.								•		•		•	•
	PSIG adj.								•		•		•	•
	VG center adj.								•		•		•	•
	V-COM adj.			•					•		•		•	•
	White balance adj.			•	•				•		•		•	•
System control	Battery down adj.												•	•

Table 5-1-1

Note : When replacing the lens block or the SY-69 board, refer to "Precaution on Replacing the Lens Block or the SY-69 board". (See page 6)

5-1. CAMERA SECTION ADJUSTMENT

1-1. PREPARATIONS BEFORE ADJUSTMENT

1-1-1. List of Service Tools

Oscilloscope
 Regulated power supply
 Digital voltmeter

Ref. No.	Name	Parts Code	Usage
J-1	Filter for color temperature correction (C14)		Auto white balance adjustment/check White balance adjustment/check
J-2	Pattern box PTB-450	J-6082-200-A	
J-3	Color bar chart for pattern box	J-6020-250-A	
J-4	Adjusting remote commander (RM-95 upgraded). (Note 1)	J-6082-053-B	
J-5	Siemens star chart	J-6080-875-A	For checking the flange back
J-6	Clear chart for pattern box	J-6080-621-A	
J-7	CPC-9 jig (Note 2)	J-6082-393-C	For connecting the adjusting remote commander For adjusting the LCD block
J-8	Minipattern box	J-6082-353-B	For adjusting the flange back
J-9	Back ground paper	J-2501-130-A	For adjusting the strobe

Note 1: If the micro processor IC in the adjusting remote commander is not the new micro processor (UPD7503G-C56-12), The pages cannot be switched. In this case, replace with the new micro processor (8-759-148-35).

Note 2: The old CPC-9 jig (Parts code: J-6082-393-B) cannot be used, because it cannot operate the adjusting remote commander.




Fig. 5-1-1

1-1-2. Preparations

Note 1: For details of how remove the cabinet and boards, refer to "2. DISASSEMBLY".

Note 2: When performing only the adjustments, the lens block and boards need not be disassemble.

- 1) Connect the equipment for adjustments according to Fig. 5-1-
- 2) Connect the Adjusting remote commander to SY-69 board CN902 via CPC-9 jig (J-6082-393-C). (See Fig. 5-1-3)

Note 3: Setting the "Forced CAMERA mode power ON" Mode

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: D, address: 10, set data: 01, and press the PAUSE button of the adjusting remote commander.

The above procedure will enable the camera power to be turned on. After completing adjustments, be sure to exit the "Forced CAMERA mode power ON Mode".

Note 4: Exiting the "Forced CAMERA mode power ON Mode"

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: D, address: 10, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 3) Select page: 0, address: 01, and set data: 00.

1-1-3. Discharging of the Flashlight Power Supply

The capacitor which is used as power supply of flashlight is charged with 200 V to 300 V voltage. Discharge this voltage before starting adjustments in order to protect service engineers from electric shock during adjustment.

Discharge procedure

- Press the FLASH button (DD-163 board S951 (CONTROL UP)) and set the NO FLASH mode.
- 2. Fabricate the discharging jig as shown in Fig. 5-1-5 locally by yourself. Connect the discharging jig to the positive (+) and negative (-) terminal of the flash voltage charge capacitor. Allow ten seconds to discharge the voltage.




Fig. 5-1-4





Fig. 5-1-2



Note 1: Don't use the 12 pin flexible board of CPC-9 jig. It causes damage to the unit.

Note 2: The old CPC-9 jig (Parts code: J-6082-393-B) cannot be used, because it cannot operate the adjusting remote commander.

Fig. 5-1-3




Fig. 5-1-5




Fig. 5-1-6

1-1-4. Precautions

1. Setting the Switch

Unless otherwise specified, set the switches as follows and perform adjustments.

101	in adjustinents.
1.	Mode Dial CAMERA
2.	ZOOM switch
	(DD-163 board S952, 953) WIDE end
3.	EV (Menu display) 0EV
4.	DSPL/LCD ON/OFF button
	(DD-163 board S954) OSD OFF
5.	WB (WHITE BALANCE)
	(Menu display) AUTO
6.	P.EFFECT (Menu display) OFF
7.	DEMO (SET UP setting) OFF
8.	VIDEO OUT (SET UP setting) NTSC

2. Order of Adjustments

Basically carry out adjustments in the order given.




Fig. 5-1-7

3. Subjects

- 1) Color bar chart (Standard picture frame).
 - When performing adjustments using the color bar chart, adjust the picture frame as shown in Fig. 5-1-7. (Standard picture frame)
- 2) Clear chart (Standard picture frame)
 Remove the color bar chart from the pattern box and insert a
 - Remove the color bar chart from the pattern box and insert a clear chart in its place. (Do not perform zoom operations during this time)
- Chart for flange back adjustment
 Join together a piece of white A0 size paper (1189mm × 841 mm) and a piece of black paper to make the chart shown in Fig. 5-1-8.

Note: Use a non-reflecting and non-glazing vellum paper. The size must be A0 or larger and the joint between the white and black paper must not have any undulations.




Fig. 5-1-8

4. Preparing the Flash Adjustment Box

A dark room is required to provide an accurate flash adjustment. If it is not available, prepare the flash adjustment box as given below;

1) Provide woody board A, B and C of 15 mm thickness.




Fig. 5-1-9

- 2) Apply black mat paint to one side of woody board A and B.
- 3) Attach background paper (J-2501-130-A) to woody board C.
- 4) Assemble so that the black sides and the background paper side of woody board A, B and C are internal. (Fig 5-1-10)




Fig. 5-1-10

1-2. INITIALIZATION OF B, D, E, F, 7, 9 PAGE DATA

1-2-1. Initialization of D Page Data

1. Initializing D Page Data

Note: If the D page data has been initialized, the following adjustments need to be performed again.

- 1) Modification of D page data
- 2) Video system adjustments
- 3) LCD system adjustments
- 4) System control system adjustments

Adjusting page	D
Adjusting Address	10 to EF

Initializing Method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	03	10	
3	4	00	2D	
4	4	01	2D	Press PAUSE button.
5	4	02		Check the data changes to "01".
6				Perform "Modification of D page Data".

2. Modification of D Page Data

If the D page data has been initialized, change the data of the "Fixed data-2" address shown in the following table by manual input.

Modifying Method:

- Before changing the data, select page: 0, address: 01, and set data: 01.
- New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.

Note: If copy the data built in the different model, the camera may not operate.

- 3) When changing the data, press the PAUSE button of the adjusting remote commander each time when setting new data to write the data in the non-volatile memory.
- 4) Check that the data of adjustment addresses is the initial value. If not, change the data to the initial value.

Processing after Completing Modification of D Page Data:

Order	Page	Address	Data	Procedure
1	2	00	29	
2	2	01	29	Press PAUSE button.

3. D Page table

Note 1: Fixed data-1: Initialized data.

(Refer to "1. Initializing the D Page Data")

Note 2: Fixed data-2: Modified data.

(Refer to "2. Modification of D Page Data")

Address	Initial value	Remark		
10	00	Test mode		
11 to 4E		Fixed data-1 (Initialized data)		
4F		Fixed data-2		
50 to 8F		Fixed data-1 (Initialized data)		
90	80			
91	88			
92	AD	Battery down adj.		
93	C2			
94	CD			
95 to C5		Fixed data-1 (Initialized data)		
C6	5A	Video sync level adj.		
C7	61	Video burst level adj.		
C8 to CD		Fixed data-1 (Initialized data)		
CE		F: 11: 2		
CF		Fixed data-2		
D0	76 / 7D	Bright adj. (Note 3)		
D1	C3 / 7E	Color adj. (Note 3)		
D2	60 / BB	White balance adj. (Note 3)		
D3	AA / 83	writte barance aug. (1vote 3)		
D4	B9 / D5	Contrast adj. (Note 3)		
D5	5C / 90	Black limit adj. (Note 3)		
D6	AC / 8D	VG center adj.(Note 3)		
D7	5C / 5C	VCO adj. (NTSC) (Note 3)		
D8	77 / 5A	V-COM adj. (Note 3)		
D9		Fixed data-2		
DA	61 / 7A	PSIG adj. (Note 3)		
DB		F: 11. 2		
DC		Fixed data-2		
DD	6A / 6B	VCO adj. (PAL) (Note 3)		
DE		F: 11. 2		
DF		Fixed data-2		
E0 to EF		Fixed data-1 (Initialized data)		

Note 3: AN12511A type / CXA8116R type

1-2-2. Initialization of B, E, F, 7, 9 Page Data1. Initializing B, E, F, 7, 9 Page Data

Note: If the B, E, F, 7, 9 Page data has been initialized,

"Modification of B, E, F, 7, 9 Page Data" and following adjustments need to be performed again.

- 1) Modification of B, E, F, 7, 9 page data
- 2) Camera system adjustments

Adjusting page	В
Adjusting Address	00 to FF
Adjusting page	Е
Adjusting Address	00 to FF
Adjusting page	F
Adjusting Address	10 to FF
Adjusting page	7
Adjusting Address	00 to FF
Adjusting page	9
Adjusting Address	00 to FF

Initializing Method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	В	00	00	Press PAUSE button.
3	6	03	10	
4	6	00	2D	
5	6	01	2D	Press PAUSE button.
6	6	02		Check the data changes to "01".
7				Perform "Modification of B, E, F, 7, 9 page Data".

2. Modification of B, E, F, 7, 9 Page Data

If the B, E, F, 7, 9 Page data has been initialized, change the data of the "Fixed data-2" address shown in the following tables by manual input.

Modifying Method:

- 1) Before changing the data, select page: 0, address: 01, and set data: 01.
- New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.

Note: If copy the data built in the different model, the camera may not operate.

- 3) When changing the data, press the PAUSE button of the adjusting remote commander each time when setting new data to write the data in the non-volatile memory.
- Check that the data of adjustment addresses is the initial value.
 If not, change the data to the initial value.

Processing after Completing Modification of B, E, F, 7, 9 Page data

Order	Page	Address	Data	Procedure
1	2	00	29	
2	2	01	29	Press PAUSE button.

3. B Page Table

Note 1: Fixed data-1: Initialized data.

(Refer to "1. Initializing B, E, F, 7, 9 Page Data")

Note 2: Fixed data-2: Modified data.

(Refer to "2. Modification of B, E, F, 7, 9 Page Data")

Address	Initial value	Remark
00 to FF		Fixed data-1 (Initialized data)

4. E Page Table

Note 1: Fixed data-1: Initialized data.

(Refer to "1. Initializing B, E, F, 7, 9 Page Data")

Note 2: Fixed data-2: Modified data.

(Refer to "2. Modification of B, E, F, 7, 9 Page Data")

Address	Initial value	Remark
00 to FF		Fixed data-1 (Initialized data)

5. F Page TableNote 1: Fixed data-1: Initialized data. (Refer to "1. Initializing the B, E, F, 7, 9 Page Data")Note 2: Fixed data-2: Modified data. (Refer to "2. Modified of B, E, F, 7, 9 Page Data")

Address	Initial value	Remark	
10	D0		
11	5C		
12	B2		
13	8C		
14	36		
15	54		
16	87		
17	71		
18	10		
19	C0		
1A	00	Flange back adj.	
1B	00	Trange back auj.	
1C	00		
1D	00		
1E	00		
1F	00		
20	20		
21	20		
22	13		
23	46		
24	0A		
25	00		
26	85		
27	В0	Light value adj.	
28	94		
29	00		
2A	00		
2B	00	F No. standard data input	
2C	00		
2D	00		
2E to 39		Fixed data-1 (Initialized data)	
3A	2F		
3B	37	Auto white balance standard data	
3C	40	input	
3D	D0	F: 11, 17, 22, 12, 12, 13	
3E	D.7	Fixed data-1 (Initialized data)	
3F	B5	Auto white balance adj.	
40	43		
41	03		
42	E9		
43	63		
44	83 D5	Color reproduction adj.	
45	D5		
46	FE 72		
47	73		
48 49 to 4C	45	Fixed data 1 (Initialized data)	
49 to 4C		Fixed data-1 (Initialized data)	

Address	<u> </u>	Domark	
Address	Initial value	Remark	
4D 4E	28 6E	Strobe white balance adj.	
4E 4F to 58	UE	Fixed data-1 (Initialized data)	
59	00	Auto white balance standard data input	
5A	14	Mechanical shutter adj.	
5B	14	Fixed data-1 (Initialized data)	
5C	63	1 1xed data-1 (IIIIIaiized data)	
5D	83		
5E	03	Color reproduction adj.	
5F	E9		
60 to 63	2,	Fixed data-1 (Initialized data)	
64	10	Strobe white balance adj.	
65 to 68		Fixed data-1 (Initialized data)	
69	02		
6A	79	Strobe white balance adj.	
6B	F8		
6C	04		
6D	A0		
6E	03		
6F	D0		
70	00		
71	00		
72	00		
73	00		
74	00		
75	00	Mechanical shutter adj.	
76	00	Weenamear snatter adj.	
77	00		
78	00		
79	00		
7A	00		
7B	33		
7C	33		
7D	33		
7E	33		
7F	33		
80	00	Auto white balance adj.	
81 to 86		Fixed data-1 (Initialized data)	
87	FF		
88	00		
89	00		
8A	00		
8B	00	Flange back adj.	
8C	00		
8D	00		
8E	00		
8F	00		

Address	Initial value	Remark
90	00	
91	00	
92	00	
93	00	
94	00	
95	00	Flange back adj.
96	00	
97	00	
98	00	
99	00	
9A	00	
9B	00	
9C to A8		Fixed data-1 (Initialized data)
A9	10	Auto white balance adj.
AA	04	Truto winte barance adj.
AB to D3		Fixed data-1 (Initialized data)
D4	80	
D5	98	
D6	A0	Mechanical shutter adj.
D7	98	
D8	90	
D9 to FF		Fixed data-1 (Initialized data)

6. 7 Page Table Note 1: Fixed data-1: Initialized data. (Refer to "1. Initializing the B, E, F, 7, 9 Page Data") **Note 2:** Fixed data-2: Modified data. (Refer to "2. Modified of B, E, F, 7, 9 Page Data")

Address	Initial value	Remark
00 to 5F		Fixed data-1 (Initialized data)
60	0F	
61	FF	
62	0F	
63	FF	
64	0F	
65	FF	
66	0F	
67	FF	
68	0F	
69	FF	
6A	0F	
6B	FF	
6C	0F	
6D	FF	
6E	0F	
6F	FF	
70	0F	
71	FF	
72	0F	CCD black defect compensation
73	FF	See Black defect compensation
74	0F	
75	FF	
76	0F	
77	FF	
78	0F	
79	FF	
7A	0F	
7B	FF	
7C	0F	
7D	FF	
7E	0F	
7F	FF	
80	0F	
81	FF	
82	0F	
83	FF	
84	0F	
85	FF	
86	0F	
87	FF	
88	0F	
89	FF	
8A	0F	
8B	FF	CCD white defect compensation
8C	0F	
8D	FF	
8E	0F	

Address	Initial value	Remark
8F	FF	
90	0F	
91	FF	
92	0F	
93	FF	
94	0F	
95	FF	
96	0F	
97	FF	
98	0F	
99	FF	
9A	0F	
9B	FF	
9C	0F	
9D	FF	
9E	0F	
9F	FF	
A0	0F	
A1	FF	
A2	0F	
A3	FF	
A4	0F	
A5	FF	
A6	0F	CCD white defect compensation
A7	FF	, cop white derive compensation
A8	0F	
A9	FF	
AA	0F	
AB	FF	
AC	0F	
AD	FF	
AE	0F	
AF	FF	
В0	0F	
B1	FF	
B2	0F	
В3	FF	
B4	0F	
В5	FF	
В6	0F	
В7	FF	
B8	0F	
В9	FF	
BA	0F	
BB	FF	
BC	0F	
BD	FF	
BE	0F	

Address	Initial value	Remark
BF	FF	
C0	0F	
C1	FF	
C2	0F	
C3	FF	
C4	0F	
C5	FF	
C6	0F	
C7	FF	
C8	0F	
C9	FF	
CA	0F	
СВ	FF	
CC	0F	
CD	FF	
CE	0F	
CF	FF	
D0	0F	
D1	FF	
D2	0F	
D3	FF	
D3	0F	
D5	FF	
D6	0F	
D0	FF	
D7	0F	
D8	FF	CCD white defect compensation
DA	0F	
	FF	
DB	0F	
DC		
DD	FF	
DE	0F	
DF	FF	
E0	0F	
E1	FF	
E2	0F	
E3	FF	
E4	0F	
E5	FF	
E6	0F	
E7	FF	
E8	0F	
E9	FF	
EA	0F	
EB	FF	
EC	0F	
ED	FF	
EE	0F	
EF	FF	
F0	0F	

Address	Initial value	Remark
F1	FF	
F2	0F	
F3	FF	
F4	0F	
F5	FF	
F6	0F	
F7	FF	
F8	0F	CCD white defect compensation
F9	FF	
FA	0F	
FB	FF	
FC	0F	
FD	FF	
FE	0F	
FF	FF	

7. 9 Page Table
Note 1: Fixed data-1: Initialized data. (Refer to "1. Initializing the B, E, F, 7, 9 Page Data")

Note 2: Fixed data-2: Modified data. (Refer to "2. Modified of B, E, F, 7, 9 Page Data")

Address Initial value Remark 00 to 07 Fixed data-1 (Initialized data) 08 Fixed data-2 09 to 67 Fixed data-1 (Initialized data) 68 Fixed data-2 69 to 6F Fixed data-1 (Initialized data) 70 00 71 00 72 00 73 00 74 00 75 00 76 00 77 00 78 00 7B 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-1 (Initialized data)	B, E, F, 7, 9 Page Data)					
08 Fixed data-2 09 to 67 Fixed data-1 (Initialized data) 68 Fixed data-2 69 to 6F Fixed data-1 (Initialized data) 70 00 71 00 72 00 73 00 74 00 75 00 76 00 77 00 78 00 7A 00 7B 00 7C 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	Address	Initial value	Remark			
09 to 67 Fixed data-1 (Initialized data) 68 Fixed data-2 69 to 6F Fixed data-1 (Initialized data) 70 00 71 00 72 00 73 00 74 00 75 00 76 00 77 00 78 00 7A 00 7B 00 7C 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	00 to 07		Fixed data-1 (Initialized data)			
68 Fixed data-2 69 to 6F Fixed data-1 (Initialized data) 70 00 71 00 72 00 73 00 74 00 75 00 76 00 77 00 78 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	08		Fixed data-2			
69 to 6F Fixed data-1 (Initialized data) 70 00 71 00 72 00 73 00 74 00 75 00 76 00 78 00 78 00 7A 00 7B 00 7C 00 7B 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	09 to 67		Fixed data-1 (Initialized data)			
70 00 71 00 72 00 73 00 74 00 75 00 76 00 77 00 78 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	68		Fixed data-2			
71 00 72 00 73 00 74 00 75 00 76 00 77 00 78 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	69 to 6F		Fixed data-1 (Initialized data)			
72 00 73 00 74 00 75 00 76 00 77 00 78 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	70	00				
73 00 74 00 75 00 76 00 77 00 78 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	71	00				
74 00 75 00 76 00 77 00 78 00 79 00 7A 00 7B 00 7D 00 7E 00 80 00 81 00 82 00 83 00 84 Fixed data-2	72	00				
75 00 76 00 77 00 78 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	73	00				
76 00 77 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 80 00 81 00 82 00 83 00 84 Fixed data-2	74	00				
77 00 78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	75	00				
78 00 79 00 7A 00 7B 00 7C 00 7D 00 7E 00 80 00 81 00 82 00 83 00 84 Fixed data-2	76	00				
79 00 7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	77	00				
7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	78	00	- Flange back adj.			
7A 00 7B 00 7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	79	00				
7C 00 7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	7A	00				
7D 00 7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	7B	00				
7E 00 7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	7C	00				
7F 00 80 00 81 00 82 00 83 00 84 Fixed data-2	7D	00				
80 00 81 00 82 00 83 00 84 Fixed data-2	7E	00				
81 00 82 00 83 00 84 Fixed data-2	7F	00				
82 00 83 00 84 Fixed data-2	80	00				
83 00 84 Fixed data-2	81	00				
84 Fixed data-2	82	00				
	83	00				
85 to FF Fixed data-1 (Initialized data)	84		Fixed data-2			
The duty (minutes duty)	85 to FF		Fixed data-1 (Initialized data)			

1-3. VIDEO SYSTEM ADJUSTMENTS

1. Video Sync Level Adjustment

Adjust the sync level of the composite video signal output.

Mode	PLAY	
Signal	Arbitrary	
Measurement Point	Video terminal of A/V OUT jack (75 Ω terminated)	
Measuring Instrument	Oscilloscope	
Adjustment Page	D	
Adjustment Address	C6	
Specified Value	A = 286 ± 5 mVp-p (NTSC) A = 300 ± 5 mVp-p (PAL)	

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	04	
3	D	C6		Change the data and set the sync level (A) to the specified value.
4	D	C6		Press PAUSE button

Processing after Completing Adjustments:

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	

2. Video Burst Level Adjustment

Adjust the burst level of the composite video signal output.

Mode	PLAY
Signal	Arbitrary
Measurement Point	Video terminal of A/V OUT jack (75 Ω terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	C7
Specified Value	A = 286 ± 8 mVp-p (NTSC) A = 300 ± 8 mVp-p (PAL)

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	04	
3	D	C7		Change the data and set the burst level (A) to the specified value.
4	D	C7		Press PAUSE button

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	




Fig. 5-1-11




Fig. 5-1-12

1-4. CAMERA SYSTEM ADJUSTMENTS

Before perform the camera system adjustments, check that the specified values of "VIDEO SYSTEM ADJUSTMENTS" are satisfied.

Note: For "CAMERA SYSTEM ADJUSTMENTS", perform in order of item numbers.

Data setting during camera system adjustments

Perform the following data setting before the camera system adjustments.

Set up setting:

 VIDEO OUT of SET UP setting NTSC (NTSC mode) (This adjustment must be performed in NTSC mode, so don't set the SET UP setting to "PAL")

Data setting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	D	10	80	Press PAUSE button.
3	2	10		Check the bit values of bit3, bit4 and bit5 are "1". (Note 1, 2)
4	D	11	40	Press PAUSE button.
5	D	10	81	Press PAUSE button.
5	6	C1		Check the data changes to "02".
6	4	06	01	
7	6	6C	01	
8				Wait for 1 second.
9	F	38	B1	Press PAUSE button.
10	F	DE	1E	Press PAUSE button.
11	F	E3	13	Press PAUSE button.
12	В	75	00	Press PAUSE button.
13	В	DE	D6	Press PAUSE button.
14	9	08	FF	Press PAUSE button.
15	9	84	00	Press PAUSE button.
16	9	F1	A5	Press PAUSE button.

Note 1: For the bit values, refer to "5-2. SERVICE MODE", "2-3. 2. Bit value discrimination".

Note 2: In case of wrong data, select page: 2, address: 0A and set data: 02.

Set the adjusting remote commander to normal LANC, and the power will be turned off and on automatically. Wait for more than 0.167 second after the power on, and set the adjusting remote commander to the service LANC. Then, retry from the step 1.

Note 3: Repeat the "Data setting method", if the power was turned off and on during the "CAMERA SYSTEM ADJUST-MENTS".

After completing the camera system adjustments, release the data setting:

Order	Page	Address	Data	Procedure
1	4	06	00	
2	6	6C	00	
3	F	38	В3	Press PAUSE button.
4	F	DE	0F	Press PAUSE button.
5	F	E3	13	Press PAUSE button.
6	В	75	10	Press PAUSE button.
7	9	F1	5A	Press PAUSE button.
8	D	11	00	Press PAUSE button.
9	D	10	00	Press PAUSE button.
10	0	01	00	

1. Flange Back Adjustment (Using the minipattern box)

The flange back of inner focus lens is adjusted automatically. If shifted, the auto focus is disordered.

Mode	CAMERA		
Subject	Siemens star chart with ND filter for minipattern box (Note 1)		
Measurement Point	Charles and TV manifes		
Measuring Instrument	Check operation on TV monitor		
Adjustment Page	F 9		
Adjustment Address	10 to 25, 87 to 9B 70 to 83		

Note 1: Dark Siemens star chart.

Note 2: Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.

Caution:

If the video lens or SY-69 board was replaced, make a setting by referring to "Precaution on Replacing the Video Lens or the SY-69 Board" on page 5-17 and then perform the adjustment.

Preparations before adjustments:

- 1) The minipattern box is installed as shown in the following figure.
 - Note 3: The attachment lenses are not used.
 - **Note 4:** Take care not to hit the mini-pattern box when extending the lens.
- 2) Install the minipattern box so that the distance between it and the front of lens of camera is less than 3 cm.
- 3) Make the height of minipattern box and the camera equal.
- 4) Check the output voltage of the regulated power supply is the specified voltage ± 0.01 Vdc.
- Check that the center of Siemens star chart meets the center of shot image screen with the zoom lens at TELE end and WIDE end respectively.
- 6) Check that the data on page: F, address: 10 to 25, 87 to 9B and page: 9, address: 70 to 83 are initial value (See table below).

9 page

Address	Data	Address	Data	Address	Data
70	00	77	00	7E	00
71	00	78	00	7F	00
72	00	79	00	80	00
73	00	7A	00	81	00
74	00	7B	00	82	00
75	00	7C	00	83	00
76	00	7D	00		

F page

. 13-					
Address	Data	Address	Data	Address	Data
10	D0	1F	00	8F	00
11	5C	20	20	90	00
12	B2	21	20	91	00
13	8C	22	13	92	00
14	36	23	46	93	00
15	54	24	0A	94	00
16	87	25	00	95	00
17	71	87	FF	96	00
18	10	88	00	97	00
19	C0	89	00	98	00
1A	00	8A	00	99	00
1B	00	8B	00	9A	00
1C	00	8C	00	9B	00
1D	00	8D	00		
1E	00	8E	00		

Specified voltage: The specified voltage varies according to the minipattern box, so adjustment the power supply output voltage to the specified voltage written on the sheet which is supplied with the minipattern box.




Fig. 5-1-13

Adjusting method:

Order	Page	Address	Data	Procedure			
1	0	01	01				
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)			
3	6	01	13	Press PAUSE button.			
4	6	01	27	Press PAUSE button. (Note 5)			
5	6	02		Check the data changes to "01".			
6	F	87		Check the data changes to "00".			

Note 5: The adjustment data will be automatically input to page: F, address: 10 to 25, 87 to 9B and page: 9, address: 70 to 83

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2				Release the data setting performed at step 2. (Refer to page 5-15)
3	0	01	00	
4				Perform"Flange Back Check".

2. Flange Back Adjustment (Using the flange back adjustment chart)

The flange back of inner focus lens is adjusted automatically. If shifted, the auto focus is disordered.

Mode	CAMERA			
Subject	Flange back adjustment chart (2.0 m from the front of the lens) (Luminance: 300 to 400 lux)			
Measurement Point	Charles and in a TV and it			
Measuring Instrument	Check operation on TV monitor			
Adjustment Page	F 9			
Adjustment Address	10 to 25, 87 to 9B 70 to 83			

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.

Caution:

If the video lens or SY-69 board was replaced, make a setting by referring to "Precaution on Replacing the Video Lens or the SY-69 Board" and then perform the adjustment.

Preparations before adjustments:

- 1) Place the Flange back adjustment chart 2.0 m from the front of the lens.
- Check that the center of Flange back adjustment chart meets the center of shot image screen with the zoom lens at TELE end and WIDE end respectively.
- 3) Check that the data on page: F, address: 10 to 25, 87 to 9B and page: 9, address: 70 to 83 are initial value (See table below).

9 page

Address	Data	Address	Data	Address	Data
70	00	77	00	7E	00
71	00	78	00	7F	00
72	00	79	00	80	00
73	00	7A	00	81	00
74	00	7B	00	82	00
75	00	7C	00	83	00
76	00	7D	00		

F page

Address	Data	Address	Data	Address	Data
10	D0	1F	00	8F	00
11	5C	20	20	90	00
12	B2	21	20	91	00
13	8C	22	13	92	00
14	36	23	46	93	00
15	54	24	0A	94	00
16	87	25	00	95	00
17	71	87	FF	96	00
18	10	88	00	97	00
19	C0	89	00	98	00
1A	00	8A	00	99	00
1B	00	8B	00	9A	00
1C	00	8C	00	9B	00
1D	00	8D	00		
1E	00	8E	00		

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	6	01	13	Press PAUSE button.
4	6	01	15	Press PAUSE button. (Note 2)
5	6	02		Check the data changes to "01".
6	F	87		Check the data changes to "00".

Note 2: The adjustment data will be automatically input to page: F, address: 10 to 25, 87 to 9B and page: 9, address: 70 to 83.

Processing after Completing Adjustment:

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2				Release the data setting performed at step 2. (Refer to page 5-15)
3	0	01	00	
4				Perform"Flange Back Check".

[Precaution on Replacing the Video Lens or the SY-69 Board]

The DSC-P5 uses the position sensor to detect the zoom position. Accordingly, the zoom position will vary if the position data changes due to the replacement of the video lens or the SY-69 board, thus causing the video lens to collide against the mechanism end when the power is turned off.

Though the position data is calibrated at the "Flange Back Adjustment", add the following work when making an adjustment at the replacement of video lens to prevent a collision of video lens.

When Replacing the Video Lens

- 1) With current video lens assembled, turn the power on, and set the bit value of Bit0 on Page:9, Address:65 to "0" using the adjusting remote commander, then turn the power off.
- Replace the video lens with a new one, turn the power on, and perform the "Flange Back Adjustment".
 Thus, new position data will be written.
- 3) After the "Flange Back Adjustment", return the bit value of Bit0 on Page:9, Address:65 to "1" using the adjusting remote commander.

When Replacing the SY-69 Board

- Replace the SY-69 board with a new one, set the mode dial to "PLAY", turn the power on, and set the bit value of Bit0 on Page:9, Address:65 to "0" using the adjusting remote commander, then turn the power off.
- Set the mode dial to "CAMERA", turn the power on, and perform the "Flange Back Adjustment".
 Thus, new position data will be written.
- 3) After the "Flange Back Adjustment", return the bit value of Bit0 on Page:9, Address:65 to "1" using the adjusting remote commander.

3. Flange Back Check

Mode	CAMERA
Subject	Siemens star chart (1.0 m from the front of the lens) (Luminance: 200 to 400 lux)
Measurement Point Measuring Instrument	Check operation on TV monitor
Specified value	Focused at the TELE end and WIDE end

Checking method:


Order	Page	Address	Data	Procedure
1				Place the Siemens star 1.0 m from the front of the lens. To open the IRIS, decrease the luminous intensity to the Siemens star up to a point before noise appear on the image.
2	0	01	01	
3				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
4	В	3D		Note dwon the data.
5	В	3D	64	Press PAUSE button.
6				Shoot the Siemens star chart with the zoom TELE end. At this time, the center of Siemens star chart should be in the center of the LCD screen.
7				Check that the lens is focused.
8	6	2C	01	
9				While observe the LCD screen, change the zoom to the WIDE end and check that the lens is focused.

Order	Page	Address	Data	Procedure
1	6	2C	00	
2	В	3D		Set the data note down at step 4, and press PAUSE button.
3				Release the data setting performed at step 3. (Refer to page 5-15)
4	0	01	00	

4. Picture Frame Setting

Mode	CAMERA
Subject	Color bar chart (Color reproduction adjustment frame with the zoom lens at WIDE end)
Measurement Point	Video terminal of A/V OUT jack (75 Ω terminated)
Measuring Instrument	Oscilloscope and TV monitor
Specified Value	A=B, C=D, E=F

Note 1: Displayed data of the page 1 of adjusting remote commander.



Switch setting:

Setting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Shoot the color bar chart with the zoom WIDE end.
3				Enter the output of VIDEO OUT to the TV monitor, and move to the position as shown in Fig. 5-1-16.
4				Horizontal width of one color (B, C) and that of black (A, D) on the color bar chart should be same. (See Fig. 5-1-14)
5				With vertical width of black (E, F) set in same, the color bar chart should come to the center of TV monitor. (See Fig. 5-1-15)
6				Check that the color bar on the TV monitor is focused.
7	0	03	22	
8	1			Note down the YH and YL data. (Note 1)

Processing after Completing Adjustment:

Order	Page	Address	Data	Procedure
1	0	03	00	
2	0	01	00	

How to reset the zoom and focus when they deviated:

Order	Page	Address	Data	Procedure	
1	6	2C	01		
2	6	90	00		
3	6	91	00		
4	6	92	YL	(Note 2)	
5	6	93	YH	(Note 2)	
6	6	01	79	Press PAUSE button.	
7	6	07		Check the data changes to "01".	
8	6	01	00	Press PAUSE button.	

Note 2: The data noted down at step 8 of "Setting method".

Check on the oscilloscope

1. Horizontal period




Fig. 5-1-14

2. Vertical period




Fig. 5-1-15

Check on the TV monitor




Fig. 5-1-16

5. F No. Standard Data Input

Compensate the unevenness of the iris meter sensitivity.

Mode	CAMERA
Subject	Clear chart (Color reproduction adjustment frame with the zoom lens at WIDE end)
Adjustment Page	F
Adjustment Address	29 to 2D

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.

Note 2: Refer to "Picture Frame Setting" for YH and YL.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	6	2C	01	
4	6	90	00	
5	6	91	00	
6	6	92	YL	(Note 2)
7	6	93	YH	(Note 2)
8	6	01	79	Press PAUSE button.
9	6	07		Check the data changes to "01".
10	6	01	00	Press PAUSE button.
11	6	01	BB	Press PAUSE button. (Note 3)
12	6	02		Check the data changes to "01".

Note 3: The adjustment data will be automatically input to page: F, address: 29 to 2D.

Processing after Completing Adjustment:

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2	6	2C	00	
3	6	92	00	
4	6	93	00	
5				Release the data setting performed at step 2. (Refer to page 5-15)
6	0	01	00	

6. Mechanical Shutter Adjustment

Adjust the period which the mechanical shutter is closed, and compensate the exposure.

Mode	CAMERA
Subject	Clear chart (Color reproduction adjustment frame with the zoom lens at WIDE end)
Adjustment Page	F
Adjustment Address	5A, 6C to 7F, D4 to D8

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.

Note 2: Refer to "Picture Frame Setting" for YH and YL.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	6	2C	01	
4	6	90	00	
5	6	91	00	
6	6	92	YL	(Note 2)
7	6	93	YH	(Note 2)
8	6	01	79	Press PAUSE button.
9	6	07		Check the data changes to "01".
10	6	01	00	Press PAUSE button.
11	6	01	AD	Press PAUSE button. (Note 3)
12	6	02		Check the data changes to "01".
13	6	AB		Check the data is "00".

Note 3: The adjustment data will be automatically input to page: F, address: 5A, 6C to 7F and D4 to D8.

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2	6	2C	00	
3	6	92	00	
4	6	93	00	
5				Release the data setting performed at step 2. (Refer to page 5-15)
6	0	01	00	

7. Light Value Adjustment

Adjust the standard light value.

Mode	CAMERA
Subject	Clear chart (Color reproduction adjustment frame with the zoom lens at WIDE end)
Measurement Point	Displayed data of page: 1 (Note 3) and page: F, address: 28
Measuring Instrument	Adjusting remote commander
Adjustment Page	F
Adjustment Address	26 to 28
Specified Value	AE level 1: 0FE0 to 1020 AE level 2: 28 to 53

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of the unit OFF/ON.

Note 2: Refer to "Picture Frame Setting" for YH and YL.

Note 3: The right 4 digits of the page: 1 displayed data of the adjusting remote commander.

1:XX:XX Displayed data

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	6	2C	01	
4	6	90	00	
5	6	91	00	
6	6	92	YL	(Note 2)
7	6	93	YH	(Note 2)
8	6	01	79	Press PAUSE button.
9	6	07		Check the data changes to "01".
10	6	01	00	Press PAUSE button.
11	6	01	0D	Press PAUSE button. (Note 4)
12	6	02		Check the data changes to "01".
13	0	03	06	
14	1			Check that the displayed data (Note 3) satisfies the AE level 1 specified value.
15	F	28		Check that the displayed data satisfies AE level 2 specified value.

Note 4: The adjustment data will be automatically input to page: F, address: 26 to 28.

Order	Page	Address	Data	Procedure
1	0	03	00	
2	6	01	00	Press PAUSE button.
3	6	2C	00	
4	6	92	00	
5	6	93	00	
6				Release the data setting performed atstep 2. (Refer to page 5-15)
7	0	01	00	

8. Auto White Balance Standard Data Input

Adjust the white balance standard data at 3200K.

Mode	CAMERA
Subject	Clear chart (Color reproduction adjustment frame)
Adjustment Page	F
Adjustment Address	3A to 3D, 59

Note 1: Check that the data of page: 6, address: 02 is "00".

If not, turn the power of unit OFF/ON.

Note 2: "Auto White Balance Standard Data Input" is available only once after the power is turned on. Turn the power off, then on again if the adjustment is retried.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	6	90	00	
4	6	91	04	
5	6	92	00	
6	6	93	30	
7	6	6C	01	
8	6	2C	01	
9	6	01	79	Press PAUSE button.
10	6	07		Check the data changes to "01".
11	6	01	11	Press PAUSE button.
12	6	01	0B	Press PAUSE button. (Note 3)
13	6	02		Check the data changes to "01".

Note 3: The adjustment data will be automatically input to page: F, address: 3A to 3D and 59.

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2	6	2C	00	
3	6	91	00	
4	6	93	00	
5				Release the data setting performed at step 2. (Refer to page 5-15)
6	0	01	00	

9. Auto White Balance Adjustment

Adjust to the proper auto white balance output data.

If it is not correct, auto white balance and color reproducibility will be poor.

Mode	CAMERA
Subject	Clear chart (Color reproduction adjustment frame)
Filter	Filter C14 for color temperature correction
Measurement Point	Displayed data of page: 1 (Note 2)
Measuring Instrument	Adjusting remote commander
Adjustment Page	F
Adjustment Address	3F, 40, 80, A9, AA
Specified Value	R ratio: 2A60 to 2BA0 B ratio: 5C60 to 5DA0

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.

Note 2: The right 4 digits of the page: 1 displayed data of the adjusting remote commander.

1:XX:XX Displayed data

Note 3: "Auto White Balance Adjustment" is available only once after the power is turned on. Turn the power off, then on again if the adjustment is retried.

Adjusting method:

Order	Page	Address	Data	Procedure
1				Place the C14 filter on the lens.
2	0	01	01	
3				Perform "Data setting during camera system adjustment". (Refer to page 5-15)
4	Е	4E		Note down the data.
5	Е	4E	80	Press PAUSE button.
6	6	90	00	
7	6	91	04	
8	6	92	00	
9	6	93	30	
10	6	6C	01	
11	6	2C	01	
12	6	01	79	Press PAUSE button.
13	6	07		Check the data changes to "01".
14	6	01	A7	Press PAUSE button.
15	F	49 4A 4B 4C		Note down the data.
16	F	49 4A 4B 4C	2B 00 5D 00	Press PAUSE button.
17	6	01	A5	Press PAUSE button. (Note 4)
18	6	02		Check the data changes to "01".
19	6	01	3F	Press PAUSE button.

Order	Page	Address	Data	Procedure
20	0	03	04	
21	1			Check that the displayed data (Note 2) satisfied the R ratio specified value.
22	0	03	05	
23	1			Check that the displayed data (Note 2) satisfied the B ratio specified value.

Note 4: The adjustment data will be automatically input to page: F, address: 3F, 40, 80, A9 and AA.

Order	Page	Address	Data	Procedure
1	0	03	00	
2	6	01	00	Press PAUSE button.
3	6	2C	00	
4	6	6C	00	
5	6	91	00	
6	6	93	00	
7	Е	4E		Set data noted down at step 4, and press PAUSE button.
8	F	49 4A 4B 4C		Set data noted down at step 15, and press PAUSE button.
9				Release the data setting performed at step 3. (Refer to page 5-15)
10	0	01	00	
11	·			Remove the C14 filter on the lens.

10. Auto White Balance Check

Mode	CAMERA			
Subject	Clear chart (Color reproduction adjustment frame)			
Filter	Filter C14 for co	lor temperature		
Measurement Point	Displayed data of of Page: 1 (Note 2)	Video terminal A/V OUT jack (75 Ω terminated)		
Measuring Instrument	Adjusting remote commander	Vectorscope		
Specified Value	R ratio: 3E00 to 4200 B ratio: 3E00 to 4200	Fig. 5-1-17 (A) and (B)		

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.

Note 2: The right 4 digits of the page: 1 displayed data of the adjusting remote commander.

1:XX:XX Displayed data

Checking method:

Order	Page	Address	Data	Procedure
1				Place the C14 filter on the lens.
2	0	01	01	
3				Perform "Data setting during camera system adjustment". (Refer to page 5-15)
4	6	90	00	
5	6	91	04	
6	6	92	00	
7	6	93	30	
8	6	6C	01	
9	6	2C	01	
10	6	01	79	Press PAUSE button.
11	6	07		Check the data changes to "01".
OUTE	OOR l	uminance p	oint ch	neck
12	6	01	3F	Press PAUSE button.
13				Check that the center of the white luminance point settles in the circle shown Fig 5-1-17 (B).
INDO	OR data	check		
14				Remove the C14 filter on the lens.
15	Е	52		Note down the data.
16	Е	52	1A	Press PAUSE button.
17	6	01	0F	Press PAUSE button.
18	0	03	04	
19	1			Check that the displayed data (Note 2) satisfied the R ratio specified value.
20	0	03	05	

Order	Page	Address	Data	Procedure		
21	1			Check that the displayed data (Note 2) satisfied the B ratio specified value.		
INDO	INDOOR luminance point check					
22				Check that the center of the white luminance point within the circle shown Fig 5-1-17 (A).		

Order	Page	Address	Data	Procedure
1	0	03	00	
2	6	01	00	Press PAUSE button.
3	6	2C	00	
4	6	6C	00	
5	6	91	00	
6	6	93	00	
7	Е	52		Set data noted down at step 15, and press PAUSE button.
8				Release the data setting performed at step 3. (Refer to page 5-15)
9	0	01	00	




Fig. 5-1-17 (A)




Fig. 5-1-17 (B)

11. Color Reproduction Adjustment

Adjust the color separation matrix coefficient so that proper color reproduction is produced.

Mode	CAMERA
Subject	Color bar chart (Color reproduction adjustment frame with the zoom lens at WIDE end)
Adjustment Page	F
Adjustment Address	41 to 48, 5C to 5F

- Note 1: Perform "Auto White Balance Standard Data Input" before this adjustment.
- **Note 2:** Check that the data of page: 6, address: 02 is "00". If not, turn the power of the unit OFF/ON.
- Note 3: Refer to "Picture Frame Setting" for YH and YL.

 Note 4: "Color Reproduction Adjustment" is available only once after the power is turned on. Turn the power off, then on again if the adjustment is retried.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	6	2C	01	
4	6	90	00	
5	6	91	00	
6	6	92	YL	(Note 3)
7	6	93	YH	(Note 3)
8	6	01	79	Press PAUSE button.
9	6	07		Check the data changes to "01".
10	6	01	00	Press PAUSE button.
11	6	01	AB	Press PAUSE button.
12	6	01	A9	Press PAUSE button. (Note 5)
13	6	02		Check the data changes to "01".

Note 5: The adjustment data will be automatically input to page: F, address: 41 to 48 and 5C to 5F.

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2	6	2C	00	
3	6	92	00	
4	6	93	00	
5				Release the data setting performed at step 2. (Refer to page 5-15)
6	0	01	00	
7				Perform "Color Reproduction Check".

12. Color Reproduction Check

Mode	CAMERA
Subject	Color bar chart (Color reproduction adjustment frame with the zoom lens at WIDE end)
Measurement Point	Video terminal of A/V OUT jack (75 Ω terminated)
Measuring Instrument	Vectorscope
Specified Value	All color luminance points should settle within each color reproduction frame.

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of the unit OFF/ON.

Note 2: Refer to "Picture Frame Setting" for YH and YL.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	6	2C	01	
4	6	90	00	
5	6	91	00	
6	6	92	YL	(Note 2)
7	6	93	YH	(Note 2)
8	6	01	79	Press PAUSE button.
9	6	07		Check the data changes to "01".
10	6	01	00	Press PAUSE button.
11	6	10	01	
12	Е	52		Note down the data.
13	Е	52	0A	Press PAUSE button.
14	6	01	0F	Press PAUSE button.
15				Check the each color luminance point is in each color reproduction frame.

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2	6	10	00	
3	6	2C	00	
4	6	92	00	
5	6	93	00	
6	E	52		Set the data noted down at step 12, and press PAUSE button.
7				Release the data setting performed at step 2. (Refer to page 5-15)
8	0	01	00	




Fig. 5-1-18

13. CCD White Defect Compensation

Mode	CAMERA
Subject	Not required
Measurement Point	Displayed data of page: 6, address: 55
Measuring Instrument	Adjusting remote commander
Adjustment Page	7
Adjustment Address	88 to FF

Note 1: Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.

Note 2: The "CCD White Defect Compensation" should be made when the set warms up at certain duration after the power was turned on, as it is affected with the temperature.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustments". (Refer to page 5-15)
3	F	DE	1E	Press PAUSE button.
4	F	E3	13	Press PAUSE button.
5	6	01	8B	Press PAUSE button. (Note 3)
6	6	02		Check the data changes to "01".
7	6	55		Check the data. 00 to 7F: Normal 80 to FF: Defective
8	6	01	00	Press PAUSE button.
9	F	DE	0F	Press PAUSE button.
10	F	E3	60	Press PAUSE button.
11	6	01	87	Press PAUSE button.
12	6	02		Check the data changes to "01".
13	6	55		Check the data is "00".

Note 3: The adjustment data will be automatically input to page: 7, address: 88 to FF.

Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2				Release the data setting performed at step 2. (Refer to page 5-15)
3	0	01	00	

14. CCD Black Defect Compensation

Mode	CAMERA
Subject	Clear chart (Color reproduction adjustment frame)
Measurement Point	Displayed data of page: 6, address: 55
Measuring Instrument	Adjusting remote commander
Adjustment Page	7
Adjustment Address	60 to 87

- **Note 1:** Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.
- **Note 2:** Check that there are no dust, no dirt and reflection of the clear chart.
- **Note 3:** Any subject other than the clear chart should be in the screen.

Adjusting method:

2 camera system adjustments' (Refer to page 5-15) 3 F DF Note down the data. 4 F DF 4C Press PAUSE button. 5 6 2C 01 6 6 90 00 7 6 91 03 8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01						
2 Perform "Data setting durin camera system adjustments" (Refer to page 5-15) 3 F DF Note down the data. 4 F DF 4C Press PAUSE button. 5 6 2C 01 6 6 90 00 7 6 91 03 8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	Order	Page	Order	Address	Data	Procedure
2 camera system adjustments' (Refer to page 5-15) 3 F DF Note down the data. 4 F DF 4C Press PAUSE button. 5 6 2C 01 6 6 90 00 7 6 91 03 8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	1	0	1	01	01	
4 F DF 4C Press PAUSE button. 5 6 2C 01 6 6 90 00 7 6 91 03 8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	2		2			Perform "Data setting during camera system adjustments". (Refer to page 5-15)
5 6 2C 01 6 6 90 00 7 6 91 03 8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	3	F	3	DF		Note down the data.
6 6 90 00 7 6 91 03 8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	4	F	4	DF	4C	Press PAUSE button.
7 6 91 03 8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	5	6	5	2C	01	
8 6 92 00 9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	6	6	6	90	00	
9 6 93 00 10 6 01 79 Press PAUSE button. 11 6 30 01	7	6	7	91	03	
10 6 01 79 Press PAUSE button. 11 6 30 01	8	6	8	92	00	
11 6 30 01	9	6	9	93	00	
	10	6	10	01	79	Press PAUSE button.
12 6 07 Check the data changes to '01'	11	6	11	30	01	
12 0 07 Check the data changes to 01	12	6	12	07		Check the data changes to "01".
13 6 01 8D Press PAUSE button. (Note 4	13	6	13	01	8D	Press PAUSE button. (Note 4)
14 6 02 Check the data changes to "01"	14	6	14	02		Check the data changes to "01".
Check the data. 00: Proceed to "Processing after Completing Adjustment 01 to 0A: Normal 0B to FF: Defective	15	6	15	55		00: Proceed to "Processing after Completing Adjustment". 01 to 0A: Normal
16 6 01 00 Press PAUSE button.	16	6	16	01	00	Press PAUSE button.
17 F DF 5A Press PAUSE button.	17	F	17	DF	5A	Press PAUSE button.
18 6 01 89 Press PAUSE button.	18	6	18	01	89	Press PAUSE button.
19 6 02 Check the data changes to "01"	19	6	19	02		Check the data changes to "01".
20 6 55 Check the data is "00".	20	6	20	55		Check the data is "00".

Note 4: The adjustment data will be automatically input to page: 7, address: 60 to 87.

				•
Order	Page	Address	Data	Procedure
1	6	01	00	Press PAUSE button.
2	6	2C	00	
3	6	30	00	
4	6	91	00	
5	F	DF		Set the data noted down at step 3, and press PAUSE button.
6				Release the data setting performed at step 2. (Refer to page 5-15)
7	0	01	00	

15. Strobe White Balance Adjustment

Adjust the white balance when the strobe light flashed.

Mode	CAMERA
Subject	Flash adjustment box (Note 3) (1 m from the front of the lens)
Adjustment Page	F
Adjustment Address	4D, 4E, 64, 69 to 6B
Specified Value	Y level data: 70 to 90 (Note 5) R-Y level data: FA to FF or 00 to 06 (Note 4) B-Y level data: FA to FF or 00 to 06 (Note 4)

- **Note 1:** Check that the data of page: 6, address: 02 is "00". If not, turn the power of unit OFF/ON.
- Note 2: Perform this adjustment in the Flash adjustment box.

 Do not block the photocell window for flash.

 Restrict external light to enter the photocell window for flash as less as possible.
- **Note 3:** Refer to "4. Preparing the Flash adjustment box". (See page 5-7)
- **Note 4:** The right four digits of the page: 1 displayed data of the adjusting remote commander.

Note 5: Displayed data of page: F, address: 64, of the adjusting remote commander.

Note 6: "Strobe White Balance Adjustment" is available only once after the power is turned on. Turn the power off, then on again if the adjustment is retried.

Switch setting:

1) FLASH (Control button) ON

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2				Perform "Data setting during camera system adjustment". (Refer to page 5-15)
3	6	14	90	
4	6	90	00	
5	6	91	00	
6	6	92	FF	
7	6	93	FF	
8	6	6C	01	
9	6	2C	01	
10	6	01	79	Press PAUSE button.
11	6	07		Check the data changes to "01".
12	6	01	67	Press PAUSE button.
13				Check the flashing of strobe light.
14	6	02		Check the data changes to "01".
15	6	01	00	Press PAUSE button.
16	6	01	67	Press PAUSE button.

Order	Page	Address	Data	Procedure
Older	1 age	Addiess	Data	
17				Check the flashing of strobe
				light.
18	6	02		Check the data changes to "01".
19	6	01	00	Press PAUSE button.
20	6	01	В9	Press PAUSE button. (Note 7)
21				Check the flashing of strobe light.
22	6	02		Check the data changes to "01".
23	6	01	00	Press PAUSE button.
24	6	01	67	Press PAUSE button.
25				Check the flashing of strobe light.
26	6	02		Check the data changes to "01".
27	0	03	02	
28	1			Check that the R-Y, B-Y level data (Note 4) satisfies the specified value.
29	F	64		Check that the Y level data (Note 5) satisfies the specified value.

Note 7: The adjustment data will be automatically input to page: F, address: 4D, 4E, 64 and 69 to 6B.

Order	Page	Address	Data	Procedure
1	0	03	00	
2	6	01	00	Press PAUSE button.
3	6	2C	00	
4	6	6C	00	
5	6	92	00	
6	6	93	00	
7	6	14	00	
8				Release the data setting performed at step 2. (Refer to page 5-15)
9	0	01	00	

1-5. LCD SYSTEM ADJUSTMENTS

Before perform the camera system adjustments, check that the specified values of "VIDEO SYSTEM ADJUSTMENTS" are satisfied.

Note 1: Taken an extreme care not to destroy the liquid crystal display module by static electricity when replacing it.

Note 2: Set the LCD BRIGHTENSS (SET UP setting) to the NORMAL.

[Adjusting connector]

Most of the measuring points for adjusting the LCD system are concentrated in CN 902 of the SY-69 board.

Connect the Measuring Instruments via the CPC-9 jig (J-6082-393-C).

The following table shows the Pin No. and signal name of CN 902.


Pin No.	Signal Name	Pin No.	Signal Name
1	BL_L1	10	HI_UNREG
2	N. C.	11	LANC IN
3	N. C.	12	LANC OUT
4	REG_GND	13	MAKER_RECOG
5	CPU_IN	14	N. C.
6	BL_L2	15	N. C.
7	HSY	16	N. C.
8	PANEL_COM	17	N. C.
9	VG	18	N. C.

[IC type check]

By measuring the resistor value between Pin ⁽³⁾ of CN902 and Pin ⁽⁴⁾ of CN902, the type of IC801 (LCD drive) can be discriminated.

SY-69 board CN902

Resistor value	IC type
15 kΩ	AN12511A
22 kΩ	CXA8116R



Note 1: Don't use the 12 pin flexible board of CPC-9 jig. It causes damage to the unit.

Note 2: The old CPC-9 jig (Parts code: J-6082-393-B) cannot be used, because it cannot operate the adjusting remote commander.

Fig. 5-1-19

1. LCD Initial Data Input (1)

Mode	PLAY
Signal	Arbitrary
Adjustment Page	В
Adjustment Address	3A to 3F

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: B, and enter the data given in the following table.

Note: Press the PAUSE button each time the data are set, as the data are written to non-volatile memory (EEPROM).

Address	Data	Remark
3A	59	
3B	00	
3C	04	Fixed data
3D	5B	1 Ixed data
3E	00	
3F	02	

Processing after Completing Adjustments:

1) Select page: 0, address: 01, and set data: 00.

2. LCD Initial Data Input (2)

Mode	PLAY
Signal	Arbitrary
Adjustment Page	D
Adjustment Address	CE to DF

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, and enter the data given in the following table.

Note: Press the PAUSE button each time the data are set, as the data are written to non-volatile memory (EEPROM).

A d d = 2 = 2	D-	4-	Damark
Address	Data		Remark
	AN12511A	CXA8116R	
CE	46	4D	Fixed value
CF	В9	D5	Tixed value
D0	76	7D	Bright Adjustment
D1	C3	7E	Color Adjustment
D2	60	BB	White Blance Adjustment
D3	AA	83	Winte Diance Augustinent
D4	В9	D5	Contrast Adjustment
D5	5C	90	Black Limit Adjustment
D6	AC	8D	VG Center Adjustment
D7	5C	5C	VCO Adjustment (NTSC)
D8	77	5A	V-COM Adjustment
D9	В0	В0	Fixed value
DA	61	7A	PSIG Adjustment
DB	00	00	Fixed value
DC	4D	4D	rixed value
DD	6A	6B	VCO Adjustment (PAL)
DE	A6	AD	Fixed value
DF	В9	D5	Takeu value

Processing after Completing Adjustments:

1) Select page: 0, address: 01, and set data: 00.

3. VCO Adjustment (SY-69 Board)

Set the VCO free-run frequency. If deviated, the LCD screen will be blurred.

Mode	PLAY
Signal	Arbitrary
Measurement Point	CH1: Pin ⑦ of CN902 (HSY) CH2: Video terminal of A/V OUT jack (75 Ω terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	D7 (NTSC) DD (PAL)
Specified Value	$T = 2.04 \pm 0.1 \mu s \text{ (NTSC)}$ $T = 2.63 \pm 0.1 \mu s \text{ (PAL)}$

Menu setting:

VIDEO OUT of SET UP setting
NTSC (NTSC mode)


(This adjustment must be performed in NTSC mode, so don't set the menu setting to "PAL")

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	D	D7		Change the data and set the phase difference (T) to the NTSC specified value.
3	D	D7		Press PAUSE button.
4	D	DD		Change the data and set the phase difference (T) to the PAL specified value.
5	D	DD		Press PAUSE button.

Processing after Completing Adjustments:

Order	Page	Address	Data	Procedure
1	0	01	00	



T: Between the center of HSY signal rising and VIDEO SYNC signal rising

Fig. 5-1-20

4. Black Limit Adjustment (SY-69 Board)

Set the maximum amplitude of the RGB decoder for driving the LCD to the specified value.


If deviated, the LCD screen image will be blackish or saturated (whitish).

Mode	PLAY
Signal	Arbitrary
Measurement Point	Pin ③ of CN902 (VG) External trigger: Pin ⑧ of CN902 (PANEL COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	D5
Specified Value	$A = 8.20 \pm 0.1 \text{ Vp-p}$

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	03	
3	D	D0	20	Set the data. (Don't press PAUSE button.)
4	D	D5		Change the data and set the voltage (A) to the specified value.
5	D	D5		Press PAUSE button.

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	



A: Between the reversed waveform peak and non-reversed waveform peak

Fig. 5-1-21

5. Bright Adjustment (SY-69 Board)

Set the amplitude of the RGB decoder for driving the LCD to the specified value.

If deviated, the LCD screen image will be blackish or saturated (whitish).


Mode	PLAY
Signal	Arbitrary
Measurement Point	Pin (9) of CN902 (VG) External trigger: Pin (8) of CN902 (PANEL COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	D0
Specified Value	$A = 7.96 \pm 0.1 \text{ Vp-p}$

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	03	
3	D	D0		Change the data and set the voltage (A) to the specified value.
4	D	D0		Press PAUSE button.
5	D	D0		Read the data and this data is named Dref.
6				Convert Dref to decimal notation, and obtain Dref'. (Note)
7				Calculate D _{CE} ' and D _{DE} ' using following equations. (decimal calculation) D _{CE} ' = Dref' - 48 D _{DE} ' = Dref' + 48
8				Convert D _{CE} ' and D _{DE} ' to hexadecimal numbers, and obtain D _{CE} and D _{DE} . (Note)
9	D	CE	DCE	Press PAUSE button.
10	D	DE	DDE	Press PAUSE button.

Note: Refer to table 5-2-2. "Hexadecimal-decimal conversion table".

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	



A: Between the reversed waveform pedestal and non-reversed waveform pedestal

Fig. 5-1-22

6. Contrast Adjustment (SY-69 Board)

Set the level of the VIDEO signal for driving the LCD to the specified value.

If deviated, the LCD screen image will be blackish or saturated (whitish).


Mode	PLAY
Signal	Arbitrary
Measurement Point	Pin (9) of CN902 (VG) External trigger: Pin (8) of CN902 (PANEL COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	D4
Specified Value	$A = 2.50 \pm 0.05 \text{ Vp-p}$

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	03	
3	D	D4		Change the data and set the voltage (A) to the specified value.
4	D	D4		Press PAUSE button.
5	D	D4		Read the data and this data is named Dref.
6	D	CF	Dref	Press PAUSE button.
7	D	DF	Dref	Press PAUSE button.

Processing after Completing Adjustments:

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	



A: Between the pedestal and 10 steps peak

Fig. 5-1-23

7. Color Adjustment (SY-69 Board)


Set the color saturation to the standard value. If, deviated, the color will be dark or light.

Mode	PLAY
Signal	Arbitray
Measurement Point	Pin (9) of CN902 (VG) External trigger: Pin (8) of CN902 (PANEL COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	D1
Specified Value	$A = 350 \pm 50 \text{ mVp-p}$

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	04	
2	D	D1		Change the data and set the voltage (A) to the specified value.
4	D	D1		Press PAUSE button.

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	



A: Between the white 100% (Reference level) and green

Fig. 5-1-24

8. VG Center Adjustment (SY-69 Board)

Set the center of VG signal for driving the LCD to the specified value.

Mode	PLAY
Signal	Arbitrary
Measurement Point	Pin (9) of CN902 (VG)
Measuring Instrument	Digital voltmeter
Adjustment Page	D
Adjustment Address	D6
Specified Value	$A = 7.00 \pm 0.05 \text{ V}$

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	02	
3	D	D6		Change the data and set the DC voltage (A) to the specified value.
4	D	D6		Press PAUSE button.

Processing after Completing Adjustments:

[Order	Page	Address	Data	Procedure
Γ	1	4	F1	00	
ſ	2	0	01	00	

9. PSIG Adjustment (SY-69 Board)

Set the common electrode drive signal level of LCD to the specified value.

Mode	PLAY
Signal	Arbitrary
Measurement Point	Pin ® of CN902 (PANEL_COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	DA
Specified Value	$A = 5.0 \pm 0.1 \text{ Vp-p}$

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	02	
3	D	DA		Change the data and set the PSIG signal level (A) to the specified value.
4	D	DA		Press PAUSE button.

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	




Fig. 5-1-25

10. V-COM Adjustment (SY-69 Board)

Set the DC bias of the common electrode drive signal of LCD to the specified value.

If deviated, the LCD display will be move, producing flicker and conspicuous vertical lines.

Mode	PLAY
Signal	Arbitrary
Measurement Point	Charless the LCD
Measuring Instrument	Check on the LCD screen
Adjustment Page	D
Adjustment Address	D8
Specified Value	The brightness difference
	between the section-A and section-B is minimum

Note 1: Perform "Bright Adjustment" and "Contrast Adjustment" before this adjustment.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	02	
3	4	10	02	
4	D	D8		Change the data so that brightness of the section A and section B is equal.
5	D	D8		Read the data and this data is named Dref.
6				Convert Dref to decimal notation, and obtain Dref'. (Note 2)
7				Calculate D _{D8} ' using following equations. (decimal calculation) D _{D8} ' = Dref' - 13
8				Convert D_{D8} ' to a hexadecimal number, and obtain D_{D8} . (Note 2)
9	D	D8	D _{D8}	Press PAUSE button.

Note 2: Refer to table 5-2-2. "Hexadecimal-decimal conversion table".

Processing after Completing Adjustments:

Order	Page	Address	Data	Procedure
1	4	F1	00	
2	4	10	00	
3	0	01	00	




Fig. 5-1-26

11. White Balance Adjustment (SY-69 Board)

Correct the white balance.

If deviated, the LCD screen color cannot be reproduced.

Mode	PLAY
Signal	Arbitrary
Measurement Point	Check on the LCD screen
Measuring Instrument	Check on the LCD screen
Adjustment Page	D
Adjustment Address	D2, D3
Specified Value	LCD screen must not be colored

Note 1: Check the white balance only when replacing the following parts. If necessary, adjust them.

- 1. LCD panel
- 2. Light induction plate
- 3. IC801

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	4	F1	02	
3	D	D2	60/BB	Press PAUSE button. (Intital value) (Note 2)
4	D	D3	AA/83	Press PAUSE button. (Intital value) (Note 2)
5				Check that the LCD screen is not colored. If not colored, proceed to "Processing after Completing Adjustments".
6	D	D2 D3		Change the data so that the LCD screen is not colored. (Note 3)

Note 2: AN12511A type/CXA8116R type

Note 3: To write in the non-volatile memory (EEPROM), press the PAUSE button each time to set the data.

		_		=
Order	Page	Address	Data	Procedure
1	4	F1	00	
2	0	01	00	

1-6. SYSTEM CONTROL SYSTEM ADJUSTMENTS

1. Battery Down Adjustment

Set the battery end voltage.

If the voltage is incorrect, the life of battery will shorten.

The image at the battery end will also be rough.

Mode	CAMERA
Subject	Arbitrary
Measurement Point	Displayed data of page: 2, address: 9A
Measuring Instrument	Adjusting remote commander
Adjustment Page	D
Adjustment Address	90 to 94

Connection:

1) Connect the regulated power supply and the digital voltmeter to the battery terminal as shown in Fig. 5-1-27.

Preparations before adjustment:

- 1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display is 4.2 ± 0.1 Vdc.
- 2) Turn off the power supply.
- 3) Set the HOLD switch of the adjusting remote commander to "HOLD" (SERVICE position).
- 4) Turn on the power supply.
- 5) Insert the memory stick to the unit, and set the CAMERA mode.

Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	
2	6	2C	01	
3				Decrease the output voltage of the regulated power supply so that digital voltmeter display is 3.20 ± 0.01 Vdc.
4	2	9A		Read the data, and this data is named Dref.
5	D	90	Dref	Press PAUSE button.
6				Convert Dref to decimal notati on and obtain Dref'. (Note)
7				Calculate D ₉₁ ', D ₉₂ ', D ₉₃ ' and D ₉₄ ' using following equations(decimal calculation) D ₉₁ '=Dref'+6 D ₉₂ '=Dref'+23 D ₉₃ '=Dref'+44 D ₉₄ '=Dref'+55
8				Convert D ₉₁ ', D ₉₂ ', D ₉₃ ' and D ₉₄ ' to a hexadecimal number, and obtain D ₉₁ , D ₉₂ , D ₉₃ and D ₉₄ (Note)
9	D	91	D ₉₁	Press PAUSE button.
10	D	92	D ₉₂	Press PAUSE button.
11	D	93	D ₉₃	Press PAUSE button.
12	D	94	D ₉₄	Press PAUSE button.

Note: Refer to table 5-2-2. "Hexadecimal-decimal conversion table"

0	rder	Page	Address	Data	Procedure
	1	6	2C	00	
	2	0	01	00	




Fig. 5-1-27

5-2. SERVICE MODE

2-1. ADJUSTING REMOTE COMMANDER

The adjusting remote commander is used for changing the calculation coefficient in signal processing, EVR data, etc. The adjusting remote commander performs bi-directional communication with the unit using the remote commander signal line (LANC). The resultant data of this bi-directional communication is written in the non-volatile memory.

1. Used the Adjusting Remote Commander

- 1) Connect the adjusting remote commander to the CN902 on the SY-69 board via CPC-9 jig (J-6082-393-C).
- 2) Set the HOLD switch of the adjusting remote commander to "HOLD" (SERVICE position).
- 3) Turn on the power with the POWER switch of the unit. If it has been properly connected, the LCD on the adjusting remote commander will display as shown in Fig. 5-2-1.




Fig. 5-2-1

- 4) Operate the adjusting remote commander as follows.
 - Changing the page

The page increases when the EDIT SEARCH + button is pressed, and decreases when the EDIT SEARCH – button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal	0	1	2	2	4	_	_	7	0	0		ъ	C	Б	г.	F
notation	U	1	2	3	4	3	О	/	ð	9	А	В	C	ע	E	Г
LCD Display		1	2	3	Ч	5	5	7	8	9	Я	Ь	С	д	Ε	F
Decimal notation	0	1	_	2	4	_		7	0	_	10	1 1	10	12	1 4	1.5
conversion value	U	1	2	3	4	3	0	/	8	9	10	11	12	13	14	15

Table 5-2-1

- Changing the address
 - The address increases when the FF (►►) button is pressed, and decreases when the REW (►►) button is pressed. There are altogether 256 addresses, from 00 to FF.
- Changing the data (Data setting)

 The data increases when the PLAY (▶) button is pressed, and decreases when the STOP (■) button is pressed. There are altogether 256 data, from 00 to FF.
- Writing the adjustment data
 The PAUSE button must be pressed to write the adjustment data in the nonvolatile memory. (The new adjustment data will not be recorded in the nonvolatile memory if this step is not performed)

2. Precautions upon Using the Adjusting Remote Commander

Mishandling of the adjusting remote commander may erase the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment.

2-2. DATA PROCESS

The calculation of the adjusting remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Table 5-2-2. indicates the hexadecimal notation- the decimal notation, calculation table.

Hexade	ecimal nontation-Decimal notati	on													② ↓		
	The lower digits of the	0	1	2	3	4	5	6	7	8	9	А	В	С	D	Е	F
	\hexadecimal notation	i '								į į							1 L
	The upper digits of the	'								į į		(A)	(b)	(८)	(년)	(E)	(F)
	hexadecimal notation													<u></u>	<u> </u>		
	0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
	2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
	3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
	4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
	5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
	6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
	7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
	8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
	9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
	A (A)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
⊕	В (Ь)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
	C (c)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
	D (d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
	E (E)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
	F (F)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

Note: () indicate the adjusting remote control unit display.

(**Example)** In the case that the adjusting remote control unit display are BD (bd).

As the upper digit of the hexadecimal notation is B (b), and the lower digit is D (d), the intersection "189" of the ① and ② in the above table is the decimal notation to be calculated.

Table 5-2-2

2-3. SERVICE MODE

1. Setting the Test Mode

Page D	Address 10
--------	------------

Data	Function
00	Normal
01	Forced CAMERA mode power ON
02	Forced PLAY mode power ON
03	Forced MOVIE mode power ON


- Before setting the data, select page: 0, address: 01, and set data:
 01
- For page D, the data set is recorded in the non-volatile memory by pressing the PAUSE button of the adjusting remote commander. In this case, take note that the test mode will not be exited even when the main power is turned off.
- After completing adjustments/repairs, be sure to return the data
 of this address to "00", and press the PAUSE button of the adjusting remote commander.

Select page: 0, address: 01, and set data: 00.

2. Bit Value Discrimination

Bit values must be discriminated using the display data of the adjusting remote commander for following items. Use the table below to discriminate if the bit value is "1" or "0".

Display on the adjustilng remote commander



	D: 1 (1		D::		
	Display on the		Bit v	alues	
	Adjusting	bit3	bit2	bit1	bit0
	remote	or	or	or	or
	commander	bit7	bit6	bit5	bit4
	0	0	0	0	0
	1	0	0	0	1
	2	0	0	1	0
	3	0	0	1	1
	4	0	1	0	0
	5	0	1	0	1
	6	0	1	1	0
	7	0	1	1	1
A	8	1	0	0	0
	9	1	0	0	1
	A (Ħ)	1	0	1	0
	B (b)	1	0	1	1
	C (c)	1	1	0	0
	D (d)	1	1	0	1
$^{f B}$	E (<i>E</i>)	1	1	1	0
	F (F)	1	1	1	1

Example: If "8E" is displayed on the adjusting remote commander, the bit values for bit7 to bit4 are shown in the ⓐ column, and the bit values for bit3 to bit0 are shown in the ⓐ column.

3. Mode Dial Check (1)

Page 2	Address 94
--------	------------

Data	Function
00 to 14	MOVIE
15 to 3D	TWILIGHT
3E to 67	CAMERA

Using method:

- 1) Select page: 2, address: 94.
- By discriminating the bit value of dispaly data, the state of the switches can be discriminated.

4. Mode Dial Check (2)

Page 2	Address 80, 86
rage 2	Audiess ou, ou

Address	Bit	Function	When bit value=1	When bit value=0
80	1	PLAY	others	PLAY
86	6	SET UP	others	SET UP

Using method:

- 1) Select page: 2, address: 80 and 86.
- By discriminating the bit value of dispaly data, the state of the switches can be discriminated.

5. Switch Check (1)

Page 2 Address 80

Bit	Function	When bit value=1	When bit value=0
0	POWER SW (CONTROL SWITCH BLOCK)	OFF	ON
1	PLAY (Mode Dial) (CONTROL SWITCH BLOCK)	others	PLAY
2			
3	SHUTTR SW (CONTROL SWITCH BLOCK)	OFF	ON
4	XSHUTTER LOCK SW (CONTROL SWITCH BLOCK)	OFF	ON
5	MEMORY STICK IN SW (MS Socket)	OUT	IN

Using method:

- 1) Select page: 2, address: 80.
- 2) By discriminating the bit value of dispaly data, the state of the switches can be discriminated.

DSC-P5

6. Switch Check (2)

Page 2	Addresses 90, 91, 93
--------	----------------------

Using method:

- 1) Select page: 2, addresses: 90, 91 and 93.
- By discriminating the dispaly data, the pressed key can be discriminated.

A d du a a a				Data			
Address	00 to 0C	0D to 27	28 to 48	49 to 74	75 to A6	A7 to DD	DE to FF
90 (KEY AD0) (IC401 ②)	CONTROL DOWN (DD-163 board) (S951)	CONTROL UP (DD-163 board) (S951)	MENU (DD-163 board) (S954)				
91 (KEY AD1) (IC401 🚳)	CONTROL RIGHT (DD-163 board) (S951)	CONTROL LEFT (DD-163 board) (S951)	CONTROL SET (DD-163 board) (S951)	DISPLAY/LCD ON/OFF (DD-163 board) (S955)			
93 (KEY AD3) (IC401 ®)	ZOOM (W) (DD-163 board) (S952)	ZOOM (T) (DD-163 board) (S953)					

7. LED Check

Page 2	Address 04	Data 01

Using method:

- 1) Select page: 2, address: 04, set data: 01, and press the PAUSE button of the adjusting remote commander.
- 2) Check that all LED except for the ACCESS LED are lit and all segments of LCD (display window) are lit.
- 3) Select page: 2, address: 04, set data: 00 and press the PAUSE button of the adjusting remote commander.

8. Self Diagnosis Code

Display Code	Countermeasure	Cause	Caution Display During Error
C:32:□□	Turn the power off and on again.	Trouble with hardware.	SYSTEM ERROR
C.12.	Format the "Memory stick".	Unformatted memory stick is inserted.	FORMAT ERROR
C:13:□□	Insert a new "Memory Stick".	Memory stick is broken.	MEMORY STICK ERROR
E:61:□□	Checking of lens drive circuit.	When failed in the focus and zoom initialization.	
E:91:□□	Checking of flash unit or replacement of flash unit.	Abnormality when flash is being charged.	_

SECTION 6 REPAIR PARTS LIST

6-1. EXPLODED VIEWS

NOTE:

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Accessories are given in the last of the electrical

The components identified by mark \triangle or dotted line with mark \triangle are


critical for safety.

Replace only with part number specified.

Les composants identifiés par une marque A sont critiquens pour la


sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-1-1. CABINET (FRONT) ASSEMBLY




Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>
1	X-3951-968-1	CABINET (FRONT) ASSY		4	3-989-735-51	SCREW (M1.7), LOCK ACE, P2	
2	3-071-056-01	PLATE (UPPER), INNER		5	3-064-225-01	LID, CPC	
3	3-071-037-01	CABINET, CENTER					

6-1-2. CABINET (REAR) ASSEMBLY



Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>
51	1-476-875-11	SWITCH BLOCK, CONTROL		61	3-071-051-01	BUTTON, FUNCTION	
52	3-071-108-01	CUSHION (MODE DIAL)		62	3-989-735-51	SCREW (M1.7), LOCK ACE, P2	
* 53	3-055-971-01	CUSHION, MICROPHONE		63	3-071-002-01	LCD WINDOW (1.5)	
54	3-071-012-01	CAP, MICROPHONE		64	3-071-003-01	SHEET (1.5), ADHESIVE	
55	3-713-791-71	SCREW (M1.7X4)		65	3-071-059-01	SHEET (ST), INSULATING	
56	X-3951-969-1	CABINET (REAR) ASSY		66	X-3951-970-1	CABINET (BOTTOM) ASSY	
57	3-071-054-01	WINDOW, JACK		67	3-070-999-01	FOOT (UN), RUBBER	
58	3-071-048-01	BUTTON, ZOOM		68	3-072-132-01	MA CUSHION	
59	3-071-055-01	COVER, JACK		69	3-072-219-01	CUSHION (NM), MICROPHONE	
60	3-071-052-01	HOLDER, FUNCTION BUTTON		MIC901	1-542-446-21	MICROPHÒNE	

6-1-3. LENS BLOCK AND LCD SECTION




: BT101 (BATTERY, LITHIUM SECONDARY) Board on the mount position. (See page 4-40.)

(Note) The lens block assembly is a mechanical unit which has completely been adjusted in the factroy. So never disassemble the lens block assembly.

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified. Les composants identifiés par une marque ▲ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

6-1-4. BATTERY HOLDER ASSEMBLY



Ref. No.	Part No.	Description	<u>Remark</u>	Ref. No.	Part No.	Description	<u>Remark</u>
151	1-682-672-11	FP-380 FLEXIBLE BOARD		159	A-7074-973-A	DD-163 BOARD, COMPLETE	
152	1-815-853-11	CONNECTOR, MEMORY STICK		160	3-071-014-01	SHEET (DD), INSULATING	
153	3-695-653-01	SCREW (1.7X3), TAPPING (B)		161	3-071-015-01	SHEET (LED), ADHESIVE	
154	X-3951-967-1	HOLDER ASSY, BATTERY		162	3-071-013-01	SP CUSHION	
155	3-071-027-01	LID, BT		163	3-071-005-01	DD SPACER	
156	X-3951-971-1	FRAME ASSY, BT MAIN		164	3-713-791-71	SCREW (M1.7X4)	
157	3-989-735-51	SCREW (M1.7), LOCK ACE, P2		BT901	1-694-854-11	BATTERY TERMINAL BOARD	
158	3-071-008-01	SP HOLDER					

CD-340

6-2. ELECTRICAL PARTS LIST

NOTE:

- · Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS

All resistors are in ohms. METAL: Metal-film resistor.

METAL OXIDE: Metal oxide-film resistor.

F: nonflammable

Abbreviation

J : Japanese model AUS: Australian model CN: Chinese model JE : Tourist model KR : Korea model CND: Canadian model

HK: Hong Kong model

Part No. Ref. No. **Description**

CD-340 BOARD, COMPLETE

(Ref. No.: 2,000 Series)

ing these items.

uA. . : μA. . uPB. . : μPB. . uPD. . : μPD. .

CAPACITORS

uF: μF

COILS uH: μH

SEMICONDUCTORS

Remark

In each case, u: μ , for example:

uPA..

uPC..

: μΡΑ. .

: $\mu PC.$.

The parts mounted on this board are not supplied individually Note:

for service.

These are included in the LENS BLOCK ASSY (A-7031-334-A).

Electrical parts list of the DD-163 board is not shown.

Pages 6-6 to 6-8 are not shown.

The components identified by • Items marked "*" are not stocked since they mark △ or dotted line with mark are seldom required for routine service. \triangle are critical for safety. Some delay should be anticipated when order-Replace only with part number specified.

> Les composants identifiés par une marque A sont critiquens pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

DSC-P5

ST-67

Ref. No.	<u>Part No.</u> A-7074-974-A		<u>Remark</u>					
		****	**************************************					
^	1-476-678-21 3-068-578-01 3-071-032-01 3-071-033-01	TABLE,	R TABLE B SENSOR	3				
		< BATTE	ERY >					
BT101	1-528-999-31	BATTER	Y, LITHIU	M SECOND	ARY			
		< CAPA	CITOR >					
C003 C005 ⚠ C008 ⚠ C010	1-162-970-11 1-125-837-91 1-165-806-11 1-137-723-21	CERAM ELECT	IC CHIP IC CHIP	0.01uF 1uF 120uF 0.047uF	10% 10% 10%	25V 6.3V 310V 250V		
		< CONN	ECTOR >					
CN102	1-778-596-21	CONNEC	CTOR, BO	ARD TO BO	ARD 30P	1		
		< DIODE	Ε>					
D001 ⚠ D002 D101	8-719-056-23 8-719-083-17 6-500-102-01	DIODE MA2S111- (K8).SO DIODE HAU140C029TP DIODE TLOH20TP (SONY2) (SELF TIMER/AF ILLUMINATOR (RED))						
		< COIL :	>					
 ∆L002	1-424-770-11	COIL, T	RIGGER					
		< TRAN	SISTOR >					
Q005 ⚠ Q011 Q012	8-729-422-87 8-729-053-74 8-729-039-61	TRANSISTOR 2SB1073-R TRANSISTOR CY25AAJ-8-T13 TRANSISTOR TPS613-BC (BRIGHT LEVEL SENSO				SENSOR)		
		< RESIS	STOR >					
R005 R006 R009 R010 R016	1-216-805-11 1-216-838-11 1-216-826-11 1-216-814-11 1-216-805-11	METAL METAL METAL METAL METAL	CHIP CHIP CHIP	47 27K 2.7K 270 47	5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W		
R017 AR018 R102	1-216-857-11 1-216-121-11 1-216-803-11	METAL RES-CH METAL	IIP	1M 1M 33	5% 5% 5%	1/16W 1/10W 1/16W		
		< TRAN	SFORMER	?>				
 ∆T001	1-435-741-21	TRANSF	ORMER,	DC-DC CON	IVERTER			

Electrical parts list of the SY-69 board is not shown.


Pages 6-10 to 6-15 are not shown.

Ref. No.	Part No.	Description Remark ACCESSORIES ***********************************
<u>↑</u> <u>↑</u> <u>↑</u> <u>↑</u> <u>↑</u>	1-476-332-11 1-476-332-21 1-476-332-31 1-476-332-41 1-569-007-11	ADAPTOR, AC (AC-LSI) (US, CND, JE, J) ADAPTOR, AC (AC-LSI) (CN) ADAPTOR, AC (AC-LSI) (KR) ADAPTOR, AC (AC-LSI) (AEP, UK, E, HK, AUS) ADAPTOR, CONVERSION (E)
<u>↑</u>	1-569-008-21 1-696-819-11 1-757-293-11 1-769-608-11 1-776-985-11	ADAPTOR, CONVERSION 2P (E) CORD, POWER (AUS) CORD, CONNECTION (USB 5P) CORD, POWER (AEP, E) CORD, POWER (KR)
<u>↑</u>	1-782-476-11 1-783-374-11 1-783-738-31 1-790-107-22 1-790-732-11	CORD, POWER (CN) CORD, POWER (UK, HK) CORD, CONNECTION (AV CONNECTING) CORD, POWER (US, CND) CORD, POWER (JE, J)
	3-050-664-11 3-065-665-01	STRAP, HAND MANUAL, INSTRUCTION (for SAFETY) (JAPANESE) (JE, J)
	3-066-676-01 3-066-677-01 3-068-191-01	SPVD-004 (P) (CD-ROM) (AEP, UK, E, HK, KR, AUS, CN) SPVD-004 (I) (CD-ROM) (US, CND, JE, J) PC INSTRUCTION MANUAL (JAPANESE) (JE, J)
	3-070-845-01 3-070-925-01 3-070-925-11 3-070-925-21	REGISTRATION (CD-ROM) (JE, J) MANUAL, INSTRUCTION (JAPANESE) (JE, J) MANUAL, INSTRUCTION (ENGLISH) (US, CND, AEP, UK, E, HK, AUS, CN) MANUAL, INSTRUCTION (FRENCH, GERMAN)
	3-070-925-31	(CND, AEP) MANUAL, INSTRUCTION (SPANISH, PORTUGUESE) (AEP, E)
	3-070-925-41	MANUAL, INSTRUCTION (ITALIAN, DUTCH) (AEP)
	3-070-925-51	MANUAL, INSTRUCTION (TRADITIONAL CHINESE, SIMPLIFIED CHINESE) (E, HK, CN)
	3-070-925-61	MANUAL, INSTRUCTION (RUSSIAN, SWEDISH) (AEP)
	3-070-925-71 3-070-925-81	MANUAL, INSTRUCTION (ARABIC) (E) MANUAL, INSTRUCTION (KOREAN) (KR)
	A-7096-900-A	CLUB 2 (JA) ASSY, PICTURE PARADISE (JE, J)

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT

Take a copy of CAMERA COLOR REPRODUCTION FRAME with a clear sheet for use.

For NTSC mode



DSC-P5

DSC-P5

DSC-P5

SONY®

SERVICE MANUAL

Level 2

2001.12

US Model
Canadian Model
AEP Model
UK Model
E Model
Hong Kong Model
Australian Model
Chinese Model
Korea Model
Tourist Model
Japanese Model

SUPPLEMENT-1

File this supplement with the service manual. (PV01-042)

• Change of Lens Block Assy.

SERVICE NOTE

• NOTE FOR REPAIR

[Precaution on Replacing the Video Lens or the SY-69 Board]

The DSC-P5 uses the position sensor to detect the zoom position. Accordingly, the zoom position will vary if the position data changes due to the replacement of the video lens or the SY-69 board, thus causing the video lens to collide against the mechanism end when the power is turned off.

Though the position data is calibrated at the "Flange Back Adjustment", add the following work when making an adjustment at the replacement of video lens to prevent a collision of video lens.

When Replacing the Video Lens


- With current video lens assembled, turn the power on, and set the bit value of Bit0 on Page:9, Address:65 to "0" using the adjusting remote commander, then turn the power off.
- Replace the video lens with a new one, turn the power on, and perform the "Flange Back Adjustment".
 Thus, new position data will be written.
- After the "Flange Back Adjustment", return the bit value of Bit0 on Page:9, Address:65 to "1" using the adjusting remote commander.

When Replacing the SY-69 Board

- 1) Replace the SY-69 board with a new one, set the mode dial to "PLAY", turn the power on, and set the bit value of Bit0 on Page:9, Address:65 to "0" using the adjusting remote commander, then turn the power off.
- Set the mode dial to "CAMERA", turn the power on, and perform the "Flange Back Adjustment".
 Thus, new position data will be written.
- After the "Flange Back Adjustment", return the bit value of Bit0 on Page:9, Address:65 to "1" using the adjusting remote commander.

[Note in Lens Frame Installation]


When tightening a screw, have both sides of the lens block assembly so as not for the load to depend.



SECTION 4 PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

CD-340 (CCD IMAGER) SCHEMATIC DIAGRAM



Precautions for Replacement of CCD Imager

- The CD-340 board mounted as a repair part is not equipped with a CCD imager.
 - When replacing this board, remove the CCD imager from the old one and mount it onto the new one.
- If the CCD imager has been replaced, carry out all the adjustments for the camera section.
- As the CCD imager may be damaged by static electricity from its structure, handle it carefully like for the MOS IC.
 In addition, ensure that the receiver is not covered with dusts nor exposed to strong light.

SECTION 5 ADJUSTMENTS

1-1. Adjusting items when replacing main parts and boards

When replacing main parts and boards, adjust the items indicated by ● in the following table.


		Replaced parts													
		Block Mounted parts					ts								
		re		eme	ent					ment					
											ator)				
				(LCD panel)	(Back light unit)	(CCD imager)	(S/H, AGC, A/D)	(EVR)	(VIDEO AMP)	(LCD drive)	(LCD Timing generator)	(EVR)			EEPROM
Adjustment section	Adjustment				(B	(C	(S)	(E	8		(L	Œ	(LETE	(LETE	田田
		e)		LCD901	D9001	IC501	IC102	IC506	IC601	IC801	IC804	IC802	(COMPLETE)	(COMPLETE)	IC503
		ns (Not	ıt.	ck	ck	board	oard	oard	oard	oard	oard	oard	oard	oard	oard
		Video lens (Note)	Flash unit	LCD block	LCD block	CD-340 board	SY-69 board	SY-69 board	SY-69 board	SY-69 board	SY-69 board	SY-69 board	ST-67 board	SY-69 board	SY-69 board
Initialization of 7, 9,	Initialization of D page data	Т				Т								•	•
B, D, E, F, page data	Initialization of B, E, F, 7, 9 page data													•	•
Video	Video sync level adj.							•				•	•		
	Video burst level adj.							•	•					•	•
Camera	Flange back adj.	•				•								•	•
	F No. standard data input	•				•								•	•
	Mechanical shutter adj.	•				•								•	•
	Light value adj.	•				•	•								•
	Auto white balance standard data input	•				•	•							•	•
	Auto white balance adj.	•				•	•							•	•
	Color reproduction adj.	•				•	•							•	•
	CCD (white and black) defect compensation					•								•	•
	Strobe white balance adj.		•			•	•						•	•	•
LCD	LCD initial data input													•	•
	VCO adj.										•	•		•	•
	Black limit adj.									•		•		•	•
	Bright adj.									•		•		•	•
	Contrast adj.									•		•		•	•
	Color adj.									•		•		•	•
	PSIG adj.									•		•		•	•
	VG center adj.									•		•		•	•
	V-COM adj.			•						•		•		•	•
	White balance adj.			•	•					•		•		•	•
System control	Battery down adj.													•	•

Table 5-1-1

Note : When replacing the video lens or the SY-69 board, refer to "Precaution on Replacing the Video Lens or the SY-69 board". (See page 2)

SECTION 6 REPAIR PARTS LIST

6-1. EXPLODED VIEWS 6-1-3. LENS BLOCK AND LCD SECTION



: BT101 (BATTERY, LITHIUM SECONDARY)
Board on the mount position.
(See original manual page 4-40.)

(Note 2) Be sure to read "Precuations for Replacement of CCD Imager" on page 3 in this supplement manual when changing the CCD imager.

(Note 1) Refer to page 2 when installing the lens frame to the lens block assembly.

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque ∆ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>
101	A-7074-984-A	SY-69 BOARD, COMPLETE (SERVICE)	
102	3-713-791-71	SCREW (M1.7X4)	
103	3-071-017-01	SHEET (STROBOSCOPE), INSULATING	ì
104	A-7074-974-A	ST-67 BOARD, COMPLETE	
105	3-071-035-01	FRAME, LENS (Note 1)	
106	3-071-020-01	SHEET (LCD), LIGHT INTERCEPTION	
107	3-989-735-51	SCREW (M1.7), LOCK ACE, P2	
108	3-071-019-01	SHEET, PROTECTION	
109	1-758-665-11	LENS, VIDEO (CE010A0)	
110	3-064-216-01	CUSHION (L)	
111	3-064-215-01	SCREW (M1.7), STEP	

Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>
112	3-070-998-01	CUSHION (LCD), INTERCEPTION	
113	1-758-633-12	FILTER BLOCK, OPTICAL	
114	3-070-143-01	PLATE, LIGHT INTERCEPTION	
115	3-054-555-01	RUBBER (K), SEAL	
116	3-070-996-01	SHEET (LENS MOTOR), PROTECTION	
117	A-7074-975-A	CD-340 BOARD, COMPLETE	
118	3-713-791-11	SCREW (M17.X5), TAPPING, P2	
△ D901	1-476-931-11	BLOCK LIGHT GUIDE PLATE (1.5)	
IC501	A-7031-134-A	CCD BLOCK ASSY (CCD IMAGER) (No	te 2)
LCD901	8-753-050-67	ACX309AK-1	

6-2. ELECTRICAL PARTS LIST

Ref. No.	Part No.	<u>Description</u>			<u>Remark</u>
	A-7074-975-A	CD-340 BOARD, 0			
		(IC501 is not in	(Ref.	No.: 2,00	00 Series) ete board)
		< CAPACITOR >			
C502 C503 C504 C505 C506	1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-162-915-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.1uF 0.1uF 0.1uF 0.1uF 10PF	10% 10% 10% 10% 0.5PF	16V 16V 16V 16V 50V
C508 C509	1-107-826-11 1-135-957-91	CERAMIC CHIP	0.1uF 10uF	10% 20%	16V 16V
		< IC >			
IC501	A-7031-134-A	CCD BLOCK ASS	Y (CCD IMA	GER) (No	ote)
		< TRANSISTOR >			
Q501 Q502	8-729-037-74 8-729-050-22	TRANSISTOR TRANSISTOR	UN9213J- 2SC4250 (` '	Y1)
		< RESISTOR >			
R501 R502 R503 R504 R505	1-216-810-11 1-216-826-11 1-216-805-11 1-216-857-11 1-216-827-11	METAL CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP	120 2.7K 47 1M 3.3K	5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W
R506	1-216-864-11	METAL CHIP	0	5%	1/16W
		< THERMISTOR >	•		
TH501	1-810-816-11	THERMISTOR, N	ΓC (1608)		

(Note) Be sure to read "Precuations for Replacement of CCD Imager" on page 3 in this supplement manual when changing the CCD imager.

SONY®

SERVICE MANUAL

Level 2

Ver 1.4 2002, 06

US Model
Canadian Model
AEP Model
UK Model
E Model
Hong Kong Model
Australian Model
Chinese Model
Korea Model
Tourist Model

SUPPLEMENT-2

File this supplement with the service manual.

(PV02-002)

· Change of the end number of the part.

6-1. EXPLODED VIEWS

6-1-2. CABINET (REAR) ASSEMBLY (See original service manual page 6-2.)

: Points changed portion.

Former type				New type					
Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>	Ref. No.	Part No.	Description	<u>Remark</u>		
51	1-476-875-11	SWITCH BLOCK, CONTROL		51	1-476-875- <u>12</u>	SWITCH BLOCK, CONTROL			

Revision History

Ver.	Date	History	Contents	S.M. Rev.
1.0	2001.09	Official Release	_	
1.1	2001.11	Correction (C1)	S.M. correction: Page 5-33, Page 5-34, Page 5-35	Yes
1.2	2001.12	Supplement-1 (S1 PV01-042)	Change of lens block assy.	No
1.3	2002.02	Correction (C2 PV01-055)	• Correction of DISASSEMBLY. (Correction of process.) S.M. correction: Page 2-1, Page 2-4	Yes
1.4	2002.06	Supplement-2 (S2 PV02-002)	Change of the end number of the part.	No
1.5	2003.01	Correction (C3)	• Correction of Flange Back Adjustment. S.M. correction: Page 5-16, Page 5-17	Yes