



“His Master’s Voice”

SERVICE MANUAL

for

FIVE-VALVE VIBRATOR POWERED BATTERY RECEIVERS

•

Dual-Wave - - - Model 329

Broadcast - - - Model 359

TECHNICAL SPECIFICATION

BATTERY

The battery required for the operation of this receiver is as follows:

One 6-volt 150-amp. hour accumulator.

The battery supplied with the receiver is already fully charged. This battery should be re-charged at least once monthly, or alternatively whenever the specific gravity as measured with a hydrometer falls below 1.140 or the voltage with the receiver in operation falls below 5.4 volts.

CONSUMPTION

The battery consumption of this model is approximately 1.0 amp. in normal operation.

SPEECH OUTPUT

Approximately 0.75 watts undistorted.

WAVE-LENGTH RANGE

187.5–545 metres (1600–550kc.).

*13.9–47 metres (21.57–6.38mc.).

*Model 329 only.

DIMENSIONS

Height	Width	Depth
35 $\frac{1}{4}$ "	29 $\frac{1}{2}$ "	13 $\frac{1}{2}$ "

WEIGHT

	Without Battery	With Battery
Nett	71 lbs.	—
Gross	82 lbs.	136 lbs.

VALVES

1C7G	Converter.
1D5G	1st I.F.
1F7G	2nd I.F. and Demodulator.
1F7G	1st AF and AVC.
1G5G	Power.

LOUDSPEAKER

The loudspeaker used is of the permanent magnetic type. It is a 10-inch model with a voice coil impedance at 400 cycles of 3.3 ohms.

CIRCUIT DESCRIPTION

This model embodies a 5-valve superheterodyne chassis comprising a Pentagrid converter followed by a two-stage I.F. amplifier. Demodulation is effected in the diode circuit at the last I.F. valve; the demodulated signal is then amplified by a duo-diode-pentode, one of the diodes of which supplies the AVC voltage; this valve is resistance-capacity coupled to a pentode which functions as output stage.

The valve filaments are connected in a series-parallel arrangement.

A split reed synchronous vibrator is used in the vibrator power supply circuit; this enables the output valve to be adequately biased by means of a resistor in the negative high tension lead; all other bias voltages are obtained from the filament circuits.

Coupling to the aerial on the broadcast band is effected through an iron-cored transformer having the normal tuned secondary.

The three I.F. transformers are permeability tuned and employ Litz wound coils with sliding iron cores. The AVC voltage is applied to the converter and I.F. valves. No AVC voltage is applied to the S.W. converter grid. Optimum delay voltage is provided for the AVC diode by means of filament voltage drop so that adequate power output may be obtained before the AVC system takes control.

Padding on the broadcast band is effected by adjustment of the oscillator secondary inductance by means of an adjustable iron core, in conjunction with a fixed padding condenser.

On the S.W. band no padding adjustment is required. All R.F. trimmers are of the air dielectric type, using a robust plunger type construction, which is entirely immune to change of capacity or detrimental atmospheric influence.

WAVE BAND SWITCHING (Model 329)

This is carried out by means of a two-position switch. The oscillator primary coils are connected in a series and are not switched; however, a little feed-back is applied across the padding condenser on the S.W. band, and this is switched in and out by contacts on the wave-change switch.

The first position of the switch (anti-clockwise) connects the short-wave coils and associate components in circuit, whilst the second position does the same with the broadcast band components.

TONE MONITOR

This is a four-position, single-deck switch, used as a combined tone control and battery switch.

1st Position.—Receiver switched off.

2nd Position (Normal).—Receiver on, maximum treble and bass note reproduction.

3rd Position (Bass).—Receiver on, high audio-frequency cut introduced.

4th Position (Speech).—Receiver on, low audio-frequency cut introduced.

DIAL LAMPS (6.3v. 0.15 amp.)

The dial lighting is controlled by a push button mounted on the side of the cabinet, which should be pressed during the process of tuning-in station. When released, this button will extinguish the dial lighting, thus saving unnecessary drain on the battery.

VIBRATOR CIRCUIT DESCRIPTION

The circuit of the vibrator unit used with this model is indicated on pages 4 & 5. This unit includes the vibrator itself, which is enclosed in a separate metal container arranged so that it can be plugged into or removed from a socket located in the vibrator unit

in a manner similar to a valve. The remainder of the vibrator unit consists of the necessary transformer and filters, the whole being contained in a metal box provided with rubber mounting buffers and coupled to the chassis and battery by means of a special plug and leads.

PRELIMINARY TESTS

1. Check over battery connections in accordance with the diagram on page 6.
2. Check over battery voltage as specified in paragraph headed "Batteries."
3. Remove fuse from A+ vibrator lead and check for continuity in the fuse.
4. Switch the receiver on by means of the combined battery and tone monitor switch, and, having removed the earth wire and turned the volume control to the maximum position, touch the finger to the grid of the second 1F7G valve (1st AF). A loud hum should be heard; this denotes that the audio frequency side of the receiver is functioning and the fault probably lies in the valves or associate circuits ahead of this position. Should no hum be heard, the fault will have developed between the first audio and output stage.
5. Check all valves for filament continuity and freedom from internal shorts.
6. To determine if the fault lies in the loudspeaker, connect a high-impedance A.C. voltmeter or output meter, with a range of approximately 0-3 volts, across the voice coil terminals on the speaker. With the receiver switched on and adjusted for the broadcast band, turn the volume control fully on and rotate the tuning control. If no deflection is given by the meter the fault lies in the receiver chassis. If a deflection is obtained, but no audible sound, the loudspeaker is at fault.
7. If the fault is still undiscovered, remove the chassis and loudspeaker from the cabinet and compare voltages with the voltage table given below.

DISMANTLING

REMOVAL OF CHASSIS

1. Remove knobs.
2. Disconnect loudspeaker and battery plugs.
3. Remove the two leads from the pilot lamp switch on the side of the cabinet.
4. Remove two fixing bolts from underside of the shelf; the chassis is now free.

REMOVAL OF LOUDSPEAKER


1. Remove speaker plug from receiver chassis.
2. Remove four screws holding speaker chassis and remove speaker.

VOLTAGE TABLE


Values given are $\pm 10\%$ with receiver tuned to a point of no reception and a low tension battery voltage of 6 volts. Bias voltages are measured between the negative side of filament and chassis. Note that the 1G5G valve (V5) bias of 14 volts is obtained from the voltage drop across the two smoothing chokes and 200 ohm resistor connected in series in the negative side of the high-tension circuit. Since this bias voltage is decoupled by means of a $\frac{1}{2}$ megohm resistor in the vibrator chassis it is not possible to measure it at the receiver, but only at the vibrator unit.

If a voltmeter with an internal resistance of less than 1000 ohms per volt is utilised, allowance must be made for the voltage drop caused by the voltmeter.

	V1 1C7G	V2 1D5G	V3 1F7GV	V4 1F7GV	V5 1G5G
Plate to Chassis Volts	140	140	138	42	136
Screen to Chassis Volts	28	42	42	30	140
Oscillator Plate to Chassis Volts	{ BC 95 SW 110	—	—	—	—
Bias Voltage		4	2	2	14
Filament Voltages	2	2	2	2	2

[illegible]

Dual-wave Model 329.



REF ID	REF NAME	REF TYPE	REF VALUE
12	APC 12	APC 12	APC 12
13	APC 13	APC 13	APC 13
14	APC 14	APC 14	APC 14
15	APC 15	APC 15	APC 15
16	APC 16	APC 16	APC 16
17	APC 17	APC 17	APC 17
18	APC 18	APC 18	APC 18
19	APC 19	APC 19	APC 19
20	APC 20	APC 20	APC 20
21	APC 21	APC 21	APC 21
22	APC 22	APC 22	APC 22
23	APC 23	APC 23	APC 23
24	APC 24	APC 24	APC 24
25	APC 25	APC 25	APC 25
26	APC 26	APC 26	APC 26
27	APC 27	APC 27	APC 27
28	APC 28	APC 28	APC 28
29	APC 29	APC 29	APC 29
30	APC 30	APC 30	APC 30
31	APC 31	APC 31	APC 31
32	APC 32	APC 32	APC 32
33	APC 33	APC 33	APC 33
34	APC 34	APC 34	APC 34
35	APC 35	APC 35	APC 35
36	APC 36	APC 36	APC 36
37	APC 37	APC 37	APC 37
38	APC 38	APC 38	APC 38
39	APC 39	APC 39	APC 39
40	APC 40	APC 40	APC 40
41	APC 41	APC 41	APC 41
42	APC 42	APC 42	APC 42
43	APC 43	APC 43	APC 43
44	APC 44	APC 44	APC 44
45	APC 45	APC 45	APC 45
46	APC 46	APC 46	APC 46
47	APC 47	APC 47	APC 47
48	APC 48	APC 48	APC 48
49	APC 49	APC 49	APC 49
50	APC 50	APC 50	APC 50
51	APC 51	APC 51	APC 51
52	APC 52	APC 52	APC 52
53	APC 53	APC 53	APC 53
54	APC 54	APC 54	APC 54
55	APC 55	APC 55	APC 55
56	APC 56	APC 56	APC 56
57	APC 57	APC 57	APC 57
58	APC 58	APC 58	APC 58
59	APC 59	APC 59	APC 59
60	APC 60	APC 60	APC 60
61	APC 61	APC 61	APC 61
62	APC 62	APC 62	APC 62
63	APC 63	APC 63	APC 63
64	APC 64	APC 64	APC 64
65	APC 65	APC 65	APC 65
66	APC 66	APC 66	APC 66
67	APC 67	APC 67	APC 67
68	APC 68	APC 68	APC 68
69	APC 69	APC 69	APC 69
70	APC 70	APC 70	APC 70
71	APC 71	APC 71	APC 71
72	APC 72	APC 72	APC 72
73	APC 73	APC 73	APC 73
74	APC 74	APC 74	APC 74
75	APC 75	APC 75	APC 75
76	APC 76	APC 76	APC 76
77	APC 77	APC 77	APC 77
78	APC 78	APC 78	APC 78
79	APC 79	APC 79	APC 79
80	APC 80	APC 80	APC 80
81	APC 81	APC 81	APC 81
82	APC 82	APC 82	APC 82
83	APC 83	APC 83	APC 83
84	APC 84	APC 84	APC 84
85	APC 85	APC 85	APC 85
86	APC 86	APC 86	APC 86
87	APC 87	APC 87	APC 87
88	APC 88	APC 88	APC 88
89	APC 89	APC 89	APC 89
90	APC 90	APC 90	APC 90
91	APC 91	APC 91	APC 91
92	APC 92	APC 92	APC 92
93	APC 93	APC 93	APC 93
94	APC 94	APC 94	APC 94
95	APC 95	APC 95	APC 95
96	APC 96	APC 96	APC 96
97	APC 97	APC 97	APC 97
98	APC 98	APC 98	APC 98
99	APC 99	APC 99	APC 99
100	APC 100	APC 100	APC 100

RADIO FREQUENCY TESTS AND ADJUSTMENTS

Instability, insensitivity or poor selectivity may indicate that the alignment of the tuned circuits is not correct. If a coil or other component associated with the H.F. or I.F. side of the receiver has been replaced or repaired, or if the wiring has been disarranged, all circuits must be realigned.

To do this, the following apparatus is required:

1. An oscillator or signal generator capable of tuning to 1600kc., 1500kc., 600kc., 460kc., 13.9 metres and 15 metres, suitably screened and with an attenuator.
2. An output meter having a range of 0-2 volts A.C. approximately.


I.F. alignment should always precede H.F. alignment, and even if only one coil or one range of coils has been serviced, the whole of the realignment should be done in the order given, i.e., broadcast band first followed by short-wave band.

In carrying out the following operations, it is important that the input to the receiver from the oscillator should be kept low and progressively reduced as the circuits are brought into line, so that the reading on the output meter does not exceed about 0.5 volt.

For all alignment operations the output meter should be connected across the loudspeaker voice coil.

I.F. ALIGNMENT

The following sketches show the layout of all principal components and adjustments referred to in the following procedure:




Dual-wave Model 329

Before commencing alignment, it is imperative that the tone monitor should be set to its second position, i.e., "Normal."

Rotate the volume control fully clockwise and set wave-change switch to broadcast band position; make sure that the vanes of the tuning condenser

are fully meshed; connect the output leads of the signal generator to the grid cap of the 1C7G valve through a 0.1 mfd. condenser and to the chassis.

(NOTE.—Do not disconnect the grid lead from the 1C7G grid.)



Broadcast Model 359

1. Tune signal generator to exactly 460kc.
2. Adjust the trimmer screws on the I.F. transformers (the top screw is the secondary and the bottom screw the primary in all three transformers) for maximum deflection of the output meter. Continue this alignment on each transformer in turn until no greater output can be obtained.

(NOTE.—If trimmer screws are screwed in too far, it may be possible to obtain a false peak due to coupling effects between the movable iron cores. Any trimmer which appears to require screwing too far in should be screwed out considerably and the true peak will then be found.)

R.F. ALIGNMENT

With controls set as for I.F. alignment, connect the signal generator output leads through a standard dummy antenna of 200 mmfd. capacity to the aerial terminal and chassis.

Check that when the ganged condenser is fully meshed the pointer falls directly over the setting line marked "S" at the extreme bottom right of the scale; the pointer is a friction fit on the condenser spindle, and can be rotated to bring it to the correct setting.

1. Tune signal generator to 600kc.
2. Rotate tuning knob until pointer is exactly over 600kc. mark on scale, and by means of padding adjustment (brass screw to left of gang condenser) align receiver so that 600kc. signal is tuned in exactly on line.
3. Tune signal generator to 1600kc.

4. Set pointer exactly over 1600kc. point on scale and adjust B.C. oscillator trimmer until signal is correctly tuned in with the pointer on the 1600kc. line.
5. Tune signal generator and receiver to 1500kc.
6. Adjust aerial trimmer for maximum output as shown on the output meter.
7. Repeat operations 1-6 inclusive. **THIS IS IMPORTANT.** Note that any broadcast stations receivable are tuned-in correctly on calibration.

SHORT-WAVE ALIGNMENT (Model 329)

1. Set wave-change switch to SW range (fully anti-clockwise). Remove the standard dummy antenna from the output lead of the signal generator and substitute a 400-ohm non-inductive resistor; connect to aerial terminal as previously.
2. Tune signal generator to 13.9 metres (21.75mc.).
3. Rotate tuning knob until pointer is over 13.9 metres, and adjust S.W. oscillator trimmer until maximum output is obtained with pointer exactly on the 13.9 metre mark. Two settings will be found at which trimmer will peak; care should be taken to see that the setting finally selected is that which gives the lower capacity in the trimmer (plunger further out). Failure to select the

correct position will cause serious tracking error and loss of sensitivity.

4. Tune receiver and signal generator to 15 metres (20mc.).
5. Adjust the SW detector and aerial trimmers in turn for maximum output while "rocking" the ganged condenser to obtain the correct resonant point.
6. Check the foregoing adjustments to ensure that the correct settings have been obtained in all trimmers.

NOTE.—The R.F. trimmers on this model are of plunger type with air dielectric, and possess exceptionally high stability and efficiency. A special adjusting tool can be obtained from the factory incorporating a box spanner for the condenser locknut, and adjusting hook for the plunger. After loosening the large locknut at the top of the condenser, the adjusting hook is inserted in the hole which will be found in the top of the plunger, which can then be easily adjusted by moving up or down as required with a slight rotary movement. When adjustment is completed, tighten the locknut securely.

ADDITIONAL DATA

Any further service information desired can be obtained by addressing an inquiry to The Service Department, The Gramophone Co. Ltd., 2 Parramatta Road, Homebush, N.S.W.