



CM1812 / KMS0912(×2)

SPLIT SYSTEM AIR CONDITIONER

Indoor Unit



Outdoor Unit



CM1812

SERVICE MANUAL

CM1812 / KMS0912(×2)

(Expanded Information)

IMPORTANT! Please Read Before Starting

This air conditioning system meets strict safety and operating standards. As the installer or service person, it is an important part of your job to install or service the system so it operates safely and efficiently.

For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning
- Follow each installation or repair step exactly as shown
- Observe all local, state, and national electrical codes
- Pay close attention to all warning and caution notices given in this manual



This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If Necessary, Get Help

These instructions are all you need for most installation sites and maintenance conditions. If you require help for a special problem, contact our sales/service outlet or your certified dealer for additional instructions.

In Case of Improper Installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

SPECIAL PRECAUTIONS

When Wiring

ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause accidental injury or death.
- Ground the unit following local electrical codes.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.

When Transporting

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminum fins on the air conditioner can cut your fingers.

When Installing...

...In a Ceiling or Wall

Make sure the ceiling/wall is strong enough to hold the unit's weight. It may be necessary to construct a strong wood or metal frame to provide added support.

...In a Room

Properly insulate any tubing run inside a room to prevent "sweating" that can cause dripping and water damage to walls and floors.

...In Moist or Uneven Locations

Use a raised concrete pad or concrete blocks to provide a solid, level foundation for the outdoor unit. This prevents water damage and abnormal vibration.

...In an Area with High Winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

...In a Snowy Area (for Heat Pump-type Systems)
Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

When Connecting Refrigerant Tubing

- Keep all tubing runs as short as possible.
- · Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them, then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.

NOTE:

Depending on the system type, liquid and gas lines may be either narrow or wide. Therefore, to avoid confusion the refrigerant tubing for your particular model is specified as either "narrow" or "wide" rather than as "liquid" or "gas."

When Servicing

- Turn the power OFF at the main power box (mains) before opening the unit to check or repair electrical parts and wiring.
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after you finish, remembering to check that no metal scraps or bits of wiring have been left inside the unit being serviced.

Table of Contents

		Page
1.	SPECIFICATIONS	
	1-1 Unit Specifications	1
	(1) CM1812	1
	(2) Applicable Indoor Unit	2
	1-2 Major Component Specifications	3
	(1) Outdoor Unit	3
	(2) Indoor Unit	4
	1-3 Other Component Specifications	5
	(1) Outdoor Unit	5
	(2) Indoor Unit	5
2.	PERFORMANCE CHARTS	
	2-1 Operating Current	6
	2-2 High and Low Pressure	7
3.	AIR THROW DISTANCE CHART	8
4.	FUNCTION	
	4-1 Room Temperature Control	9
	4-2 Freeze Prevention	10
	4-3 Fan Speed Auto (Indoor Fan)	10
5.	ELECTRICAL DATA	
	● Schematic Diagram	11
	• Electric Wiring Diagram (PCB Ass'y)	12
6.	TROUBLESHOOTING	
	6-1 Check before and after troubleshooting.	14
	(1) Check power supply wiring	14
	(2) Check inter-unit wiring	14
	(3) Check power supply	14
	(4) Check lead wires and connectors in indoor and outdoor units	14
	(5) Reference	15
	(a) Condition of general cooling operation	

6-2	Air conditioner does not operate	16
	(1) Circuit breaker trips (or fuse blows)	16
	(a) When circuit breaker is set to ON, it trips in a few moments	
	(b) Circuit breaker trips in several minutes after turning air conditioner ON	
	(2) All units (indoor and outdoor) do not run	18
	(a) Power is not supplied	
	(b) Check OPERATION selector switch in indoor unit	
	(c) Check fuse F1 in indoor unit	
	(3) Neither indoor unit A nor compressor motor A runs	20
	(a) Check transformer in indoor unit A (or B)	
	(b) Check fuse on PCB Ass'y in indoor unit A (or B)	
6-3	A particular component of air conditioner does not operate	22
	(1) Only compressor motor A does not run (or B)	22
	(2) Only indoor fan does not run	23
	(3) Only outdoor fan does not run	23
6-4	Air conditioner operates, but abnormalities occur	24
	(1) Poor Cooling	24
	(2) Excessive Cooling	25
6-5	Indoor (heat exchanger) coil temperature sensor (TH1) is defective	25
	(1) Open	25
	(2) Shortage	25
	ECKING ELECTRICAL COMPONENTS	
7-1	Measurement of Insulation Resistance	26
	(1) Power Supply Wires	26
	(2) Indoor Unit	26
	(3) Outdoor Unit	26
	(4) Measurement of Insulation Resistance for Electrical Parts	26
	Checking Continuity of Fuse on PCB Ass'y	27
	Checking Motor Capacitor	27
7-4	Appearance of Electrical Parts	28
	(1) Auxiliary Relay	28
	(2) Relay	28

1. SPECIFICATIONS

1-1 Unit Specifications

(1) CM1812

M - J - J	NT -	Outdoor unit		СМ	11812
Model No. Applicable indoor unit			oor unit	KM	S0912
300				Co	oling
maı	No. of indoor units			1	2
Performance	Canacity		BTU/h	9,000 / 8,800	18,000 / 17,600
Pe	Capacity		kW	2.64 / 2.58	5.27 / 5.16
i	Phase, Frequency		Hz	Single, 60	Single, 60
ba	Voltage rating		V	230 / 208	230 / 208
atin	Available voltage rang	e	V	187 to 253	187 to 253
Electrical Rating	Running amperes		A	4.3 / 4.5	8.6 / 9.0
Hics	Power input		W	930 / 910	1,860 / 1,820
lect	Power factor		%	94 / 97	94 / 97
Щ	Starting amperes		A	27	27 × 2
	S. E. E. R.		BTU/Wh	10.0 / 10.0	10.0 / 10.0
	Fan speeds	• 1		AND AND ADDRESS OF THE PROPERTY OF THE PROPERT	1
	Compressor		-	Ro	tary
	Refrigerant amount ch	arged at shipment	lbs. (kg)		< 2 (980 × 2)
	Refrigerant control			Capilla	ary tube
	Operation sound	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	dB-A		54
ည်	Refrigerant tubing con	nections			е туре
Features	Max. allowable tubing		ft. (m)	33	(10)
F.	i		ft. (m)	50 (15)	
	Limit of elevation difference ft. (i between the 2 units		ft. (m)	23 (7)	
		Narrow tube	in. (mm)	1/4 (6.35)	
	Refrigerant tube o.d.	Wide tube	in. (mm)	3/8 ((9.52)
	Refrigerant tube kit			Optional	
	Height		in. (mm)	24-13/	16 (630)
જું	Width		in. (mm)	32-11/	16 (830)
ght	Depth		in. (mm)	12-13/	32 (315)
Dimensions & Weight	Net weight	•••••	lbs. (kg)	130 (58.96)
Ö.	Shipping volume		cu. ft. (cu. m)	10.34	(0.96)
	Shipping weight (Appr	rox.)	lbs. (kg)	136.4	(61.9)

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are: Outside air temperature 95°F DB/75°F WB

Indoor unit entering air temperature 80°F DB/67°F WB

(2) Applicable Indoor Unit

Model	No.			KMS0912
Type				Wall-mounted
43			11 To Call State State Control of the Control of th	Cooling
Performance			BTU/h	9,000 / 8,800
Ē	Capacity		kW	2.64 / 2.58
erfc	Air circulation (High)		cu. ft./min.	220 / 210
14	Moisture removal (High	1)	pints/h	2.2 / 2.1
cal 1g	Phase, Frequency		Hz	Single, 60
Electrical Rating	Voltage rating		V	230 / 208
Ele R	Available voltage range	:	V	187 to 253
	Controls			Microprocessor
	Control unit			Wireless remote control unit
	Temperature control			IC thermostat
	Timer			ON/OFF, 24-hours & Program
	Fan speeds			3
es	Air deflector	Hori	zontal / Vertical	Manual / Manual
Features	Air filter			Washable, easy access
굕	Operation sound	Hi / Me / Lo	dB-A	45 / 35 / 30
	Refrigerant tubing connections			Flare type
	Deficement who and	Narrow tube	in. (mm)	1/4 (6.35)
	Refrigerant tube o.d.	Wide tube	in. (mm)	3/8 (9.52)
!	Refrigerant tube kit			Optional
	Accessories			Hanging wall bracket
	Height in. (mm)		in. (mm)	13-19/32 (345)
s &	Width in. (mm)		in. (mm)	31-1/2 (800)
ion ight	Depth		in. (mm)	7-3/32 (180)
Dimensions & Weight	Net weight		lbs. (kg)	24 (11)
Din	Shipping volume		cu. ft. (cu. m)	3.3 (0.093)
	Shipping weight		lbs. (kg)	29 (13)

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are: Outside air temperature 95°F DB/75°F WB

Indoor unit entering air temperature 80°F DB/67°F WB

1-2 Major Component Specifications

(1) Outdoor Unit

Unit M	lodel No.				CM	11812	
Fuse					AC 2	50V, 3A	
	Type				Rotary	(hermetic)	
	Model Number				C-R70H6V 2		
	No. of cyl rpm				1	. 3,500	
	Nominal output		W (H.P.)	700	(1)×2		
	Compres	sor lubricant		cc	50	00 × 2	
	Coil resis	tance		Ω	C -	R: 2.51	
jo	(Ambient	(Ambient temp. 77°F)			C – S: 5.58		
Compressor		Туре			Internal	External	
duc		Overload re	lay models			MRA98735-9201 × 2	
Ŭ	Safety	Operating		°F	- Management	311 ± 9	
	devices	temp.	Close	°F		156 ± 20	
		Operating a (Ambient te	mp. emp. 77°F)			Trip in 6 to 16 sec. at 24A	
	D			μF	17.	.5 × 2	
		VAC VAC			370		
	Crank cas						
Fan	Туре				Pro	peller	
иц.	Number .	Dia.		in. (mm)	1 15	-3/4 (400)	
	Model					S-51C6P	
	No. of po	le rpm (230)V, High)		6	990	
	Nominal	output		W (H.P.)	50	(1/15)	
	Coil resistance			Ω	WHT – C	GRY: 89.9	
otor	(Ambient temp. 68°F)				YEL: 180.0		
Fan Motor					WHT – F	PNK: 155.8	
Fan		Туре			Int	ernal	
	Safety device	Operating	Open	°F	266 ± 14		
į	301100	temp.	Close	°F	174	1 ± 27	
	Run capa	citor		μF		2	
	Kun capa			VAC	4	140	
	Coil				Aluminum plate	e fin / Copper tube	
Heat Exch.	Rows	Fins per inch				. 14.1	
	Face area			ft. ² (m ²)		(0.48)	
Externa	al Finish				Acrylic baked-	on enamel finish	

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

(2) Indoor Unit

Unit M	Iodel No.				KMS0912	
Remote Control Unit			RCS-KS0911			
19 EF				POW-KS0911		
Controller PCB	Control c	ircuit fuse	•••••		AC 250V, 3A	
Fan	Туре				Cross-flow	
强	Noumber	Dia. and le	ngth	in. (mm)	1 O.D. 3-17/32 (90), L 24-5/8 (626)	
	Model	Number			SV4T-11D6P 1	
	No. of po	le rpm (230	V, High)		4 1,450	
	Nominal	output		W(H.P.)	10 (1/75)	
	Coil resis	tance		Ω	WHT – GRY: 464.8	
<u> </u>	(Ambient temp. 68°F)				WHT - VLT: 209.8	
10tc					VLT – YEL: 93.4	
Fan Motor					YEL - PNK: 539.6	
此	Туре				Internal	
	Safety devices	Operating	Open	°F	266 ± 14	
		temp.	Close	°F	174 ± 27	
	D.,,,	-		μF	0.6	
	Run capa	citor		VAC	440	
	Coil				Aluminum plate fin / Copper tube	
Heat Exch.	Rows	Fins per inch			2 14.1	
_ н	Face area	· • • • · · · · · · • • • • · · · · · ·		ft. ² (m ²)	1.63 (0.15)	

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

1-3 Other Component Specifications

(1) Outdoor Unit

Auxiliary Relay		MY2F-T1-USTS
Coil rating		AC 240V, 60Hz
Coil resistance	kΩ (at 77°F)	18.8 ± 15%
Contact rating		AC 240V, 5A

(2) Indoor Unit

Transformer		ATR-H122U
Rated	Primary	AC 220V, 60Hz
	Secondary	10V, 1.2A
	Capacity	12VA
Coil resistance	Ω (at 77°F)	Primary (WHT – WHT): 146 ± 15%
		Secondary (BRN – BRN): $0.5 \pm 15\%$
Thermal cut-off temp.		259°F, 2A, 250V

Relay		DFU12D1-F(M)
Coil rating		DC 12V
Coil resistance	Ω (at 68°F)	$160 \pm 10\%$
Contact rating		AC 250V, 20A

Thermistor (coil sense	эг)		PBC-41I	E-S4	
Resistance	kΩ	14°F	23.7 ± 5%	77°F	5.3 ± 5%
		32°F	$15.0 \pm 5\%$	86°F	$4.4 \pm 5\%$
		50°F	$9.7 \pm 5\%$	104°F	$3.1 \pm 5\%$
		68°F	$6.5 \pm 5\%$		


Thermistor (room sen			SDT-500	B6-2	
Resistance	kΩ	50°F	$10.3 \pm 4\%$	86°F	$4.0 \pm 4\%$
		59°F	$8.0 \pm 4\%$	104°F	$2.6 \pm 4\%$
		68°F	$6.3 \pm 4\%$	122°F	$1.8 \pm 4\%$
	•	77°F	$5.0 \pm 4\%$		

2. PERFORMANCE CHARTS


2-1 Operating Current

Operating current characteristics versus outdoor ambient temperature and indoor temperature (Indoor relative humidity: 50%, Indoor fan speed: High)

230V



208V




2-2 High and Low Pressure

• High Pressure

High pressure characteristics versus outdoor ambient temperature and indoor temperature (Indoor relative humidity: 50%, Indoor fan speed: High)


230V / 208V



• Low Pressure


Low pressure characteristics versus outdoor ambient temperature and indoor temperature (Indoor relative humidity: 50%, Indoor fan speed: High)

230V / 208V



3. AIR THROW DISTANCE CHART


Model: KMS0912



4. FUNCTION

4-1 Room Temperature Control


- Room temperature control is obtained by cycling the compressor ON and OFF under control of the room temperature sensor in the remote control unit.
- The room temperature (and other information) is transmitted every 3 minutes by the remote control unit to the controller in the indoor unit.



- The control circuit will not attempt to turn the compressor ON until the compressor has been OFF for at least 3 minutes. To protect the compressor from stalling out when trying to start against the high side refrigerant pressure, the control circuit has a built-in automatic time delay to allow the internal pressure to equalize.
- As a protective measure, the control circuit switches the compressor OFF after 5 minutes or more of compressor operation.
- Thermo ON : When the room temperature is above $T + 2^{\circ}F$ ($T^{\circ}F$ is set temperature). Compressor \rightarrow ON
- Thermo OFF: When the room temperature is equal to or below set temperature T°F.
 Compressor → OFF


4-2 Freeze Prevention

- This function prevents freezing of the indoor heat exchange coil.
- When the compressor has been running for 10 minutes or more and the temperature of the indoor heat exchange coil falls below 27°F, the control circuit stops the compressor for at least 6 minutes.



4-3 Fan Speed Auto (Indoor Fan)

- The fan speed does not change within 1 minute.
- The number shows temperature for REMOCON sensor.





5. ELECTRICAL DATA

• Schematic Diagram

CM1812 / KMS0912 (×2)

Symbol	Description
OUTDOOR UNIT	, , , , , , , , , , , , , , , , , , ,
FMO	OLTDOOR FAN MOTOR
49F0	OLTDOOR FAN MOTOR INTERNAL PROTECTOR
OLR, A, OLR, B	CCMPRESSOR MOTOR OVERLOAD RELAY
CMA, CMB	CCMPRESSOR MOTOR
CA, CB, CC	CAPACITOR
RA, RB	RELAY
E	FUSE 250V, 3A
INDOOR UNIT	
FMI	INDOOR FAN MOTOR
49H	INDOOR FAN MOTOR INTERNAL PROTECTOR
O	CAPACITOR
TR	TRANSFORMER
RY	POWER RELAY
THI	THERMISTOR (COIL TEMP. SENSOR)
TH2	THERMISTOR (ROOM TEMP. SENSOR)
SW ASSY	SWITCH ASS'Y SW-KS0911
RCS	WIRELESS REMOTE CONTROL UNIT RCS-KS0911
POW-KS0911	CONTROLLER PCB ASS'Y
ĹŦ.,	FUSE 250V, 3A
Λ	VARISTOR
ВД	BRIDGE DIODE
ū	CAPACITOR
R1	RESISTOR
RY1, RY2	AUXILJARY RELAY





POW-KS0911

Symbol	Description	Specifications	
BZ101	BUZZER	PKM24SP3807	
C1	CAPACITOR	2200μF 25V	
C2	CAPACITOR	1μF 50V	
C3	CAPACITOR	10μF 50V	
C5	CAPACITOR	1μF 50V	
C6	CAPACITOR	220μF 16V	
C7	CAPACITOR	1μF 50V	
C9	CAPACITOR	0.1μF 50V	
C10	CAPACITOR	0.00003μF 50V	
C11	CAPACITOR	0.00003μF 50V	
C12	CAPACITOR	0.022μF 50V	
C13	CAPACITOR	. 0.1μF 50V	
C14	CAPACITOR	100μF 10V	
C15	CAPACITOR	0.022μF 50V	
	CAI AUTOR		
C17	CAPACITOR	0.0047μF 50V	
C18	CAPACITOR	0.022μF 50V	
C19	CAPACITOR	0.022μF 50V	
C20	CAPACITOR	0.022μF 50V	
C21	CAPACITOR	0.1μF 50V	
CA1	CAPACITOR	0.0047μF-4 50V	
	CAFACITON	0.0047με-4 300	
	••••••••••••••••••	***************************************	
		<u> </u>	
D4	DIODE	DS446	
D5	DIODE	DS446	
D6	DIODE	DS446	
D7	DIODE	DS446	
D8	DIODE	DS446	
D9		······	
	DIODE	DS446 DS446	
D10 D11	DIODE	DS446	
DII	DIODE		
D13	DIODE	DS446	
• • • • • • • • • • • • • • • • • • • •	· • • • • • • • • • • • • • • • • • • •	DS446	
D14 D15	DIODE	DS446	
DSW1	SWITCH	SSGM 2P	
DSW1	SWITCH	JKS1120-0401	
DOVVZ	SWILCH	JNO1120-0401	
DB	BBIDGE DIONE	DRAIOC	
	BRIDGE DIODE FUSE	DBA10C 250V, 3A	
F		***************************************	
IC1	IC IC	LA5693D TMS73C161-C76577	
IC2	IC IC	LB1234	
		: 101204	
	TRANSISTOR	2SA1289	
Q1 Q2	TRANSISTOR	·····	
,	***************************************	2SC536-E 2SC536-E	
Q3	TRANSISTOR	. 20000°E	
		·	

POW-KS0911

Symbol	Description	Specif	Specifications		
R1	RESISTOR (CARBON)	5.6Ω	±5%	1/2W	
R2	RESISTOR (CARBON)	27ΚΩ	±5%	1/4W	
R5	RESISTOR (CARBON)	390Ω	±5%	1/4W	
	112001011(071112011)				
R7	RESISTOR (CARBON)	1ΚΩ	±5%	1/4W	
R8	RESISTOR (CARBON)		±5%	1/4W	
R9	RESISTOR (CARBON)	22ΚΩ	+5%	1/4W	
R10	RESISTOR (CARBON)		±5%	1/4W	
R11	RESISTOR (CARBON)	4.7ΚΩ	±5%	1/4W	
R12	RESISTOR (CARBON)	5.6ΚΩ	±5%	1/4W	
R13	RESISTOR (CARBON)		±5%	1/4W	
R14	RESISTOR (CARBON)		±5%	1/4W	
R15	RESISTOR (METAL)		±1%	1/4W	
R16	RESISTOR (METAL)		±1%	1/4W	
R17	RESISTOR (METAL)		±1%	1/4W	
R18	RESISTOR (METAL)		±1%	1/4W	
R19	RESISTOR (METAL)		±1%	1/4W	
R20	RESISTOR (METAL)		±1%	1/4W	
R21	RESISTOR (METAL)		±1%	1/4W	
R22	RESISTOR (METAL)		±1%	1/4W	
R23	RESISTOR (CARBON)		±5%	1/4W	
R24	RESISTOR (CARBON)		±5%	1/4W	
R25	RESISTOR (CARBON)		±5%	1/4W	
R26	RESISTOR (CARBON)		±5%	1/4W	
R27	RESISTOR (CARBON)		±5%	1/4W	
R28	RESISTOR (CARBON)		±5%	1/4W	
R29	RESISTOR (CARBON)		±5%	1/4W	
R30	RESISTOR (CARBON)		±5%	1/4W	
R31	RESISTOR (CARBON)		±5%	1/4W	
	TIEOIOTOTI (OATIBOTI)	0.0112			
R33	RESISTOR (CARBON)	56ΚΩ	±5%	1/4W	
	:				
	: 				
R40	RESISTOR (CARBON)		±5%	1/4W	
R41	RESISTOR (CARBON)		±5%	1/4W	
RA1	RESISTOR		±5%	1/4W	
RA2	RESISTOR	. 	±5%	1/4W	
RA3	RESISTOR		±5%	1/4W	
RY1	RELAY	LZG-12HE			
RY2	RELAY	VB12TBU			
	VADIOTOD	ONDOOLIA			
V	VARISTOR	SNR681KD			
X	CRYSTAL	CSA-4MG			
3P SUP	CONNECTOR	2-173270-3	• • • • • • • •		
5P FM	CONNECTOR	2-173270-5	· • · · · · · • · ·		
2P PRY	CONNECTOR	8-173270-2			
2P SEC	CONNECTOR	5273-02A			
2P TEST	CONNECTOR	NHK-P2T-N	• • • • • • • •		
2P TH1	CONNECTOR	8-171825-2			
2P TH2	CONNECTOR	2-171825-2	• • • • • • • •		
2P CM	CONNECTOR	5273-02A-E	L		
9P SW	CONNECTOR	171825-9			

6. TROUBLESHOOTING


6-1 Check before and after troubleshooting.

(1) Check power supply wiring.

• Check that power supply wires are correctly connected to terminals No. 7 and No. 8 on the 8P terminal plate in the outdoor unit.

(2) Check inter-unit wiring.

• Check that inter-unit wires are correctly connected to indoor unit from outdoor unit.



(3) Check power supply.

- \bullet Check that voltage is in specified range ($\pm 10\%$ of the rating).
- Check that power is being supplied.



If the following troubleshooting must be done with power being supplied, be careful about any uninsulated live part that can cause ELECTRIC SHOCK.


(4) Check lead wires and connectors in indoor and outdoor units.

- Check that coating of lead wires is not damaged.
- Check that lead wires and connectors are connected firmly.
- Check that wiring is correct.

(5) Reference

(a) Condition of general cooling operation


ON/OFF operation button	ON
COOL/FAN selector switch	COOL
Indoor fan speed	HIGH
Thermo	ON



6-2 Air conditioner does not operate.

- (1) Circuit breaker trips (or fuse blows).
 - (a) When circuit breaker is set to ON, it trips in a few moments (resetting is not possible).
 - There is a possibility of ground fault.
 - Measure insulation resistance.

If resistance value is $1M\Omega$ or less, insulation is defective ("NO").



- *Set circuit breaker to OFF.
- Remove power supply wires from terminal plate in outdoor unit.
 Measure insulation resistance of power supply wires.

 NO

 Do rewiring.
- Remove inter-unit wires from terminal plate in indoor unit.
 Measure insulation resistance of indoor unit.
 Measure insulation resistance of electrical parts in indoor unit.
- Remove inter-unit wires from terminal plate in outdoor unit.
 Measure insulation resistance of outdoor unit.
 Measure insulation resistance of electrical parts in outdoor unit.
- Measure insulation resistance of inter-unit wires.

 NO


 Do rewiring.

(b) Circuit breaker trips in several minutes after turning air conditioner ON.

- There is a possibility of short circuit. (Below figure is a case of indoor unit A being turned on.)
- Check capacity of circuit breaker.


 Is capacity of circuit breaker suitable?

 Replace it with suitable one (larger capacity).
- Measure resistance of compressor motor winding.
- Measure resistance of outdoor fan motor winding.




(2) All unit (indoor and outdoor) do not run.


(a) Power is not supplied.




(b) Check OPERATION selector switch in indoor unit.



(c) Check fuse F1 in indoor unit.




• Measure coil resistance of relays RA and RB.



(3) Neither indoor unit A nor compressor motor A runs.

(Or, neither indoor unit B nor compressor motor B runs.)


- (a) Check transformer in indoor unit A (or B).
 - Measure resistance of transformer winding.




Neither indoor unit A nor compressor motor A runs. (cont'd)

(or neither indoor unit B nor compressor motor B runs.)


(b) Check fuse on PCB Ass'y in indoor unit A (or B).







6-3 A particular component of air conditioner does not operate.


(1) Only compressor motor A does not run (or B).








(2) Only indoor fan does not run.




(3) Only outdoor fan does not run.




6-4 Air conditioner operates, but abnormalities occur.

(1) Poor Cooling



(2) Excessive Cooling



6-5 Indoor (heat exchanger) coil temperature sensor (TH1) is defective.

(1) Open

Even though the air conditioner does not thermo OFF, compressor and outdoor fan repeat ON for 10 minutes and OFF for 6 minutes.

(2) Shortage

When dehumidified water freezes in the indoor coil, the freeze prevention function does not work.

7. CHECKING ELECTRICAL COMPONENTS

7-1 Measurement of Insulation Resistance

• The insulation is in good condition if the resistance exceeds 1 $M\Omega$.

(1) Power Supply Wires

Clamp the grounded wire of the power supply wires with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on either of the power wires. (Fig. 1)

Then measure the resistance between the grounded wire and the other power wires. (Fig. 1)

(2) Indoor Unit

Clamp an aluminum plate fin or copper tube with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on ①, and then ② on the terminal plate. (Fig. 2)

(3) Outdoor Unit

Clamp a metallic part of the unit with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on ①, and then ② on the 2P terminal plate. (Fig. 2)

(4) Measurement of Insulation Resistance for Electrical Parts

Disconnect the lead wires of the desired electric part from terminal plate, PCB Ass'y, capacitor, etc. Similarly disconnect the connector. Then measure the insulation resistance. (Figs. 1 to 4)

Refer to Electric Wiring Diagram.

Note: If the probe cannot enter the poles because the hole is too narrow then use a probe with a thinner pin.





Fig. 1






Fig. 3




Fig. 4

7-2 Checking Continuity of Fuse on PCB Ass'y

 Check for continuity using a multimeter as shown in Fig. 5.

Note:

Method Used to Replace Fuse on PCB Ass'y

- 1. Remove the PCB Ass'y from the electrical component box.
- 2. Pull out the fuse at the metal clasp using pliers while heating the soldered leads on the back side of the PCB Ass'y with a soldering iron (30W or 60W). (Fig. 6)
- Remove the fuse ends one by one. For replacement, insert a fuse of the same rating and solder it. (Allow time to radiate heat during soldering so that the fuse does not melt.)



When replacing the fuse, be sure not to break down the varistor.

7-3 Checking Motor Capacitor

Remove the lead wires from the capacitor terminals, and then place a probe on the capacitor terminals as shown in Fig. 7. Observe the deflection of the pointer, setting the resistance measuring range of the multimeter to the maximum value.

The capacitor is "good" if the pointer bounces to a great extent and then gradually returns to its original position.

The range of deflection and deflection time differ according to the capacity of the capacitor.




Fig. 5




Fig. 6




Fig. 7

7-4 Appearance of Electrical Parts

(1) Auxiliary Relay

MY2F-T1-USTS




Fig. 8

(2) Relay

DFU12D1-F (M)




Fig. 9