HX 2540





**Philips Domestic Appliances and Personal Care** 

# ServiceManual

### **PRODUCT INFORMATION**

Small-volume brush head

Active tip

Controlled Pressure System

End-rounded bristles

2 speeds

Timer : Red light signal to indicate the two

minutes brushing time

Charging light : When the battery in the tooth

brush is being charged, the pilot

light is green

"Battery low" indication: Pilot light is red and blinks for

10 seconds after the tooth brush

has been switched off.

Number of brushes inserted in luxury carton: 2

Topography colour V-shape : blue

# **TECHNICAL DATA**

Voltage : 200-240 V, 50-60 Hz

Power consumption : 3 Watts

Speed (top) : up to 15.000 brush strokes

per minute

Pressure control click at : 250 gr. Charging time (empty to full) : 16 hours Operating time (full to empty) :  $\pm$  25 minutes Battery type : NiCd

Product meets the requirements regarding interference suppression on radio and TV.

### SERVICE INFORMATION

# Hand unit tooth brush (1)

Never open the hand unit of the tooth brush, because the unit is not water tight anymore.

In case of a defect, then complete unit must be replaced.

# Charging unit (2)

In case of a defective charging unit or cordset, the complete charging unit must be replaced.

## **NOTES**

For standardisation reasons the hand unit of the HX 2540 has to be replaced by the hand unit of the HX 2550. The hand unit of the HX 2550 also has a charging light, that is green and blinks, when the battery is being charged and that burns continuously when the battery has been fully charged.

When discarding the appliance, remove the built-in rechargeable battery.

The battery should be completely empty of charge.

Published by Philips Domestic Appliances and Personal Care

Printed in the Netherlands


© Copyright reserved

Subject to modification









Pos	Description	Service code
ı	Reachargeable hand unit (NiCd)	4822 218 12093
2	Charging unit 200-240 V. Euro plug	4822 219 10755
	Charging unit 220 V. Korean plug	4822 219 10756
3	Set of brushes (2 pcs in blister pack)	4822 479 20272
	Dir. for use: UK, D, N, S, SF, D and Gr	4822 736 17093
	Dir. for use: UK, D, F, NL, E, P, I and TR	4822 736 17092
	Dir. for use: Far East languages + UK	4822 736 17095
	All East European languages	4822 736 17094