





FM FRONT END & AM RF PCB ASSY

"DECK ASSY"

"MAIN PCB ASSY"

"FRONT PCB ASSY"

OPTION: FRONT CH LINE-OUT

OPTION: FRONT CH LINE-OUT

*OPTION: CD CHANGER CONTROL TO CD CHANGER MINI DIN JACK

❑ WIRING DIAGRAM

