

Service
Service
Service



Philips Domestic Appliances and Personal Care

Service Manual

Product Information

Features : 6 small rollers
6 large rollers

Extra sets of rollers are available under:

HP4400 : containing 3 large rollers + 3 small rollers

HP4402 : containing 8 small rollers

HP4403 : containing 6 large rollers

Voltage : 230 - 240 V
Power consumption : 400 Watts


Maintenance:

To descale the product NEVER use a descaling agent or other chemicals.

USE VINEGAR ONLY.

N.B. The rollers are not suitable for long hair.

HP4500



DAP0276

pos	description	service code
1	cover water reservoir	4822 442 00764
2	lid water reservoir	4822 442 00765
3	measuring beaker	4822 418 10236
4	roller grip	4822 401 11685
5	set of rollers HP4400 (3 small + 3 large ones)	4822 528 11091
6	set of rollers HP4402 (8 small ones)	4822 528 11092
7	set of rollers HP4403 (6 large ones)	4822 528 11093