

Service Service Service



Service Manual

PRODUCT INFORMATION

Voltage : 110V, 220-240V
 Frequency : 50-60Hz
 Power consumption : 700W
 Color setting : Ivory / orange
 Time switch : mechanical 15 min \pm 15%
 Max. temperature : 240 C

SERVICE INFORMATION

- In case of a technical defect, ovens have to be replaced.

1 Control knob	4822 410 12514
2 Crumb tray	4822 418 10441
3 Grill rack	4822 458 10691
4 Food tray	4822 418 10442

