


Service Service Service



Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

Vision vacuum cleaner

Use Service Manual 4822 729 21878 to identify the spares.

HR 8879 is for service purposes **identical to HR 8882**, however use for following items the codes:

1	4822 410 11298	cord-winder pedal
2	4822 442 01029	accessory cover
4	4822 442 01031	lead lid
9	4822 442 01041	dust cover
11	4822 460 11093	dust-cover snaplock
13	4822 441 12053	version panel
14	4822 466 11641	switch pedal
39	4822 441 12019	button panel

of the **Vision** vacuum cleaner **HR 8892**.

