

Service
Service
Service

HP 510
HP 710



Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

Type	HP 510	HP 710
Mains supply 120 Volt	x	x
200 - 240 Volt	x	x
Battery NiMh	x	x
NiCd	x	x
Charge indication light	-	x
Interval light	-	-
Oscillating brush head + active tip	x	x
Topography, colour v - shape	blue	green
Variable speed	-	x
Speed	60 Hz	45/60 Hz
Container for 4 brushes	-	-
Wall holder facility	x	x

SERVICE INFORMATION

Hand unit tooth brush (1)

Never open the hand unit of the tooth brush, because the unit is not water tight anymore.
In case of a defect, the complete unit must be replaced.

Charging unit (2)

In case of a defective charging unit or cordset, the complete charging unit must be replaced.

NOTES

For standardisation reasons, the handunit of the HP 710 has to be replaced by the hand unit of the HP 735.

When discarding the appliance, remove the built-in rechargeable battery.

The battery should be completely empty of charge.



This product meets the requirements regarding interference suppression on radio and TV.



PHILIPS

HP 510

HP 710



Pos	Description	Service code
1	hand unit tooth brush NiMh HP 510	4822 690 10145
1	hand unit tooth brush NiCd HP 510	4822 690 10146
1	hand unit tooth brush NiMh HP 735	4822 690 10142
1	hand unit tooth brush NiCd HP 735	4822 690 10143
2	charging unit 200-240 V, Euro plug	4822 219 10374
2	charging unit 220 V, Korean plug	4822 219 10375
2	charging unit 120 V, flat pin plug	4822 219 10376
2	charging unit 200-240 V, Australian plug	4822 219 10377
4	wall bracket	4822 402 10872
5	set tooth brushes HP 790	4822 479 20218