



Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

TECHNICAL INFORMATION

- Voltage : 220 - 240 V
- Frequency : 50 - 60 Hz
- Power consumption : 1000 W
- Coloursetting : HD2541/10 : White / mineral green
- SAP coding : HD2541

REPAIR INSTRUCTIONS


In case of a technical defect, toaster has to be replaced.
Only crumb tray have been listed as spare part.

ASSEMBLY & DISASSEMBLY ADVICE

- No specific issues

OPTIONAL (accessories)

- No specific issues



Pos	Service code	Description	
1	9965 000 02959	Crumbtray	Green
	9965 000 21075	Crumbtray	Mineral Green