

# Service Information

1996-12-03

HR6371  
HR6374  
HR6377

DAP135

## Domestic Appliances and Personal Care

### Safety screw.

These non electronic vacuum cleaners with cordwinder are provided with the pedal of the electronic version and in stead of a control knob a flat closed cap has been mounted.

To comply with all safety requirements, **underneath the flat closed cap** a screw has to be used as for the versions with electronics.

There have been produced a number of appliances without the screw, if these appliances are offered for service please **add the screw**.

To enable you to remove the flat closed cap for service purposes we advice you to remove the flat closed cap by means of a sucking-cup.

Appliances without a screw can be recognised due to the fact that the pedal can be lifted up in the middle. By unlocking the two nocks at the corners the pedal can be removed with the flat closed cap remaining in its place.

