

SERVICE MANUAL

COMPACT DISC STEREO
SYSTEM

BASIC TAPE MECHANISM : TN-21ZSC-2003
BASIC CD MECHANISM : DA11T3C

このサービスマニュアルはシンプル版です。改定版発行時に差し替えて使用してください。

- Replace this Service Manual with "Revision Publishing" when it is issued.

ELECTRICAL MAIN PARTS LIST -1

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
IC				C118	87-010-263-080		CAP, ELECT 100-10V
	87-A20-734-010		IC, TDA2007A	C119	87-010-197-080		CAP, CHIP 0.01 DM
	87-A21-443-040		C-IC, M62495AFP	C120	87-010-401-080		CAP, ELECT 1-50V
	8A-CLB-602-010		IC, LC867240A-5P15	C122	87-010-213-080		C-CAP, S 0.015-50 B
	87-A21-245-010		IC, RPM6938-V4	C123	87-010-404-080		CAP, ELECT 4.7-50V
	87-A21-145-040		C-IC, BA4560F-E2	C124	87-010-402-080		CAP, ELECT 2.2-50V
	87-A20-446-010		C-IC, LA9241ML	C126	87-010-408-080		CAP, ELECT 47-50V
	87-A20-459-010		C-IC, LC78622ED	C127	87-010-248-080		CAP, ELECT 220-10V
	87-A21-093-010		IC, LA6541D	C132	87-010-237-080		CAP, ELECT 1000-16V
	87-070-127-110		IC, LC72131 D	C136	87-010-197-080		CAP, CHIP 0.01 DM
	87-A20-913-010		IC, LA1837NL	C137	87-010-197-080		CAP, CHIP 0.01 DM
TRANSISTOR				C138	87-010-197-080		CAP, CHIP 0.01 DM
	87-026-610-080		TR, KTC3198GR	C139	87-010-197-080		CAP, CHIP 0.01 DM
	89-213-702-010		TR, 2SB1370 (1.8W)	C143	87-010-401-080		CAP, ELECT 1-50V
	87-A30-185-010		TR, 2SD1381FQR	C144	87-010-401-080		CAP, ELECT 1-50V
	87-026-313-080		TR, DTC343TS	C147	87-010-190-080		S CHIP F 0.01
	87-026-237-080		CHIP-TR, DTC124XK	C148	87-010-190-080		S CHIP F 0.01
	87-026-223-080		TR, DTC143TK	C149	87-010-190-080		S CHIP F 0.01
	89-320-011-080		TR, 2SC2001 (15W)	C150	87-010-263-080		CAP, ELECT 100-10V
	87-CD7-603-080		TR, SS8050<KS, EZS>	C151	87-010-263-080		CAP, ELECT 100-10V
	89-318-154-080		TR, 2SC1815 (0.4W)	C152	87-010-182-080		C-CAP, S 2200P-50 B
	87-026-291-080		TR, DTC124XS	C153	87-010-166-080		C-CAP, S 100P-50 SL
	89-112-965-080		TR, 2SA1296 (0.75W)	C154	87-010-545-080		CAP, ELECT 0.22-50V
	87-A30-227-080		TR, 2SB1010Q	C155	87-010-545-080		CAP, ELECT 0.22-50V
	87-026-463-080		TR, 2SA933S (0.3W)	C157	87-010-404-080		CAP, ELECT 4.7-50V
	87-026-239-080		TR, DTC114TK (0.2W)	C158	87-010-545-080		CAP, ELECT 0.22-50V
	87-026-210-080		CHIP-TR, DTC144EK	C159	87-010-545-080		CAP, ELECT 0.22-50V
	87-A30-196-080		TR, 2SC4115SRS	C161	87-010-404-080		CAP, ELECT 4.7-50V
	89-327-143-080		TR, 2SC2714 (0.1W)	C162	87-010-405-080		CAP, ELECT 10-50V
	87-A30-072-080		C-TR, RT1P 144C	C163	87-010-405-080		CAP, ELECT 10-50V
	89-505-434-540		C-FET, 2SK543 (4/5)<KS, EZS>	C164	87-010-405-080		CAP, ELECT 10-50V
	87-A30-257-080		C-TR, 2SD1306E<KS, EZS>	C165	87-010-405-080		CAP, ELECT 10-50V
	87-A30-074-080		C-TR, RT1P 141C<KS, EZS>	C166	87-010-404-080		CAP, ELECT 4.7-50V
DIODE				C167	87-010-404-080		CAP, ELECT 4.7-50V
	87-020-465-080		DIODE, 1SS133 (110MA)	C169	87-010-197-080		CAP, CHIP 0.01DM <KS, EZS>
	87-A40-393-090		DIODE, 1N5402GW(F20)	C170	87-010-197-080		CAP, CHIP 0.01 DM <KS, EZS>
	87-070-334-080		ZENER, MTZJ10B	C171	87-010-404-080		CAP, ELECT 4.7-50V
	87-017-932-080		ZENER, MTJ6.2B	C175	87-010-237-080		CAP, ELECT 1000-16V
	87-A40-347-080		ZENER, MTZJ2.2B	C301	87-010-322-080		C-CAP, S 100P-50 CH
	87-070-136-080		ZENER, MTZJ5.1B	C302	87-015-951-080		CAP, E 1-50 LL
	87-020-027-080		CHIP-DIODE 1SS184	C304	87-010-406-080		CAP, ELECT 22-50
	87-027-825-080		ZENER, HZ9A3L	C306	87-010-405-080		CAP, ELECT 10-50V
	87-A40-291-080		DIODE, 1N4148 (CPT)	C307	87-010-248-080		CAP, ELECT 220-10V
	87-A40-234-080		ZENER, MTZJ5.6A <KS, EZS>	C308	87-010-405-080		CAP, ELECT 10-50V
	87-A40-270-080		C-DIODE, MC2838 <KS, EZS>	C309	87-010-322-080		C-CAP, S 100P-50 CH
MAIN C.B				C311	87-010-406-080		CAP, ELECT 22-50
C101	87-010-190-080		S CHIP F 0.01	C312	87-015-951-080		CAP, E 1-50 LL
C102	87-010-190-080		S CHIP F 0.01	C314	87-010-426-080		C-CAP, S 0.012-25 B
C103	87-010-190-080		S CHIP F 0.01	C315	87-010-404-080		CAP, ELECT 4.7-50V
C104	87-010-404-080		CAP, ELECT 4.7-50V	C316	87-010-404-080		CAP, ELECT 4.7-50V
C105	87-010-403-080		CAP, ELECT 3.3-50V	C319	87-010-426-080		C-CAP, S 0.012-25 B
C106	87-010-192-080		C-CAP, S 0.022-50 F	C320	87-010-197-080		CAP, CHIP 0.01 DM <KS, EZS>
C107	87-010-192-080		C-CAP, S 0.022-50 F	C322	87-010-112-080		CAP, ELECT 100-16V
C108	87-010-192-080		C-CAP, S 0.022-50 F	C325	87-010-178-080		CHIP CAP 1000P
C109	87-010-192-080		C-CAP, S 0.022-50 F	C326	87-010-178-080		CHIP CAP 1000P
C110	87-010-190-080		S CHIP F 0.01	C327	87-010-178-080		CHIP CAP 1000P
C111	87-016-658-090		CAP, E 4700-35 SMG	C329	87-015-695-080		CAP, E 1-50 7L
C112	87-012-140-080		CAP 470P	C330	87-012-140-080		CAP 470P<KS, EZS>
C113	87-010-190-080		S CHIP F 0.01	C701	87-010-381-080		CAP, ELECT 330-16V
C114	87-010-408-080		CAP, ELECT 47-50V	C702	87-010-404-080		CAP, ELECT 4.7-50V
C115	87-010-112-080		CAP, ELECT 100-16V	C703	87-012-286-080		CAP, U 0.01-25
C116	87-010-101-080		CAP, ELECT 220-16	C704	87-012-286-080		CAP, U 0.01-25
				C709	87-012-195-080		C-CAP, U 100P-50CH
				C711	87-010-263-080		CAP, ELECT 100-10V
				C712	87-010-196-080		CHIP CAPACITOR, 0.1-25
				C713	87-012-286-080		CAP, U 0.01-25
				C714	87-012-286-080		<KS, EZS>
				C715	87-012-195-080		CAP, U 0.01-25 C-CAP, U 100P-50CH <KS, EZS>

ELECTRICAL MAIN PARTS LIST -2

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	8A-HC7-007-010		WINDOW, CD				
2	8A-HC7-005-010		WINDOW, DISPLAY				
3	8A-HC7-040-010		LID ASSY, CD311<LHB, LHS>	C785	87-010-401-080		CAP, ELECT 1-50V<LHS>
				C785	87-010-405-080		CAP, ELECT 10-
							50V<KS, EZS>
3	8A-HC7-037-010		LID ASSY, CD 311(LL)<LHLL>	C786	87-010-401-080		CAP, ELECT 1-50V<LHS>
4	85-HC6-205-110		SHAFT, LID(300) HK	C786	87-010-405-080		CAP, ELECT 10-
							50V<KS, EZS>
5	8A-HC7-204-010		SPR-T, OPEN	C787	87-012-287-080		C-CAP, U 0.015-25
6	8A-HC7-018-010		LEVER, OPEN				F<KS, EZS>
7	8A-HC7-015-010		CABI				
			ASSY, CENTER<LHB, LHS>	C788	87-012-287-080		C-CAP, U 0.015-25
7	8A-HC7-035-010		CABI ASSY, CENTER				F<KS, EZS>
			(LL)<LHLL>	C789	87-012-275-080		C-CAP, U 1200P-50 B
8	8Z-HC1-225-010		DMFR, MECHA(SP)	C789	87-012-275-080		C-CAP, U 1200P-50 B
				C790	87-012-275-080		C-CAP, U 1200P-50 B
				C791	87-010-405-080		CAP, ELECT 10-50V
9	8A-HC7-201-010		GUIDE, LCD				
10	8Z-HC7-205-010		BAT-CONTACT, (-)				
11	8A-HC7-202-010		BAT-CONTACT, (+)	C793	87-012-275-080		C-CAP, U 1200P-50
12	87-HC8-205-010		BAT-CONTACT, (+) (-)				B<KS, EZS>
13	8A-HC7-012-010		KNOB, SL HOLD	C793	87-012-273-080		C-CAP, U 820P-50
							B<LHS>
14	8A-HC7-016-010		CABI ASSY, BOTTOM	C794	87-010-406-080		CAP, ELECT 22-50
			<LHB, LHS>	C795	87-010-596-080		CAP, S 0.047-16
14	8A-HC7-036-010		CABI ASSY, BOTTOM	C796	87-010-403-080		CAP, ELECT 3.3-50V
			(LL)<LHLL>				
15	88-HC6-021-010		FOOT, DIA10	C797	87-012-276-080		CAP, CHIP SS 1500 PBK
A	87-067-869-010		V+1.7-8 HL BLK	C798	87-012-276-080		CAP, CHIP SS 1500 PBK
B	87-067-868-010		V+1.7-4 HL BLK	C799	87-010-829-080		CAP, U 0.047-16
				C803	87-018-047-080		CAP, CER 0.01-
C715	87-012-195-080		C-CAP, U 100P-				16V<KS, EZS>
			50CH<KS, EZS>	C812	87-012-286-080		CAP, U 0.01-25
C717	87-012-286-080		CAP, U 0.01-25				
C719	87-012-286-080		CAP, U 0.01-25	C814	87-012-286-080		CAP, U 0.01-
C720	87-012-195-080		C-CAP, U 100P-50CH				25<KS, EZS>
C721	87-012-176-080		CAP 15P	C820	87-010-260-080		CAP, ELECT 47-25V
C722	87-012-176-080		CAP 15P	C821	87-012-286-080		CAP, U 0.01-25
				C822	87-012-286-080		CAP, U 0.01-25
				C823	87-012-286-080		CAP, U 0.01-25
C723	87-012-274-080		CHIP CAP, U 1000P-50B				
C725	87-018-131-080		CAP, CER 1000P-50V	C824	87-012-172-080		CAPACITOR CHIP U 10P
C727	87-010-196-080		CHIP CAPACITOR, 0.1-25				CH<KS, EZS>
C728	87-010-248-080		CAP, ELECT 220-10V	C828	87-010-196-080		CHIP CAPACITOR, 0.1-25
C729	87-012-274-080		CHIP CAP, U 1000P-50B	C829	87-010-196-080		CHIP CAPACITOR, 0.1-25
				C909	87-012-286-080		CAP, U 0.01-
							25<KS, EZS>
C731	87-012-286-080		CAP, U 0.01-25	C910	87-012-286-080		CAP, U 0.01-
C752	87-012-284-080		CAP, U 6800P-				25<KS, EZS>
			50<KS, EZS>				
C753	87-012-195-080		C-CAP, U 100P-				
			50CH<KS, EZS>	C940	87-012-286-080		CAP, U 0.01-
C755	87-012-286-080		CAP, U 0.01-				25<KS, EZS>
			25<KS, EZS>	C942	87-012-172-080		CAPACITOR CHIP U 10P
C756	87-012-286-080		CAP, U 0.01-25				CH<KS, EZS>
				C947	87-012-286-080		CAP, U 0.01-
C757	87-012-188-080		C-CAP, U 47P-50 CH				25<KS, EZS>
C758	87-012-167-080		C-CAP, U 5P-50 CH	C949	87-A10-039-080		C-CAP, U 470P-50 J
C761	87-010-196-080		CHIP CAPACITOR, 0.1-				CH<KS, EZS>
			25<KS, EZS>	C952	87-012-286-080		CAP, U 0.01-
C762	87-012-286-080		CAP, U 0.01-				25<KS, EZS>
			25<KS, EZS>				
C763	87-010-829-080		CAP, U 0.047-16	C958	87-010-197-080		CAP, CHIP 0.01
							DM<KS, EZS>
C764	87-012-337-080		C-CAP, U 56P-50	C959	87-010-831-080		C-CAP, U, 0.1-16F
			CH<LHS>	C960	87-010-196-080		CHIP CAPACITOR, 0.1-25
C765	87-012-286-080		CAP, U 0.01-25	C961	87-012-170-080		C-CAP, U 8P-50 CH<LHS>
C766	87-010-197-080		CAP, CHIP 0.01	C962	87-010-401-080		CAP, ELECT 1-
			DM<KS, EZS>				50V<KS, EZS>
C768	87-012-286-080		CAP, U 0.01-25				
C769	87-010-260-080		CAP, ELECT 47-25V	C963	87-010-196-080		CHIP CAPACITOR, 0.1-
							25<LHS>
C770	87-010-829-080		CAP, U 0.047-16	CF801	87-008-423-010		CERAMIC FILTER,
C771	87-010-383-080		CAP, ELECT 33-25V				SFE10.7<KS, EZS>
C772	87-010-829-080		CAP, U 0.047-16	CF801	87-008-261-010		FILTER, SFE10.7MA5-
C773	87-010-196-080		CHIP CAPACITOR, 0.1-25				A<LHS>
C774	87-010-263-080		CAP, ELECT 100-10V	CF802	82-785-747-010		CF MS2 GHY R<KS, EZS>
				CF802	87-008-261-010		FILTER, SFE10.7MA5-
							A<LHS>
C775	87-010-404-080		CAP, ELECT 4.7-50V				
C776	87-012-286-080		CAP, U 0.01-25	CN301	87-009-036-010		CONNECTOR, 8P PH V
C777	87-010-400-080		CAP, ELECT 0.47-50V				WHT
C778	87-010-401-080		CAP, ELECT 1-50V	!F101	87-A91-217-010		FUSE, 3.15A 250V T 50T
C779	87-010-401-080		CAP, ELECT 1-50V	!FC1	87-033-213-080		CLAMP, FUSE
				!FC2	87-033-213-080		CLAMP, FUSE
C780	87-010-196-080		CHIP CAPACITOR, 0.1-25	FFE801	A8-6ZA-19C-170		6ZA-1 YFEENC<KS, EZS>
C781	87-010-405-080		CAP, ELECT 10-50V				
C782	87-010-405-080		CAP, ELECT 10-50V				
C783	87-012-286-080		CAP, U 0.01-25	FFE801	A8-8ZA-193-070		8ZA-1 YFEUNC<LHS>
C784	87-012-286-080		CAP, U 0.01-25	J101	87-A60-354-010		JACK, PIN 2P MSP -

ELECTRICAL MAIN PARTS LIST -3

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
				X202	87-A70-185-080		VIB,CER 5.76MHZ TF21
1	87-B30-285-010		AC ADAPTOR,AC-D603HRNC				
2	87-B30-326-010		HEADPHONE,HP-M048				
3	8A-HC7-914-010		IB,LH(3L)C F	CD C.B			
4	87-A90-312-010		PLUG,CONVERSION WTN-1157R1	C500	87-016-459-040		CAP,E 470-10 SMG
242V-05				C502	87-016-459-040		CAP,E 470-10 SMG
J102	87-A60-754-010		TERMINAL,SPK 4P MSP-	C503	87-016-459-040		CAP,E 470-10 SMG
154V-05				C505	87-010-196-080		CHIP CAPACITOR,0.1-25
J103	87-A60-420-010		JACK,3.5 ST (MSC)	C507	87-010-196-080		CHIP CAPACITOR,0.1-25
J104	87-099-608-010		JACK, DC				
HEC3800<KS,EZS>				C510	87-010-197-080		CAP, CHIP 0.01 DM
J801	87-A60-202-010		TERMINAL,ANT 4P MSP-	C513	87-010-196-080		CHIP CAPACITOR,0.1-25
154V-02<LHS>				C514	87-010-196-080		CHIP CAPACITOR,0.1-25
J801	87-A60-880-010		TERMINAL,ANT-PAL 2P	C515	87-012-157-080		C-CAP,S 330P-50 CH
MSP-313V-0<KS,EZS>				C516	87-010-545-080		CAP, ELECT 0.22-50V
L101	87-005-366-010		COIL, 1UH	C525	87-010-176-080		C-CAP,S 680P-50 SL
L102	87-005-366-010		COIL, 1UH	C528	87-012-156-080		C-CAP,S 220P-50 CH
L104	87-005-676-080		COIL,2.2UH K LF5.0S	C529	87-010-545-080		CAP, ELECT 0.22-50V
				C530	87-012-140-080		CAP 470P
L301	88-CL6-609-010		COIL,BIAS 8CL6	C531	87-010-374-080		CAP, ELECT 47-10V
L771	87-A50-266-010		COIL,FM DET-2N(TOK)				
L772	87-A90-733-010		FLTR,PCFAZH-450 (TOK)	C532	87-010-401-080		CAP, ELECT 1-50V
L781	87-005-847-080			C533	87-010-184-080		CHIP CAPACITOR
COIL,2.2UH(CECS)<KS,EZS>				3300P(K)			
L832	87-005-847-080			C534	87-010-197-080		CAP, CHIP 0.01 DM
COIL,2.2UH(CECS)<KS,EZS>				C535	87-010-145-080		C-CAP,S 1P-50 CH
				C536	87-010-312-080		C-CAP,S 15P-50 CH
L941	87-A50-020-010		COIL,ANT				
LW(COI)<KS,EZS>				C537	87-010-309-080		C-CAP,1000P-50 CH
L942	87-A50-019-010		COIL,OSC	C538	87-010-196-080		CHIP CAPACITOR,0.1-25
LW(COI)<KS,EZS>				C539	87-010-404-080		CAP, ELECT 4.7-50V
L981	87-NF4-650-010		COIL,AM PACK	C540	87-010-196-080		CHIP CAPACITOR,0.1-25
4N(TOK)<LHS>				C541	87-010-405-080		CAP, ELECT 10-50V
PR100	87-A90-091-080		PROTECTOR,2A 491				
PR101	87-026-689-080		PROTECTOR,1A 60V 491	C542	87-010-369-080		C-CAP,S 0.033-25 K B
				C543	87-010-405-080		CAP, ELECT 10-50V
TC942	87-011-164-010		CAPACITOR,TRIMMER	C545	87-010-197-080		CAP, CHIP 0.01 DM
30P<KS,EZS>				C546	87-010-374-080		CAP, ELECT 47-10V
WH101	87-099-043-010		CONN 2P EH	C547	87-010-263-080		CAP, ELECT 100-10V
X721	87-A70-061-010		VIB,XTAL 4.500MHZ				
CSA-309				C548	87-010-263-080		CAP, ELECT 100-10V
				C549	87-010-198-080		CAP, CHIP 0.022
				C550	87-010-248-080		CAP, ELECT 220-10V
FRONT C.B				C551	87-010-178-080		CHIP CAP 1000P
				C552	87-010-197-080		CAP, CHIP 0.01 DM
C201	87-010-375-080		CAP,E 330-10 SME				
C202	87-012-350-080		C-CAP,1-25 F	C553	87-010-374-080		CAP, ELECT 47-10V
C203	87-010-197-080		CAP, CHIP 0.01 DM	C555	87-010-403-080		CAP, ELECT 3.3-50V
C205	87-010-178-080		CHIP CAP 1000P	C556	87-010-197-080		CAP, CHIP 0.01 DM
C208	87-010-197-080		CAP, CHIP 0.01 DM	C557	87-010-197-080		CAP, CHIP 0.01 DM
				C558	87-010-197-080		CAP, CHIP 0.01 DM
C209	87-010-196-080		CHIP CAPACITOR,0.1-25				
C210	87-010-196-080		CHIP CAPACITOR,0.1-25	C559	87-010-315-080		C-CAP,S 27P-50 CH
C211	87-010-314-080		C-CAP,S 22P-50V	C560	87-010-263-080		CAP, ELECT 100-10V
C212	87-010-318-080		C-CAP,S 47P-50 CH	C561	87-010-196-080		CHIP CAPACITOR,0.1-25
C213	87-010-154-080		CAP CHIP 10P	C562	87-010-196-080		CHIP CAPACITOR,0.1-25
				C563	87-012-156-080		C-CAP,S 220P-50 CH
C214	87-012-149-080		C-CAP,S 30P-50 CH				
C215	87-010-312-080		C-CAP,S 15P-50 CH	C565	87-010-263-080		CAP, ELECT 100-10V
C216	87-010-400-080		CAP, ELECT 0.47-50V	C566	87-010-196-080		CHIP CAPACITOR,0.1-25
C217	87-010-196-080		CHIP CAPACITOR,0.1-25	C568	87-010-197-080		CAP, CHIP 0.01 DM
CN201	87-099-720-010		CONN,30P TYK-B(P)	C570	87-010-197-080		CAP, CHIP 0.01 DM
				C571	87-010-248-080		CAP, ELECT 220-10V
CN202	87-A60-404-010		CONN,3P TKX-P03P-F1				
L206	87-003-098-080		COIL,2.2UH	C572	87-010-196-080		CHIP CAPACITOR,0.1-25
LCD201	8Z-CL8-665-110		LCD,ZCL-8	C573	87-010-197-080		CAP, CHIP 0.01 DM
S200	87-A90-095-080		SW,TACT EVQ11G04M	C578	87-010-197-080		CAP, CHIP 0.01 DM
S201	87-A90-095-080		SW,TACT EVQ11G04M	C579	87-010-263-080		CAP, ELECT 100-10V
				C582	87-010-197-080		CAP, CHIP 0.01 DM
S202	87-A90-095-080		SW,TACT EVQ11G04M				
S203	87-A90-095-080		SW,TACT EVQ11G04M	C583	87-010-405-080		CAP, ELECT 10-50V
S205	87-A90-095-080		SW,TACT EVQ11G04M	C587	87-010-166-080		C-CAP,S 100P-50 SL
S207	87-A90-095-080		SW,TACT EVQ11G04M	C589	87-010-166-080		C-CAP,S 100P-50 SL
S208	87-A90-095-080		SW,TACT EVQ11G04M	C590	87-010-166-080		C-CAP,S 100P-50 SL
				C591	87-010-166-080		C-CAP,S 100P-50 SL
S213	87-A90-095-080		SW,TACT EVQ11G04M				
S214	87-A90-095-080		SW,TACT EVQ11G04M	C592	87-010-166-080		C-CAP,S 100P-50 SL
S216	87-A90-095-080		SW,TACT EVQ11G04M	C593	87-010-197-080		CAP, CHIP 0.01 DM
S217	87-A90-095-080		SW,TACT EVQ11G04M	C594	87-010-263-080		CAP, ELECT 100-10V
S218	87-A90-095-080		SW,TACT EVQ11G04M	C596	87-010-404-080		CAP, ELECT 4.7-50V
				C597	87-010-197-080		CAP, CHIP 0.01 DM
S220	87-A90-095-080		SW,TACT EVQ11G04M				
SW301	8Z-CL8-668-010		SW,RP ZCL8	C598	87-010-197-080		CAP, CHIP 0.01 DM
X201	87-030-364-010		VIB,XTAL 32.768K CT	C601	87-010-197-080		CAP, CHIP 0.01 DM


ELECTRICAL MAIN PARTS LIST -4

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
CN501	87-009-345-010		CONN,2P PH H	D947	87-A40-365-080		LED,L-1154 SGD
CN510	87-009-034-010		CONN,6P PH V	D948	87-A40-365-080		LED,L-1154 SGD
CN520	87-A60-248-010		CONN,16P H CFF1416	D949	87-A40-365-080		LED,L-1154 SGD
L501	87-005-647-080		COIL,10UH K LF5S				
L502	87-005-659-080		COIL,100UH K LF5.0S	AC C.B			
R503	87-029-019-010		RES, FUSEIBLE 1/2W-2.2	CNA101	8A-CLA-630-010		CONN ASSY,2P PT
SFR501	87-A90-787-080		SFR,100K H HOKU	SW1	87-A90-178-010		SW SL1-1-2<LHS>
X501	87-A70-046-010		VIB,XTAL 16.934MHZ	T1	87-A60-317-010		TERMINAL, 1P MSC
				T2	87-A60-317-010		TERMINAL, 1P MSC
LED C.B				MOTOR C.B			
D941	87-A40-365-080		LED,L-1154 SGD	M2	9X-262-576-910		MOTOR GEAR ASSY
D942	87-A40-365-080		LED,L-1154 SGD	PIN3	91-564-722-110		CONNECTOR 6P
D943	87-A40-365-080		LED,L-1154 SGD	SW1	91-572-085-120		LEAF SW
D944	87-A40-365-080		LED,L-1154 SGD				
D945	87-A40-365-080		LED,L-1154 SGD				
D946	87-A40-365-080		LED,L-1154 SGD				

MECHANICAL PARTS LIST - 1

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	8A-CLB-007-010		WINDOW, CASS		27	8Z-CL8-201-010	GUIDE, LCD
2	8A-CLB-005-010		LID, CASS	⚠	28	87-A80-092-010	AC CORD ASSY, E BLK SUN FAI
3	8A-CLB-006-010		BOX, CASS				
4	8Z-CL8-209-010		SPR-T, CASS	⚠	29	8A-CLL-621-010	PT, EZ ACL-L<KS, EZS>
5	8A-CLB-004-010		WINDOW, DISP<LHS, KS>	⚠	29	8A-CLL-620-010	PT, H ACL-L<LHS>
6	87-B00-002-010		BADGE, AIWA 30 ABS SIL		30	8Z-CDB-169-010	PANEL, CD SANYO
7	8Z-CL8-204-010		CUSH, FOOT		31	8Z-CL8-206-010	SPR-P, REC
8	8A-CLM-002-010		CABI, FRONT EX<LHS, KS>		32	8Z-CL8-214-010	DMPR, HLDR BE
8	8A-CLM-001-010		CABI, FRONT EZ<EZS>				
9	8A-CLB-008-010		KEY, CASS SET		33	84-CD5-215-010	GEAR
10	8A-CLB-009-010		KEY, CONT		34	84-CD5-216-010	BRACKET
11	8A-CLB-013-010		KEY, RT PTY<EZS>		35	86-NFZ-231-010	DMPR, 70
12	8A-CLB-012-010		KEY, POWER		36	87-064-108-110	HLDR, NC LUTCH
13	8A-CLB-010-010		KEY, SKIP		A	87-B10-239-010	QT2+3-8 W/O CR
14	8A-CLB-011-010		KEY, P/S		B	8Z-CL8-220-010	W, 30-0856-01-01-01
15	8Z-CDB-170-010		BASE, CHUCK		C	87-067-579-010	TAPPING SCREW, BVT2+3-8
16	88-CD9-211-210		RING, CHUCK		D	87-067-703-010	TAPPING SCREW, BVT2+3-10
17	87-036-368-010		MAGNET		E	87-342-074-010	UT2+2.6-8
18	8A-CLB-002-010		LID, CD		F	87-761-096-410	VFT2+3-10 GLD
19	8Z-CL8-683-010		CONN ASSY, 2P CD DOOR		G	87-B10-230-010	BVT2+3-10 W/O SLOT SILVER CR
20	8Z-CL8-205-010		SPR-T, CD		H	87-571-033-410	TAPPING SCREW, VIT+2-4
21	8A-CLB-003-010		CHAS, CD				
22	M8-ZZK-E90-070		DA11T3C				
23	88-CT6-206-010		CUSHION, CD				
24	8Z-CL8-681-010		CONN ASSY, 6P CD MOTOR				
25	8A-CLB-028-010		CABI, REAR EZ<KS, EZS>				
25	8A-CLB-037-010		CABI, REAR H<LHS>				
26	8Z-CL8-682-010		FF-CABLE, 16P 1.0 180MM				

ACCESSORIES LIST-1

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	8A-CLM-906-010		IB,EZ(9L)B<EVS>	3	87-A90-118-010		ANT,WIRE FM
1	8A-CLM-905-010		IB,K(E)B<KS>				(Z)<KS,EVS>
1	8A-CLM-902-010		IB,LH(ESP)B<LHS>	 4	87-A91-017-010		PLUG,CONVERSION
2	87-A90-030-010		ANT,LOOP AM-NC C				JT-0476<KS,EVS>
3	87-043-115-010		ANT,FEEDER FM<LHS>	5	8A-CLB-961-010		RC UNIT,RC-AAT11

SPEAKER LIST-1

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
	8A-CLL-600-010		SPKR, 40HM 5W ACL-L				
	8A-CLB-014-010		CABI, FR SPKR				
	8A-CLB-016-010		FRAME, SPKR				
	8Z-CL7-107-010		BADGE, AIWA SILVER				
	8A-CLL-601-010		CORDASSY, SPKR-BLK ACL-L/M				



アイワ株式会社
AIWA CO.,LTD.

〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)
2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110-8710, JAPAN TEL:03 (3827) 3111