

Service
Service
Service

Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

Voltage : 220-240V
 Frequency : 50-60Hz
 Power consumption : 1400W
 Color setting : Ivory / Pearl Blue
 : White / Green

SERVICE INFORMATION

	HD2560/A	HD2562/A
Crumb tray	x	x
Bun warmer	-	x

- Max. timer setting: 210 sec. \pm 15%
- In case a technical defect, toaster has to be replaced.
- Only numbered items are serviceable parts.

1 Bun warmer Ivory	996500001179
2 Crumb tray Zinc Brown	996500001180
Crumb tray Green	996500001181

DFU
 West Europe 422200192092

