

# 712 RTD Calibrator

# Compact, lightweight, and easy to carry



### 712 RTD Calibrator

- Measure temperature from RTD output
- Simulate RTD output
- Rosemount pulsed RTD transmitter compatible
- Operates with seven types of RTDs
- Measure additional RTDs using Ohms measurement function
- Simulate additional RTDs using Ohms source function
- °F or °C selectable
- Four shrouded banana jacks

#### **General features**

- Compact and lightweight
- Simple controls
- Clear, 5-digit, liquid crystal display
- Operating temperature:
  - -10°C to 55°C
- Safety: CSA C22.2 No. 1010.1:1992
- Three-year warranty
- Included:
  - Fluke 712 RTD Calibrator
- Protective Yellow Holster with Flex-Stand™
- Test leads and alligator clips
- Single 9V alkaline battery
- Instructions (14 languages)

## **General specifications**

Maximum voltage: 30 volts Non-operating temperature:

-40°C to 60°C

**Operating temperature:** -10°C to 55°C **Relative humidity:** 95% (10°C to 30°C); 75% (30°C to 40°C); 45% (40°C to 50°C); 45% (40°C to 50°C); 45% (50°C to 55°C)

50°C); 35% (50°C to 55°C) **Operating altitude:** 3,000m max

Shock: 1m drop test Vibration: random, 2g, 5-500 Hz Safety: CSA C22.2 No. 1010.1:1992

EMC: EN50082-1:1992 and EN55022:1994 Class B

**Size/weight:** 187 mm L x 87 mm W x 32 mm D (7.35 in L x 3.41 in W x 1.25 in D) 330g (12 oz)

Size/weight, (with holster and FlexStand<sup>TM</sup>): 201mm L x 98 mm W x 52 mm D (7.93 in L x 3.86 in W x 2.06 in D) 600g (21 oz)

**Power:** 9V battery ANSI/NEDA 1604A or

IEC 6LR619V alkaline

Battery Life: 4 to 20 hours, typical, depending on functions used Warranty: Three years



# Specifications (18° to 28°C, one year)

Function	Range	Resolution	Accuracy	Notes
Measure/simulate RTD	-200 to 800°C (Pt 100)	0.1°C, 0.1°F	0.33°C, 0.6°F (Pt 100)	Pt; 100 200 500 1000 (385); Pt 100 (392); Pt 100 (392) JIS; Ni 120 (672)
Measure/simulate resistance	15 $\Omega$ to 3200 $\Omega$	0.1 Ω	$0.1\Omega$ to $1~\Omega$	

# Ordering Information

Fluke-712 RTD Calibrator

Need technical assistance? Call:

1-800-44-FLUKE

Toll-free in the U.S. (905) 890-7600 in Canada (425) 356-5500 other countries

For more information to be sent to you by fax, call 1-800-FLUKE-FAX in the U.S. and Canada. Or, visit our Website at http://www.fluke.com

Fluke. Keeping your world up and running.