

Service
Service
Service

Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

Voltage : 220-240V
 Frequency : 50-60Hz
 Power consumption : 980W
 Color setting : Ivory / Pearl Blue
 : White / Green

SERVICE INFORMATION

	HD2531/A	HD2534/B
Crumb tray	x	x
Bun warmer	-	x

- Max. timer setting:
 HD2531/A 190 sec. \pm 15%
 HD2534/B 160 sec. \pm 15%
- In case a technical defect, toaster has to be replaced.
- Only numbered items are serviceable parts.

- | | |
|-------------------------|--------------|
| 1 Bun warmer Ivory | 996500001098 |
| 2 Crumb tray Zinc Brown | 996500001099 |
| Crumb tray Green | 996500001100 |

DFU
 West Europe 422200192002

