



Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

TECHNICAL INFORMATION

- Voltage : 220 - 240 V
- Frequency : 50 - 60 Hz
- Power consumption : 1050 W
- Coloursetting HD2533/70 : Riviera Blue
HD2533/60 : Raven Black
- SAP coding : HD2533

REPAIR INSTRUCTIONS


In case of a technical defect, toaster has to be replaced.
Only crumbtray and bunwarmer have been listed as spare parts.

ASSEMBLY & DISASSEMBLY ADVICE

- No specific issues

OPTIONAL (accessories)

- No specific issues



Pos	Service code	Description	
1	9965 000 21063	Bunwarmer	Riviera Blue
	9965 000 21064	Bunwarmer	Raven Black
2	9965 000 21065	Crumbtray	Riviera Blue
	9965 000 21066	Crumbtray	Raven Black