

Service Bulletin

Date	Ref. No.	Model	TD
21.11.97	IP01897	CMD-Z1	
Subject			IRIS
Vibration Noise When Battery Is Charging In Cradle			C14X

SYMPTOM

When charging the CMD-Z1 battery QN-022BP in the charging cradle QN-020BC, sometimes a vibration noise may be heard.

CAUSE

Resonance depending on the current drawn.

SOLUTION

This is no real problem, there is no danger at all. The only simple solution is to shift the battery slightly left or right when vibration occurs and to inform customers of this fact.