
**HD 7607/A** 









PRODUCT INFORMATION

100, 120, 230 V Voltage Frequency 50 - 60 Hz Power consumption: 850 + 550 W Contents jug 1500 cc Coloursetting ceramic white

### **SERVICE INFORMATION**

Thermostat switch-off temp: 140 °C Thermal fuse cut-off temp: 298 °C

### **REPAIR INSTRUCTIONS**

### 1. Electrical circuit

When the appliance does not work, check the electrical circuit. If the thermal fuse or thermostat prove defective, the complete pump unit has to be replaced.


# 2. De-scaling

If the water system is nearly or less clogged by scale then operate the coffeemaker a few times with vinegar or with a 10-15% solution of either vinegar-acid, citric acid or tartar-acid, into cold tap water.

Do not use other de-scaling agents as these may harm the appliance.

If this procedure does not restore the function, then switch off the coffeemaker when the acid has passed through during appr. 3 min. Keep the appliance in this condition overnight and continue/repeat the cleaning operation. After the de-scaling procedure, operate the coffeemaker twice with tap water in order to rinse away any residual substances.

MSH coding 8827 607 00000



### 3. Pump unit removal

To separate the pump unit from the hotplate unit (item 23), the two plastic snaps at place A have to be loosened. Then the pump unit can be lifted out easily.

## 4. Exchanging the switch unit


Remove the panel (13) by carefully pushing a small screwdriver into the chink at point A and moving it towards to point B (see exploded view). Do not damage the housing. If the panel has been damaged, get a new one.

PRODUCTS MEETS THE REQUIREMENTS REGARDING INTERFERENCE SUPPRESION ON RADIO AND TELEVISION.

AFTER THE PRODUCT HAS BEEN REPAIRED IT SHOULD FUNCTION PROPERLY AND HAS TO MEET THE SAFETY REQUIREMENTS AS LAID DOWN OFFICIALLY ESTABLISHED AT THIS MOMENT.

Published by Philips Domestic Appliances and Personal Care Printed in The Netherlands ©Copyright reserved

Subject to modification








99/06

# **HD 7607/A**



1	4222 247 58520	Tank lid	ceramic white
2	4222 247 58540	Disc	zinc brown
3	4222 247 58530	Spout	zinc brown
5	4222 247 58510	Rim	zinc brown
6	4222 246 22890	Cord Euro	black
7	4222 447 05680	Stud	
8	4222 247 58440	Jug lever	zinc brown
9	4222 247 55880	Spout pipe	
10	4222 247 55780	Switch casing	
11	4222 246 23640	Rota switch	
12	4222 246 25390	Switch ASO	zinc brown
13	4222 259 33470	Switch panel	ceramic white
14	4222 247 58490	Rota button	zinc brown
15	4222 247 58550	Filterholder 1)	zinc brown
16	4222 240 06060	Dripstop spring	

17	4222 247 06630	Ring	
18	4222 247 58560	Dripstop	zinc brown
19	4222 247 58260	Jug lid	zinc brown
20	4222 256 32630	Jug assy 2)	zinc brown
21	4222 259 28090	Pump assy	
22	4222 240 06040	Hotplate	
23	4222 247 55540	Hotplate ring	
24	4222 259 20460	Valve	
25	4222 247 06440	Hose piece	
26	4222 245 71470	Wire spring	
27	4222 247 40210	Spoon	black
28	4222 001 91890	D.F.U.	
		GBR, FRA, GER, NLD, ESP, PRT	
		DNK, NOR, SWE, FIN, GRC, TUR.	
29	4222 247 55690	Fload	orange
30	4222 247 58430	Window wall	zinc brown

1) Optional part for use as an insert in item 15: 4822 480 50479 Permanent filter nylon Permanent filter stainless steel Permanent filter gold

2) Commercial trade number of the jug HD 7953